

Elastic Storage Server
Version 5.0

Problem Determination Guide



Elastic Storage Server
Version 5.0

Problem Determination Guide



Note

Before using this information and the product it supports, read the information in “Notices” on page 125.

This edition applies to version 5.x of the Elastic Storage Server (ESS) for Power, to version 4 release 2 modification 2 of the following product, and to all subsequent releases and modifications until otherwise indicated in new editions:

- IBM Spectrum Scale RAID (product number 5641-GRS)

Significant changes or additions to the text and illustrations are indicated by a vertical line (|) to the left of the change.

IBM welcomes your comments; see the topic “How to submit your comments” on page viii. When you send information to IBM, you grant IBM a nonexclusive right to use or distribute the information in any way it believes appropriate without incurring any obligation to you.

© **Copyright IBM Corporation 2014, 2017.**

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

Contents

Tables	v
---------------	----------

About this information	vii
-------------------------------	------------

Prerequisite and related information	vii
--------------------------------------	-----

Conventions used in this information	viii
--------------------------------------	------

How to submit your comments	viii
-----------------------------	------

Summary of changes	ix
---------------------------	-----------

Chapter 1. Best practices for troubleshooting	1
--	----------

How to get started with troubleshooting	1
---	---

Back up your data	1
-------------------	---

Resolve events in a timely manner	2
-----------------------------------	---

Keep your software up to date	2
-------------------------------	---

Subscribe to the support notification	2
---------------------------------------	---

Know your IBM warranty and maintenance agreement details	2
--	---

Know how to report a problem	3
------------------------------	---

Chapter 2. Limitations	5
-------------------------------	----------

Limit updates to Red Hat Enterprise Linux (ESS 5.0)	5
---	---

Chapter 3. Collecting information about an issue	7
---	----------

Chapter 4. Contacting IBM	9
----------------------------------	----------

Information to collect before contacting the IBM Support Center	9
---	---

How to contact the IBM Support Center	11
---------------------------------------	----

Chapter 5. Maintenance procedures	13
--	-----------

Updating the firmware for host adapters, enclosures, and drives	13
---	----

Disk diagnosis	14
----------------	----

Background tasks	15
------------------	----

Server failover	16
-----------------	----

Data checksums	16
----------------	----

Disk replacement	16
------------------	----

Other hardware service	17
------------------------	----

Replacing failed disks in an ESS recovery group: a sample scenario	17
--	----

Replacing failed ESS storage enclosure components: a sample scenario	22
--	----

Replacing a failed ESS storage drawer: a sample scenario	23
--	----

Replacing a failed ESS storage enclosure: a sample scenario	29
---	----

Replacing failed disks in a Power 775 Disk Enclosure recovery group: a sample scenario	36
--	----

Directed maintenance procedures	42
---------------------------------	----

Replace disks	42
----------------------	-----------

Update enclosure firmware	43
----------------------------------	-----------

Update drive firmware	43
-----------------------	----

Update host-adapter firmware	43
------------------------------	----

Start NSD	44
-----------	----

Start GPFS daemon	44
-------------------	----

Increase fileset space	44
------------------------	----

Synchronize node clocks	45
-------------------------	----

Start performance monitoring collector service	45
--	----

Start performance monitoring sensor service	46
---	----

Chapter 6. References	47
------------------------------	-----------

Events	47
--------	----

Messages	105
----------	-----

Message severity tags	106
-----------------------	-----

IBM Spectrum Scale RAID messages	107
----------------------------------	-----

Notices	125
----------------	------------

Trademarks	126
------------	-----

Glossary	129
-----------------	------------

Index	135
--------------	------------

Tables

1. Conventions	viii	16. Events for the DISK component.	66
2. IBM websites for help, services, and information	3	17. Events for the file system component	66
3. Background tasks	15	18. Events for the GPFS component.	77
4. ESS fault tolerance for drawer/enclosure	24	19. Events for the GUI component	84
5. ESS fault tolerance for drawer/enclosure	30	20. Events for the HadoopConnector component	90
6. DMPs	42	21. Events for the KEYSTONE component	91
7. Events for arrays defined in the system	47	22. Events for the NFS component	92
8. Enclosure events	48	23. Events for the Network component	96
9. Virtual disk events	52	24. Events for the object component	98
10. Physical disk events.	52	25. Events for the Performance component	103
11. Recovery group events.	53	26. Events for the SMB component	105
12. Server events	53	27. IBM Spectrum Scale message severity tags ordered by priority	106
13. Events for the AUTH component	56	28. ESS GUI message severity tags ordered by priority	107
14. Events for the CESNetwork component	58		
15. Events for the Transparent Cloud Tiering component.	61		

About this information

This information guides you in monitoring and troubleshooting the Elastic Storage Server (ESS) Version 5.x for Power® and all subsequent modifications and fixes for this release.

Prerequisite and related information

ESS information

The ESS 5.x library consists of these information units:

- *Deploying the Elastic Storage Server*, SC27-6659
- *Elastic Storage Server: Quick Deployment Guide*, SC27-8580
- *Elastic Storage Server: Problem Determination Guide*, SA23-1457
- *IBM Spectrum Scale RAID: Administration*, SC27-6658

For more information, see IBM® Knowledge Center:

http://www-01.ibm.com/support/knowledgecenter/SSYSP8_5.0.0/sts50_welcome.html

For the latest support information about IBM Spectrum Scale™ RAID, see the IBM Spectrum Scale RAID FAQ in IBM Knowledge Center:

http://www.ibm.com/support/knowledgecenter/SSYSP8/sts_welcome.html

Related information

For information about:

- IBM Spectrum Scale, see IBM Knowledge Center:
http://www.ibm.com/support/knowledgecenter/STXKQY/ibmspectrumscale_welcome.html
- IBM POWER8® servers, see IBM Knowledge Center:
<http://www.ibm.com/support/knowledgecenter/POWER8/p8hdx/POWER8welcome.htm>
- The DCS3700 storage enclosure, see:
 - *System Storage® DCS3700 Quick Start Guide*, GA32-0960-03:
<http://www.ibm.com/support/docview.wss?uid=ssg1S7004915>
 - *IBM System Storage DCS3700 Storage Subsystem and DCS3700 Storage Subsystem with Performance Module Controllers: Installation, User's, and Maintenance Guide*, GA32-0959-07:
<http://www.ibm.com/support/docview.wss?uid=ssg1S7004920>
- The IBM Power Systems™ EXP24S I/O Drawer (FC 5887), see IBM Knowledge Center :
http://www.ibm.com/support/knowledgecenter/8247-22L/p8ham/p8ham_5887_kickoff.htm
- Extreme Cluster/Cloud Administration Toolkit (xCAT), go to the xCAT website :
http://sourceforge.net/p/xcats/wiki/Main_Page/

Conventions used in this information

Table 1 describes the typographic conventions used in this information. UNIX file name conventions are used throughout this information.

Table 1. Conventions

Convention	Usage
bold	Bold words or characters represent system elements that you must use literally, such as commands, flags, values, and selected menu options. Depending on the context, bold typeface sometimes represents path names, directories, or file names.
<u>bold underlined</u>	<u>bold underlined</u> keywords are defaults. These take effect if you do not specify a different keyword.
constant width	Examples and information that the system displays appear in constant-width typeface. Depending on the context, constant-width typeface sometimes represents path names, directories, or file names.
<i>italic</i>	<i>Italic</i> words or characters represent variable values that you must supply. <i>Italics</i> are also used for information unit titles, for the first use of a glossary term, and for general emphasis in text.
<key>	Angle brackets (less-than and greater-than) enclose the name of a key on the keyboard. For example, <Enter> refers to the key on your terminal or workstation that is labeled with the word <i>Enter</i> .
\	In command examples, a backslash indicates that the command or coding example continues on the next line. For example: <pre>mkcondition -r IBM.FileSystem -e "PercentTotUsed > 90" \ -E "PercentTotUsed < 85" -m p "FileSystem space used"</pre>
{item}	Braces enclose a list from which you must choose an item in format and syntax descriptions.
[item]	Brackets enclose optional items in format and syntax descriptions.
<Ctrl-x>	The notation <Ctrl-x> indicates a control character sequence. For example, <Ctrl-c> means that you hold down the control key while pressing <c>.
item...	Ellipses indicate that you can repeat the preceding item one or more times.
	In <i>synopsis</i> statements, vertical lines separate a list of choices. In other words, a vertical line means <i>Or</i> . In the left margin of the document, vertical lines indicate technical changes to the information.

How to submit your comments

Your feedback is important in helping us to produce accurate, high-quality information. You can add comments about this information in IBM Knowledge Center:

http://www.ibm.com/support/knowledgecenter/SSYSP8/sts_welcome.html

To contact the IBM Spectrum Scale development organization, send your comments to the following email address:

scale@us.ibm.com

Summary of changes

ESS 5.0 introduces the following enhancements and changes.

Occasionally, modifications and fixes are available for a given ESS release. For more information, see the release notes, which describe the highlights of a given modification or fix, on the Fix Central website:

<http://www.ibm.com/support/fixcentral>

A vertical line (|) to the left of text and illustrations indicates technical changes or additions made to the previous edition of the information.

| **Summary of changes for ESS Version 5.0 as updated, January 2017.**

| • **ESS core updates**

- | – IBM Spectrum Scale RAID V4.2.2 PTF1 efix5
- | – Change from all previous versions of ESS

| • **Support of Red Hat Enterprise Linux 7.2**

- | – Change from all previous versions of ESS
- | – Kernel release 3.10.0-327.36.3.el7.ppc64 (PPC64BE)
- | – Kernel release 3.10.0-327.36.3.el7.ppc64le (PPC64LE)

| • **Support of MLNX_OFED_LINUX-3.4-1.0.0.7**

- | – Change from all previous versions of ESS except ESS 4.5.2
- | – No change of network adapter (IB and Ethernet) support from ESS 4.5.x

| • **Install Toolkit updates**

- | – Updated Install Toolkit
- | – Changes from all previous versions of ESS

| • **Updated firmware RPM**

- | – Updated firmware for IBM PCIe x8 Cache SAS RAID Internal Adapter
- | – Support for updated drive FW
- | – Changes from all previous versions of ESS

Chapter 1. Best practices for troubleshooting

Following certain best practices make the troubleshooting process easier.

How to get started with troubleshooting

Troubleshooting the issues reported in the system is easier when you follow the process step-by-step.

When you experience some issues with the system, go through the following steps to get started with the troubleshooting:

1. Check the events that are reported in various nodes of the cluster by using the **mmhealth node show** command.
2. Check the user action corresponding to the active events and take the appropriate action. For more information on the events and corresponding user action, see “Events” on page 47.
3. Collect the details of the issues through logs, dumps, and traces. You can use various CLI commands and **Settings > Diagnostic Data** GUI page to collect the details of the issues reported in the system.
4. Based on the type of issue, browse through the various topics that are listed in the troubleshooting section and try to resolve the issue.
5. If you cannot resolve the issue by yourself, contact IBM Support.

Back up your data

You need to back up data regularly to avoid data loss. It is also recommended to take backups before you start troubleshooting. The IBM Spectrum Scale provides various options to create data backups.

Follow the guidelines in the following sections to avoid any issues while creating backup:

- *GPFS(tm) backup data in IBM Spectrum Scale: Concepts, Planning, and Installation Guide*
- *Backup considerations for using IBM Spectrum Protect™ in IBM Spectrum Scale: Concepts, Planning, and Installation Guide*
- *Configuration reference for using IBM Spectrum Protect with IBM Spectrum Scale(tm) in IBM Spectrum Scale: Administration Guide*
- *Protecting data in a file system using backup in IBM Spectrum Scale: Administration Guide*
- *Backup procedure with SOBAR in IBM Spectrum Scale: Administration Guide*

The following best practices help you to troubleshoot the issues that might arise in the data backup process:

1. Enable the most useful messages in **mmbackup** command by setting the **MMBACKUP_PROGRESS_CONTENT** and **MMBACKUP_PROGRESS_INTERVAL** environment variables in the command environment prior to issuing the **mmbackup** command. Setting **MMBACKUP_PROGRESS_CONTENT=7** provides the most useful messages. For more information on these variables, see *mmbackup command* in *IBM Spectrum Scale: Command and Programming Reference*.
2. If the **mmbackup** process is failing regularly, enable debug options in the backup process:
Use the **DEBUGmmbackup** environment variable or the **-d** option that is available in the **mmbackup** command to enable debugging features. This variable controls what debugging features are enabled. It is interpreted as a bitmask with the following bit meanings:

0x001 Specifies that basic debug messages are printed to STDOUT. There are multiple components that comprise **mmbackup**, so the debug message prefixes can vary. Some examples include:

```
mmbackup:mmbackup.sh  
DEBUGtsbackup33:
```

0x002 Specifies that temporary files are to be preserved for later analysis.

0x004 Specifies that all dsmd command output is to be mirrored to STDOUT.

The **-d** option in the **mmbackup** command line is equivalent to **DEBUGmmbackup = 1**.

3. To troubleshoot problems with backup subtask execution, enable debugging in the tsbuhelper program.

Use the **DEBUGtsbuhelper** environment variable to enable debugging features in the mmbackup helper program tsbuhelper.

Resolve events in a timely manner

Resolving the issues in a timely manner helps to get attention on the new and most critical events. If there are a number of unfixed alerts, fixing any one event might become more difficult because of the effects of the other events. You can use either CLI or GUI to view the list of issues that are reported in the system.

You can use the **mmhealth node eventlog** to list the events that are reported in the system.

The **Monitoring > Events** GUI page lists all events reported in the system. You can also mark certain events as read to change the status of the event in the events view. The status icons become gray in case an error or warning is fixed or if it is marked as read. Some issues can be resolved by running a fix procedure. Use the action **Run Fix Procedure** to do so. The Events page provides a recommendation for which fix procedure to run next.

Keep your software up to date

Check for new code releases and update your code on a regular basis.

This can be done by checking the IBM support website to see if new code releases are available: IBM Elastic Storage Server support website. The release notes provide information about new function in a release plus any issues that are resolved with the new release. Update your code regularly if the release notes indicate a potential issue.

Note: If a critical problem is detected on the field, IBM may send a flash, advising the user to contact IBM for an efix. The efix when applied might resolve the issue.

Subscribe to the support notification

Subscribe to support notifications so that you are aware of best practices and issues that might affect your system.

Subscribe to support notifications by visiting the IBM support page on the following IBM website:
<http://www.ibm.com/support/mynotifications>.

By subscribing, you are informed of new and updated support site information, such as publications, hints and tips, technical notes, product flashes (alerts), and downloads.

Know your IBM warranty and maintenance agreement details

If you have a warranty or maintenance agreement with IBM, know the details that must be supplied when you call for support.

For more information on the IBM Warranty and maintenance details, see Warranties, licenses and maintenance.

Know how to report a problem

If you need help, service, technical assistance, or want more information about IBM products, you find a wide variety of sources available from IBM to assist you.

IBM maintains pages on the web where you can get information about IBM products and fee services, product implementation and usage assistance, break and fix service support, and the latest technical information. The following table provides the URLs of the IBM websites where you can find the support information.

Table 2. IBM websites for help, services, and information

Website	Address
IBM home page	http://www.ibm.com
Directory of worldwide contacts	http://www.ibm.com/planetwide
Support for ESS	IBM Elastic Storage Server support website
Support for IBM System Storage and IBM Total Storage products	http://www.ibm.com/support/entry/portal/product/system_storage/

Note: Available services, telephone numbers, and web links are subject to change without notice.

Before you call

Make sure that you have taken steps to try to solve the problem yourself before you call. Some suggestions for resolving the problem before calling IBM Support include:

- Check all hardware for issues beforehand.
- Use the troubleshooting information in your system documentation. The troubleshooting section of the IBM Knowledge Center contains procedures to help you diagnose problems.

To check for technical information, hints, tips, and new device drivers or to submit a request for information, go to the IBM Elastic Storage Server support website.

Using the documentation

Information about your IBM storage system is available in the documentation that comes with the product. That documentation includes printed documents, online documents, readme files, and help files in addition to the IBM Knowledge Center.

Chapter 2. Limitations

Read this section to learn about product limitations.

Limit updates to Red Hat Enterprise Linux (ESS 5.0)

Limit errata updates to RHEL to security updates and updates requested by IBM Service.

ESS 5.0 supports Red Hat Enterprise Linux 7.2 (kernel release 3.10.0-327.36.3.el7.ppc64). It is highly recommended that you install only the following types of updates to RHEL:

- Security updates.
- Errata updates that are requested by IBM Service.

Chapter 3. Collecting information about an issue

- | To begin the troubleshooting process, collect information about the issue that the system is reporting.
- | From the EMS, issue the following command:

```
gsssnap -i -g -N <IO node1>,<IO node 2>,...,<IO node X>
```
- | The system will return a **gpfs.snap**, an **installcheck**, and the data from each node.
- | For more information, see *gsssnap script* in *Deploying the Elastic Storage Server*.

Chapter 4. Contacting IBM

Specific information about a problem such as: symptoms, traces, error logs, GPFS™ logs, and file system status is vital to IBM in order to resolve an IBM Spectrum Scale RAID problem.

Obtain this information as quickly as you can after a problem is detected, so that error logs will not wrap and system parameters that are always changing, will be captured as close to the point of failure as possible. When a serious problem is detected, collect this information and then call IBM.

Information to collect before contacting the IBM Support Center

For effective communication with the IBM Support Center to help with problem diagnosis, you need to collect certain information.

Information to collect for all problems related to IBM Spectrum Scale RAID

Regardless of the problem encountered with IBM Spectrum Scale RAID, the following data should be available when you contact the IBM Support Center:

1. A description of the problem.
2. Output of the failing application, command, and so forth.

To collect the **gpfs.snap** data and the ESS tool logs, issue the following from the EMS:

```
gsssnap -g -i -n <IO node1>, <IOnode2>,... <ioNodeX>
```

3. A tar file generated by the **gpfs.snap** command that contains data from the nodes in the cluster. In large clusters, the **gpfs.snap** command can collect data from certain nodes (for example, the affected nodes, NSD servers, or manager nodes) using the **-N** option.

For more information about gathering data using the **gpfs.snap** command, see the *IBM Spectrum Scale: Problem Determination Guide*.

If the **gpfs.snap** command cannot be run, collect these items:

- a. Any error log entries that are related to the event:
 - On a Linux node, create a tar file of all the entries in the **/var/log/messages** file from all nodes in the cluster or the nodes that experienced the failure. For example, issue the following command to create a tar file that includes all nodes in the cluster:

```
mmdash -v -N all "cat /var/log/messages" > all.messages
```

- On an AIX® node, issue this command:

```
errpt -a
```

For more information about the operating system error log facility, see the *IBM Spectrum Scale: Problem Determination Guide*.

- b. A master GPFS log file that is merged and chronologically sorted for the date of the failure. (See the *IBM Spectrum Scale: Problem Determination Guide* for information about creating a master GPFS log file.
- c. If the cluster was configured to store dumps, collect any internal GPFS dumps written to that directory relating to the time of the failure. The default directory is **/tmp/mmfs**.
- d. On a failing Linux node, gather the installed software packages and the versions of each package by issuing this command:

```
rpm -qa
```
- e. On a failing AIX node, gather the name, most recent level, state, and description of all installed software packages by issuing this command:

```
lspp -l
```

- f. File system attributes for all of the failing file systems, issue:
`mmfsfs Device`
 - g. The current configuration and state of the disks for all of the failing file systems, issue:
`mmfsdisk Device`
 - h. A copy of file `/var/mmfs/gen/mmsdrfs` from the primary cluster configuration server.
4. If you are experiencing one of the following problems, see the appropriate section before contacting the IBM Support Center:
- For delay and deadlock issues, see “Additional information to collect for delays and deadlocks.”
 - For file system corruption or MMFS_FSSTRUCT errors, see “Additional information to collect for file system corruption or MMFS_FSSTRUCT errors.”
 - For GPFS daemon crashes, see “Additional information to collect for GPFS daemon crashes.”

Additional information to collect for delays and deadlocks

When a delay or deadlock situation is suspected, the IBM Support Center will need additional information to assist with problem diagnosis. If you have not done so already, make sure you have the following information available before contacting the IBM Support Center:

1. Everything that is listed in “Information to collect for all problems related to IBM Spectrum Scale RAID” on page 9.
2. The deadlock debug data collected automatically.
3. If the cluster size is relatively small and the `maxFilesToCache` setting is not high (less than 10,000), issue the following command:

```
gpfs.snap --deadlock
```

If the cluster size is large or the `maxFilesToCache` setting is high (greater than 1M), issue the following command:

```
gpfs.snap --deadlock --quick
```

For more information about the `--deadlock` and `--quick` options, see the *IBM Spectrum Scale: Problem Determination Guide*.

Additional information to collect for file system corruption or MMFS_FSSTRUCT errors

When file system corruption or MMFS_FSSTRUCT errors are encountered, the IBM Support Center will need additional information to assist with problem diagnosis. If you have not done so already, make sure you have the following information available before contacting the IBM Support Center:

1. Everything that is listed in “Information to collect for all problems related to IBM Spectrum Scale RAID” on page 9.
2. Unmount the file system everywhere, then run `mmfsck -n` in offline mode and redirect it to an output file.

The IBM Support Center will determine when and if you should run the `mmfsck -y` command.

Additional information to collect for GPFS daemon crashes

When the GPFS daemon is repeatedly crashing, the IBM Support Center will need additional information to assist with problem diagnosis. If you have not done so already, make sure you have the following information available before contacting the IBM Support Center:

1. Everything that is listed in “Information to collect for all problems related to IBM Spectrum Scale RAID” on page 9.
2. Make sure the `/tmp/mmfs` directory exists on all nodes. If this directory does not exist, the GPFS daemon will not generate internal dumps.

3. Set the traces on this cluster and *all* clusters that mount any file system from this cluster:
`mmtracectl --set --trace=def --trace-recycle=global`
4. Start the trace facility by issuing:
`mmtracectl --start`
5. Recreate the problem if possible or wait for the assert to be triggered again.
6. Once the assert is encountered on the node, turn off the trace facility by issuing:
`mmtracectl --off`
If traces were started on multiple clusters, **mmtracectl --off** should be issued immediately on all clusters.
7. Collect **gpfs.snap** output:
`gpfs.snap`

How to contact the IBM Support Center

IBM support is available for various types of IBM hardware and software problems that IBM Spectrum Scale customers may encounter.

These problems include the following:

- IBM hardware failure
- Node halt or crash not related to a hardware failure
- Node hang or response problems
- Failure in other software supplied by IBM

If you have an IBM Software Maintenance service contract

If you have an IBM Software Maintenance service contract, contact IBM Support as follows:

Your location	Method of contacting IBM Support
In the United States	Call 1-800-IBM-SERV for support.
Outside the United States	Contact your local IBM Support Center or see the Directory of worldwide contacts (www.ibm.com/planetwide).

When you contact IBM Support, the following will occur:

1. You will be asked for the information you collected in “Information to collect before contacting the IBM Support Center” on page 9.
2. You will be given a time period during which an IBM representative will return your call. Be sure that the person you identified as your contact can be reached at the phone number you provided in the PMR.
3. An online Problem Management Record (PMR) will be created to track the problem you are reporting, and you will be advised to record the PMR number for future reference.
4. You may be requested to send data related to the problem you are reporting, using the PMR number to identify it.
5. Should you need to make subsequent calls to discuss the problem, you will also use the PMR number to identify the problem.

If you do not have an IBM Software Maintenance service contract

If you do not have an IBM Software Maintenance service contract, contact your IBM sales representative to find out how to proceed. Be prepared to provide the information you collected in “Information to collect before contacting the IBM Support Center” on page 9.

For failures in non-IBM software, follow the problem-reporting procedures provided with that product.

Chapter 5. Maintenance procedures

Very large disk systems, with thousands or tens of thousands of disks and servers, will likely experience a variety of failures during normal operation.

To maintain system productivity, the vast majority of these failures must be handled automatically without loss of data, without temporary loss of access to the data, and with minimal impact on the performance of the system. Some failures require human intervention, such as replacing failed components with spare parts or correcting faults that cannot be corrected by automated processes.

You can also use the ESS GUI to perform various maintenance tasks. The ESS GUI lists various maintenance-related events in its event log in the **Monitoring > Events** page. You can set up email alerts to get notified when such events are reported in the system. You can resolve these events or contact the IBM Support Center for help as needed. The ESS GUI includes various maintenance procedures to guide you through the fix process.

Updating the firmware for host adapters, enclosures, and drives

After creating a GPFS cluster, you can install the most current firmware for host adapters, enclosures, and drives.

- | After creating a GPFS cluster, install the most current firmware for host adapters, enclosures, and drives
- | only if instructed to do so by IBM support. Then, address issues that occur because you have not
- | upgraded to a later version of ESS.

You can update the firmware either manually or with the help of directed maintenance procedures (DMP) that are available in the GUI. The ESS GUI lists events in its event log in the **Monitoring > Events** page if the host adapter, enclosure, or drive firmware is not up-to-date, compared to the currently-available firmware packages on the servers. Select **Run Fix Procedure** from the **Action** menu for the firmware-related event to launch the corresponding DMP in the GUI. For more information on the available DMPs, see *Directed maintenance procedures* in *Elastic Storage Server: Problem Determination Guide*.

The most current firmware is packaged as the **gpfs.gss.firmware** RPM. You can find the most current firmware on Fix Central.

1. Sign in with your IBM ID and password.
2. On the **Find product** tab:
 - a. In the **Product selector** field, type: IBM Spectrum Scale RAID and click on the arrow to the right
 - | b. On the **Installed Version** drop-down menu, select: 5.0.0
 - c. On the **Platform** drop-down menu, select: Linux 64-bit,pSeries
 - d. Click on **Continue**
3. On the **Select fixes** page, select the most current fix pack.
4. Click on **Continue**
5. On the **Download options** page, select radio button to the left of your preferred downloading method. Make sure the check box to the left of Include prerequisites and co-requisite fixes (you can select the ones you need later) has a check mark in it.
6. Click on **Continue** to go to the **Download files...** page and download the fix pack files.

The **gpfs.gss.firmware** RPM needs to be installed on all ESS server nodes. It contains the most current updates of the following types of supported firmware for a ESS configuration:

- Host adapter firmware

- Enclosure firmware
- Drive firmware
- Firmware loading tools.

For command syntax and examples, see *mmchfirmware* command in *IBM Spectrum Scale RAID: Administration*.

Disk diagnosis

For information about disk hospital, see *Disk hospital* in *IBM Spectrum Scale RAID: Administration*.

When an individual disk I/O operation (read or write) encounters an error, IBM Spectrum Scale RAID completes the NSD client request by reconstructing the data (for a read) or by marking the unwritten data as stale and relying on successfully written parity or replica strips (for a write), and starts the disk hospital to diagnose the disk. While the disk hospital is diagnosing, the affected disk will not be used for serving NSD client requests.

Similarly, if an I/O operation does not complete in a reasonable time period, it is timed out, and the client request is treated just like an I/O error. Again, the disk hospital will diagnose what went wrong. If the timed-out operation is a disk write, the disk remains temporarily unusable until a pending timed-out write (PTOW) completes.

The disk hospital then determines the exact nature of the problem. If the cause of the error was an actual media error on the disk, the disk hospital marks the offending area on disk as temporarily unusable, and overwrites it with the reconstructed data. This cures the media error on a typical HDD by relocating the data to spare sectors reserved within that HDD.

If the disk reports that it can no longer write data, the disk is marked as *readonly*. This can happen when no spare sectors are available for relocating in HDDs, or the flash memory write endurance in SSDs was reached. Similarly, if a disk reports that it cannot function at all, for example not spin up, the disk hospital marks the disk as *dead*.

The disk hospital also maintains various forms of *disk badness*, which measure accumulated errors from the disk, and of *relative performance*, which compare the performance of this disk to other disks in the same declustered array. If the badness level is high, the disk can be marked *dead*. For less severe cases, the disk can be marked *failing*.

Finally, the IBM Spectrum Scale RAID server might lose communication with a disk. This can either be caused by an actual failure of an individual disk, or by a fault in the disk interconnect network. In this case, the disk is marked as *missing*. If the relative performance of the disk drops below 66% of the other disks for an extended period, the disk will be declared *slow*.

If a disk would have to be marked *dead*, *missing*, or *readonly*, and the problem affects individual disks only (not a large set of disks), the disk hospital tries to recover the disk. If the disk reports that it is not started, the disk hospital attempts to start the disk. If nothing else helps, the disk hospital power-cycles the disk (assuming the JBOD hardware supports that), and then waits for the disk to return online.

Before actually reporting an individual disk as *missing*, the disk hospital starts a search for that disk by polling all disk interfaces to locate the disk. Only after that fast poll fails is the disk actually declared *missing*.

If a large set of disks has faults, the IBM Spectrum Scale RAID server can continue to serve read and write requests, provided that the number of failed disks does not exceed the fault tolerance of either the RAID code for the vdisk or the IBM Spectrum Scale RAID vdisk configuration data. When any disk fails, the server begins rebuilding its data onto spare space. If the failure is not considered *critical*, rebuilding is

throttled when user workload is present. This ensures that the performance impact to user workload is minimal. A failure might be considered critical if a vdisk has no remaining redundancy information, for example three disk faults for 4-way replication and $8 + 3p$ or two disk faults for 3-way replication and $8 + 2p$. During a critical failure, critical rebuilding will run as fast as possible because the vdisk is in imminent danger of data loss, even if that impacts the user workload. Because the data is declustered, or spread out over many disks, and all disks in the declustered array participate in rebuilding, a vdisk will remain in critical rebuild only for short periods of time (several minutes for a typical system). A double or triple fault is extremely rare, so the performance impact of critical rebuild is minimized.

In a multiple fault scenario, the server might not have enough disks to fulfill a request. More specifically, such a scenario occurs if the number of unavailable disks exceeds the fault tolerance of the RAID code. If some of the disks are only temporarily unavailable, and are expected back online soon, the server will stall the client I/O and wait for the disk to return to service. Disks can be temporarily unavailable for any of the following reasons:

- The disk hospital is diagnosing an I/O error.
- A timed-out write operation is pending.
- A user intentionally suspended the disk, perhaps it is on a carrier with another failed disk that has been removed for service.

If too many disks become unavailable for the primary server to proceed, it will fail over. In other words, the whole recovery group is moved to the backup server. If the disks are not reachable from the backup server either, then all vdisks in that recovery group become unavailable until connectivity is restored.

A vdisk will suffer data loss when the number of permanently failed disks exceeds the vdisk fault tolerance. This data loss is reported to NSD clients when the data is accessed.

Background tasks

While IBM Spectrum Scale RAID primarily performs NSD client read and write operations in the foreground, it also performs several long-running maintenance tasks in the background, which are referred to as *background tasks*. The background task that is currently in progress for each declustered array is reported in the long-form output of the **mmlsrecoverygroup** command. Table 3 describes the long-running background tasks.

Table 3. Background tasks

Task	Description
repair-RGD/VCD	Repairing the internal recovery group data and vdisk configuration data from the failed disk onto the other disks in the declustered array.
rebuild-critical	Rebuilding virtual tracks that cannot tolerate any more disk failures.
rebuild-1r	Rebuilding virtual tracks that can tolerate only one more disk failure.
rebuild-2r	Rebuilding virtual tracks that can tolerate two more disk failures.
rebuild-offline	Rebuilding virtual tracks where failures exceeded the fault tolerance.
rebalance	Rebalancing the spare space in the declustered array for either a missing pdisk that was discovered again, or a new pdisk that was added to an existing array.
scrub	Scrubbing vdisks to detect any silent disk corruption or latent sector errors by reading the entire virtual track, performing checksum verification, and performing consistency checks of the data and its redundancy information. Any correctable errors found are fixed.

Server failover

If the primary IBM Spectrum Scale RAID server loses connectivity to a sufficient number of disks, the recovery group attempts to fail over to the backup server. If the backup server is also unable to connect, the recovery group becomes unavailable until connectivity is restored. If the backup server had taken over, it will relinquish the recovery group to the primary server when it becomes available again.

Data checksums

IBM Spectrum Scale RAID stores checksums of the data and redundancy information on all disks for each vdisk. Whenever data is read from disk or received from an NSD client, checksums are verified. If the checksum verification on a data transfer to or from an NSD client fails, the data is retransmitted. If the checksum verification fails for data read from disk, the error is treated similarly to a media error:

- The data is reconstructed from redundant data on other disks.
- The data on disk is rewritten with reconstructed good data.
- The disk badness is adjusted to reflect the silent read error.

Disk replacement

You can use the ESS GUI for detecting failed disks and for disk replacement.

When one disk fails, the system will rebuild the data that was on the failed disk onto spare space and continue to operate normally, but at slightly reduced performance because the same workload is shared among fewer disks. With the default setting of two spare disks for each large declustered array, failure of a single disk would typically not be a sufficient reason for maintenance.

When several disks fail, the system continues to operate even if there is no more spare space. The next disk failure would make the system unable to maintain the redundancy the user requested during vdisk creation. At this point, a service request is sent to a maintenance management application that requests replacement of the failed disks and specifies the disk FRU numbers and locations.

In general, disk maintenance is requested when the number of failed disks in a declustered array reaches the disk replacement threshold. By default, that threshold is identical to the number of spare disks. For a more conservative disk replacement policy, the threshold can be set to smaller values using the **mmchrecoverygroup** command.

Disk maintenance is performed using the **mmchcarrier** command with the **--release** option, which:

- Suspends any functioning disks on the carrier if the multi-disk carrier is shared with the disk that is being replaced.
- If possible, powers down the disk to be replaced or all of the disks on that carrier.
- Turns on indicators on the disk enclosure and disk or carrier to help locate and identify the disk that needs to be replaced.
- If necessary, unlocks the carrier for disk replacement.

After the disk is replaced and the carrier reinserted, another **mmchcarrier** command with the **--replace** option powers on the disks.

You can replace the disk either manually or with the help of directed maintenance procedures (DMP) that are available in the GUI. The ESS GUI lists events in its event log in the **Monitoring > Events** page if a disk failure is reported in the system. Select the *gnr_pdisk_replaceable* event from the list of events and then select **Run Fix Procedure** from the **Action** menu to launch the replace disk DMP in the GUI. For more information, see *Replace disks* in *Elastic Storage Server: Problem Determination Guide*.

Other hardware service

While IBM Spectrum Scale RAID can easily tolerate a single disk fault with no significant impact, and failures of up to three disks with various levels of impact on performance and data availability, it still relies on the vast majority of all disks being functional and reachable from the server. If a major equipment malfunction prevents both the primary and backup server from accessing more than that number of disks, or if those disks are actually destroyed, all vdisks in the recovery group will become either unavailable or suffer permanent data loss. As IBM Spectrum Scale RAID cannot recover from such catastrophic problems, it also does not attempt to diagnose them or orchestrate their maintenance.

In the case that a IBM Spectrum Scale RAID server becomes permanently disabled, a manual failover procedure exists that requires recabling to an alternate server. For more information, see the **mmchrecoverygroup** command in the *IBM Spectrum Scale: Command and Programming Reference*. If both the primary and backup IBM Spectrum Scale RAID servers for a recovery group fail, the recovery group is unavailable until one of the servers is repaired.

Replacing failed disks in an ESS recovery group: a sample scenario

The scenario presented here shows how to detect and replace failed disks in a recovery group built on an ESS building block.

Detecting failed disks in your ESS enclosure

Assume a GL4 building block on which the following two recovery groups are defined:

- BB1RGL, containing the disks in the left side of each drawer
- BB1RGR, containing the disks in the right side of each drawer

Each recovery group contains the following:

- One log declustered array (LOG)
- Two data declustered arrays (DA1, DA2)

The data declustered arrays are defined according to GL4 best practices as follows:

- 58 pdisks per data declustered array
- Default disk replacement threshold value set to 2

The replacement threshold of 2 means that IBM Spectrum Scale RAID only requires disk replacement when two or more disks fail in the declustered array; otherwise, rebuilding onto spare space or reconstruction from redundancy is used to supply affected data. This configuration can be seen in the output of **mmisrecoverygroup** for the recovery groups, which are shown here for BB1RGL:

```
# mmisrecoverygroup BB1RGL -L
```

recovery group	declustered arrays	vdisks	pdisks	format	version
BB1RGL	4	8	119	4.1.0.1	

declustered array	needs service	vdisks	pdisks	spares	replace threshold	free space	scrub duration	background activity task	progress	priority
SSD	no	1	1	0,0	1	186 GiB	14 days	scrub	8%	low
NVR	no	1	2	0,0	1	3648 MiB	14 days	scrub	8%	low
DA1	no	3	58	2,31	2	50 TiB	14 days	scrub	7%	low
DA2	no	3	58	2,31	2	50 TiB	14 days	scrub	7%	low

vdisk	RAID code	declustered array	vdisk size	block size	checksum granularity	state	remarks
-----	-----	-----	-----	-----	-----	-----	-----

ltip_BB1RGL	2WayReplication	NVR	48 MiB	2 MiB	512	ok	logTip
ltbackup_BB1RGL	Unreplicated	SSD	48 MiB	2 MiB	512	ok	logTipBackup
lhome_BB1RGL	4WayReplication	DA1	20 GiB	2 MiB	512	ok	log
reserved1_BB1RGL	4WayReplication	DA2	20 GiB	2 MiB	512	ok	logReserved
BB1RGLMETA1	4WayReplication	DA1	750 GiB	1 MiB	32 KiB	ok	
BB1RGLDATA1	8+3p	DA1	35 TiB	16 MiB	32 KiB	ok	
BB1RGLMETA2	4WayReplication	DA2	750 GiB	1 MiB	32 KiB	ok	
BB1RGLDATA2	8+3p	DA2	35 TiB	16 MiB	32 KiB	ok	
config data		declustered array	VCD spares	actual rebuild spare space		remarks	
rebuild space		DA1	31	35 pdisk			
rebuild space		DA2	31	35 pdisk			
config data		max disk group fault tolerance		actual disk group fault tolerance		remarks	
rg descriptor		1 enclosure + 1 drawer		1 enclosure + 1 drawer		limiting fault tolerance	
system index		2 enclosure		1 enclosure + 1 drawer		limited by rg descriptor	
vdisk		max disk group fault tolerance		actual disk group fault tolerance		remarks	
ltip_BB1RGL		1 pdisk		1 pdisk			
ltbackup_BB1RGL		0 pdisk		0 pdisk			
lhome_BB1RGL		3 enclosure		1 enclosure + 1 drawer		limited by rg descriptor	
reserved1_BB1RGL		3 enclosure		1 enclosure + 1 drawer		limited by rg descriptor	
BB1RGLMETA1		3 enclosure		1 enclosure + 1 drawer		limited by rg descriptor	
BB1RGLDATA1		1 enclosure		1 enclosure			
BB1RGLMETA2		3 enclosure		1 enclosure + 1 drawer		limited by rg descriptor	
BB1RGLDATA2		1 enclosure		1 enclosure			
active recovery group server			servers				
c45f01n01-ib0.gpfs.net			c45f01n01-ib0.gpfs.net,c45f01n02-ib0.gpfs.net				

The indication that disk replacement is called for in this recovery group is the value of yes in the needs service column for declustered array DA1.

The fact that DA1 is undergoing rebuild of its IBM Spectrum Scale RAID tracks that can tolerate one strip failure is by itself not an indication that disk replacement is required; it merely indicates that data from a failed disk is being rebuilt onto spare space. Only if the replacement threshold has been met will disks be marked for replacement and the declustered array marked as needing service.

IBM Spectrum Scale RAID provides several indications that disk replacement is required:

- Entries in the Linux syslog
- The **pdReplacePdisk** callback, which can be configured to run an administrator-supplied script at the moment a pdisk is marked for replacement
- The output from the following commands, which may be performed from the command line on any IBM Spectrum Scale RAID cluster node (see the examples that follow):
 1. **mmlsrecoverygroup** with the **-L** flag shows yes in the needs service column
 2. **mmlsrecoverygroup** with the **-L** and **--pdisk** flags; this shows the states of all pdisks, which may be examined for the replace pdisk state
 3. **mmlspdisk** with the **--replace** flag, which lists only those pdisks that are marked for replacement

Note: Because the output of **mmlsrecoverygroup -L --pdisk** is long, this example shows only some of the pdisks (but includes those marked for replacement).

```
# mmlsrecoverygroup BB1RGL -L --pdisk
```

recovery group	declustered arrays	vdisk	pdisk
BB1RGL	3	5	119

declustered array	needs service	vdisks	pdisks	spares	replace threshold	free space	scrub duration	background activity task	progress	priority
LOG	no	1	3	0	1	534 GiB	14 days	scrub	1%	low
DA1	yes	2	58	2	2	0 B	14 days	rebuild-lr	4%	low
DA2	no	2	58	2	2	1024 MiB	14 days	scrub	27%	low

pdisk	n. active, total paths	declustered array	free space	user condition	state, remarks
[...]					
e1d4s06	2, 4	DA1	62 GiB	normal	ok
e1d5s01	0, 0	DA1	70 GiB	replaceable	slow/noPath/systemDrain/noRGD/noVCD/replace
e1d5s02	2, 4	DA1	64 GiB	normal	ok
e1d5s03	2, 4	DA1	63 GiB	normal	ok
e1d5s04	0, 0	DA1	64 GiB	replaceable	failing/noPath/systemDrain/noRGD/noVCD/replace
e1d5s05	2, 4	DA1	63 GiB	normal	ok
[...]					

The preceding output shows that the following pdisks are marked for replacement:

- e1d5s01 in DA1
- e1d5s04 in DA1

The naming convention used during recovery group creation indicates that these disks are in Enclosure 1 Drawer 5 Slot 1 and Enclosure 1 Drawer 5 Slot 4. To confirm the physical locations of the failed disks, use the **mmfspdisk** command to list information about the pdisks in declustered array DA1 of recovery group BB1RGL that are marked for replacement:

```
# mmfspdisk BB1RGL --declustered-array DA1 --replace
pdisk:
  replacementPriority = 0.98
  name = "e1d5s01"
  device = ""
  recoveryGroup = "BB1RGL"
  declusteredArray = "DA1"
  state = "slow/noPath/systemDrain/noRGD/noVCD/replace"
  .
  .
  .
pdisk:
  replacementPriority = 0.98
  name = "e1d5s04"
  device = ""
  recoveryGroup = "BB1RGL"
  declusteredArray = "DA1"
  state = "failing/noPath/systemDrain/noRGD/noVCD/replace"
  .
  .
  .
```

The physical locations of the failed disks are confirmed to be consistent with the pdisk naming convention and with the IBM Spectrum Scale RAID component database:

Disk	Location	User Location
pdisk e1d5s01	SV21314035-5-1	Rack BB1 U01-04, Enclosure BB1ENC1 Drawer 5 Slot 1
pdisk e1d5s04	SV21314035-5-4	Rack BB1 U01-04, Enclosure BB1ENC1 Drawer 5 Slot 4

This shows how the component database provides an easier-to-use location reference for the affected physical disks. The pdisk name e1d5s01 means “Enclosure 1 Drawer 5 Slot 1.” Additionally, the location provides the serial number of enclosure 1, SV21314035, with the drawer and slot number. But the user location that has been defined in the component database can be used to precisely locate the disk in an equipment rack and a named disk enclosure: This is the disk enclosure that is labeled “BB1ENC1,” found in compartments U01 - U04 of the rack labeled “BB1,” and the disk is in drawer 5, slot 1 of that enclosure.

The relationship between the enclosure serial number and the user location can be seen with the **mmfscmp** command:

```
# mmfscmp --serial-number SV21314035
```

Storage Enclosure Components

Comp ID	Part Number	Serial Number	Name	Display ID
2	1818-80E	SV21314035	BB1ENC1	

Replacing failed disks in a GL4 recovery group

Note: In this example, it is assumed that two new disks with the appropriate Field Replaceable Unit (FRU) code, as indicated by the fru attribute (90Y8597 in this case), have been obtained as replacements for the failed pdisks e1d5s01 and e1d5s04.

Replacing each disk is a three-step process:

1. Using the **mmchcarrier** command with the **--release** flag to inform IBM Spectrum Scale to locate the disk, suspend it, and allow it to be removed.
2. Locating and removing the failed disk and replacing it with a new one.
3. Using the **mmchcarrier** command with the **--replace** flag to begin use of the new disk.

IBM Spectrum Scale RAID assigns a priority to pdisk replacement. Disks with smaller values for the **replacementPriority** attribute should be replaced first. In this example, the only failed disks are in DA1 and both have the same **replacementPriority**.

Disk e1d5s01 is chosen to be replaced first.

1. To release pdisk e1d5s01 in recovery group BB1RGL:

```
# mmchcarrier BB1RGL --release --pdisk e1d5s01
[I] Suspending pdisk e1d5s01 of RG BB1RGL in location SV21314035-5-1.
[I] Location SV21314035-5-1 is Rack BB1 U01-04, Enclosure BB1ENC1 Drawer 5 Slot 1.
[I] Carrier released.
```

- Remove carrier.
- Replace disk in location SV21314035-5-1 with FRU 90Y8597.
- Reinsert carrier.
- Issue the following command:

```
mmchcarrier BB1RGL --replace --pdisk 'e1d5s01'
```

IBM Spectrum Scale RAID issues instructions as to the physical actions that must be taken, and repeats the user-defined location to help find the disk.

2. To allow the enclosure BB1ENC1 with serial number SV21314035 to be located and identified, IBM Spectrum Scale RAID will turn on the enclosure’s amber “service required” LED. The enclosure’s bezel should be removed. This will reveal that the amber “service required” and blue “service allowed” LEDs for drawer 5 have been turned on.

Drawer 5 should then be unlatched and pulled open. The disk in slot 1 will be seen to have its amber and blue LEDs turned on.

Unlatch and pull up the handle for the identified disk in slot 1. Lift out the failed disk and set it aside. The drive LEDs turn off when the slot is empty. A new disk with FRU 90Y8597 should be lowered in place and have its handle pushed down and latched.

Since the second disk replacement in this example is also in drawer 5 of the same enclosure, leave the drawer open and the enclosure bezel off. If the next replacement were in a different drawer, the drawer would be closed; and if the next replacement were in a different enclosure, the enclosure bezel would be replaced.

3. To finish the replacement of pdisk eld5s01:

```
# mmchcarrier BB1RGL --replace --pdisk eld5s01
[I] The following pdisks will be formatted on node server1:
    /dev/sdmi
[I] Pdisk eld5s01 of RG BB1RGL successfully replaced.
[I] Resuming pdisk eld5s01#026 of RG BB1RGL.
[I] Carrier resumed.
```

When the **mmchcarrier --replace** command returns successfully, IBM Spectrum Scale RAID begins rebuilding and rebalancing IBM Spectrum Scale RAID strips onto the new disk, which assumes the pdisk name eld5s01. The failed pdisk may remain in a temporary form (indicated here by the name eld5s01#026) until all data from it rebuilds, at which point it is finally deleted. Notice that only one block device name is mentioned as being formatted as a pdisk; the second path will be discovered in the background.

Disk eld5s04 is still marked for replacement, and DA1 of BBRGL will still need service. This is because the IBM Spectrum Scale RAID replacement policy expects all failed disks in the declustered array to be replaced after the replacement threshold is reached.

Pdisk eld5s04 is then replaced following the same process.

1. Release pdisk eld5s04 in recovery group BB1RGL:

```
# mmchcarrier BB1RGL --release --pdisk eld5s04
[I] Suspending pdisk eld5s04 of RG BB1RGL in location SV21314035-5-4.
[I] Location SV21314035-5-4 is Rack BB1 U01-04, Enclosure BB1ENC1 Drawer 5 Slot 4.
[I] Carrier released.
```

- Remove carrier.
- Replace disk in location SV21314035-5-4 with FRU 90Y8597.
- Reinsert carrier.
- Issue the following command:

```
mmchcarrier BB1RGL --replace --pdisk 'eld5s04'
```

2. Find the enclosure and drawer, unlatch and remove the disk in slot 4, place a new disk in slot 4, push in the drawer, and replace the enclosure bezel.

3. To finish the replacement of pdisk eld5s04:

```
# mmchcarrier BB1RGL --replace --pdisk eld5s04
[I] The following pdisks will be formatted on node server1:
    /dev/sdfd
[I] Pdisk eld5s04 of RG BB1RGL successfully replaced.
[I] Resuming pdisk eld5s04#029 of RG BB1RGL.
[I] Carrier resumed.
```

The disk replacements can be confirmed with **mmlsrecoverygroup -L --pdisk**:

```
# mmlsrecoverygroup BB1RGL -L --pdisk
```

		declustered			
recovery group		arrays	vdisks	pdisks	
BB1RGL		3	5	121	
declustered array	needs service	vdisks	pdisks	spares	replace threshold
				free space	scrub duration
				background task	activity progress
					priority

LOG	no	1	3	0	1	534 GiB	14 days	scrub	1%	low
DA1	no	2	60	2	2	3647 GiB	14 days	rebuild-1r	4%	low
DA2	no	2	58	2	2	1024 MiB	14 days	scrub	27%	low

pdisk	n. active, total paths	declustered array	free space	user condition	state, remarks
-----	-----	-----	-----	-----	-----
[...]					
e1d4s06	2, 4	DA1	62 GiB	normal	ok
e1d5s01	2, 4	DA1	1843 GiB	normal	ok
e1d5s01#026	0, 0	DA1	70 GiB	draining	slow/noPath/systemDrain /adminDrain/noRGD/noVCD
e1d5s02	2, 4	DA1	64 GiB	normal	ok
e1d5s03	2, 4	DA1	63 GiB	normal	ok
e1d5s04	2, 4	DA1	1853 GiB	normal	ok
e1d5s04#029	0, 0	DA1	64 GiB	draining	failing/noPath/systemDrain /adminDrain/noRGD/noVCD
e1d5s05	2, 4	DA1	62 GiB	normal	ok
[...]					

Notice that the temporary pdisks (e1d5s01#026 and e1d5s04#029) representing the now-removed physical disks are counted toward the total number of pdisks in the recovery group BB1RGL and the declustered array DA1. They exist until IBM Spectrum Scale RAID rebuild completes the reconstruction of the data that they carried onto other disks (including their replacements). When rebuild completes, the temporary pdisks disappear, and the number of disks in DA1 will once again be 58, and the number of disks in BBRGL will once again be 119.

Replacing failed ESS storage enclosure components: a sample scenario

The scenario presented here shows how to detect and replace failed storage enclosure components in an ESS building block.

Detecting failed storage enclosure components

The **mm1senclosure** command can be used to show you which enclosures need service along with the specific component. A best practice is to run this command every day to check for failures.

```
# mm1senclosure all -L --not-ok
```

serial number	needs service	nodes
-----	-----	-----
SV21313971	yes	c45f02n01-ib0.gpfs.net

component type	serial number	component id	failed value	unit	properties
-----	-----	-----	-----	-----	-----
fan	SV21313971	1_BOT_LEFT	yes	RPM	FAILED

This indicates that enclosure SV21313971 has a failed fan.

When you are ready to replace the failed component, use the **mmchenclosure** command to identify whether it is safe to complete the repair action or whether IBM Spectrum Scale needs to be shut down first:

```
# mmchenclosure SV21313971 --component fan --component-id 1_BOT_LEFT
```

mmenclosure: Proceed with the replace operation.

The fan can now be replaced.

Special note about detecting failed enclosure components

In the following example, only the enclosure itself is being called out as having failed; the specific component that has actually failed is not identified. This typically means that there are drive “Service Action Required (Fault)” LEDs that have been turned on in the drawers. In such a situation, the **mmfspdsk all --not-ok** command can be used to check for dead or failing disks.

```
mmfenclosure all -L --not-ok
```

serial number	needs service	nodes
SV13306129	yes	c45f01n01-ib0.gpfs.net

component type	serial number	component id	failed value	unit	properties
enclosure	SV13306129	ONLY	yes		NOT_IDENTIFYING,FAILED

Replacing a failed ESS storage drawer: a sample scenario

Prerequisite information:

- IBM Spectrum Scale 4.1.1 PTF8 or 4.2.1 PTF1 is a prerequisite for this procedure to work. If you are not at one of these levels or higher, contact IBM.
- This procedure is intended to be done as a partnership between the storage administrator and a hardware service representative. The storage administrator is expected to understand the IBM Spectrum Scale RAID concepts and the locations of the storage enclosures. The storage administrator is responsible for all the steps except those in which the hardware is actually being worked on.
- The pdisks in a drawer span two recovery groups; therefore, it is very important that you examine the pdisks and the fault tolerance of the vdisks in both recovery groups when going through these steps.
- An underlying principle is that drawer replacement should never deliberately put any vdisk into critical state. When vdisks are in critical state, there is no redundancy and the next single sector or IO error can cause unavailability or data loss. If drawer replacement is not possible without making the system critical, then the ESS has to be shut down before the drawer is removed. An example of drawer replacement will follow these instructions.

Replacing a failed ESS storage drawer requires the following steps:

1. If IBM Spectrum Scale is shut down: perform drawer replacement as soon as possible. Perform steps 4b and 4c and then restart IBM Spectrum Scale.
2. Examine the states of the pdisks in the affected drawer. If all the pdisk states are missing, dead, or replace, then go to step 4b to perform drawer replacement as soon as possible without going through any of the other steps in this procedure.

Assuming that you know the enclosure number and drawer number and are using standard pdisk naming conventions, you could use the following commands to display the pdisks and their states:

```
mmf recoverygroup LeftRecoveryGroupName -L --pdisk | grep e{EnclosureNumber}d{DrawerNumber}
mmf recoverygroup RightRecoveryGroupName -L --pdisk | grep e{EnclosureNumber}d{DrawerNumber}
```

3. Determine whether online replacement is possible.
 - a. Consult the following table to see if drawer replacement is theoretically possible for this configuration. The only required input at this step is the ESS model.

The table shows each possible ESS system as well as the configuration parameters for the systems. If the table indicates that online replacement is impossible, IBM Spectrum Scale will need to be shut down (on at least the two I/O servers involved) and you should go back to step 1. The fault tolerance notation uses E for enclosure, D for drawer, and P for pdisk.

Additional background information on interpreting the fault tolerance values:

- For many of the systems, 1E is reported as the fault tolerance; however, this does not mean that failure of x arbitrary drawers or y arbitrary pdisks can be tolerated. It means that the failure of all the entities in one entire enclosure can be tolerated.
- A fault tolerance of 1E+1D or 2D implies that the failure of two arbitrary drawers can be tolerated.

Table 4. ESS fault tolerance for drawer/enclosure

Hardware type (model name...)			DA configuration			Fault tolerance					Is online replacement possible?
IBM ESS	Enclosure type	# Encl.	# Data DA per RG	Disks per DA	# Spares	RG desc	Mirrored vdisk		Parity vdisk		
GS1	2U-24	1	1	12	1	4P	3Way	2P	8+2p	2P	No drawers, enclosure impossible
							4Way	3P	8+3p	3P	No drawers, enclosure impossible
GS2	2U-24	2	1	24	2	4P	3Way	2P	8+2p	2P	No drawers, enclosure impossible
							4Way	3P	8+3p	3P	No drawers, enclosure impossible
GS4	2U-24	4	1	48	2	1E+1P	3Way	1E+1P	8+2p	2P	No drawers, enclosure impossible
							4Way	1E+1P	8+3p	1E	No drawers, enclosure impossible
GS6	2U-24	6	1	72	2	1E+1P	3Way	1E+1P	8+2p	1E	No drawers, enclosure impossible
							4Way	1E+1P	8+3p	1E+1P	No drawers, enclosure possible.
GL2	4U-60 (5d)	2	1	58	2	4D	3Way	2D	8+2p	2D	Drawer possible, enclosure impossible.
							4Way	3D	8+3p	1D+1P	Drawer possible, enclosure impossible
GL4	4U-60 (5d)	4	2	58	2	1E+1D	3Way	1E+1D	8+2p	2D	Drawer possible, enclosure impossible
							4Way	1E+1D	8+3p	1E	Drawer possible, enclosure impossible
GL4	4U-60 (5d)	4	1	116	4	1E+1D	3Way	1E+1D	8+2p	2D	Drawer possible, enclosure impossible
							4Way	1E+1D	8+3p	1E	Drawer possible, enclosure impossible

Table 4. ESS fault tolerance for drawer/enclosure (continued)

Hardware type (model name...)			DA configuration			Fault tolerance					Is online replacement possible?
GL6	4U-60 (5d)	6	3	58	2	1E+1D	3Way	1E+1D	8+2p	1E	Drawer possible, enclosure impossible
							4Way	1E+1D	8+3p	1E+1D	Drawer possible, enclosure possible.
GL6	4U-60 (5d)	6	1	174	6	1E+1D	3Way	1E+1D	8+2p	1E	Drawer possible, enclosure impossible
							4Way	1E+1D	8+3p	1E+1D	Drawer possible, enclosure possible.

- b. Determine the actual disk group fault tolerance of the vdisks in both recovery groups using the **mm1srecoverygroup RecoveryGroupName -L** command. The rg descriptor and all the vdisks must be able to tolerate the loss of the item being replaced plus one other item. This is necessary because the disk group fault tolerance code uses a definition of "tolerance" that includes the system running in critical mode. But since putting the system into critical is not advised, one other item is required. For example, all the following would be a valid fault tolerance to continue with drawer replacement: 1E+1D, 1D+1P, and 2D.
 - c. Compare the actual disk group fault tolerance with the disk group fault tolerance listed in Table 4 on page 24. If the system is using a mix of 2-fault-tolerant and 3-fault-tolerant vdisks, the comparisons must be done with the weaker (2-fault-tolerant) values. If the fault tolerance can tolerate at least the item being replaced plus one other item, then replacement can proceed. Go to step 4.
4. Drawer Replacement procedure.
 - a. Quiesce the pdisks.
Choose one of the following methods to suspend all the pdisks in the drawer.
 - Using the **chdrawer** sample script:
`/usr/lpp/mmfs/samples/vdisk/chdrawer EnclosureSerialNumber DrawerNumber --release`
 - Manually using the **mmchpdisk** command:

```
for slotNumber in 01 02 03 04 05 06 ; do mmchpdisk LeftRecoveryGroupName --pdisk \
e{EnclosureNumber}d{DrawerNumber}s{$slotNumber} --suspend ; done

for slotNumber in 07 08 09 10 11 12 ; do mmchpdisk RightRecoveryGroupName --pdisk \
e{EnclosureNumber}d{DrawerNumber}s{$slotNumber} --suspend ; done
```

 Verify that the pdisks were suspended using the **mm1srecoverygroup** command as shown in step 2.
 - b. Remove the drives; make sure to record the location of the drives and label them. You will need to replace them in the corresponding slots of the new drawer later.
 - c. Replace the drawer following standard hardware procedures.
 - d. Replace the drives in the corresponding slots of the new drawer.
 - e. Resume the pdisks.
Choose one of the following methods to resume all the pdisks in the drawer.
 - Using the **chdrawer** sample script:
`/usr/lpp/mmfs/samples/vdisk/chdrawer EnclosureSerialNumber DrawerNumber --replace`
 - Manually using the **mmchpdisk** command:

```
for slotNumber in 01 02 03 04 05 06 ; do mmchpdisk LeftRecoveryGroupName --pdisk
e{EnclosureNumber}d{DrawerNumber}s{$slotNumber} --resume ; done

for slotNumber in 07 08 09 10 11 12 ; do mmchpdisk RightRecoveryGroupName --pdisk
e{EnclosureNumber}d{DrawerNumber}s{$slotNumber} --resume ; done
```

You can verify that the pdisks are no longer suspended using the **mm1srecoverygroup** command as shown in step 2.

5. Verify that the drawer has been successfully replaced.

Examine the states of the pdisks in the affected drawers. All the pdisk states should be ok and the second column of the output should all be "2" indicating that 2 paths are being seen. Assuming that you know the enclosure number and drawer number and are using standard pdisk naming conventions, you could use the following commands to display the pdisks and their states:

```
mm1srecoverygroup LeftRecoveryGroupName -L --pdisk | grep e{EnclosureNumber}d{DrawerNumber}
mm1srecoverygroup RightRecoveryGroupName -L --pdisk | grep e{EnclosureNumber}d{DrawerNumber}
```

Example

The system is a GL4 with vdisks that have 4way mirroring and 8+3p RAID codes. Assume that the drawer that contains pdisk e2d3s01 needs to be replaced because one of the drawer control modules has failed (so that you only see one path to the drives instead of 2). This means that you are trying to replace drawer 3 in enclosure 2. Assume that the drawer spans recovery groups rgL and rgR.

Determine the enclosure serial number:

```
> mm1spdisk rgL --pdisk e2d3s01 | grep -w location
location = "SV21106537-3-1"
```

Examine the states of the pdisks and find that they are all ok.

```
> mm1srecoverygroup rgL -L --pdisk | grep e2d3
e2d3s01      1, 2    DA1      1862 GiB  normal    ok
e2d3s02      1, 2    DA1      1862 GiB  normal    ok
e2d3s03      1, 2    DA1      1862 GiB  normal    ok
e2d3s04      1, 2    DA1      1862 GiB  normal    ok
e2d3s05      1, 2    DA1      1862 GiB  normal    ok
e2d3s06      1, 2    DA1      1862 GiB  normal    ok

> mm1srecoverygroup rgR -L --pdisk | grep e2d3
e2d3s07      1, 2    DA1      1862 GiB  normal    ok
e2d3s08      1, 2    DA1      1862 GiB  normal    ok
e2d3s09      1, 2    DA1      1862 GiB  normal    ok
e2d3s10      1, 2    DA1      1862 GiB  normal    ok
e2d3s11      1, 2    DA1      1862 GiB  normal    ok
e2d3s12      1, 2    DA1      1862 GiB  normal    ok
```

Determine whether online replacement is theoretically possible by consulting Table 4 on page 24.

The system is ESS GL4, so according to the last column drawer replacement is theoretically possible.

Determine the actual disk group fault tolerance of the vdisks in both recovery groups.

```
> mm1srecoverygroup rgL -L
```

recovery group	declustered arrays	vdisks	pdisks	format version
rgL	4	5	119	4.2.0.1

declustered array	needs service	vdisks	pdisks	spares	replace threshold	free space	scrub duration	background activity task	progress	priority
SSD	no	1	1	0,0	1	186 GiB	14 days	scrub	8%	low
NVR	no	1	2	0,0	1	3632 MiB	14 days	scrub	8%	low

DA1	no	3	58	2,31	2	16 GiB	14 days	scrub	5%	low
DA2	no	0	58	2,31	2	152 TiB	14 days	inactive	0%	low

vdisk	RAID code	declustered array	vdisk size	block size	checksum granularity	state	remarks
logtip_rgL	2WayReplication	NVR	48 MiB	2 MiB	4096	ok	logTip
logtipbackup_rgL	Unreplicated	SSD	48 MiB	2 MiB	4096	ok	logTipBackup
loghome_rgL	4WayReplication	DA1	20 GiB	2 MiB	4096	ok	log
md_DA1_rgL	4WayReplication	DA1	101 GiB	512 KiB	32 KiB	ok	
da_DA1_rgL	8+3p	DA1	110 TiB	8 MiB	32 KiB	ok	

config data	declustered array	VCD spares	actual rebuild spare space	remarks
rebuild space	DA1	31	35 pdisk	
rebuild space	DA2	31	36 pdisk	

config data	max disk group fault tolerance	actual disk group fault tolerance	remarks
rg descriptor	1 enclosure + 1 drawer	1 enclosure + 1 drawer	limiting fault tolerance
system index	2 enclosure	1 enclosure + 1 drawer	limited by rg descriptor

vdisk	max disk group fault tolerance	actual disk group fault tolerance	remarks
logtip_rgL	1 pdisk	1 pdisk	
logtipbackup_rgL	0 pdisk	0 pdisk	
loghome_rgL	3 enclosure	1 enclosure + 1 drawer	limited by rg descriptor
md_DA1_rgL	3 enclosure	1 enclosure + 1 drawer	limited by rg descriptor
da_DA1_rgL	1 enclosure	1 enclosure	

active recovery group server	servers
c55f05n01-te0.gpfs.net	c55f05n01-te0.gpfs.net,c55f05n02-te0.gpfs.net

.
.
.

> mmlsrecoverygroup rgR -L

recovery group	declustered arrays	vdisk	pdisk	format version
rgR	4	5	119	4.2.0.1

declustered array	needs service	vdisk	pdisk	spares	replace threshold	free space	scrub duration	background activity task	progress	priority
SSD	no	1	1	0,0	1	186 GiB	14 days	scrub	8%	low
NVR	no	1	2	0,0	1	3632 MiB	14 days	scrub	8%	low
DA1	no	3	58	2,31	2	16 GiB	14 days	scrub	5%	low
DA2	no	0	58	2,31	2	152 TiB	14 days	inactive	0%	low

vdisk	RAID code	declustered array	vdisk size	block size	checksum granularity	state	remarks
logtip_rgR	2WayReplication	NVR	48 MiB	2 MiB	4096	ok	logTip
logtipbackup_rgR	Unreplicated	SSD	48 MiB	2 MiB	4096	ok	logTipBackup
loghome_rgR	4WayReplication	DA1	20 GiB	2 MiB	4096	ok	log
md_DA1_rgR	4WayReplication	DA1	101 GiB	512 KiB	32 KiB	ok	
da_DA1_rgR	8+3p	DA1	110 TiB	8 MiB	32 KiB	ok	

config data	declustered array	VCD spares	actual rebuild spare space	remarks
rebuild space	DA1	31	35 pdisk	
rebuild space	DA2	31	36 pdisk	

config data	max disk group fault tolerance	actual disk group fault tolerance	remarks
rg descriptor	1 enclosure + 1 drawer	1 enclosure + 1 drawer	limiting fault tolerance
system index	2 enclosure	1 enclosure + 1 drawer	limited by rg descriptor

vdisk	max disk group fault tolerance	actual disk group fault tolerance	remarks
-------	--------------------------------	-----------------------------------	---------

logtip_rgR	1 pdisk	1 pdisk	
logtipbackup_rgR	0 pdisk	0 pdisk	
loghome_rgR	3 enclosure	1 enclosure + 1 drawer	limited by rg descriptor
md_DA1_rgR	3 enclosure	1 enclosure + 1 drawer	limited by rg descriptor
da_DA1_rgR	1 enclosure	1 enclosure	
active recovery group server		servers	
c55f05n02-te0.gpfs.net		c55f05n02-te0.gpfs.net,c55f05n01-te0.gpfs.net	

The rg descriptor has an actual fault tolerance of 1 enclosure + 1 drawer (1E+1D). The data vdisks have a RAID code of 8+3P and an actual fault tolerance of 1 enclosure (1E). The metadata vdisks have a RAID code of 4WayReplication and an actual fault tolerance of 1 enclosure + 1 drawer (1E+1D).

Compare the actual disk group fault tolerance with the disk group fault tolerance listed in Table 4 on page 24.

The actual values match the table values exactly. Therefore, drawer replacement can proceed.

Quiesce the pdisks.

Choose one of the following methods to suspend all the pdisks in the drawer.

- Using the **chdrawer** sample script:

```
/usr/lpp/mmfs/samples/vdisk/chdrawer SV21106537 3 --release
```

- Manually using the **mmchpdisk** command:

```
for slotNumber in 01 02 03 04 05 06 ; do mmchpdisk rgL --pdisk e2d3s$slotNumber --suspend ; done
for slotNumber in 07 08 09 10 11 12 ; do mmchpdisk rgR --pdisk e2d3s$slotNumber --suspend ; done
```

Verify the states of the pdisks and find that they are all suspended.

```
> mmlsrecoverygroup rgL -L --pdisk | grep e2d3
e2d3s01      0, 2    DA1      1862 GiB  normal  ok/suspended
e2d3s02      0, 2    DA1      1862 GiB  normal  ok/suspended
e2d3s03      0, 2    DA1      1862 GiB  normal  ok/suspended
e2d3s04      0, 2    DA1      1862 GiB  normal  ok/suspended
e2d3s05      0, 2    DA1      1862 GiB  normal  ok/suspended
e2d3s06      0, 2    DA1      1862 GiB  normal  ok/suspended
> mmlsrecoverygroup rgR -L --pdisk | grep e2d3
e2d3s07      0, 2    DA1      1862 GiB  normal  ok/suspended
e2d3s08      0, 2    DA1      1862 GiB  normal  ok/suspended
e2d3s09      0, 2    DA1      1862 GiB  normal  ok/suspended
e2d3s10      0, 2    DA1      1862 GiB  normal  ok/suspended
e2d3s11      0, 2    DA1      1862 GiB  normal  ok/suspended
e2d3s12      0, 2    DA1      1862 GiB  normal  ok/suspended
```

Remove the drives; make sure to record the location of the drives and label them. You will need to replace them in the corresponding slots of the new drawer later.

Replace the drawer following standard hardware procedures.

Replace the drives in the corresponding slots of the new drawer.

Resume the pdisks.

- Using the **chdrawer** sample script:

```
/usr/lpp/mmfs/samples/vdisk/chdrawer EnclosureSerialNumber DrawerNumber --replace
```

- Manually using the **mmchpdisk** command:


```
for slotNumber in 01 02 03 04 05 06 ; do mmchpdisk rgL --pdisk e2d3s$slotNumber --resume ; done
for slotNumber in 07 08 09 10 11 12 ; do mmchpdisk rgR --pdisk e2d3s$slotNumber --resume ; done
```

Verify that all the pdisks have been resumed.

```
> mmlsrecoverygroup rgL -L --pdisk | grep e2d3
    e2d3s01          2, 2    DA1          1862 GiB  normal    ok
    e2d3s02          2, 2    DA1          1862 GiB  normal    ok
    e2d3s03          2, 2    DA1          1862 GiB  normal    ok
    e2d3s04          2, 2    DA1          1862 GiB  normal    ok
    e2d3s05          2, 2    DA1          1862 GiB  normal    ok
    e2d3s06          2, 2    DA1          1862 GiB  normal    ok

> mmlsrecoverygroup rgR -L --pdisk | grep e2d3
    e2d3s07          2, 2    DA1          1862 GiB  normal    ok
    e2d3s08          2, 2    DA1          1862 GiB  normal    ok
    e2d3s09          2, 2    DA1          1862 GiB  normal    ok
    e2d3s10          2, 2    DA1          1862 GiB  normal    ok
    e2d3s11          2, 2    DA1          1862 GiB  normal    ok
    e2d3s12          2, 2    DA1          1862 GiB  normal    ok
```

Replacing a failed ESS storage enclosure: a sample scenario

Enclosure replacement should be rare. Online replacement of an enclosure is only possible on a GL6 and GS6.

Prerequisite information:

- IBM Spectrum Scale 4.1.1 PTF8 or 4.2.1 PTF1 is a prerequisite for this procedure to work. If you are not at one of these levels or higher, contact IBM.
 - This procedure is intended to be done as a partnership between the storage administrator and a hardware service representative. The storage administrator is expected to understand the IBM Spectrum Scale RAID concepts and the locations of the storage enclosures. The storage administrator is responsible for all the steps except those in which the hardware is actually being worked on.
 - The pdisks in a drawer span two recovery groups; therefore, it is very important that you examine the pdisks and the fault tolerance of the vdisks in both recovery groups when going through these steps.
 - An underlying principle is that enclosure replacement should never deliberately put any vdisk into critical state. When vdisks are in critical state, there is no redundancy and the next single sector or IO error can cause unavailability or data loss. If drawer replacement is not possible without making the system critical, then the ESS has to be shut down before the drawer is removed. An example of drawer replacement will follow these instructions.
1. If IBM Spectrum Scale is shut down: perform the enclosure replacement as soon as possible. Perform steps 4b through 4h and then restart IBM Spectrum Scale.
 2. Examine the states of the pdisks in the affected enclosure. If all the pdisk states are missing, dead, or replace, then go to step 4b to perform drawer replacement as soon as possible without going through any of the other steps in this procedure.

Assuming that you know the enclosure number and are using standard pdisk naming conventions, you could use the following commands to display the pdisks and their states:

```
mmlsrecoverygroup LeftRecoveryGroupName -L --pdisk | grep e{EnclosureNumber}
mmlsrecoverygroup RightRecoveryGroupName -L --pdisk | grep e{EnclosureNumber}
```

3. Determine whether online replacement is possible.
 - a. Consult the following table to see if enclosure replacement is theoretically possible for this configuration. The only required input at this step is the ESS model. The table shows each possible ESS system as well as the configuration parameters for the systems. If the table indicates that online replacement is impossible, IBM Spectrum Scale will need to be shut down (on at least the two I/O servers involved) and you should go back to step 1. The fault tolerance notation uses E for enclosure, D for drawer, and P for pdisk.

Additional background information on interpreting the fault tolerance values:

- For many of the systems, 1E is reported as the fault tolerance; however, this does not mean that failure of x arbitrary drawers or y arbitrary pdisks can be tolerated. It means that the failure of all the entities in one entire enclosure can be tolerated.
- A fault tolerance of 1E+1D or 2D implies that the failure of two arbitrary drawers can be tolerated.

Table 5. ESS fault tolerance for drawer/enclosure

Hardware type (model name...)			DA configuration			Fault tolerance					Is online replacement possible?
IBM ESS	Enclosure type	# Encl.	# Data DA per RG	Disks per DA	# Spares	RG desc	Mirrored vdisk		Parity vdisk		
GS1	2u-24	1	1	12	1	4P	3Way	2P	8+2p	2P	No drawers, enclosure impossible
							4Way	3P	8+3p	3P	No drawers, enclosure impossible
GS2	2U-24	2	1	24	2	4P	3Way	2P	8+2p	2P	No drawers, enclosure impossible
							4Way	3P	8+3p	3P	No drawers, enclosure impossible
GS4	2U-24	4	1	48	2	1E+1P	3Way	1E+1P	8+2p	2P	No drawers, enclosure impossible
							4Way	1E+1P	8+3p	1E	No drawers, enclosure impossible
GS6	2U-24	6	1	72	2	1E+1P	3Way	1E+1P	8+2p	1E	No drawers, enclosure impossible
							4Way	1E+1P	8+3p	1E+1P	No drawers, enclosure possible.
GL2	4U-60 (5d)	2	1	58	2	4D	3Way	2D	8+2p	2D	Drawer possible, enclosure impossible.
							4Way	3D	8+3p	1D+1P	Drawer possible, enclosure impossible
GL4	4U-60 (5d)	4	2	58	2	1E+1D	3Way	1E+1D	8+2p	2D	Drawer possible, enclosure impossible
							4Way	1E+1D	8+3p	1E	Drawer possible, enclosure impossible
GL4	4U-60 (5d)	4	1	116	4	1E+1D	3Way	1E+1D	8+2p	2D	Drawer possible, enclosure impossible
							4Way	1E+1D	8+3p	1E	Drawer possible, enclosure impossible

Table 5. ESS fault tolerance for drawer/enclosure (continued)

Hardware type (model name...)			DA configuration			Fault tolerance					Is online replacement possible?
GL6	4U-60 (5d)	6	3	58	2	1E+1D	3Way	1E+1D	8+2p	1E	Drawer possible, enclosure impossible
							4Way	1E+1D	8+3p	1E+1D	Drawer possible, enclosure possible.
GL6	4U-60 (5d)	6	1	174	6	1E+1D	3Way	1E+1D	8+2p	1E	Drawer possible, enclosure impossible
							4Way	1E+1D	8+3p	1E+1D	Drawer possible, enclosure possible.

- b. Determine the actual disk group fault tolerance of the vdisks in both recovery groups using the **mm1srecoverygroup RecoveryGroupName -L** command. The rg descriptor and all the vdisks must be able to tolerate the loss of the item being replaced plus one other item. This is necessary because the disk group fault tolerance code uses a definition of "tolerance" that includes the system running in critical mode. But since putting the system into critical is not advised, one other item is required. For example, all the following would be a valid fault tolerance to continue with enclosure replacement: 1E+1D and 1E+1P.
 - c. Compare the actual disk group fault tolerance with the disk group fault tolerance listed in Table 5 on page 30. If the system is using a mix of 2-fault-tolerant and 3-fault-tolerant vdisks, the comparisons must be done with the weaker (2-fault-tolerant) values. If the fault tolerance can tolerate at least the item being replaced plus one other item, then replacement can proceed. Go to step 4.
4. Enclosure Replacement procedure.
 - a. Quiesce the pdisks.

For GL systems, issue the following commands for each drawer.

```
for slotNumber in 01 02 03 04 05 06 ; do mmchpdisk LeftRecoveryGroupName --pdisk
    e{EnclosureNumber}d{DrawerNumber}s{$slotNumber} --suspend ; done

for slotNumber in 07 08 09 10 11 12 ; do mmchpdisk RightRecoveryGroupName --pdisk
    e{EnclosureNumber}d{DrawerNumber}s{$slotNumber} --suspend ; done
```

For GS systems, issue:

```
for slotNumber in 01 02 03 04 05 06 07 08 09 10 11 12 ; do mmchpdisk LeftRecoveryGroupName --pdisk
    e{EnclosureNumber}s{$slotNumber} --suspend ; done

for slotNumber in 13 14 15 16 17 18 19 20 21 22 23 24 ; do mmchpdisk RightRecoveryGroupName --pdisk
    e{EnclosureNumber}s{$slotNumber} --suspend ; done
```

Verify that the pdisks were suspended using the **mm1srecoverygroup** command as shown in step 2.
 - b. Remove the drives; make sure to record the location of the drives and label them. You will need to replace them in the corresponding slots of the new enclosure later.
 - c. Replace the enclosure following standard hardware procedures.
 - Remove the SAS connections in the rear of the enclosure.
 - Remove the enclosure.
 - Install the new enclosure.
 - d. Replace the drives in the corresponding slots of the new enclosure.
 - e. Connect the SAS connections in the rear of the new enclosure.
 - f. Power up the enclosure.

- g. Verify the SAS topology on the servers to ensure that all drives from the new storage enclosure are present.
- h. Update the necessary firmware on the new storage enclosure as needed.
- i. Resume the pdisks.

For GL systems, issue:

```
for slotNumber in 01 02 03 04 05 06 ; do mmchpdisk LeftRecoveryGroupName --pdisk
    e{EnclosureNumber}d{DrawerNumber}s{$slotNumber} --resume ; done

for slotNumber in 07 08 09 10 11 12 ; do mmchpdisk RightRecoveryGroupName --pdisk
    e{EnclosureNumber}d{DrawerNumber}s{$slotNumber} --resume ; done
```

For GS systems, issue:

```
for slotNumber in 01 02 03 04 05 06 07 08 09 10 11 12 ; do mmchpdisk LeftRecoveryGroupName --pdisk
    e{EnclosureNumber}s{$slotNumber} --resume ; done

for slotNumber in 13 14 15 16 17 18 19 20 21 22 23 24 ; do mmchpdisk RightRecoveryGroupName --pdisk
    e{EnclosureNumber}s{$slotNumber} --resume ; done
```

Verify that the pdisks were resumed using the **mm1srecoverygroup** command as shown in step 2.

Example

The system is a GL6 with vdisks that have 4way mirroring and 8+3p RAID codes. Assume that the enclosure that contains pdisk e2d3s01 needs to be replaced. This means that you are trying to replace enclosure 2.

Assume that the enclosure spans recovery groups rgL and rgR.

Determine the enclosure serial number:

```
> mm1spdisk rgL --pdisk e2d3s01 | grep -w location
location = "SV21106537-3-1"
```

Examine the states of the pdisks and find that they are all ok instead of missing. (Given that you have a failed enclosure, all the drives would not likely be in an ok state, but this is just an example.)

```
> mm1srecoverygroup rgL -L --pdisk | grep e2
```

e2d1s01	2, 4	DA1	96 GiB	normal	ok
e2d1s02	2, 4	DA1	96 GiB	normal	ok
e2d1s04	2, 4	DA1	96 GiB	normal	ok
e2d1s05	2, 4	DA2	2792 GiB	normal	ok/noData
e2d1s06	2, 4	DA2	2792 GiB	normal	ok/noData
e2d2s01	2, 4	DA1	96 GiB	normal	ok
e2d2s02	2, 4	DA1	98 GiB	normal	ok
e2d2s03	2, 4	DA1	96 GiB	normal	ok
e2d2s04	2, 4	DA2	2792 GiB	normal	ok/noData
e2d2s05	2, 4	DA2	2792 GiB	normal	ok/noData
e2d2s06	2, 4	DA2	2792 GiB	normal	ok/noData
e2d3s01	2, 4	DA1	96 GiB	normal	ok
e2d3s02	2, 4	DA1	94 GiB	normal	ok
e2d3s03	2, 4	DA1	96 GiB	normal	ok
e2d3s04	2, 4	DA2	2792 GiB	normal	ok/noData
e2d3s05	2, 4	DA2	2792 GiB	normal	ok/noData
e2d3s06	2, 4	DA2	2792 GiB	normal	ok/noData
e2d4s01	2, 4	DA1	96 GiB	normal	ok
e2d4s02	2, 4	DA1	96 GiB	normal	ok
e2d4s03	2, 4	DA1	96 GiB	normal	ok
e2d4s04	2, 4	DA2	2792 GiB	normal	ok/noData
e2d4s05	2, 4	DA2	2792 GiB	normal	ok/noData
e2d4s06	2, 4	DA2	2792 GiB	normal	ok/noData
e2d5s01	2, 4	DA1	96 GiB	normal	ok

```

e2d5s02          2, 4      DA1          96 GiB normal    ok
e2d5s03          2, 4      DA1          96 GiB normal    ok
e2d5s04          2, 4      DA2        2792 GiB normal    ok/noData
e2d5s05          2, 4      DA2        2792 GiB normal    ok/noData
e2d5s06          2, 4      DA2        2792 GiB normal    ok/noData
> mmlsrecoverygroup rgR -L --pdisk | grep e2
e2d1s07          2, 4      DA1          96 GiB normal    ok
e2d1s08          2, 4      DA1          94 GiB normal    ok
e2d1s09          2, 4      DA1          96 GiB normal    ok
e2d1s10          2, 4      DA2        2792 GiB normal    ok/noData
e2d1s11          2, 4      DA2        2792 GiB normal    ok/noData
e2d1s12          2, 4      DA2        2792 GiB normal    ok/noData
e2d2s07          2, 4      DA1          96 GiB normal    ok
e2d2s08          2, 4      DA1          96 GiB normal    ok
e2d2s09          2, 4      DA1          94 GiB normal    ok
e2d2s10          2, 4      DA2        2792 GiB normal    ok/noData
e2d2s11          2, 4      DA2        2792 GiB normal    ok/noData
e2d2s12          2, 4      DA2        2792 GiB normal    ok/noData
e2d3s07          2, 4      DA1          94 GiB normal    ok
e2d3s08          2, 4      DA1          96 GiB normal    ok
e2d3s09          2, 4      DA1          96 GiB normal    ok
e2d3s10          2, 4      DA2        2792 GiB normal    ok/noData
e2d3s11          2, 4      DA2        2792 GiB normal    ok/noData
e2d3s12          2, 4      DA2        2792 GiB normal    ok/noData
e2d4s07          2, 4      DA1          96 GiB normal    ok
e2d4s08          2, 4      DA1          94 GiB normal    ok
e2d4s09          2, 4      DA1          96 GiB normal    ok
e2d4s10          2, 4      DA2        2792 GiB normal    ok/noData
e2d4s11          2, 4      DA2        2792 GiB normal    ok/noData
e2d4s12          2, 4      DA2        2792 GiB normal    ok/noData
e2d5s07          2, 4      DA2        2792 GiB normal    ok/noData
e2d5s08          2, 4      DA1        108 GiB normal    ok
e2d5s09          2, 4      DA1        108 GiB normal    ok
e2d5s10          2, 4      DA2        2792 GiB normal    ok/noData
e2d5s11          2, 4      DA2        2792 GiB normal    ok/noData

```

Determine whether online replacement is theoretically possible by consulting Table 5 on page 30.

The system is ESS GL6, so according to the last column enclosure replacement is theoretically possible.

Determine the actual disk group fault tolerance of the vdisks in both recovery groups.

```
> mmlsrecoverygroup rgL -L
```

recovery group	declustered arrays		vdisks	pdisks	format version	
rgL	4		5	177	4.2.0.1	

declustered array	needs service	vdisks	pdisks	spares	replace threshold	free space	scrub duration	background activity		
								task	progress	priority
SSD	no	1	1	0,0	1	186 GiB	14 days	scrub	8%	low
NVR	no	1	2	0,0	1	3632 MiB	14 days	scrub	8%	low
DA1	no	3	174	2,31	2	16 GiB	14 days	scrub	5%	low

vdisk	RAID code	declustered array	vdisk size	block size	checksum granularity	state	remarks
logtip_rgL	2WayReplication	NVR	48 MiB	2 MiB	4096	ok	logTip
logtipbackup_rgL	Unreplicated	SSD	48 MiB	2 MiB	4096	ok	logTipBackup
loghome_rgL	4WayReplication	DA1	20 GiB	2 MiB	4096	ok	log
md_DA1_rgL	4WayReplication	DA1	101 GiB	512 KiB	32 KiB	ok	
da_DA1_rgL	8+3p	DA1	110 TiB	8 MiB	32 KiB	ok	

```

config data      declustered array  VCD spares  actual rebuild spare space  remarks
-----
rebuild space    DA1                  31          35 pdisk

config data      max disk group fault tolerance  actual disk group fault tolerance  remarks
-----
rg descriptor     1 enclosure + 1 drawer              1 enclosure + 1 drawer              limiting fault tolerance
system index      2 enclosure                          1 enclosure + 1 drawer              limited by rg descriptor

vdisk            max disk group fault tolerance  actual disk group fault tolerance  remarks
-----
logtip_rgL        1 pdisk                            1 pdisk
logtipbackup_rgL  0 pdisk                            0 pdisk
loghome_rgL       3 enclosure                        1 enclosure + 1 drawer              limited by rg descriptor
md_DA1_rgL        3 enclosure                        1 enclosure + 1 drawer              limited by rg descriptor
da_DA1_rgL        1 enclosure + 1 drawer              1 enclosure + 1 drawer

active recovery group server  servers
-----
c55f05n01-te0.gpfs.net      c55f05n01-te0.gpfs.net,c55f05n02-te0.gpfs.net

.
.
.
> mmlsrecoverygroup rgR -L

recovery group      declustered
                    arrays      vdisks  pdisks  format version
-----
rgR                  4          5      177      4.2.0.1

declustered  needs  vdisks  pdisks  spares  replace  free space  scrub  background activity
array        service  -----  -----  -----  threshold  -----  duration  task  progress  priority
-----
SSD          no          1        1        0,0      1          186 GiB    14 days  scrub      8%    low
NVR          no          1        2        0,0      1          3632 MiB   14 days  scrub      8%    low
DA1          no          3       174      2,31     2          16 GiB    14 days  scrub      5%    low

vdisk            RAID code      declustered  vdisk size  block size  checksum  state  remarks
array            array
-----
logtip_rgR       2WayReplication  NVR          48 MiB      2 MiB       4096    ok     logTip
logtipbackup_rgR Unreplicated     SSD          48 MiB      2 MiB       4096    ok     logTipBackup
loghome_rgR      4WayReplication  DA1          20 GiB      2 MiB       4096    ok     log
md_DA1_rgR       4WayReplication  DA1          101 GiB     512 KiB     32 KiB   ok
da_DA1_rgR       8+3p            DA1          110 TiB     8 MiB       32 KiB   ok

config data      declustered array  VCD spares  actual rebuild spare space  remarks
-----
rebuild space    DA1                  31          35 pdisk

config data      max disk group fault tolerance  actual disk group fault tolerance  remarks
-----
rg descriptor     1 enclosure + 1 drawer              1 enclosure + 1 drawer              limiting fault tolerance
system index      2 enclosure                          1 enclosure + 1 drawer              limited by rg descriptor

vdisk            max disk group fault tolerance  actual disk group fault tolerance  remarks
-----
logtip_rgR        1 pdisk                            1 pdisk
logtipbackup_rgR  0 pdisk                            0 pdisk
loghome_rgR       3 enclosure                        1 enclosure + 1 drawer              limited by rg descriptor
md_DA1_rgR        3 enclosure                        1 enclosure + 1 drawer              limited by rg descriptor
da_DA1_rgR        1 enclosure + 1 drawer              1 enclosure + 1 drawer

active recovery group server  servers
-----
c55f05n02-te0.gpfs.net      c55f05n02-te0.gpfs.net,c55f05n01-te0.gpfs.net

```

The rg descriptor has an actual fault tolerance of 1 enclosure + 1 drawer (1E+1D). The data vdisks have a RAID code of 8+3P and an actual fault tolerance of 1 enclosure (1E). The metadata vdisks have a RAID code of 4WayReplication and an actual fault tolerance of 1 enclosure + 1 drawer (1E+1D).

Compare the actual disk group fault tolerance with the disk group fault tolerance listed in Table 5 on page 30.

The actual values match the table values exactly. Therefore, enclosure replacement can proceed.

Quiesce the pdisks.

```
for slotNumber in 01 02 03 04 05 06 ; do mmchpdisk rgL --pdisk e2d1s$slotNumber --suspend ; done
for slotNumber in 07 08 09 10 11 12 ; do mmchpdisk rgR --pdisk e2d1s$slotNumber --suspend ; done

for slotNumber in 01 02 03 04 05 06 ; do mmchpdisk rgL --pdisk e2d2s$slotNumber --suspend ; done
for slotNumber in 07 08 09 10 11 12 ; do mmchpdisk rgR --pdisk e2d2s$slotNumber --suspend ; done

for slotNumber in 01 02 03 04 05 06 ; do mmchpdisk rgL --pdisk e2d3s$slotNumber --suspend ; done
for slotNumber in 07 08 09 10 11 12 ; do mmchpdisk rgR --pdisk e2d3s$slotNumber --suspend ; done

for slotNumber in 01 02 03 04 05 06 ; do mmchpdisk rgL --pdisk e2d4s$slotNumber --suspend ; done
for slotNumber in 07 08 09 10 11 12 ; do mmchpdisk rgR --pdisk e2d4s$slotNumber --suspend ; done

for slotNumber in 01 02 03 04 05 06 ; do mmchpdisk rgL --pdisk e2d5s$slotNumber --suspend ; done
for slotNumber in 07 08 09 10 11 12 ; do mmchpdisk rgR --pdisk e2d5s$slotNumber --suspend ; done
```

Verify the pdisks were suspended using the `mm1srecoverygroup` command. You should see `suspended` as part of the `pdisk` state.

```
> mm1srecoverygroup rgL -L --pdisk | grep e2d
e2d1s01      0, 4      DA1      96 GiB normal ok/suspended
e2d1s02      0, 4      DA1      96 GiB normal ok/suspended
e2d1s04      0, 4      DA1      96 GiB normal ok/suspended
e2d1s05      0, 4      DA2     2792 GiB normal ok/suspended
e2d1s06      0, 4      DA2     2792 GiB normal ok/suspended
e2d2s01      0, 4      DA1      96 GiB normal ok/suspended
.
.
.

> mm1srecoverygroup rgR -L --pdisk | grep e2d
e2d1s07      0, 4      DA1      96 GiB normal ok/suspended
e2d1s08      0, 4      DA1      94 GiB normal ok/suspended
e2d1s09      0, 4      DA1      96 GiB normal ok/suspended
e2d1s10      0, 4      DA2     2792 GiB normal ok/suspended
e2d1s11      0, 4      DA2     2792 GiB normal ok/suspended
e2d1s12      0, 4      DA2     2792 GiB normal ok/suspended
e2d2s07      0, 4      DA1      96 GiB normal ok/suspended
e2d2s08      0, 4      DA1      96 GiB normal ok/suspended
.
.
.
```

Remove the drives; make sure to record the location of the drives and label them. You will need to replace them in the corresponding drawer slots of the new enclosure later.

Replace the enclosure following standard hardware procedures.

- Remove the SAS connections in the rear of the enclosure.
- Remove the enclosure.
- Install the new enclosure.

Replace the drives in the corresponding drawer slots of the new enclosure.

Connect the SAS connections in the rear of the new enclosure.

Power up the enclosure.

Verify the SAS topology on the servers to ensure that all drives from the new storage enclosure are present.

Update the necessary firmware on the new storage enclosure as needed.

Resume the pdisks.

```
for slotNumber in 01 02 03 04 05 06 ; do mmchpdisk rgL --pdisk e2d1s$slotNumber --resume ; done
for slotNumber in 07 08 09 10 11 12 ; do mmchpdisk rgR --pdisk e2d1s$slotNumber --resume ; done
for slotNumber in 01 02 03 04 05 06 ; do mmchpdisk rgL --pdisk e2d2s$slotNumber --resume ; done
for slotNumber in 07 08 09 10 11 12 ; do mmchpdisk rgR --pdisk e2d2s$slotNumber --resume ; done
for slotNumber in 01 02 03 04 05 06 ; do mmchpdisk rgL --pdisk e2d3s$slotNumber --resume ; done
for slotNumber in 07 08 09 10 11 12 ; do mmchpdisk rgR --pdisk e2d3s$slotNumber --resume ; done
for slotNumber in 01 02 03 04 05 06 ; do mmchpdisk rgL --pdisk e2d4s$slotNumber --resume ; done
for slotNumber in 07 08 09 10 11 12 ; do mmchpdisk rgR --pdisk e2d4s$slotNumber --resume ; done
for slotNumber in 01 02 03 04 05 06 ; do mmchpdisk rgL --pdisk e2d5s$slotNumber --resume ; done
for slotNumber in 07 08 09 10 11 12 ; do mmchpdisk rgR --pdisk e2d5s$slotNumber --resume ; done
```

Verify that the pdisks were resumed by using the `mm1srecoverygroup` command.

```
> mm1srecoverygroup rgL -L --pdisk | grep e2
```

e2d1s01	2, 4	DA1	96 GiB	normal	ok
e2d1s02	2, 4	DA1	96 GiB	normal	ok
e2d1s04	2, 4	DA1	96 GiB	normal	ok
e2d1s05	2, 4	DA2	2792 GiB	normal	ok/noData
e2d1s06	2, 4	DA2	2792 GiB	normal	ok/noData
e2d2s01	2, 4	DA1	96 GiB	normal	ok
.					
.					
.					

```
> mm1srecoverygroup rgR -L --pdisk | grep e2
```

e2d1s07	2, 4	DA1	96 GiB	normal	ok
e2d1s08	2, 4	DA1	94 GiB	normal	ok
e2d1s09	2, 4	DA1	96 GiB	normal	ok
e2d1s10	2, 4	DA2	2792 GiB	normal	ok/noData
e2d1s11	2, 4	DA2	2792 GiB	normal	ok/noData
e2d1s12	2, 4	DA2	2792 GiB	normal	ok/noData
e2d2s07	2, 4	DA1	96 GiB	normal	ok
e2d2s08	2, 4	DA1	96 GiB	normal	ok
.					
.					
.					

Replacing failed disks in a Power 775 Disk Enclosure recovery group: a sample scenario

The scenario presented here shows how to detect and replace failed disks in a recovery group built on a Power 775 Disk Enclosure.

Detecting failed disks in your enclosure

Assume a fully-populated Power 775 Disk Enclosure (serial number 000DE37) on which the following two recovery groups are defined:

- 000DE37TOP containing the disks in the top set of carriers
- 000DE37BOT containing the disks in the bottom set of carriers

Each recovery group contains the following:

- one log declustered array (LOG)
- four data declustered arrays (DA1, DA2, DA3, DA4)

The data declustered arrays are defined according to Power 775 Disk Enclosure best practice as follows:

- 47 pdisks per data declustered array
- each member pdisk from the same carrier slot
- default disk replacement threshold value set to 2

The replacement threshold of 2 means that GNR will only require disk replacement when two or more disks have failed in the declustered array; otherwise, rebuilding onto spare space or reconstruction from redundancy will be used to supply affected data.

This configuration can be seen in the output of **mm1srecoverygroup** for the recovery groups, shown here for 000DE37TOP:

```
# mm1srecoverygroup 000DE37TOP -L
```

recovery group	declustered arrays	vdisk	pdisk
000DE37TOP	5	9	192

declustered array	needs service	vdisk	pdisk	spare	replace threshold	free space	scrub duration	background activity task progress priority
DA1	no	2	47	2	2	3072 MiB	14 days	scrub 63% low
DA2	no	2	47	2	2	3072 MiB	14 days	scrub 19% low
DA3	yes	2	47	2	2	0 B	14 days	rebuild-2r 48% low
DA4	no	2	47	2	2	3072 MiB	14 days	scrub 33% low
LOG	no	1	4	1	1	546 GiB	14 days	scrub 87% low

vdisk	RAID code	declustered array	vdisk size	remarks
000DE37TOPLOG	3WayReplication	LOG	4144 MiB	log
000DE37TOPDA1META	4WayReplication	DA1	250 GiB	
000DE37TOPDA1DATA	8+3p	DA1	17 TiB	
000DE37TOPDA2META	4WayReplication	DA2	250 GiB	
000DE37TOPDA2DATA	8+3p	DA2	17 TiB	
000DE37TOPDA3META	4WayReplication	DA3	250 GiB	
000DE37TOPDA3DATA	8+3p	DA3	17 TiB	
000DE37TOPDA4META	4WayReplication	DA4	250 GiB	
000DE37TOPDA4DATA	8+3p	DA4	17 TiB	

active recovery group server	servers
server1	server1,server2

The indication that disk replacement is called for in this recovery group is the value of yes in the needs service column for declustered array DA3.

The fact that DA3 (the declustered array on the disks in carrier slot 3) is undergoing rebuild of its RAID tracks that can tolerate two strip failures is by itself not an indication that disk replacement is required; it merely indicates that data from a failed disk is being rebuilt onto spare space. Only if the replacement threshold has been met will disks be marked for replacement and the declustered array marked as needing service.

GNR provides several indications that disk replacement is required:

- entries in the AIX error report or the Linux syslog

- the **pdReplacePdisk** callback, which can be configured to run an administrator-supplied script at the moment a pdisk is marked for replacement
- the POWER7[®] cluster event notification TEAL agent, which can be configured to send disk replacement notices when they occur to the POWER7 cluster EMS
- the output from the following commands, which may be performed from the command line on any GPFS cluster node (see the examples that follow):
 1. **mmlsrecoverygroup** with the **-L** flag shows yes in the needs service column
 2. **mmlsrecoverygroup** with the **-L** and **--pdisk** flags; this shows the states of all pdisks, which may be examined for the replace pdisk state
 3. **mmlspdisk** with the **--replace** flag, which lists only those pdisks that are marked for replacement

Note: Because the output of **mmlsrecoverygroup -L --pdisk** for a fully-populated disk enclosure is very long, this example shows only some of the pdisks (but includes those marked for replacement).

```
# mmlsrecoverygroup 000DE37TOP -L --pdisk
```

recovery group	declustered arrays	vdisks	pdisks								
000DE37TOP	5	9	192								
declustered array	needs service	vdisks	pdisks	spares	replace threshold	free space	scrub duration	background activity			
								task	progress	priority	
DA1	no	2	47	2	2	3072 MiB	14 days	scrub	63%	low	
DA2	no	2	47	2	2	3072 MiB	14 days	scrub	19%	low	
DA3	yes	2	47	2	2	0 B	14 days	rebuild-2r	68%	low	
DA4	no	2	47	2	2	3072 MiB	14 days	scrub	34%	low	
LOG	no	1	4	1	1	546 GiB	14 days	scrub	87%	low	

pdisk	n. active, total paths	declustered array	free space	user condition	state, remarks
[...]					
c014d1	2, 4	DA1	62 GiB	normal	ok
c014d2	2, 4	DA2	279 GiB	normal	ok
c014d3	0, 0	DA3	279 GiB	replaceable	dead/systemDrain/noRGD/noVCD/replace
c014d4	2, 4	DA4	12 GiB	normal	ok
[...]					
c018d1	2, 4	DA1	24 GiB	normal	ok
c018d2	2, 4	DA2	24 GiB	normal	ok
c018d3	2, 4	DA3	558 GiB	replaceable	dead/systemDrain/noRGD/noVCD/noData/replace
c018d4	2, 4	DA4	12 GiB	normal	ok
[...]					

The preceding output shows that the following pdisks are marked for replacement:

- c014d3 in DA3
- c018d3 in DA3

The naming convention used during recovery group creation indicates that these are the disks in slot 3 of carriers 14 and 18. To confirm the physical locations of the failed disks, use the **mmlspdisk** command to list information about those pdisks in declustered array DA3 of recovery group 000DE37TOP that are marked for replacement:

```
# mmlspdisk 000DE37TOP --declustered-array DA3 --replace
pdisk:
  replacementPriority = 1.00
  name = "c014d3"
  device = "/dev/rhdisk158,/dev/rhdisk62"
  recoveryGroup = "000DE37TOP"
  declusteredArray = "DA3"
  state = "dead/systemDrain/noRGD/noVCD/replace"
  .
  .
  .
pdisk:
```

```

replacementPriority = 1.00
name = "c018d3"
device = "/dev/rhdisk630,/dev/rhdisk726"
recoveryGroup = "000DE37TOP"
declusteredArray = "DA3"
state = "dead/systemDrain/noRGD/noVCD/noData/replace"
.
.
.

```

The preceding location code attributes confirm the pdisk naming convention:

Disk	Location code	Interpretation
pdisk c014d3	78AD.001.000DE37-C14-D3	Disk 3 in carrier 14 in the disk enclosure identified by enclosure type 78AD.001 and serial number 000DE37
pdisk c018d3	78AD.001.000DE37-C18-D3	Disk 3 in carrier 18 in the disk enclosure identified by enclosure type 78AD.001 and serial number 000DE37

Replacing the failed disks in a Power 775 Disk Enclosure recovery group

Note: In this example, it is assumed that two new disks with the appropriate Field Replaceable Unit (FRU) code, as indicated by the fru attribute (74Y4936 in this case), have been obtained as replacements for the failed pdisks c014d3 and c018d3.

Replacing each disk is a three-step process:

1. Using the **mmchcarrier** command with the **--release** flag to suspend use of the other disks in the carrier and to release the carrier.
2. Removing the carrier and replacing the failed disk within with a new one.
3. Using the **mmchcarrier** command with the **--replace** flag to resume use of the suspended disks and to begin use of the new disk.

GNR assigns a priority to pdisk replacement. Disks with smaller values for the **replacementPriority** attribute should be replaced first. In this example, the only failed disks are in DA3 and both have the same **replacementPriority**.

Disk c014d3 is chosen to be replaced first.

1. To release carrier 14 in disk enclosure 000DE37:

```

# mmchcarrier 000DE37TOP --release --pdisk c014d3
[I] Suspending pdisk c014d1 of RG 000DE37TOP in location 78AD.001.000DE37-C14-D1.
[I] Suspending pdisk c014d2 of RG 000DE37TOP in location 78AD.001.000DE37-C14-D2.
[I] Suspending pdisk c014d3 of RG 000DE37TOP in location 78AD.001.000DE37-C14-D3.
[I] Suspending pdisk c014d4 of RG 000DE37TOP in location 78AD.001.000DE37-C14-D4.
[I] Carrier released.

```

- Remove carrier.
- Replace disk in location 78AD.001.000DE37-C14-D3 with FRU 74Y4936.
- Reinsert carrier.
- Issue the following command:

```
mmchcarrier 000DE37TOP --replace --pdisk 'c014d3'
```

Repair timer is running. Perform the above within 5 minutes to avoid pdisks being reported as missing.

GNR issues instructions as to the physical actions that must be taken. Note that disks may be suspended only so long before they are declared missing; therefore the mechanical process of physically performing disk replacement must be accomplished promptly.

Use of the other three disks in carrier 14 has been suspended, and carrier 14 is unlocked. The identify lights for carrier 14 and for disk 3 are on.

- Carrier 14 should be unlatched and removed. The failed disk 3, as indicated by the internal identify light, should be removed, and the new disk with FRU 74Y4936 should be inserted in its place. Carrier 14 should then be reinserted and the latch closed.
- To finish the replacement of pdisk c014d3:

```
# mmchcarrier 000DE37TOP --replace --pdisk c014d3
[I] The following pdisks will be formatted on node server1:
    /dev/rhdisk354
[I] Pdisk c014d3 of RG 000DE37TOP successfully replaced.
[I] Resuming pdisk c014d1 of RG 000DE37TOP.
[I] Resuming pdisk c014d2 of RG 000DE37TOP.
[I] Resuming pdisk c014d3#162 of RG 000DE37TOP.
[I] Resuming pdisk c014d4 of RG 000DE37TOP.
[I] Carrier resumed.
```

When the **mmchcarrier --replace** command returns successfully, GNR has resumed use of the other 3 disks. The failed pdisk may remain in a temporary form (indicated here by the name c014d3#162) until all data from it has been rebuilt, at which point it is finally deleted. The new replacement disk, which has assumed the name c014d3, will have RAID tracks rebuilt and rebalanced onto it. Notice that only one block device name is mentioned as being formatted as a pdisk; the second path will be discovered in the background.

This can be confirmed with **mmlsrecoverygroup -L --pdisk**:

```
# mmlsrecoverygroup 000DE37TOP -L --pdisk
```

recovery group	declustered arrays	vdisks	pdisks								
000DE37TOP	5	9	193								

declustered array	needs service	vdisks	pdisks	spares	replace threshold	free space	scrub duration	background activity		
								task	progress	priority
DA1	no	2	47	2	2	3072 MiB	14 days	scrub	63%	low
DA2	no	2	47	2	2	3072 MiB	14 days	scrub	19%	low
DA3	yes	2	48	2	2	0 B	14 days	rebuild-2r	89%	low
DA4	no	2	47	2	2	3072 MiB	14 days	scrub	34%	low
LOG	no	1	4	1	1	546 GiB	14 days	scrub	87%	low

pdisk	n. active, total paths	declustered array	free space	user condition	state, remarks
[...]					
c014d1	2, 4	DA1	23 GiB	normal	ok
c014d2	2, 4	DA2	23 GiB	normal	ok
c014d3	2, 4	DA3	550 GiB	normal	ok
c014d3#162	0, 0	DA3	543 GiB	replaceable	dead/adminDrain/noRGD/noVCD/noPath
c014d4	2, 4	DA4	23 GiB	normal	ok
[...]					
c018d1	2, 4	DA1	24 GiB	normal	ok
c018d2	2, 4	DA2	24 GiB	normal	ok
c018d3	0, 0	DA3	558 GiB	replaceable	dead/systemDrain/noRGD/noVCD/noData/replace
c018d4	2, 4	DA4	23 GiB	normal	ok
[...]					

Notice that the temporary pdisk c014d3#162 is counted in the total number of pdisks in declustered array DA3 and in the recovery group, until it is finally drained and deleted.

Notice also that pdisk c018d3 is still marked for replacement, and that DA3 still needs service. This is because GNR replacement policy expects all failed disks in the declustered array to be replaced once the replacement threshold is reached. The replace state on a pdisk is not removed when the total number of failed disks goes under the threshold.

Pdisk c018d3 is replaced following the same process.

1. Release carrier 18 in disk enclosure 000DE37:

```
# mmchcarrier 000DE37TOP --release --pdisk c018d3
[I] Suspending pdisk c018d1 of RG 000DE37TOP in location 78AD.001.000DE37-C18-D1.
[I] Suspending pdisk c018d2 of RG 000DE37TOP in location 78AD.001.000DE37-C18-D2.
[I] Suspending pdisk c018d3 of RG 000DE37TOP in location 78AD.001.000DE37-C18-D3.
[I] Suspending pdisk c018d4 of RG 000DE37TOP in location 78AD.001.000DE37-C18-D4.
[I] Carrier released.
```

- Remove carrier.
- Replace disk in location 78AD.001.000DE37-C18-D3 with FRU 74Y4936.
- Reinsert carrier.
- Issue the following command:

```
mmchcarrier 000DE37TOP --replace --pdisk 'c018d3'
```

Repair timer is running. Perform the above within 5 minutes to avoid pdisks being reported as missing.

2. Unlatch and remove carrier 18, remove and replace failed disk 3, reinsert carrier 18, and close the latch.

3. To finish the replacement of pdisk c018d3:

```
# mmchcarrier 000DE37TOP --replace --pdisk c018d3

[I] The following pdisks will be formatted on node server1:
/dev/rhdisk674
[I] Pdisk c018d3 of RG 000DE37TOP successfully replaced.
[I] Resuming pdisk c018d1 of RG 000DE37TOP.
[I] Resuming pdisk c018d2 of RG 000DE37TOP.
[I] Resuming pdisk c018d3#166 of RG 000DE37TOP.
[I] Resuming pdisk c018d4 of RG 000DE37TOP.
[I] Carrier resumed.
```

Running **mmlsrecoverygroup** again will confirm the second replacement:

```
# mmlsrecoverygroup 000DE37TOP -L --pdisk
```

recovery group	declustered arrays	vdisks	pdisks								
000DE37TOP	5	9	192								
declustered array	needs service	vdisks	pdisks	spares	replace threshold	free space	scrub duration	background activity			
								task	progress	priority	
DA1	no	2	47	2	2	3072 MiB	14 days	scrub	64%	low	
DA2	no	2	47	2	2	3072 MiB	14 days	scrub	22%	low	
DA3	no	2	47	2	2	2048 MiB	14 days	rebalance	12%	low	
DA4	no	2	47	2	2	3072 MiB	14 days	scrub	36%	low	
LOG	no	1	4	1	1	546 GiB	14 days	scrub	89%	low	
pdisk	n. active, total paths	declustered array	free space	user condition	state, remarks						
[...]											
c014d1	2, 4	DA1	23 GiB	normal	ok						
c014d2	2, 4	DA2	23 GiB	normal	ok						
c014d3	2, 4	DA3	271 GiB	normal	ok						
c014d4	2, 4	DA4	23 GiB	normal	ok						
[...]											
c018d1	2, 4	DA1	24 GiB	normal	ok						
c018d2	2, 4	DA2	24 GiB	normal	ok						
c018d3	2, 4	DA3	542 GiB	normal	ok						
c018d4	2, 4	DA4	23 GiB	normal	ok						
[...]											

Notice that both temporary pdisks have been deleted. This is because c014d3#162 has finished draining, and because pdisk c018d3#166 had, before it was replaced, already been completely drained (as evidenced by the noData flag). Declustered array DA3 no longer needs service and once again contains 47 pdisks, and the recovery group once again contains 192 pdisks.

Directed maintenance procedures

The directed maintenance procedures (DMPs) assist you to repair a problem when you select the action **Run fix procedure** on a selected event from the **Monitoring > Events** page. DMPs are present for only a few events reported in the system.

The following table provides details of the available DMPs and the corresponding events.

Table 6. DMPs

DMP	Event ID
Replace disks	gnr_pdisk_replaceable
Update enclosure firmware	enclosure_firmware_wrong
Update drive firmware	drive_firmware_wrong
Update host-adapter firmware	adapter_firmware_wrong
Start NSD	disk_down
Start GPFS daemon	gpfs_down
Increase fileset space	inode_error_high and inode_warn_high
Synchronize Node Clocks	time_not_in_sync
Start performance monitoring collector service	pmcollector_down
Start performance monitoring sensor service	pmsensors_down

Replace disks

The replace disks DMP assists you to replace the disks.

The following are the corresponding event details and proposed solution:

- **Event name:** gnr_pdisk_replaceable
- **Problem:** The state of a physical disk is changed to “replaceable”.
- **Solution:** Replace the disk.

The ESS GUI detects if a disk is broken and whether it needs to be replaced. In this case, launch this DMP to get support to replace the broken disks. You can use this DMP either to replace one disk or multiple disks.

The DMP automatically launches in corresponding mode depending on situation. You can launch this DMP from the pages in the GUI and follow the wizard to release one or more disks:

- **Monitoring > Hardware** page: Select **Replace Broken Disks** from the **Actions** menu.
- **Monitoring > Hardware** page: Select the broken disk to be replaced in an enclosure and then select **Replace** from the **Actions** menu.
- **Monitoring > Events** page: Select the *gnr_pdisk_replaceable* event from the event listing and then select **Run Fix Procedure** from the **Actions** menu.
- **Storage > Physical** page: Select **Replace Broken Disks** from the **Actions** menu.
- **Storage > Physical** page: Select the disk to be replaced and then select **Replace Disk** from the **Actions** menu.

The system issues the **mmchcarrier** command to replace disks as given in the following format:

```
/usr/lpp/mmfs/bin/mmchcarrier <<Disk_RecoveryGroup>>  
--replace|--release|--resume --pdisk <<Disk_Name>> [--force-release]
```

For example: `/usr/lpp/mmfs/bin/mmchcarrier G1 --replace --pdisk G1FSP11`

Update enclosure firmware

The update enclosure firmware DMP assists to update the enclosure firmware to the latest level.

The following are the corresponding event details and the proposed solution:

- **Event name:** enclosure_firmware_wrong
- **Problem:** The reported firmware level of the environmental service module is not compliant with the recommendation.
- **Solution:** Update the firmware.

If more than one enclosure is not running the newest version of the firmware, the system prompts to update the firmware. The system issues the **mmchfirmware** command to update firmware as given in the following format:

```
mmchfirmware --esms <<ESM_Name>> --cluster  
    <<Cluster_Id>>- for all the enclosures :    mmchfirmware --esms --cluster  
    <<Cluster_Id>>
```

For example, for a single enclosure:

```
mmchfirmware --esms 181880E-SV20706999_ESM_B -cluster 1857390657572243170
```

For all enclosures:

```
mmchfirmware --esms -cluster 1857390657572243170
```

Update drive firmware

The update drive firmware DMP assists to update the drive firmware to the latest level so that the physical disk becomes compliant.

The following are the corresponding event details and the proposed solution:

- **Event name:** drive_firmware_wrong
- **Problem:** The reported firmware level of the physical disk is not compliant with the recommendation.
- **Solution:** Update the firmware.

If more than one disk is not running the newest version of the firmware, the system prompts to update the firmware. The system issues the **chfirmware** command to update firmware as given in the following format:

For single disk:

```
chfirmware --pdisks <<entity_name>> --cluster <<Cluster_Id>>
```

For example:

```
chfirmware --pdisks <<ENC123001/DRV-2>> --cluster 1857390657572243170
```

For all disks:

```
chfirmware --pdisks --cluster <<Cluster_Id>>
```

For example:

```
chfirmware --pdisks -cluster 1857390657572243170
```

Update host-adapter firmware

The Update host-adapter firmware DMP assists to update the host-adapter firmware to the latest level.

The following are the corresponding event details and the proposed solution:

- **Event name:** adapter_firmware_wrong

- **Problem:** The reported firmware level of the host adapter is not compliant with the recommendation.
- **Solution:** Update the firmware.

If more than one host-adapter is not running the newest version of the firmware, the system prompts to update the firmware. The system issues the **chfirmware** command to update firmware as given in the following format:

For single disk:

```
chfirmware --hostadapter <<Host_Adapter_Name>> --cluster <<Cluster_Id>>
```

For example:

```
chfirmware --hostadapter <<c45f02n04_HBA_2>> --cluster 1857390657572243170
```

For all disks:

```
chfirmware --hostadapter --cluster <<Cluster_Id>>
```

For example:

```
chfirmware --pdisk -cluster 1857390657572243170
```

Start NSD

The Start NSD DMP assists to start NSDs that are not working.

The following are the corresponding event details and the proposed solution:

- **Event ID:** disk_down
- **Problem:** The availability of an NSD is changed to “down”.
- **Solution:** Recover the NSD

The DMP provides the option to start the NSDs that are not functioning. If multiple NSDs are down, you can select whether to recover only one NSD or all of them.

The system issues the **mmchdisk** command to recover NSDs as given in the following format:

```
/usr/lpp/mmfs/bin/mmchdisk <device> start -d <disk description>
```

For example: `/usr/lpp/mmfs/bin/mmchdisk r1_FS start -d G1_r1_FS_data_0`

Start GPFS daemon

When the GPFS daemon is down, GPFS functions do not work properly on the node.

The following are the corresponding event details and the proposed solution:

- **Event ID:** gpfs_down
- **Problem:** The GPFS daemon is down. GPFS is not operational on node.
- **Solution:** Start GPFS daemon.

The system issues the **mmstartup -N** command to restart GPFS daemon as given in the following format:

```
/usr/lpp/mmfs/bin/mmstartup -N <Node>
```

For example: `usr/lpp/mmfs/bin/mmstartup -N gss-05.localnet.com`

Increase fileset space

The system needs inodes to allow I/O on a fileset. If the inodes allocated to the fileset are exhausted, you need to either increase the number of maximum inodes or delete the existing data to free up space.

The procedure helps to increase the maximum number of inodes by a percentage of the already allocated inodes. The following are the corresponding event details and the proposed solution:

- **Event ID:** inode_error_high and inode_warn_high
- **Problem:** The inode usage in the fileset reached an exhausted level
- **Solution:** increase the maximum number of inodes

The system issues the **mmchfileset** command to recover NSDs as given in the following format:

```
/usr/lpp/mmfs/bin/mmchfileset <Device> <Fileset> --inode-limit <inodesMaxNumber>
```

For example: `/usr/lpp/mmfs/bin/mmchfileset r1_FS testFileset --inode-limit 2048`

Synchronize node clocks

The time must be in sync with the time set on the GUI node. If the time is not in sync, the data that is displayed in the GUI might be wrong or it does not even display the details. For example, the GUI does not display the performance data if time is not in sync.

The procedure assists to fix timing issue on a single node or on all nodes that are out of sync. The following are the corresponding event details and the proposed solution:

- **Event ID:** time_not_in_sync
- **Limitation:** This DMP is not available in sudo wrapper clusters. In a sudo wrapper cluster, the user name is different from 'root'. The system detects the user name by finding the parameter `GPFS_USER=<user name>`, which is available in the file `/usr/lpp/mmfs/gui/conf/gpfsgui.properties`.
- **Problem:** The time on the node is not synchronous with the time on the GUI node. It differs more than 1 minute.
- **Solution:** Synchronize the time with the time on the GUI node.

The system issues the **sync_node_time** command as given in the following format to synchronize the time in the nodes:

```
/usr/lpp/mmfs/gui/bin/sync_node_time <nodeName>
```

For example: `/usr/lpp/mmfs/gui/bin/sync_node_time c55f06n04.gpfs.net`

Start performance monitoring collector service

The collector services on the GUI node must be functioning properly to display the performance data in the IBM Spectrum Scale management GUI.

The following are the corresponding event details and the proposed solution:

- **Event ID:** pmcollector_down
- **Limitation:** This DMP is not available in sudo wrapper clusters when a remote *pmcollector* service is used by the GUI. A remote *pmcollector* service is detected in case a different value than localhost is specified in the `ZIMonAddress` in file, which is located at: `/usr/lpp/mmfs/gui/conf/gpfsgui.properties`. In a sudo wrapper cluster, the user name is different from 'root'. The system detects the user name by finding the parameter `GPFS_USER=<user name>`, which is available in the file `/usr/lpp/mmfs/gui/conf/gpfsgui.properties`.
- **Problem:** The performance monitoring collector service *pmcollectoris* in inactive state.
- **Solution:** Issue the **systemctl status pmcollector** to check the status of the collector. If *pmcollector* service is inactive, issue **systemctl start pmcollector**.

The system restarts the performance monitoring services by issuing the **systemctl restart pmcollector** command.

The performance monitoring collector service might be on some other node of the current cluster. In this case, the DMP first connects to that node, then restarts the performance monitoring collector service.

```
ssh <nodeAddress> systemctl restart pmcollector
```

For example: `ssh 10.0.100.21 systemctl restart pmcollector`

In a sudo wrapper cluster, when collector on remote node is down, the DMP does not restart the collector services by itself. You need to do it manually.

Start performance monitoring sensor service

You need to start the sensor service to get the performance details in the collectors. If sensors and collectors are not started, the GUI and CLI do not display the performance data in the IBM Spectrum Scale management GUI.

The following are the corresponding event details and the proposed solution:

- **Event ID:** `pmsensors_down`
- **Limitation:** This DMP is not available in sudo wrapper clusters. In a sudo wrapper cluster, the user name is different from 'root'. The system detects the user name by finding the parameter `GPFS_USER=<user name>`, which is available in the file `/usr/lpp/mmfs/gui/conf/gpfsgui.properties`.
- **Problem:** The performance monitoring sensor service *pmsensor* is not sending any data. The service might be down or the difference between the time of the node and the node hosting the performance monitoring collector service *pmcollector* is more than 15 minutes.
- **Solution:** Issue **`systemctl status pmsensors`** to verify the status of the sensor service. If *pmsensor* service is inactive, issue **`systemctl start pmsensors`**.

The system restarts the sensors by issuing **`systemctl restart pmsensors`** command.

For example: `ssh gss-15.localnet.com systemctl restart pmsensors`

Chapter 6. References

The IBM Elastic Storage Server system displays a warning or error message when it encounters an issue that needs user attention. The message severity tags indicate the severity of the issue

Events

The recorded events are stored in local database on each node. The user can get a list of recorded events by using the **mmhealth node eventlog** command.

The recorded events can also be displayed through GUI.

The following sections list the RAS events that are applicable to various components of the IBM Spectrum Scale system:

- “Array events”
- “Enclosure events” on page 48
- “Virtual disk events” on page 52
- “Physical disk events” on page 52
- “Recovery group events” on page 53
- “Server events” on page 53
- “Authentication events” on page 56
- “CES network events” on page 58
- “Transparent Cloud Tiering events” on page 61
- “Disk events” on page 66
- “File system events” on page 66
- “GPFS events” on page 77
- “GUI events” on page 84
- “Hadoop connector events” on page 90
- “Keystone events” on page 91
- “NFS events” on page 92
- “Network events” on page 96
- “Object events” on page 98
- “Performance events” on page 103
- “SMB events” on page 105

Array events

The following table lists array events.

Table 7. Events for arrays defined in the system

Event	Event Type	Severity	Message	Description	Cause	User Action
gnr_array_found	INFO_ADD_ENTITY	INFO	GNR declustered array {0} was found.	A GNR declustered array listed in the IBM Spectrum Scale configuration was detected.	N/A	N/A

Table 7. Events for arrays defined in the system (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
gnr_array_vanished	INFO_DELETE_ENTITY	INFO	GNR declustered array {0} was not detected.	A GNR declustered array listed in the IBM Spectrum Scale configuration was not detected	A GNR declustered array, listed in the IBM Spectrum Scale configuration as mounted before, is not found. This could be a valid situation	Run the mmfsrecoverygroup command to verify that all expected GNR declustered array exist.
gnr_array_ok	STATE_CHANGE	INFO	GNR declustered array {0} is healthy.	The declustered array state is healthy.	N/A	N/A
gnr_array_needservice	STATE_CHANGE	WARNING	GNR declustered array {0} needs service.	The declustered array state needs service.	N/A	N/A
gnr_array_unknown	STATE_CHANGE	WARNING	GNR declustered array {0} is in unknown state.	The declustered array state is unknown.	N/A	N/A

Enclosure events

The following table lists enclosure events.

Table 8. Enclosure events

Event	Event Type	Severity	Message	Description	Cause	User Action
enclosure_found	INFO_ADD_ENTITY	INFO	Enclosure {0} was detected.	A GNR enclosure listed in the IBM Spectrum Scale configuration was detected.	N/A	N/A
enclosure_vanished	INFO_DELETE_ENTITY	INFO	Enclosure {0} was not detected.	A GNR enclosure listed in the IBM Spectrum Scale configuration was not detected	A GNR enclosure, listed in the IBM Spectrum Scale configuration as mounted before, is not found. This could be a valid situation.	Run the mmfsenclosure command to verify whether all expected enclosures exist.
enclosure_ok	STATE_CHANGE	INFO	Enclosure {0} is healthy.	The enclosure state is healthy.	N/A	N/A
enclosure_unknown	STATE_CHANGE	WARNING	Enclosure state {0} is unknown.	The enclosure state is unknown.	N/A	N/A
fan_ok	STATE_CHANGE	INFO	Fan {0} is healthy.	The fan state is healthy.	N/A	N/A
dcm_ok	STATE_CHANGE	INFO	DCM {id[1]} is healthy.	The DCM state is healthy.	N/A	N/A
esm_ok	STATE_CHANGE	INFO	ESM {0} is healthy.	The ESM state is healthy.	N/A	N/A
power_supply_ok	STATE_CHANGE	INFO	Power supply {0} is healthy.	The power supply state is healthy.	N/A	N/A
voltage_sensor_ok	STATE_CHANGE	INFO	Voltage sensor {0} is healthy.	The voltage sensor state is healthy.	N/A	N/A
temp_sensor_ok	STATE_CHANGE	INFO	Temperature sensor {0} is healthy.	The temperature sensor state is healthy.	N/A	N/A

Table 8. Enclosure events (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
enclosure_needservice	STATE_CHANGE	WARNING	Enclosure {0} needs service.	The enclosure needs service.	N/A	N/A
fan_failed	STATE_CHANGE	WARNING	Fan {0} is failed.	The fan state is failed.	N/A	N/A
dcm_failed	STATE_CHANGE	WARNING	DCM {0} is failed.	The DCM state is failed.	N/A	N/A
dcm_not_available	STATE_CHANGE	WARNING	DCM {0} is not available.	The DCM is either not installed or not responding.	N/A	N/A
dcm_drawer_open	STATE_CHANGE	WARNING	DCM {0} drawer is open.	The DCM drawer is open.	N/A	N/A
esm_failed	STATE_CHANGE	WARNING	ESM {0} is failed.	The ESM state is failed.	N/A	N/A
esm_absent	STATE_CHANGE	WARNING	ESM {0} is absent.	The ESM is not installed.	N/A	N/A
power_supply_failed	STATE_CHANGE	WARNING	Power supply {0} is failed.	The power supply state is failed.	N/A	N/A
power_supply_absent	STATE_CHANGE	WARNING	Power supply {0} is missing.	The power supply is missing.	N/A	N/A
power_switched_off	STATE_CHANGE	WARNING	Power supply {0} is switched off.	The requested on bit is off, which indicates that the power supply is manually turned on or requested to turn on by setting the requested on bit.	N/A	N/A
power_supply_off	STATE_CHANGE	WARNING	Power supply {0} is off	The power supply is not providing power.	N/A	N/A
power_high_voltage	STATE_CHANGE	WARNING	Power supply {0} reports high voltage.	The DC power supply voltage is greater than the threshold.	N/A	N/A
power_high_current	STATE_CHANGE	WARNING	Power supply {0} reports high current.	The DC power supply current is greater than the threshold.	N/A	N/A
power_no_power	STATE_CHANGE	WARNING	Power supply {0} has no power.	Power supply has no input AC power. The power supply may be turned off or disconnected from the AC supply.	N/A	N/A
voltage_sensor_failed	STATE_CHANGE	WARNING	Voltage sensor {0} is failed.	The voltage sensor state is failed	N/A	N/A

Table 8. Enclosure events (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
voltage_bus_failed	STATE_CHANGE	WARNING	Voltage sensor {0} I2C bus is failed.	The voltage sensor I2C bus has failed.	N/A	N/A
voltage_high_critical	STATE_CHANGE	WARNING	Voltage sensor {0} measured a high voltage value.	The voltage has exceeded the actual high critical threshold value for at least one sensor.	N/A	N/A
voltage_high_warn	STATE_CHANGE	WARNING	Voltage sensor {0} measured a high voltage value.	The voltage has exceeded the actual high warning threshold value for at least one sensor.	N/A	N/A
voltage_low_critical	STATE_CHANGE	WARNING	Voltage sensor {0} measured a low voltage value.	The voltage has fallen below the actual low critical threshold value for at least one sensor.	N/A	N/A
voltage_low_warn	STATE_CHANGE	WARNING	Voltage sensor {0} measured a low voltage value.	The voltage has fallen below the actual low warning threshold value for at least one sensor.	N/A	N/A
temp_sensor_failed	STATE_CHANGE	WARNING	Temperature sensor {0} is failed.	The temperature sensor state is failed.	N/A	N/A
temp_bus_failed	STATE_CHANGE	WARNING	Temperature sensor {0} I2C bus is failed.	The temperature sensor I2C bus is failed.	N/A	N/A
temp_high_critical	STATE_CHANGE	WARNING	Temperature sensor {0} measured a high temperature value.	The temperature has exceeded the actual high critical threshold value for at least one sensor.	N/A	N/A
temp_high_warn	STATE_CHANGE	WARNING	Temperature sensor {0} measured a high temperature value.	The temperature has exceeded the actual high warning threshold value for at least one sensor.	N/A	N/A

Table 8. Enclosure events (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
temp_low_critical	STATE_CHANGE	WARNING	Temperature sensor {0} measured a low temperature value.	The temperature has fallen below the actual low critical threshold value for at least one sensor.	N/A	N/A
temp_low_warn	STATE_CHANGE	WARNING	Temperature sensor {0} measured a low temperature value.	The temperature has fallen below the actual low warning threshold value for at least one sensor.	N/A	N/A
enclosure_firmware_ok	STATE_CHANGE	INFO	The firmware level of enclosure {0} is correct.	The firmware level of the enclosure is correct.	N/A	N/A
enclosure_firmware_wrong	STATE_CHANGE	WARNING	The firmware level of enclosure {0} is wrong.	The firmware level of the enclosure is wrong.	N/A	Check the installed firmware level using mm1sfirmware command.
enclosure_firmware_notavail	STATE_CHANGE	WARNING	The firmware level of enclosure {0} is not available.	The firmware level of the enclosure is not available.	N/A	Check the installed firmware level using mm1sfirmware command.
drive_firmware_ok	STATE_CHANGE	INFO	The firmware level of drive {0} is correct.	The firmware level of the drive is correct.	N/A	N/A
drive_firmware_wrong	STATE_CHANGE	WARNING	The firmware level of drive {0} is wrong.	The firmware level of the drive is wrong.	N/A	Check the installed firmware level using the mm1sfirmware command.
drive_firmware_notavail	STATE_CHANGE	WARNING	The firmware level of drive {0} is not available.	The firmware level of the drive is not available.	N/A	Check the installed firmware level using the mm1sfirmware command.
adapter_firmware_ok	STATE_CHANGE	INFO	The firmware level of adapter {0} is correct.	The firmware level of the adapter is correct.	N/A	N/A
adapter_firmware_wrong	STATE_CHANGE	WARNING	The firmware level of adapter {0} is wrong.	The firmware level of the adapter is wrong.	N/A	Check the installed bios level using mm1sfirmware command.
adapter_firmware_notavail	STATE_CHANGE	WARNING	The firmware level of adapter {0} is not available.	The firmware level of the adapter is not available.	N/A	Check the installed bios level using the mm1sfirmware command.
adapter_bios_ok	STATE_CHANGE	INFO	The bios level of adapter {0} is correct.	The bios level of the adapter is correct.	N/A	N/A
adapter_bios_wrong	STATE_CHANGE	WARNING	The bios level of adapter {0} is wrong.	The bios level of the adapter is wrong.	N/A	Check the installed bios level using mm1sfirmware command

Table 8. Enclosure events (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
adapter_bios_notavail	STATE_CHANGE	WARNING	The bios level of adapter {0} is not available.	The bios level of the adapter is not available.	N/A	Check the installed bios level using mm1sfirmware command

Virtual disk events

The following table lists virtual disk events.

Table 9. Virtual disk events

Event	Event Type	Severity	Message	Description	Cause	User Action
gnr_vdisk_found	INFO_ADD_ENTITY	INFO	GNR vdisk {0} was found.	A GNR vdisk listed in the IBM Spectrum Scale configuration was detected	N/A	N/A
gnr_vdisk_vanished	INFO_DELETE_ENTITY	INFO	GNR vdisk {0} is not detected.	A GNR vdisk listed in the IBM Spectrum Scale configuration is not detected.	A GNR vdisk, listed in the IBM Spectrum Scale configuration as mounted before, is not found. This could be a valid situation.	Run mm1svdisk to verify whether all expected GNR vdisk exist.
gnr_vdisk_ok	STATE_CHANGE	INFO	GNR vdisk {0} is healthy.	The vdisk state is healthy.	N/A	N/A
gnr_vdisk_critical	STATE_CHANGE	ERROR	GNR vdisk {0} is critical degraded.	The vdisk state is critical degraded.	N/A	N/A
gnr_vdisk_offline	STATE_CHANGE	ERROR	GNR vdisk {0} is offline.	The vdisk state is offline.	N/A	N/A
gnr_vdisk_degraded	STATE_CHANGE	WARNING	GNR vdisk {0} is degraded.	The vdisk state is degraded.	N/A	N/A
gnr_vdisk_unknown	STATE_CHANGE	WARNING	GNR vdisk {0} is unknown.	The vdisk state is unknown.	N/A	N/A

Physical disk events

The following table lists physical disk events.

Table 10. Physical disk events

Event	Event Type	Severity	Message	Description	Cause	User Action
gnr_pdisk_found	INFO_ADD_ENTITY	INFO	GNR pdisk {0} is detected.	A GNR pdisk listed in the IBM Spectrum Scale configuration is detected.	N/A	N/A
gnr_pdisk_vanished	INFO_DELETE_ENTITY	INFO	GNR pdisk {0} is not detected.	A GNR pdisk listed in the IBM Spectrum Scale configuration is not detected.	A GNR pdisk, listed in the IBM Spectrum Scale configuration as mounted before, is not detected. This could be a valid situation.	Run the mm1spdisk command verify whether all expected GNR pdisk exist.
gnr_pdisk_ok	STATE_CHANGE	INFO	GNR pdisk {0} is healthy.	The pdisk state is healthy.	N/A	N/A
gnr_pdisk_replaceable	STATE_CHANGE	ERROR	GNR pdisk {0} is replaceable.	The pdisk state is replaceable.	N/A	N/A
gnr_pdisk_draining	STATE_CHANGE	ERROR	GNR pdisk {0} is draining.	The pdisk state is draining.	N/A	N/A

Table 10. Physical disk events (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
gnr_pdisk_unknown	STATE_CHANGE	ERROR	GNR pdisks are in unknown state.	The pdisk state is unknown.	N/A	N/A

Recovery group events

The following table lists recovery group events.

Table 11. Recovery group events

Event	Event Type	Severity	Message	Description	Cause	User Action
gnr_rg_found	INFO_ADD_ENTITY	INFO	GNR recovery group {0} is detected.	A GNR recovery group listed in the IBM Spectrum Scale configuration is detected.	N/A	N/A
gnr_rg_vanished	INFO_DELETE_ENTITY	INFO	GNR recovery group {0} is not detected.	A GNR recovery group listed in the IBM Spectrum Scale configuration is not detected.	A GNR recovery group, listed in the IBM Spectrum Scale configuration as mounted before, is not detected. This could be a valid situation.	Run the mmfsrecoverygroup command to verify whether all expected GNR recovery group exist.
gnr_rg_ok	STATE_CHANGE	INFO	GNR recovery group {0} is healthy.	The recovery group is healthy.	N/A	N/A
gnr_rg_failed	STATE_CHANGE	INFO	GNR recovery group {0} is not active.	The recovery group is not active.	N/A	N/A

Server events

The following table lists server events.

Table 12. Server events

Event	Event Type	Severity	Message	Description	Cause	User Action
cpu_peci_ok	STATE_CHANGE	INFO	PECI state of CPU {0} is ok.	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
cpu_peci_failed	STATE_CHANGE	ERROR	PECI state of CPU {0} failed.	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
cpu_qpi_link_ok	STATE_CHANGE	INFO	QPI Link of CPU {0} is ok.	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
cpu_qpi_link_failed	STATE_CHANGE	ERROR	QPI Link of CPU {0} is failed.	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
cpu_temperature_ok	STATE_CHANGE	ERROR	QPI Link of CPU {0} is failed.	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
cpu_temperature_ok	STATE_CHANGE	INFO	CPU {0} temperature is normal ({1}).	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
cpu_temperature_failed	STATE_CHANGE			The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
server_power_supply_temp_ok	STATE_CHANGE	INFO	Temperature of Power Supply {0} is ok. ({1})	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.

Table 12. Server events (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
server_power_supply_temp_failed	STATE_CHANGE	ERROR	Temperature of Power Supply {0} is too high. ({1})	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
server_power_supply_oc_line_12V_ok	STATE_CHANGE	INFO	OC Line 12V of Power Supply {0} is ok.	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
server_power_supply_oc_line_12V_failed	STATE_CHANGE	ERROR	OC Line 12V of Power Supply {0} failed.	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
server_power_supply_ov_line_12V_ok	STATE_CHANGE	INFO	OV Line 12V of Power Supply {0} is ok.	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
server_power_supply_ov_line_12V_failed	STATE_CHANGE	ERROR	OV Line 12V of Power Supply {0} failed.	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
server_power_supply_uv_line_12V_ok	STATE_CHANGE	INFO	UV Line 12V of Power Supply {0} is ok.	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
server_power_supply_uv_line_12V_failed	STATE_CHANGE	ERROR	UV Line 12V of Power Supply {0} failed.	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
server_power_supply_aux_line_12V_ok	STATE_CHANGE	INFO	AUX Line 12V of Power Supply {0} is ok.	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
server_power_supply_aux_line_12V_failed	STATE_CHANGE	ERROR	AUX Line 12V of Power Supply {0} failed.	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
server_power_supply_fan_ok	STATE_CHANGE	INFO	Fan of Power Supply {0} is ok.	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
server_power_supply_fan_failed	STATE_CHANGE	ERROR	Fan of Power Supply {0} failed.	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
server_power_supply_voltage_ok	STATE_CHANGE	INFO	Voltage of Power Supply {0} is ok.	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
server_power_supply_voltage_failed	STATE_CHANGE	ERROR	Voltage of Power Supply {0} is not ok.	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
server_power_supply_ok	STATE_CHANGE	INFO	Power Supply {0} is ok.	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
server_power_supply_failed	STATE_CHANGE	ERROR	Power Supply {0} failed.	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
pci_riser_temp_ok	STATE_CHANGE	INFO	The temperature of PCI Riser {0} is ok. ({1})	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
pci_riser_temp_failed	STATE_CHANGE	ERROR	The temperature of PCI Riser {0} is too high. ({1})	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
server_fan_ok	STATE_CHANGE	INFO	Fan {0} is ok. ({1})	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
server_fan_failed	STATE_CHANGE	ERROR	Fan {0} failed. ({1})	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
dimm_ok	STATE_CHANGE	INFO	DIMM {0} is ok.	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
dimm_failed	STATE_CHANGE	ERROR	DIMM {0} failed.	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.

Table 12. Server events (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
pci_ok	STATE_CHANGE	INFO	PCI {0} is ok.	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
pci_failed	STATE_CHANGE	ERROR	PCI {0} failed.	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
fan_zone_ok	STATE_CHANGE	INFO	Fan Zone {0} is ok.	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
fan_zone_failed	STATE_CHANGE	ERROR	Fan Zone {0} failed.	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
drive_ok	STATE_CHANGE	INFO	Drive {0} is ok.	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
drive_failed	STATE_CHANGE	ERROR	Drive {0} failed.	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
dasd_backplane_ok	STATE_CHANGE	INFO	DASD Backplane {0} is ok.	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
dasd_backplane_failed	STATE_CHANGE	ERROR	DASD Backplane {0} failed.	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
server_cpu_ok	STATE_CHANGE	INFO	All CPUs of server {0} are fully available.	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
server_cpu_failed	STATE_CHANGE	ERROR	At least one CPU of server {0} failed.	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
server_dimm_ok	STATE_CHANGE	INFO	All DIMMs of server {0} are fully available.	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
server_dimm_failed	STATE_CHANGE	ERROR	At least one DIMM of server {0} failed.	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
server_pci_ok	STATE_CHANGE	INFO	All PCIs of server {0} are fully available.	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
server_pci_failed	STATE_CHANGE	ERROR	At least one PCI of server {0} failed.	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
server_ps_conf_ok	STATE_CHANGE	INFO	All Power Supply Configurations of server {0} are ok.	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
server_ps_conf_failed	STATE_CHANGE	ERROR	At least one Power Supply Configuration of server {0} is not ok.	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
server_ps_heavyload_ok	STATE_CHANGE	INFO	No Power Supplies of server {0} are under heavy load.	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
server_ps_heavyload_failed	STATE_CHANGE	ERROR	At least one Power Supply of server {0} is under heavy load.	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
server_ps_resource_ok	STATE_CHANGE	INFO	Power Supply resources of server {0} are ok.	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
server_ps_resource_failed	STATE_CHANGE	ERROR	At least one Power Supply of server {0} has insufficient resources.	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.

Table 12. Server events (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
server_ps_unit_ok	STATE_CHANGE	INFO	All Power Supply units of server {0} are fully available.	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
server_ps_unit_failed	STATE_CHANGE	ERROR	At least one Power Supply unit of server {0} failed.	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
server_ps_ambient_ok	STATE_CHANGE	INFO	Power Supply ambient of server {0} is ok.	The GUI checks the hardware state using xCAT.	he hardware part is ok.	None.
server_ps_ambient _failed	STATE_CHANGE	ERROR	At least one Power Supply ambient of server {0} is not okay.	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
server_boot_status_ok	STATE_CHANGE	INFO	The boot status of server {0} is normal.	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
server_boot_status _failed	STATE_CHANGE	ERROR	System Boot failed on server {0}.	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
server_planar_ok	STATE_CHANGE	INFO	Planar state of server {0} is healthy, the voltage is normal ({1}).	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
server_planar_failed	STATE_CHANGE	ERROR	Planar state of server {0} is unhealthy, the voltage is too low or too high ({1}).	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
server_sys_board_ok	STATE_CHANGE	INFO	The system board of server {0} is healthy.	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
server_sys_board _failed	STATE_CHANGE	ERROR	The system board of server {0} failed.	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
server_system_event _log_ok	STATE_CHANGE	INFO	The system event log of server {0} operates normally.	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
server_system_event _log_full	STATE_CHANGE	ERROR	The system event log of server {0} is full.	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
server_ok	STATE_CHANGE	INFO	The server {0} is healthy.	The GUI checks the hardware state using xCAT.	The hardware part is ok.	None.
server_failed	STATE_CHANGE	ERROR	The server {0} failed.	The GUI checks the hardware state using xCAT.	The hardware part failed.	None.
hmc_event	STATE_CHANGE	INFO	HMC Event: {1}	The GUI collects events raised by the HMC.	An event from the HMC arrived.	None.

Authentication events

The following table lists the events that are created for the *AUTH* component.

Table 13. Events for the AUTH component

Event	Event Type	Severity	Message	Description	Cause	User Action
ads_down	STATE_CHANGE	ERROR	The external Active Directory (AD) server is unresponsive.	The external AD server is unresponsive.	The local node is unable to connect to any AD server.	Local node is unable to connect to any AD server. Verify the network connection and check whether the AD servers are operational.

Table 13. Events for the AUTH component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
ads_failed	STATE_CHANGE	ERROR	The local winbindd service is unresponsive.	The local winbindd service is unresponsive.	The local winbindd service does not respond to ping requests. This is a mandatory prerequisite for Active Directory service.	Try to restart winbindd service and if not successful, perform winbindd troubleshooting procedures.
ads_up	STATE_CHANGE	INFO	The external Active Directory (AD) server is up.	The external AD server is up.	The external AD server is operational.	N/A
ads_warn	INFO	WARNING	External Active Directory (AD) server monitoring service returned unknown result	External AD server monitoring service returned unknown result.	An internal error occurred while monitoring the external AD server.	An internal error occurred while monitoring the external AD server. Perform troubleshooting procedures.
ldap_down	STATE_CHANGE	ERROR	The external LDAP server {0} is unresponsive.	The external LDAP server <LDAP server> is unresponsive.	The local node is unable to connect to the LDAP server.	Local node is unable to connect to the LDAP server. Verify the network connection and check whether the LDAP server is operational.
ldap_up	STATE_CHANGE	INFO	External LDAP server {0} is up.	The external LDAP server is operational.		N/A
nis_down	STATE_CHANGE	ERROR	External Network Information Server (NIS) {0} is unresponsive.	External NIS server <NIS server> is unresponsive.	The local node is unable to connect to any NIS server.	Local node is unable to connect to any NIS server. Verify network connection and check whether the NIS servers are operational.
nis_failed	STATE_CHANGE	ERROR	The ypbind daemon is unresponsive.	The ypbind daemon is unresponsive.	The local ypbind daemon does not respond.	Local ypbind daemon does not respond. Try to restart the ypbind daemon. If not successful, perform ypbind troubleshooting procedures.
nis_up	STATE_CHANGE	INFO	External Network Information Server (NIS) {0} is up	External NIS server is operational.		N/A
nis_warn	INFO	WARNING	External Network Information Server (NIS) monitoring returned unknown result.	The external NIS server monitoring returned unknown result.	An internal error occurred while monitoring external NIS server.	Perform troubleshooting procedures.
sssd_down	STATE_CHANGE	ERROR	SSSD process is not functioning.	The SSSD process is not functioning.	The SSSD authentication service is not running.	Perform the SSSD troubleshooting procedures.
sssd_restart	INFO	INFO	SSSD process is not functioning. Trying to start it.	Attempt to start the SSSD authentication process.	The SSSD process is not functioning.	N/A
sssd_up	STATE_CHANGE	INFO	SSSD process is now functioning.	The SSSD process is now functioning properly.	The SSSD authentication process is running.	N/A
sssd_warn	INFO	WARNING	SSSD service monitoring returned unknown result.	The SSSD authentication service monitoring returned unknown result.	An internal error occurred in the SSSD service monitoring.	Perform the troubleshooting procedures.

Table 13. Events for the AUTH component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
wnbd_down	STATE_CHANGE	ERROR	Winbindd service is not functioning.	The winbindd authentication service is not functioning.	The winbindd authentication service is not functioning.	Verify the configuration and connection with Active Directory server.
wnbd_restart	INFO	INFO	Winbindd service is not functioning. Trying to start it.	Attempt to start the winbindd service.	The winbindd process was not functioning.	N/A
wnbd_up	STATE_CHANGE	INFO	Winbindd process is now functioning.	The winbindd authentication service is operational.		N/A
wnbd_warn	INFO	WARNING	Winbindd process monitoring returned unknown result.	The winbindd authentication process monitoring returned unknown result.	An internal error occurred while monitoring the winbindd authentication process.	Perform the troubleshooting procedures.
yp_down	STATE_CHANGE	ERROR	Ypbind process is not functioning.	The ypbind process is not functioning.	The ypbind authentication service is not functioning.	Perform the troubleshooting procedures.
yp_restart	INFO	INFO	Ypbind process is not functioning. Trying to start it.	Attempt to start the ypbind process.	The ypbind process is not functioning.	N/A
yp_up	STATE_CHANGE	INFO	Ypbind process is now functioning.	The ypbind service is operational.		N/A
yp_warn	INFO	WARNING	Ypbind process monitoring returned unknown result	The ypbind process monitoring returned unknown result.	An internal error occurred while monitoring the ypbind service.	Perform troubleshooting procedures.

CES network events

The following table lists the events that are created for the *CESNetwork* component.

Table 14. Events for the CESNetwork component

Event	Event Type	Severity	Message	Description	Cause	User Action
ces_bond_down	STATE_CHANGE	ERROR	All slaves of the CES-network bond {0} are down.	All slaves of the CES-network bond are down.	All slaves of this network bond are down.	Check the bonding configuration, network configuration, and cabling of all slaves of the bond.
ces_bond_degraded	STATE_CHANGE	INFO	Some slaves of the CES-network bond {0} are down.	Some of the CES-network bond parts are malfunctioning.	Some slaves of the bond are not functioning properly.	Check bonding configuration, network configuration, and cabling of the malfunctioning slaves of the bond.
ces_bond_up	STATE_CHANGE	INFO	All slaves of the CES bond {0} are working as expected.	This CES bond is functioning properly.	All slaves of this network bond are functioning properly.	N/A

Table 14. Events for the CESNetwork component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
ces_disable_node_network	INFO	INFO	Network is disabled.		Informational message. Clean up after a 'mmchnode --ces-disable' command. Disabling CES service on the node disables the network configuration.	N/A
ces_enable_node_network	INFO	INFO	Network is enabled.	The network configuration is enabled when CES service is enabled by using the mmchnode --ces-enable command.	Enabling CES service on the node also enables the network services.	N/A
ces_many_tx_errors	STATE_CHANGE	ERROR	CES NIC {0} reported many TX errors since the last monitoring cycle.	The CES-related NIC reported many TX errors since the last monitoring cycle.	Cable connection issues.	Check cable contacts or try a different cable. Refer the /proc/net/dev folder to find out TX errors reported for this adapter since the last monitoring cycle.
ces_network_connectivity_down	STATE_CHANGE	ERROR	The CES NIC {0} could not connect to the gateway.	The CES-related network adapter could not connect to the gateway.	The gateway responds to the sent connections-checking packets.	Check network configuration of the network adapter, gateway configuration, and path to the gateway.
ces_network_connectivity_up	STATE_CHANGE	INFO	CES NIC {0} can connect to the gateway.	A CES-related NIC can connect to the gateway.	N/A	N/A
ces_network_down	STATE_CHANGE	ERROR	CES NIC {0} is down.	This CES-related network adapter is down.	This network adapter is disabled.	Enable the network adapter and if the problem persists, verify the system logs for more details.
ces_network_found	INFO	INFO	A new CES-related NIC {0} is detected.	A new CES-related network adapter is detected.	The output of the ip a command lists a new NIC.	N/A
ces_network_ips_down	STATE_CHANGE	WARNING	No CES relevant NICs are detected.	No CES-relevant network adapters or CES IPs detected, which makes the node unavailable for the CES clients.	No network adapters have the CES-relevant IPs, which makes the node unavailable for the CES clients.	Check the network cabling and network configuration.

Table 14. Events for the CESNetwork component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
ces_network_ips_up	STATE_CHANGE	INFO	CES-relevant IPs served by NICs are detected.	CES-relevant IPs are served by network adapters. This makes the node available for the CES clients.	At least one CES-relevant IP is assigned to a network adapter.	N/A
ces_network_link_down	STATE_CHANGE	ERROR	Physical link of the CES NIC {0} is down.	The physical link of this CES-related network adapter is down.	The flag LOWER_UP is not set for this NIC in the output of the <code>ip a</code> command.	Check the cabling of this network adapter.
ces_network_link_up	STATE_CHANGE	INFO	Physical link of the CES NIC {0} is up.	The physical link of this CES-related network adapter is up.	The flag LOWER_UP is set for this NIC in the output of the <code>ip a</code> command.	N/A
ces_network_up	STATE_CHANGE	INFO	CES NIC {0} is up.	This CES-related network adapter is up.	This network adapter is enabled.	N/A
ces_network_vanished	INFO	INFO	CES NIC {0} could not be detected.	One of CES-related network adapters could not be detected.	One of the previously monitored NICs is not listed in the output of the <code>ip a</code> command.	N/A
ces_no_tx_errors	STATE_CHANGE	INFO	CES NIC {0} had no or an insignificant number of TX errors.	A CES-related NIC had no or an insignificant number of TX errors.	The <code>/proc/net/dev</code> folder lists no or an insignificant number of TX errors for this adapter since the last monitoring cycle.	Check the network cabling and network infrastructure.
ces_startup_network	INFO	INFO	CES network service is started.	CES network is started.	CES network IPs are active.	N/A
handle_network_problem_info	INFO	INFO	Handle network problem - Problem: {0},Argument: {1}	Information about network related reconfigurations. This can be enable or disable IPs and assign or unassign IPs.	A change in the network configuration.	N/A
move_cesip_from	INFO	INFO	Address {0} is moved from this node to node {1}.	CES IP address is moved from the current node to another node.	Rebalancing of CES IP addresses.	N/A

Table 14. Events for the CESNetwork component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
move_cesips_info	INFO	INFO	A move request for IP addresses is performed.	In case of node failures, CES IP addresses can be moved from one node to one or more other nodes. This message is logged on a node that is monitoring the affected node; not necessarily on any affected node itself.	A CES IP movement was detected.	N/A
move_cesip_to	INFO	INFO	Address {0} is moved from node {1} to this node.	A CES IP address is moved from another node to the current node.	Rebalancing of CES IP addresses.	N/A

Transparent Cloud Tiering events

The following table lists the events that are created for the *Transparent Cloud Tiering* component.

Table 15. Events for the Transparent Cloud Tiering component

Event	Event Type	Severity	Message	Description	Cause	User Action
tct_account_active	STATE_CHANGE	INFO	Cloud provider account that is configured with Transparent cloud tiering service is active.	Cloud provider account that is configured with Transparent cloud tiering service is active.		N/A
tct_account_bad_req	STATE_CHANGE	ERROR	Transparent cloud tiering is failed to connect to the cloud provider because of request error.	Transparent cloud tiering is failed to connect to the cloud provider because of request error.	Bad request.	Check trace messages and error logs for further details.
tct_account_certinvalidpath	STATE_CHANGE	ERROR	Transparent cloud tiering is failed to connect to the cloud provider because it was unable to find valid certification path.	Transparent cloud tiering is failed to connect to the cloud provider because it was unable to find valid certification path.	Unable to find valid certificate path.	Check trace messages and error logs for further details.
tct_account_connecterror	STATE_CHANGE	ERROR	An error occurred while attempting to connect a socket to the cloud provider URL.	The connection was refused remotely by cloud provider.	No process is accessing the cloud provider.	Check whether the cloud provider host name and port numbers are valid.
tct_account_configerror	STATE_CHANGE	ERROR	Transparent cloud tiering refused to connect to the cloud provider.	Transparent cloud tiering refused to connect to the cloud provider.	Some of the cloud provider-dependent services are down.	Check whether the cloud provider-dependent services are up and running.
tct_account_configured	STATE_CHANGE	WARNING	Cloud provider account is configured with Transparent cloud tiering but the service is down.	Cloud provider account is configured with Transparent cloud tiering but the service is down.	Transparent cloud tiering the service is down.	Run the command mmcloudgateway service start command to resume the cloud gateway service.

Table 15. Events for the Transparent Cloud Tiering component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
tct_account_containecreator error	STATE_CHANGE	ERROR	The cloud provider container creation is failed.	The cloud provider container creation is failed.	The cloud provider account might not be authorized to create container.	Check trace messages and error logs for further details. Also, check that the account create-related issues in the <i>Transparent Cloud Tiering issues</i> section of the <i>IBM Spectrum Scale Problem Determination Guide</i> .
tct_account_dbcorrupt	STATE_CHANGE	ERROR	The database of Transparent cloud tiering service is corrupted.	The database of Transparent cloud tiering service is corrupted.	Database is corrupted.	Check trace messages and error logs for further details. Use the mmcloudgateway files rebuildDB command to repair it.
tct_account_direrror	STATE_CHANGE	ERROR	Transparent cloud tiering failed because one of its internal directories is not found.	Transparent cloud tiering failed because one of its internal directories is not found.	Transparent cloud tiering service internal directory is missing.	Check trace messages and error logs for further details.
tct_account_invalidurl	STATE_CHANGE	ERROR	Cloud provider account URL is not valid.	The reason could be because of HTTP 404 Not Found error.	The reason could be because of HTTP 404 Not Found error.	Check whether the cloud provider URL is valid.
stct_account_invalid credential	STATE_CHANGE	ERROR	The network of Transparent cloud tiering node is down.	The network of Transparent cloud tiering node is down	Network connection problem.	Check trace messages and error logs for further details. Check whether the network connection is valid.
tct_account_malformedurl	STATE_CHANGE	ERROR	Cloud provider account URL is malformed	Cloud provider account URL is malformed.	Malformed cloud provider URL.	Check whether the cloud provider URL is valid.
tct_account_manyretries	INFO	WARNING	Transparent cloud tiering service is having too many retries internally.	Transparent cloud tiering service is having too many retries internally.	The Transparent cloud tiering service might be having connectivity issues with the cloud provider.	Check trace messages and error logs for further details.
tct_account_noroute	STATE_CHANGE	ERROR	The response from cloud provider is invalid.	The response from cloud provider is invalid.	The cloud provider URL return response code -1.	Check whether the cloud provider URL is accessible.
tct_account_notconfigured	STATE_CHANGE	WARNING	Transparent cloud tiering is not configured with cloud provider account.	The Transparent cloud tiering is not configured with cloud provider account.	The Transparent cloud tiering is installed but account is not configured or deleted.	Run the mmcloudgateway account create command to create the cloud provider account.

Table 15. Events for the Transparent Cloud Tiering component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
tct_account_preconderror	STATE_CHANGE	ERROR	Transparent cloud tiering is failed to connect to the cloud provider because of precondition failed error.	Transparent cloud tiering is failed to connect to the cloud provider because of precondition failed error.	Cloud provider URL returned HTTP 412 Precondition Failed.	Check trace messages and error logs for further details.
tct_account_rkm_down	STATE_CHANGE	ERROR	The remote key manager configured for Transparent cloud tiering is not accessible.	The remote key manager that is configured for Transparent cloud tiering is not accessible.	The Transparent cloud tiering is failed to connect to IBM Security Key Lifecycle Manager.	Check trace messages and error logs for further details.
tct_account_lkm_down	STATE_CHANGE	ERROR	The local key manager configured for Transparent cloud tiering is either not found or corrupted.	The local key manager configured for Transparent cloud tiering is either not found or corrupted.	Local key manager not found or corrupted.	Check trace messages and error logs for further details.
tct_account_servererror	STATE_CHANGE	ERROR	Transparent cloud tiering service is failed to connect to the cloud provider because of cloud provider service unavailability error.	Transparent cloud tiering service is failed to connect to the cloud provider because of cloud provider server error or container size has reached max storage limit.	Cloud provider returned HTTP 503 Server Error.	Cloud provider returned HTTP 503 Server Error.
tct_account_sockettimeout	NODE	ERROR	Timeout has occurred on a socket while connecting to the cloud provider.	Timeout has occurred on a socket while connecting to the cloud provider.	Network connection problem.	Check trace messages and the error log for further details. Check whether the network connection is valid.
tct_account_sslbadcert	STATE_CHANGE	ERROR	Transparent cloud tiering is failed to connect to the cloud provider because of bad certificate.	Transparent cloud tiering is failed to connect to the cloud provider because of bad certificate.	Bad SSL certificate.	Check trace messages and error logs for further details.
tct_account_sslcerterror	STATE_CHANGE	ERROR	Transparent cloud tiering is failed to connect to the cloud provider because of the untrusted server certificate chain.	Transparent cloud tiering is failed to connect to the cloud provider because of untrusted server certificate chain.	Untrusted server certificate chain error.	Check trace messages and error logs for further details.
tct_account_sslerror	STATE_CHANGE	ERROR	Transparent cloud tiering is failed to connect to the cloud provider because of error the SSL subsystem.	Transparent cloud tiering is failed to connect to the cloud provider because of error the SSL subsystem.	Error in SSL subsystem.	Check trace messages and error logs for further details.
tct_account_sslhandshake error	STATE_CHANGE	ERROR	The cloud account status is failed due to unknown SSL handshake error.	The cloud account status is failed due to unknown SSL handshake error.	Transparent cloud tiering and cloud provider could not negotiate the desired level of security.	Check trace messages and error logs for further details.

Table 15. Events for the Transparent Cloud Tiering component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
tct_account_sslhandshake failed	STATE_CHANGE	ERROR	Transparent cloud tiering is failed to connect to the cloud provider because they could not negotiate the desired level of security.	Transparent cloud tiering is failed to connect to the cloud provider because they could not negotiate the desired level of security.	Transparent cloud tiering and cloud provider server could not negotiate the desired level of security.	Check trace messages and error logs for further details.
tct_account_sslinvalidalgo	STATE_CHANGE	ERROR	Transparent cloud tiering is failed to connect to the cloud provider because of invalid SSL algorithm parameters.	Transparent cloud tiering is failed to connect to the cloud provider because of invalid or inappropriate SSL algorithm parameters.	Invalid or inappropriate SSL algorithm parameters.	Check trace messages and error logs for further details.
gtct_account_sslinvalid paddin	STATE_CHANGE	ERROR	Transparent cloud tiering is failed to connect to the cloud provider because of invalid SSL padding.	Transparent cloud tiering is failed to connect to the cloud provider because of invalid SSL padding.	Invalid SSL padding.	Check trace messages and error logs for further details.
tct_account_sslnottrustedcert	STATE_CHANGE	ERROR	Transparent cloud tiering is failed to connect to the cloud provider because of not trusted server certificate.	Transparent cloud tiering is failed to connect to the cloud provider because of not trusted server certificate.	Cloud provider server SSL certificate is not trusted.	Check trace messages and error logs for further details.
gtct_account_sslunrecognized ms	STATE_CHANGE	ERROR	Transparent cloud tiering is failed to connect to the cloud provider because of unrecognized SSL message.	Transparent cloud tiering is failed to connect to the cloud provider because of unrecognized SSL message.	Unrecognized SSL message.	Check trace messages and error logs for further details.
tct_account_sslnocert	STATE_CHANGE	ERROR	Transparent cloud tiering is failed to connect to the cloud provider because of no available certificate.	Transparent cloud tiering is failed to connect to the cloud provider because of no available certificate.	No available certificate.	Check trace messages and error logs for further details.
tct_account_sslsocketclosed	STATE_CHANGE	ERROR	Transparent cloud tiering is failed to connect to the cloud provider because remote host closed connection during handshake.	Transparent cloud tiering is failed to connect to the cloud provider because remote host closed connection during handshake.	Remote host closed connection during handshake.	Check trace messages and error logs for further details.
tct_account_sslkeyerror	STATE_CHANGE	ERROR	Transparent cloud tiering is failed to connect cloud provider because of bad SSL key.	Transparent cloud tiering is failed to connect cloud provider because of bad SSL key or misconfiguration.	Bad SSL key or misconfiguration.	Check trace messages and error logs for further details.
tct_account_sslpeererror	STATE_CHANGE	ERROR	Transparent cloud tiering is failed to connect to the cloud provider because its identity has not been verified.	Transparent cloud tiering is failed to connect to the cloud provider because its identity is not verified.	Cloud provider identity is not verified.	Check trace messages and error logs for further details.

Table 15. Events for the Transparent Cloud Tiering component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
tct_account_sslprotocolerror	STATE_CHANGE	ERROR	Transparent cloud tiering is failed to connect cloud provider because of error in the operation of the SSL protocol.	Transparent cloud tiering is failed to connect cloud provider because of error in the operation of the SSL protocol.	SSL protocol implementation error.	Check trace messages and error logs for further details.
tct_account_sslunknowncert	STATE_CHANGE	ERROR	Transparent cloud tiering is failed to connect to the cloud provider because of unknown certificate.	Transparent cloud tiering is failed to connect to the cloud provider because of unknown certificate.	Unknown SSL certificate.	Check trace messages and error logs for further details.
tct_account_timeskewerror	STATE_CHANGE	ERROR	The time observed on the Transparent cloud tiering service node is not in sync with the time on target cloud provider.	The time observed on the Transparent cloud tiering service node is not in sync with the time on target cloud provider.	Current time stamp of Transparent cloud tiering service is not in sync with target cloud provider.	Change Transparent cloud tiering service node time stamp to be in sync with NTP server and rerun the operation.
tct_account_unknownerror	STATE_CHANGE	ERROR	The cloud provider account is not accessible due to unknown error.	The cloud provider account is not accessible due to unknown error.	Unknown runtime exception.	Check trace messages and error logs for further details.
tct_account_unreachable	STATE_CHANGE	ERROR	Cloud provider account URL is not reachable.	The cloud provider's URL is unreachable because either it is down or network issues.	The cloud provider URL is not reachable.	Check trace messages and the error log for further details. Check the DNS settings.
tct_fs_configured	STATE_CHANGE	INFO	The Transparent cloud tiering is configured with file system.	The Transparent cloud tiering is configured with file system.		N/A
tct_fs_notconfigured	STATE_CHANGE	WARNING	The Transparent cloud tiering is not configured with file system.	The Transparent cloud tiering is not configured with file system.	The Transparent cloud tiering is installed but file system is not configured or deleted.	Run the command mmcloudgateway filesystem create to configure the file system.
tct_service_down	STATE_CHANGE	ERROR	Transparent cloud tiering service is down.	The Transparent cloud tiering service is down and could not be started.	The mmcloudgateway service status command returns 'Stopped' as the status of the Transparent cloud tiering service.	Run the command mmcloudgateway service start to start the cloud gateway service.
tct_service_suspended	STATE_CHANGE	WARNING	Transparent cloud tiering service is suspended.	The Transparent cloud tiering service is suspended manually.	The mmcloudgateway service status command returns 'Suspended' as the status of the Transparent cloud tiering service.	Run the mmcloudgateway service start command to resume the Transparent cloud tiering service.
tct_service_up	STATE_CHANGE	INFO	Transparent cloud tiering service is up and running.	The Transparent cloud tiering service is up and running.		N/A

Table 15. Events for the Transparent Cloud Tiering component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
tct_service_warn	INFO	WARNING	Transparent cloud tiering monitoring returned unknown result.	The Transparent cloud tiering check returned unknown result.		Perform troubleshooting procedures.
tct_service_restart	INFO	WARNING	The Transparent cloud tiering service failed. Trying to recover.	Attempt to restart the Transparent cloud tiering process.	A problem with the Transparent cloud tiering process is detected.	N/A
tct_service_notconfigured	STATE_CHANGE	WARNING	Transparent cloud tiering is not configured.	The Transparent cloud tiering service was either not configured or never started.	The Transparent cloud tiering service was either not configured or never started.	Set up the Transparent cloud tiering and start its service.

Disk events

The following table lists the events that are created for the *DISK* component.

Table 16. Events for the DISK component

Event	Event Type	Severity	Message	Description	Cause	User Action
disk_down	STATE_CHANGE	WARNING	The disk {0} is down.	A disk is down.	This can indicate a hardware issue. This might be because of a hardware issue.	If the down state is unexpected, then refer the <i>Disk issues</i> section in the <i>IBM Spectrum Scale Troubleshooting Guide</i> and perform the troubleshooting procedures.
disk_up	STATE_CHANGE	INFO	The disk {0} is up.	Disk is up.	A disk was detected in up state.	N/A
disk_found	INFO	INFO	The disk {0} is detected.	A disk was detected.	A disk was detected.	N/A
disk_vanished	INFO	INFO	The disk {0} is not detected.	A declared disk is not detected.	A disk is not in use for a file system. This could be a valid situation. A disk is not available for a file system. This could be a valid situation that demands troubleshooting.	N/A

File system events

The following table lists the events that are created for the *file system* component.

Table 17. Events for the file system component

Event	Event Type	Severity	Message	Description	Cause	User Action
filesystem_found	INFO	INFO	The file system {0} is detected.	A file system listed in the IBM Spectrum Scale configuration was detected.	N/A	N/A

Table 17. Events for the file system component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
filesystem_vanished	INFO	INFO	The file system {0} is not detected.	A file system listed in the IBM Spectrum Scale configuration was not detected.	A file system, which is listed as a mounted file system in the IBM Spectrum Scale configuration, is not detected. This could be valid situation that demands troubleshooting.	Issue the mmismountall_tocall command to verify whether all the expected file systems are mounted.
fs_forced_unmount	STATE_CHANGE	ERROR	The file system {0} was {1} forced to unmount.	A file system was forced to unmount by IBM Spectrum Scale.	A situation like a kernel panic might have initiated the unmount process.	Check error messages and logs for further details. Also, see the <i>File system forced unmount</i> and <i>File system issues</i> topics in the IBM Spectrum Scale documentation.
fserrallocblock	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Msg={2}	Corrupted alloc segment detected while attempting to alloc disk block.	A file system corruption is detected.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_FSSTRUCT errors</i> topic.
fserrbadacref	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Msg={2}	File references invalid ACL.	A file system corruption is detected.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_FSSTRUCT errors</i> topic.

Table 17. Events for the file system component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
fserrbadblock	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Msg={2}	Invalid directory block.	A file system corruption is detected.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_FSSTRUCT errors</i> topic.
fserrbadindex	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Msg={2}	Bad disk index in disk address.	A file system corruption is detected.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_FSSTRUCT errors</i> topic.
fserrbadsector	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Msg={2}	Bad sector number in disk address or start sector plus length is exceeding the size of the disk.	A file system corruption is detected.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_FSSTRUCT errors</i> topic.

Table 17. Events for the file system component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
fserrbaddittoaddr	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Msg={2}	Invalid ditto address.	A file system corruption is detected.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> . topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_ FSSTRUCT errors</i> topic.
fserrbadinodeorgen	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Msg={2}	Deleted inode has a directory entry or the generation number do not match to the directory.	A file system corruption is detected.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> . topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_ FSSTRUCT errors</i> topic.
fserrbadinodestatus	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Msg={2}	Inode status is changed to <i>Bad</i> . The expected status is: <i>Deleted</i> .	A file system corruption is detected.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> . topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_ FSSTRUCT errors</i> topic.

Table 17. Events for the file system component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
fserrbadptrreplications	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Msg={2}	Invalid computed pointer replication factors.	Invalid computed pointer replication factors.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_ FSSTRUCT errors</i> topic.
fserrbadreplicationcounts	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Msg={2}	Invalid current or maximum data or metadata replication counts.	A file system corruption is detected.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_ FSSTRUCT errors</i> topic.
fserrbadxattrblock	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Msg={2}	Invalid extended attribute block.	A file system corruption is detected.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_ FSSTRUCT errors</i> topic.

Table 17. Events for the file system component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
fserrcheckheaderfailed	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Msg={2}	CheckHeader returned an error.	A file system corruption detected.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> . topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_ FSSTRUCT errors</i> topic.
fserrclonetree	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Msg={2}	Invalid cloned file tree structure.	A file system corruption detected.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> . topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_ FSSTRUCT errors</i> topic.
fserrdeallocblock	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Msg={2}	Corrupted alloc segment detected while attempting to dealloc the disk block.	A file system corruption detected.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> . topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_ FSSTRUCT errors</i> topic.

Table 17. Events for the file system component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
fserrdotdotnotfound	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Msg={2}	Unable to locate an entry.	A file system corruption detected.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_ FSSTRUCT errors</i> topic.
fserrgennummismatch	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Msg={2}	The generation number entry in '..' does not match with the actual generation number of the parent directory.	A file system corruption detected.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_ FSSTRUCT errors</i> topic.
fserrinconsistentfilesetrootdir	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Msg={2}	Inconsistent fileset or root directory. That is, fileset is in use, root dir '..' points to itself.	A file system corruption detected.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_ FSSTRUCT errors</i> topic.

Table 17. Events for the file system component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
fserrinconsistentfilesetsnapshot	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Msg={2}	Inconsistent fileset or snapshot records. That is, fileset snapList points to a SnapItem that does not exist.	A file system corruption detected.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_ FSSTRUCT errors</i> topic.
fserrinconsistentinode	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Msg={2}	Size data in inode are inconsistent.	A file system corruption detected.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_ FSSTRUCT errors</i> topic.
fserrindirectblock	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Msg={2}	Invalid indirect block header information in the inode.	A file system corruption detected.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_ FSSTRUCT errors</i> topic.

Table 17. Events for the file system component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
fserrindirectionlevel	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Msg={2}	Invalid indirection level in inode.	A file system corruption detected.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_ FSSTRUCT errors</i> topic.
fserrinodecorrupted	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Msg={2}	Infinite loop in the lfs layer because of a corrupted inode or directory entry.	A file system corruption detected.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_ FSSTRUCT errors</i> topic.
fserrinodenummismatch	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Msg={2}	The inode number that is found in the '..' entry does not match with the actual inode number of the parent directory.	A file system corruption detected.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_ FSSTRUCT errors</i> topic.

Table 17. Events for the file system component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
fserrinvalid	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Unknown error={2}.	Unrecognized FSSTRUCT error received.	A file system corruption detected.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> . topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_ FSSTRUCT errors</i> topic.
fserrinvalidfilesetmetadata record	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Unknown error={2}.	Invalid fileset metadata record.	A file system corruption detected.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> . topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_ FSSTRUCT errors</i> topic.
fserrinvalidsnapshotstates	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Unknown error={2}.	Invalid snapshot states. That is, more than one snapshot in an inode space is being emptied (SnapBeingDeleted One).	A file system corruption detected.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> . topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_ FSSTRUCT errors</i> topic.

Table 17. Events for the file system component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
fserrsnapinodemodified	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Unknown error={2}.	Inode was modified without saving old content to shadow inode file.	A file system corruption detected.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_FSSTRUCT errors</i> topic.
fserrvalidate	STATE_CHANGE	ERROR	The following error occurred for the file system {0}: ErrNo={1}, Unknown error={2}.	A file system corruption detected. Validation routine failed on a disk read.	A file system corruption detected.	Check error message and the <i>mmfs.log.latest</i> log for further details. For more information, see the <i>Checking and repairing a file system</i> and <i>Managing file systems</i> topics in the IBM Spectrum Scale documentation. If the file system is severely damaged, the best course of action is available in the <i>Additional information to collect for file system corruption or MMFS_FSSTRUCT errors</i> topic.
fsstruct_error	STATE_CHANGE	WARNING	The following structure error is detected in the file system {0}: Err={1} msg={2}.	A file system structure error is detected. This issue might cause different events.	A file system issue was detected.	Repair actions depend on the kind of error. See documentation.
fsstruct_fixed	STATE_CHANGE	INFO	The structure error reported for the file system {0} is marked as fixed.	A file system structure error is marked as fixed.	A file system issue was resolved.	N/A
fs_unmount_info	INFO	INFO	The file system {0} is unmounted {1}.	A file system is unmounted.	A file system is unmounted.	N/A
fs_remount_mount	STATE_CHANGE_EXTERNAL	INFO	The file system {0} is mounted.	A file system is mounted.	A new or previously unmounted file system is mounted.	N/A
mounted_fs_check	STATE_CHANGE	INFO	The file system {0} is mounted.	The file system is mounted.	A file system is mounted and no mount state mismatch information detected.	N/A

Table 17. Events for the file system component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
stale_mount	STATE_CHANGE	WARNING	Found stale mounts for the file system {0}.	A mount state information mismatch was detected between the details reported by the mm1smount command and the information that is stored in the /proc/mounts.	A file system might not be fully mounted or unmounted.	Issue the mm1smount all_local command to verify that all expected file systems are mounted.
unmounted_fs_ok	STATE_CHANGE	INFO	The file system {0} is probably needed, but not declared as automount.	An internally mounted or a declared but not mounted file system was detected.	A declared file system is not mounted.	N/A
unmounted_fs_check	STATE_CHANGE	WARNING	The file system {0} is probably needed, but not mounted.	An internally mounted or a declared but not mounted file system was detected.	A file system might not be fully mounted or unmounted.	Issue the mm1smount all_local command to verify that all expected file systems are mounted.

GPFS events

The following table lists the events that are created for the GPFS component.

Table 18. Events for the GPFS component

Event	Event Type	Severity	Message	Description	Cause	User Action
ccr_client_init_ok	STATE_CHANGE	INFO	GPFS CCR client initialization is ok {0}.	GPFS CCR client initialization is ok.	N/A	N/A
ccr_client_init_fail	STATE_CHANGE	ERROR	GPFS CCR client initialization failed Item={0},ErrMsg={1}, Failed={2}.	GPFS CCR client initialization failed. See message for details.	The item specified in the message is either not available or corrupt.	Recover this degraded node from a still intact node by using the mmsdrrestore -p <NODE> command with <NODE> specifying the intact node. See the man page of the mmsdrrestore for more details.
ccr_client_init_warn	STATE_CHANGE	WARNING	GPFS CCR client initialization failed Item={0},ErrMsg={1}, Failed={2}.	GPFS CCR client initialization failed. See message for details.	The item specified in the message is either not available or corrupt.	Recover this degraded node from a still intact node by using the mmsdrrestore -p <NODE> command with <NODE> specifying the intact node. See the man page of the mmsdrrestore for more details.
ccr_auth_keys_ok	STATE_CHANGE	INFO	The security file used by GPFS CCR is ok {0}.	The security file used by GPFS CCR is ok.	N/A	N/A

Table 18. Events for the GPFS component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
ccr_auth_keys_fail	STATE_CHANGE	ERROR	The security file used by GPFS CCR is corrupt Item={0},ErrMsg={1}, Failed={2}	The security file used by GPFS CCR is corrupt. See message for details.	Either the security file is missing or corrupt.	Recover this degraded node from a still intact node by using the mmsdrrestore -p <NODE> command with <NODE> specifying the intact node. See the man page of the mmsdrrestore for more details.
ccr_paxos_cached_ok	STATE_CHANGE	INFO	The stored GPFS CCR state is ok {0}	The stored GPFS CCR state is ok.		N/A
ccr_paxos_cached_fail	STATE_CHANGE	ERROR	The stored GPFS CCR state is corrupt Item={0},ErrMsg={1}, Failed={2}	The stored GPFS CCR state is corrupt. See message for details.	Either the stored GPFS CCR state file is corrupt or empty.	Recover this degraded node from a still intact node by using the mmsdrrestore -p <NODE> command with <NODE> specifying the intact node. See the man page of the mmsdrrestore for more details.
ccr_paxos_12_fail	STATE_CHANGE	ERROR	The stored GPFS CCR state is corrupt Item={0},ErrMsg={1}, Failed={2}	The stored GPFS CCR state is corrupt. See message for details.	tbd	Recover this degraded node from a still intact node by using the mmsdrrestore -p <NODE> command with <NODE> specifying the intact node. See the man page of the mmsdrrestore for more details.
ccr_paxos_12_ok	STATE_CHANGE	INFO	The stored GPFS CCR state is ok {0}	The stored GPFS CCR state is ok.	N/A	N/A
ccr_paxos_12_warn	STATE_CHANGE	WARNING	The stored GPFS CCR state is corrupt Item={0},ErrMsg={1}, Failed={2}	The stored GPFS CCR state is corrupt. See message for details.	One stored GPFS state file is missing or corrupt.	No user action necessary, GPFS will repair this automatically.
ccr_local_server_ok	STATE_CHANGE	INFO	The local GPFS CCR server is reachable {0}	The local GPFS CCR server is reachable.	N/A	N/A
ccr_local_server_warn	STATE_CHANGE	WARNING	The local GPFS CCR server is not reachable Item={0},ErrMsg={1}, Failed={2}	The local GPFS CCR server is not reachable. See message for details.	Either the local network or firewall is not configured properly or the local GPFS daemon is not responding.	Check the network and firewall configuration with regards to the used GPFS communication port (default: 1191). Restart GPFS on this node.

Table 18. Events for the GPFS component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
ccr_ip_lookup_ok	STATE_CHANGE	INFO	The IP address lookup for the GPFS CCR component is ok {0}	The IP address lookup for the GPFS CCR component is ok.	N/A	N/A
ccr_ip_lookup_warn	STATE_CHANGE	WARNING	The IP address lookup for the GPFS CCR component takes too long. Item={0},ErrMsg={1}, Failed={2}	The IP address lookup for the GPFS CCR component takes too long, resulting in slow administration commands. See message for details.	Either the local network or the DNS is misconfigured.	Check the local network and DNS configuration.
ccr_quorum_nodes_fail	STATE_CHANGE	ERROR	A majority of the quorum nodes are not reachable over the management network. Item={0},ErrMsg={1}, Failed={2}	A majority of the quorum nodes are not reachable over the management network. GPFS declares quorum loss. See message for details.	Due to the misconfiguration of network or firewall, the quorum nodes cannot communicate with each other.	Check the network and firmware (default port 1191 must not be blocked) configuration of the quorum nodes that are not reachable.
ccr_quorum_nodes_ok	STATE_CHANGE	INFO	All quorum nodes are reachable {0}	All quorum nodes are reachable.	N/A	N/A
ccr_quorum_nodes_warn	STATE_CHANGE	WARNING	Clustered Configuration Repository issue with Item={0},ErrMsg={1}, Failed={2}	At least one quorum node is not reachable. See message for details.	The quorum node is not reachable due to the network or firewall misconfiguration.	Check the network and firmware (default port 1191 must not be blocked) configuration of the quorum node that is not reachable.
ccr_comm_dir_fail	STATE_CHANGE	ERROR	The files committed to the GPFS CCR are not complete or corrupt. Item={0},ErrMsg={1}, Failed={2}	The files committed to the GPFS CCR are not complete or corrupt. See message for details.	The local disk might be full.	Check the local disk space and remove the unnecessary files. Recover this degraded node from a still intact node by using the mmsdrrestore -p <NODE> command with <NODE> specifying the intact node. See the man page of the mmsdrrestore command for more details.
ccr_comm_dir_ok	STATE_CHANGE	INFO	The files committed to the GPFS CCR are complete and intact {0}	The files committed to the GPFS CCR are complete and intact..	N/A	N/A

Table 18. Events for the GPFS component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
ccr_comm_dir_warn	STATE_CHANGE	WARNING	The files committed to the GPFS CCR are not complete or corrupt Item={0},ErrMsg={1}, Failed={2}	The files committed to the GPFS CCR are not complete or corrupt. See message for details.	The local disk might be full.	Check the local disk space and remove the unnecessary files. Recover this degraded node from a still intact node by using the mmsdrrestore -p <NODE> command with <NODE> specifying the intact node. See the man page of the mmsdrrestore command for more details.
ccr_tiebreaker_dsk_fail	STATE_CHANGE	ERROR	Access to tiebreaker disks failed Item={0},ErrMsg={1}, Failed={2}	Access to all tiebreaker disks failed. See message for details.	Corrupted disk.	Check whether the tiebreaker disks are available.
ccr_tiebreaker_dsk_ok	STATE_CHANGE	INFO	All tiebreaker disks used by the GPFS CCR are accessible {0}	All tiebreaker disks used by the GPFS CCR are accessible.	N/A	N/A
ccr_tiebreaker_dsk_warn	STATE_CHANGE	WARNING	At least one tiebreaker disk is not accessible Item={0},ErrMsg={1}, Failed={2}	At least one tiebreaker disk is not accessible. See message for details.	Corrupted disk.	Check whether the tiebreaker disks are accessible.
cluster_state_manager_reset	INFO	INFO	Clear memory of cluster state manager for this node.	A reset request for the monitor state manager is received.	A reset request for the monitor state manager is received.	N/A
nodeleave_info	INFO	INFO	The CES node {0} left the cluster.	Shows the name of the node that leaves the cluster. This event might be logged on a different node; not necessarily on the leaving node.	A CES node left the cluster. The name of the leaving node is provided.	N/A
nodestatechange_info	INFO	INFO	Message: A CES node state change: Node {0} {1} {2} flag	Shows the modified node state. For example, the node turned to suspended mode, network down.	A node state change was detected. Details are shown in the message.	N/A

Table 18. Events for the GPFS component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
quorumloss	INFO	WARNING	The cluster detected a quorum loss.	The number of required quorum nodes does not match the minimum requirements. This can be an expected situation.	The cluster is in inconsistent or split-brain state. Reasons could be network or hardware issues, or quorum nodes are removed from the cluster. The event might not be logged on the same node that causes the quorum loss.	Recover from the underlying issue. Make sure the cluster nodes are up and running.
gpfs_down	STATE_CHANGE	ERROR	The IBM Spectrum Scale service is not running on this node. Normal operation cannot be done.	The IBM Spectrum Scale service is not running. This can be an expected state when the IBM Spectrum Scale service is shut down.	The IBM Spectrum Scale service is not running.	Check the state of the IBM Spectrum Scale file system daemon, and check for the root cause in the <code>/var/adm/ras/mmfs.log.latest</code> log.
gpfs_up	STATE_CHANGE	INFO	The IBM Spectrum Scale service is running.	The IBM Spectrum Scale service is running.	The IBM Spectrum Scale service is running.	N/A
gpfs_warn	INFO	WARNING	IBM Spectrum Scale process monitoring returned unknown result. This could be a temporary issue.	Check of the IBM Spectrum Scale file system daemon returned unknown result. This could be a temporary issue, like a timeout during the check procedure.	The IBM Spectrum Scale file system daemon state could not be determined due to a problem.	Find potential issues for this kind of failure in the <code>/var/adm/ras/mmsysmonitor.log</code> file.
info_on_duplicate_events	INFO	INFO	The event {0}{id} was repeated {1} times	Multiple messages of the same type were deduplicate to avoid log flooding.	Multiple events of the same type processed.	N/A
shared_root_bad	STATE_CHANGE	ERROR	Shared root is unavailable.	The CES shared root file system is bad or not available. This file system is required to run the cluster because it stores the cluster-wide information. This problem triggers a failover.	The CES framework detects the CES shared root file system to be unavailable on the node.	Check if the CES shared root file system and other expected IBM Spectrum Scale file systems are mounted properly.

Table 18. Events for the GPFS component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
shared_root_ok	STATE_CHANGE	INFO	Shared root is available.	The CES shared root file system is available. This file system is required to run the cluster because it stores cluster-wide information.	The CES framework detects the CES shared root file system to be OK.	N/A
quorum_down	STATE_CHANGE	ERROR	A quorum loss is detected.	The monitor service has detected a quorum loss. Reasons could be network or hardware issues, or quorum nodes are removed from the cluster. The event might not be logged on the node that causes the quorum loss.	The local node does not have quorum. It might be in an inconsistent or split-brain state.	Check whether the cluster quorum nodes are running and can be reached over the network. Check local firewall settings.
quorum_up	STATE_CHANGE	INFO	Quorum is detected.	The monitor detected a valid quorum.		N/A
quorum_warn	INFO	WARNING	The IBM Spectrum Scale quorum monitor could not be executed. This could be a timeout issue	The quorum state monitoring service returned an unknown result. This might be a temporary issue, like a timeout during the monitoring procedure.	The quorum state could not be determined due to a problem.	Find potential issues for this kind of failure in the <code>/var/adm/ras/mmsysmonitor.log</code> file.
deadlock_detected	INFO	WARNING	The cluster detected a IBM Spectrum Scale file system deadlock	The cluster detected a deadlock in the IBM Spectrum Scale file system.	High file system activity might cause this issue.	The problem might be temporary or permanent. Check the <code>/var/adm/ras/mmfs.log.latest</code> log files for more detailed information.
gpfsport_access_up	STATE_CHANGE	INFO	Access to IBM Spectrum Scale ip {0} port {1} ok	The TCP access check of the local IBM Spectrum Scale file system daemon port is successful.	The IBM Spectrum Scale file system service access check is successful.	N/A

Table 18. Events for the GPFS component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
gpfsport_down	STATE_CHANGE	ERROR	IBM Spectrum Scale port {0} is not active	The expected local IBM Spectrum Scale file system daemon port is not detected.	The IBM Spectrum Scale file system daemon is not running.	Check whether the IBM Spectrum Scale service is running.
gpfsport_access_down	STATE_CHANGE	ERROR	No access to IBM Spectrum Scale ip {0} port {1}. Check firewall settings	The access check of the local IBM Spectrum Scale file system daemon port is failed.	The port is probably blocked by a firewall rule.	Check whether the IBM Spectrum Scale file system daemon is running and check the firewall for blocking rules on this port.
gpfsport_up	STATE_CHANGE	INFO	IBM Spectrum Scale port {0} is active	The expected local IBM Spectrum Scale file system daemon port is detected.	The expected local IBM Spectrum Scale file system daemon port is detected.	N/A
gpfsport_warn	INFO	WARNING	IBM Spectrum Scale monitoring ip {0} port {1} returned unknown result	The IBM Spectrum Scale file system daemon port returned an unknown result.	The IBM Spectrum Scale file system daemon port could not be determined due to a problem.	Find potential issues for this kind of failure in the logs.
gpfsport_access_warn	INFO	WARNING	IBM Spectrum Scale access check ip {0} port {1} failed. Check for valid IBM Spectrum Scale-IP	The access check of the IBM Spectrum Scale file system daemon port returned an unknown result.	The IBM Spectrum Scale file system daemon port access could not be determined due to a problem.	Find potential issues for this kind of failure in the logs.
longwaiters_found	STATE_CHANGE	ERROR	Detected IBM Spectrum Scale long-waiters.	Longwaiter threads found in the IBM Spectrum Scale file system.	High load might cause this issue.	Check log files. This could be also a temporary issue.
no_longwaiters_found	STATE_CHANGE	INFO	No IBM Spectrum Scale long-waiters	No longwaiter threads found in the IBM Spectrum Scale file system.	No longwaiter threads found in the IBM Spectrum Scale file system.	N/A
longwaiters_warn	INFO	WARNING	IBM Spectrum Scale long-waiters monitoring returned unknown result.	The long waiters check returned an unknown result.	The IBM Spectrum Scale file system long waiters check could not be determined due to a problem.	Find potential issues for this kind of failure in the logs.
quorumreached_detected	INFO	INFO	Quorum is achieved.	The cluster has achieved quorum.	The cluster has achieved quorum.	N/A

GUI events

The following table lists the events that are created for the *GUI* component.

Table 19. Events for the GUI component

Event	Event Type	Severity	Message	Description	Cause	User Action
gui_down	STATE_CHANGE	ERROR	The status of the GUI service must be {0} but it is {1} now.	The GUI service is down.	The GUI service is not running on this node, although it has the node class GUI_MGMT_SERVER_NODE.	Restart the GUI service or change the node class for this node.
gui_up	STATE_CHANGE	INFO	The status of the GUI service is {0} as expected.	The GUI service is running	The GUI service is running as expected.	N/A
gui_warn	INFO	INFO	The GUI service returned an unknown result.	The GUI service returned an unknown result.	The service or systemctl command returned unknown results about the GUI service.	Use either the service or systemctl command to check whether the GUI service is in the expected status. If there is no gpfs GUI service although the node has the node class GUI_MGMT_SERVER_NODE, see the GUI documentation. Otherwise, monitor whether this warning appears more often.
gui_reachable_node	STATE_CHANGE	INFO	The GUI can reach the node {0}.	The GUI checks the reachability of all nodes.	The specified node can be reached by the GUI node.	None.
gui_unreachable_node	STATE_CHANGE	ERROR	The GUI can not reach the node {0}.	The GUI checks the reachability of all nodes.	The specified node can not be reached by the GUI node.	Check your firewall or network setup and if the specified node is up and running.
gui_cluster_up	STATE_CHANGE	INFO	The GUI detected that the cluster is up and running.	The GUI checks the cluster state.	The GUI calculated that a sufficient amount of quorum nodes is up and running.	None.
gui_cluster_down	STATE_CHANGE	ERROR	The GUI detected that the cluster is down.	The GUI checks the cluster state.	The GUI calculated that an insufficient amount of quorum nodes is up and running.	Check why the cluster lost quorum.
gui_cluster_state_unknown	STATE_CHANGE	WARNING	The GUI can not determine the cluster state.	The GUI checks the cluster state.	The GUI can not determine if a sufficient amount of quorum nodes is up and running.	None.
time_in_sync	STATE_CHANGE	INFO	The time on node {0} is in sync with the clusters median.	The GUI checks the time on all nodes.	The time on the specified node is in sync with the cluster median.	None.
time_not_in_sync	STATE_CHANGE	NODE	The time on node {0} is not in sync with the clusters median.	The GUI checks the time on all nodes.	The time on the specified node is not in sync with the cluster median.	Synchronize the time on the specified node.
time_sync_unknown	STATE_CHANGE	WARNING	The time on node {0} could not be determined.	The GUI checks the time on all nodes.	The time on the specified node could not be determined.	Check if the node is reachable from the GUI.

Table 19. Events for the GUI component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
gui_pmcollector_connection_failed	STATE_CHANGE	ERROR	The GUI can not connect to the pmcollector running on {0} using port {1}.	The GUI checks the connection to the pmcollector.	The GUI can not connect to the pmcollector.	Check if the pmcollector service is running and the verify the firewall/network settings.
gui_pmcollector_connection_ok	STATE_CHANGE	INFO	The GUI can connect to the pmcollector running on {0} using port {1}.	The GUI checks the connection to the pmcollector.	The GUI can connect to the pmcollector.	None.
host_disk_normal	STATE_CHANGE	INFO	The local file systems on node {0} reached a normal level.	The GUI checks the fill level of the local file systems.	The fill level of the local file systems is ok.	None.
host_disk_filled	STATE_CHANGE	WARNING	A local file system on node {0} reached a warning level. {1}	The GUI checks the fill level of the local file systems.	The local file systems reached a warning level.	Delete data on the local disk.
host_disk_full	STATE_CHANGE	ERROR	A local file system on node {0} reached a nearly exhausted level. {1}	The GUI checks the fill level of the local filesystems.	The local file systems reached a nearly exhausted level.	Delete data on the local disk.
host_disk_unknown	STATE_CHANGE	WARNING	The fill level of local file systems on node {0} is unknown.	The GUI checks the fill level of the local filesystems.	Could not determine fill state of the local filesystems.	None.
xcat_nodelist_unknown	STATE_CHANGE	WARNING	State of the node {0} in xCAT is unknown.	The GUI checks if xCAT can manage the node.	The state of the node within xCAT could not be determined.	None.
xcat_nodelist_ok	STATE_CHANGE	INFO	The node {0} is known by xCAT.	The GUI checks if xCAT can manage the node.	xCAT knows about the node and manages it.	None.
xcat_nodelist_missing	STATE_CHANGE	ERROR	The node {0} is unknown by xCAT.	The GUI checks if xCAT can manage the node.	The xCAT does not know about the node.	Add the node to xCAT and ensure that the host name used in xCAT matches the host name known by the node itself.
xcat_state_unknown	STATE_CHANGE	WARNING	Availability of xCAT on cluster {0} is unknown.	The GUI checks the xCAT state.	The availability and state of xCAT could not be determined.	None.
xcat_state_ok	STATE_CHANGE	INFO	The availability of xCAT on cluster {0} is OK.	The GUI checks the xCAT state.	The availability and state of xCAT is OK.	None.
xcat_state_unconfigured	STATE_CHANGE	WARNING	The xCAT host is not configured on cluster {0}.	The GUI checks the xCAT state.	The host where xCAT is located is not specified.	Specify the host name or IP where xCAT is located.
xcat_state_no_connection	STATE_CHANGE	ERROR	Unable to connect to xCAT node {1} on cluster {0}.	The GUI checks the xCAT state.	Cannot connect to the node specified as xCAT host.	Check that the IP address is correct and ensure that root does have key-based SSH set up to the xCAT node.
xcat_state_error	STATE_CHANGE	INFO	The xCAT on node {1} failed to operate properly on cluster {0}.	The GUI checks the xCAT state.	The node specified as xCAT host is reachable but either xCAT is not installed on the node or not operating properly.	Check xCAT installation and try xCAT commands ninv and rvitals for errors.

Table 19. Events for the GUI component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
xcat_state_invalid_version	STATE_CHANGE	WARNING	The xCAT service has not the recommended version ({1} actual/recommended)	The GUI checks the xCAT state.	The reported version of xCAT is not compliant with the recommendation.	Install the recommended xCAT version.
sudo_ok	STATE_CHANGE	INFO	Sudo wrappers were enabled on the cluster and the GUI configuration for the cluster '{0}' is correct.	No problems regarding the current configuration of the GUI and the cluster were found.		N/A
sudo_admin_not_configured	STATE_CHANGE	ERROR	Sudo wrappers are enabled on the cluster '{0}', but the GUI is not configured to use Sudo Wrappers.	Sudo wrappers are enabled on the cluster, but the value for GPFS_ADMIN in /usr/lpp/mmfs/gui/conf/gpfsgui.properties was either not set or is still set to root. The value of GPFS_ADMIN should be set to the user name for which sudo wrappers were configured on the cluster.		Make sure that sudo wrappers were correctly configured for a user that is available on the GUI node and all other nodes of the cluster. This user name should be set as the value of the GPFS_ADMIN option in /usr/lpp/mmfs/gui/conf/gpfsgui.properties. After that restart the GUI using 'systemctl restart gpfsgui'.
sudo_admin_not_exist	STATE_CHANGE	ERROR	Sudo wrappers are enabled on the cluster '{0}', but there is a misconfiguration regarding the user '{1}' that was set as GPFS_ADMIN in the GUI properties file.	Sudo wrappers are enabled on the cluster, but the user name that was set as GPFS_ADMIN in the GUI properties file at /usr/lpp/mmfs/gui/conf/gpfsgui.properties does not exist on the GUI node.		Make sure that sudo wrappers were correctly configured for a user that is available on the GUI node and all other nodes of the cluster. This user name should be set as the value of the GPFS_ADMIN option in /usr/lpp/mmfs/gui/conf/gpfsgui.properties. After that restart the GUI using 'systemctl restart gpfsgui'.

Table 19. Events for the GUI component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
sudo_connect_error	STATE_CHANGE	ERROR	Sudo wrappers are enabled on the cluster '{0}', but the GUI cannot connect to other nodes with the user name '{1}' that was defined as GPFS_ADMIN in the GUI properties file.	When sudo wrappers are configured and enabled on a cluster, the GUI does not execute commands as root, but as the user for which sudo wrappers were configured. This user should be set as GPFS_ADMIN in the GUI properties file at /usr/lpp/mmfs/gui/conf/gpfsgui.properties		Make sure that sudo wrappers were correctly configured for a user that is available on the GUI node and all other nodes of the cluster. This user name should be set as the value of the GPFS_ADMIN option in /usr/lpp/mmfs/gui/conf/gpfsgui.properties. After that restart the GUI using 'systemctl restart gpfsgui'.
sudo_admin_set_but_disabled	STATE_CHANGE	WARNING	Sudo wrappers are not enabled on the cluster '{0}', but GPFS_ADMIN was set to a non-root user.	Sudo wrappers are not enabled on the cluster, but the value for GPFS_ADMIN in /usr/lpp/mmfs/gui/conf/gpfsgui.properties was set to a non-root user. The value of GPFS_ADMIN should be set to 'root' when sudo wrappers are not enabled on the cluster.</explanation>		Set GPFS_ADMIN in /usr/lpp/mmfs/gui/conf/gpfsgui.properties to 'root'. After that restart the GUI using 'systemctl restart gpfsgui'.
gui_config_cluster_id_ok	STATE_CHANGE	INFO	The cluster ID of the current cluster '{0}' and the cluster ID in the database do match.	No problems regarding the current configuration of the GUI and the cluster were found.		N/A
gui_config_cluster_id_mismatch	STATE_CHANGE	ERROR	The cluster ID of the current cluster '{0}' and the cluster ID in the database do not match ('{1}'). It seems that the cluster was recreated.	When a cluster is deleted and created again, the cluster ID changes, but the GUI's database still references the old cluster ID.		Clear the GUI's database of the old cluster information by dropping all tables: psql postgres postgres -c 'drop schema fscs cascade'. Then restart the GUI (systemctl restart gpfsgui).

Table 19. Events for the GUI component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
gui_config_command_audit_ok	STATE_CHANGE	INFO	Command Audit is turned on on cluster level.	Command Audit is turned on on cluster level. This way the GUI will refresh the data it displays automatically when Spectrum Scale commands are executed via the CLI on other nodes in the cluster.		N/A
gui_config_command_audit_off_cluster	STATE_CHANGE	WARNING	Command Audit is turned off on cluster level.	Command Audit is turned off on cluster level. This configuration will lead to lags in the refresh of data displayed in the GUI.	Command Audit is turned off on cluster level.	Change the cluster configuration option <code>\commandAudit\</code> to 'on' (mmchconfig commandAudit=on) or 'syslogonly' (mmchconfig commandAudit=syslogonly). This way the GUI will refresh the data it displays automatically when Spectrum Scale commands are executed via the CLI on other nodes in the cluster.
gui_config_command_audit_off_nodes	STATE_CHANGE	WARNING	Command Audit is turned off on the following nodes: {1}	Command Audit is turned off on some nodes. This configuration will lead to lags in the refresh of data displayed in the GUI.	Command Audit is turned off on some nodes.	Change the cluster configuration option 'commandAudit' to 'on' (mmchconfig commandAudit=on -N [node name]) or 'syslogonly' (mmchconfig commandAudit=syslogonly -N [node name]) for the affected nodes. This way the GUI will refresh the data it displays automatically when Spectrum Scale commands are executed via the CLI on other nodes in the cluster.

Table 19. Events for the GUI component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
gui_pmsensors_connection_failed	STATE_CHANGE	ERROR	The performance monitoring sensor service 'pmsensors' on node {0} is not sending any data.	The GUI checks if data can be retrieved from the pmcollector service for this node.	The performance monitoring sensor service 'pmsensors' is not sending any data. The service might be down or the time of the node is more than 15 minutes away from the time on the node hosting the performance monitoring collector service 'pmcollector'.	Check with 'systemctl status pmsensors'. If pmsensors service is 'inactive', run 'systemctl start pmsensors'.
gui_pmsensors_connection_ok	STATE_CHANGE	INFO	The state of performance monitoring sensor service 'pmsensor' on node {0} is OK.	The GUI checks if data can be retrieved from the pmcollector service for this node.	The state of performance monitoring sensor service 'pmsensor' is OK and it is sending data.	None.
gui_snap_running	INFO	WARNING	Operations for rule {1} are still running at the start of the next management of rule {1}.	Operations for a rule are still running at the start of the next management of that rule	Operations for a rule are still running.	None.
gui_snap_rule_ops_exceeded	INFO	WARNING	The number of pending operations exceeds {1} operations for rule {2}.	The number of pending operations for a rule exceed a specified value.	The number of pending operations for a rule exceed a specified value.	None.
gui_snap_total_ops_exceeded	INFO	WARNING	The total number of pending operations exceeds {1} operations.	The total number of pending operations exceed a specified value.	The total number of pending operations exceed a specified value.	None.
gui_snap_time_limit_exceeded_fset	INFO	WARNING	A snapshot operation exceeds {1} minutes for rule {2} on file system {3}, file set {0}.	The snapshot operation resulting from the rule is exceeding the established time limit.	A snapshot operation exceeds a specified number of minutes.	None.
gui_snap_time_limit_exceeded_fs	INFO	WARNING	A snapshot operation exceeds {1} minutes for rule {2} on file system {0}.	The snapshot operation resulting from the rule is exceeding the established time limit.	A snapshot operation exceeds a specified number of minutes.	None.
gui_snap_create_failed_fset	INFO	ERROR	A snapshot creation invoked by rule {1} failed on file system {2}, file set {0}.	The snapshot was not created according to the specified rule.	A snapshot creation invoked by a rule fails.	Try to create the snapshot again manually.
gui_snap_create_failed_fs	INFO	ERROR	A snapshot creation invoked by rule {1} failed on file system {0}.	The snapshot was not created according to the specified rule.	A snapshot creation invoked by a rule fails.	Try to create the snapshot again manually.
gui_snap_delete_failed_fset	INFO	ERROR	A snapshot deletion invoked by rule {1} failed on file system {2}, file set {0}.	The snapshot was not deleted according to the specified rule.	A snapshot deletion invoked by a rule fails.	Try to manually delete the snapshot.

Table 19. Events for the GUI component (continued)

Event	Event Type	Severity	Message	Description	Cause	User Action
gui_snap_delete_failed_fs	INFO	ERROR	A snapshot deletion invoked by rule {1} failed on file system {0}.	The snapshot was not deleted according to the specified rule.	A snapshot deletion invoked by a rule fails.	Try to manually delete the snapshot.

Hadoop connector events

The following table lists the events that are created for the *HadoopConnector* component.

Table 20. Events for the HadoopConnector component

Event	Event type	Severity	Message	Description	Cause	User Action
hadoop_datanode_down	STATE_CHANGE	ERROR	Hadoop DataNode service is down.	The Hadoop DataNode service is down.	The Hadoop DataNode process is not running.	Start the Hadoop DataNode service.
hadoop_datanode_up	STATE_CHANGE	INFO	Hadoop DataNode service is up.	The Hadoop DataNode service is running.	The Hadoop DataNode process is running.	N/A
hadoop_datanode_warn	INFO	WARNING	Hadoop DataNode monitoring returned unknown results.	The Hadoop DataNode service check returned unknown results.	The Hadoop DataNode service status check returned unknown results.	If this status persists after a few minutes, restart the DataNode service.
hadoop_namenode_down	STATE_CHANGE	ERROR	Hadoop NameNode service is down.	The Hadoop NameNode service is down.	The Hadoop NameNode process is not running.	Start the Hadoop NameNode service.
hadoop_namenode_up	STATE_CHANGE	INFO	Hadoop NameNode service is up.	The Hadoop NameNode service is running.	The Hadoop NameNode process is running.	N/A
hadoop_namenode_warn	INFO	WARNING	Hadoop NameNode monitoring returned unknown results.	The Hadoop NameNode service status check returned unknown results.		If this status persists after a few minutes, restart the NameNode service.

Keystone events

The following table lists the events that are created for the *KEYSTONE* component.

Table 21. Events for the KEYSTONE component

Event	EventType	Severity	Message	Description	Cause	User action
ks_failed	STATE_CHANGE	ERROR	The status of the keystone (httpd) process must be {0} but it is {1} now.	The keystone (httpd) process is not in the expected state.	If the object authentication is local, the AD or LDAP process is failed unexpectedly. If the object authentication is none or user-defined, the process is not stopped as expected.	Perform the troubleshooting procedure.
ks_ok	STATE_CHANGE	INFO	The status of the keystone (httpd) is {0} as expected.	The keystone (httpd) process is in the expected state.	If the object authentication is local, the AD or LDAP process is running. If the object authentication is none or user-defined, then the process is stopped as expected.	N/A
ks_restart	INFO	WARNING	The {0} service is failed. Trying to recover.			
ks_url_exfail	STATE_CHANGE	WARNING	Keystone request failed due to {0}.			
ks_url_failed	STATE_CHANGE	ERROR	The {0} request to keystone is failed.	A keystone URL request failed.	An HTTP request to keystone failed.	Check that httpd / keystone is running on the expected server and is accessible with the defined ports.
ks_url_ok	STATE_CHANGE	INFO	The {0} request to keystone is successful.	A keystone URL request was successful.	A HTTP request to keystone returned successfully.	N/A
ks_url_warn	INFO	WARNING	Keystone request on {0} returned unknown result.	A keystone URL request returned an unknown result.	A simple HTTP request to keystone returned with an unexpected error.	Check that httpd / keystone is running on the expected server and is accessible with the defined ports.
ks_warn	INFO	WARNING	Keystone (httpd) process monitoring returned unknown result.	The keystone (httpd) monitoring returned an unknown result.	A status query for httpd returned an unexpected error.	Check service script and settings of httpd.
postgresql_failed	STATE_CHANGE	ERROR	The status of the postgresql-obj process must be {0} but it is {1} now.	The postgresql-obj process is in an unexpected mode.	The database backend for object authentication is supposed to run on a single node. Either the database is not running on the designated node or it is running on a different node.	Check that postgresql-obj is running on the expected server.

Table 21. Events for the KEYSTONE component (continued)

Event	EventType	Severity	Message	Description	Cause	User action
postgresql_ok	STATE_CHANGE	INFO	The status of the postgresql-obj process is {0} as expected.	The postgresql-obj process is in the expected mode.	The database backend for object authentication is supposed to run on the right node while being stopped on other nodes.	N/A
postgresql_warn	INFO	WARNING	The status of the postgresql-obj process monitoring returned unknown result.	The postgresql-obj process monitoring returned an unknown result.	A status query for postgresql-obj returned with an unexpected error.	Check postgres database engine.

NFS events

The following table lists the events that are created for the NFS component.

Table 22. Events for the NFS component

Event	EventType	Severity	Message	Description	Cause	User Action
dbus_error	STATE_CHANGE	WARNING	DBus availability check failed.	DBus availability check failed.	The DBus was detected as down. This might cause several issues on the local node.	Stop the NFS service, restart the DBus, and start the NFS service again.
disable_nfs_service	INFO	INFO	CES NFS service is disabled.	The NFS service is disabled on this node. Disabling a service also removes all configuration files. This is different from stopping a service.	The user issued mmces service disable nfs command to disable the NFS service.	N/A
enable_nfs_service	INFO	INFO	CES NFS service is enabled.	The NFS service is enabled on this node. Enabling a protocol service also automatically installs the required configuration files with the current valid configuration settings.	The user enabled NFS services by issuing the mmces service enable nfs command.	N/A
ganeshaexit	INFO	INFO	CES NFS is stopped.	An NFS server instance has terminated.	An NFS instance is terminated somehow.	Restart the NFS service when the root cause for this issue is solved.
ganeshaGrace	INFO	INFO	CES NFS is set to grace mode.	The NFS server is set to grace mode for a limited time. This gives time to the previously connected clients to recover their file locks.	The grace period is always cluster wide. NFS export configurations might have changed, and one or more NFS servers were restarted.	N/A

Table 22. Events for the NFS component (continued)

Event	EventType	Severity	Message	Description	Cause	User Action
nfs3_down	INFO	WARNING	NFSv3 NULL check is failed.	The NFSv3 NULL check failed when expected it to be functioning. The NFSv3 NULL verifies whether the NFS server reacts on NFSv3 requests. The NFSv3 protocol must be enabled for this check. If this down state is detected, further checks are done to figure out if the NFS server is working. If the NFS server seems to be not working, then a failover is triggered. If NFSv3 and NFSv4 protocols are configured, then only the NFSv3 NULL test is performed.	The NFS server might hang or is under high load so that the request might not be processed.	Check the health state of the NFS server and restart, if necessary.
nfs3_up	INFO	INFO	NFSv4 NULL check is successful.	The NFSv4 NULL check is successful.	The NFS v4 NULL check works as expected.	N/A
nfs4_down	INFO	WARNING	NFSv4 NULL check is failed.	The NFSv4 NULL check failed. The NFSv4 NULL check verifies whether the NFS server reacts on the NFSv4 requests. The NFSv4 protocol must be enabled for this check. If this down state is detected, further checks are done to figure out if the NFS server is working. If the NFS server is not working, then a failover is triggered.	The NFS server might hang or is under high load so that the request might not be processed.	Check the health state of the NFS server and restart, if necessary.
nfs4_up	INFO	INFO	NFSv4 NULL check is successful.	The NFS v4 NULL check was successful.	The NFS v4 NULL check works as expected.	N/A
nfs_active	STATE_CHANGE	INFO	NFS service is now active.	The NFS service must be up and running, and in a healthy state to provide the configured file exports.	The NFS server is detected as active.	N/A

Table 22. Events for the NFS component (continued)

Event	EventType	Severity	Message	Description	Cause	User Action
nfs_dbus_error	STATE_CHANGE	WARNING	NFS check through Dbus is failed.	The NFS service must be registered on Dbus to be fully working.	The NFS service is registered on Dbus, but there was a problem accessing it.	Check the health state of the NFS service and restart the NFS service. Check the log files for reported issues.
nfs_dbus_failed	STATE_CHANGE	WARNING	NFS check through Dbus did not return expected message.	NFS service configuration settings (log configuration settings) are queried through Dbus. The result is checked for expected keywords.	The NFS service is registered on Dbus, but the check through Dbus did not return the expected result.	Stop the NFS service and start it again. Check the log configuration of the NFS service.
nfs_dbus_ok	STATE_CHANGE	INFO	NFS check through Dbus is successful.	Check that the NFS service is registered on Dbus and working.	The NFS service is registered on Dbus and working.	N/A
nfs_in_grace	STATE_CHANGE	WARNING	NFS service is in grace mode.	The monitor detected that CES NFS is in grace mode. During this time, the CES NFS state is shown as degraded.	The NFS service was started or restarted.	N/A
nfs_not_active	STATE_CHANGE	ERROR	NFS service is not active.	A check showed that the CES NFS service, which is supposed to be running is not active.	Process might have hung.	Restart the CES NFS.
nfs_not_dbus	STATE_CHANGE	WARNING	NFS service not available as Dbus service.	The NFS service is currently not registered on Dbus. In this mode, the NFS service is not fully working. Exports cannot be added or removed, and not set in grace mode, which is important for data consistency.	The NFS service might have been started while the Dbus was down.	Stop the NFS service, restart the Dbus, and start the NFS service again.
nfsd_down	STATE_CHANGE	ERROR	NFSD process is not running.	Checks for an NFS service process.	The NFS server process was not detected.	Check the health state of the NFS server and restart, if necessary. The process might hang or is in failed state.
nfsd_up	STATE_CHANGE	INFO	NFSD process is running.	Checks for a NFS service process.	The NFS server process was detected. Some further checks are done then.	N/A

Table 22. Events for the NFS component (continued)

Event	EventType	Severity	Message	Description	Cause	User Action
nfsd_warn	INFO	WARNING	NFSD process monitoring returned unknown result.	Checks for a NFS service process.	The NFS server process state might not be determined due to a problem.	Check the health state of the NFS server and restart, if necessary.
portmapper_down	STATE_CHANGE	ERROR	Portmapper port 111 is not active.	The portmapper is needed to provide the NFS services to clients.	The portmapper is not running on port 111.	N/A
portmapper_up	STATE_CHANGE	INFO	Portmapper port is now active.	The portmapper is needed to provide the NFS services to clients.	The portmapper is running on port 111.	N/A
portmapper_warn	INFO	WARNING	Portmapper port monitoring (111) returned unknown result.	The portmapper is needed to provide the NFS services to clients.	The portmapper status might not be determined due to a problem.	Restart the portmapper, if necessary.
postIpChange_info	INFO	INFO	IP addresses are modified.	IP addresses are moved among the cluster nodes.	CES IP addresses were moved or added to the node, and activated.	N/A
rquotad_down	INFO	INFO	The rpc.rquotad process is not running.	Currently not in use. Future.	N/A	N/A
rquotad_up	INFO	INFO	The rpc.rquotad process is running.	Currently not in use. Future.	N/A	N/A
start_nfs_service	INFO	INFO	CES NFS service is started.	Information about a NFS service start.	The NFS service is started by issuing the mmces service start nfs command.	N/A
statd_down	STATE_CHANGE	ERROR	The rpc.statd process is not running.	The statd process is used by NFSv3 to handle file locks.	The statd process is not running.	Stop and start the NFS service. This attempts to start the statd process also.
statd_up	STATE_CHANGE	INFO	The rpc.statd process is running.	The statd process is used by NFS v3 to handle file locks.	The statd process is running.	N/A
stop_nfs_service	INFO	INFO	CES NFS service is stopped.	CES NFS service is stopped.	The NFS service is stopped. This could be because the user issued the mmces service stop nfs command to stop the NFS service.	N/A

Network events

The following table lists the events that are created for the *Network* component.

Table 23. Events for the Network component

Event	EventType	Severity	Message	Description	Cause	User Action
bond_degraded	STATE_CHANGE	INFO	Some slaves of the network bond {0} is down.	Some of the bond parts are malfunctioning.	Some slaves of the bond are not functioning properly.	Check the bonding configuration, network configuration, and cabling of the malfunctioning slaves of the bond.
bond_down	STATE_CHANGE	ERROR	All slaves of the network bond {0} are down.	All slaves of a network bond are down.	All slaves of this network bond are down.	Check the bonding configuration, network configuration, and cabling of all slaves of the bond.
bond_up	STATE_CHANGE	INFO	All slaves of the network bond {0} are working as expected.	This bond is functioning properly.	All slaves of this network bond are functioning properly.	N/A
ces_disable_node network	INFO	INFO	Network is disabled.	The network configuration is disabled as the mmchnode --ces-disable command is issued by the user.	The network configuration is disabled as the mmchnode --ces-disable command is issued by the user.	N/A
ces_enable_node network	INFO	INFO	Network is enabled.	The network configuration is enabled as a result of issuing the mmchnode --ces-enable command.	The network configuration is enabled as a result of issuing the mmchnode --ces-enable command.	N/A
ces_startup_network	INFO	INFO	CES network service is started.	The CES network is started.	CES network IPs are started.	N/A
handle_network _problem_info	INFO	INFO	The following network problem is handled: Problem: {0}, Argument: {1}	Information about network- related reconfigurations. For example, enable or disable IPs and assign or unassign IPs.	A change in the network configuration.	N/A
many_tx_errors	STATE_CHANGE	ERROR	NIC {0} had many TX errors since the last monitoring cycle.	The network adapter had many TX errors since the last monitoring cycle.	The /proc/net/dev folder lists the TX errors that are reported for this adapter.	Check the network cabling and network infrastructure.
move_cesip_from	INFO	INFO	The IP address {0} is moved from this node to the node {1}.	A CES IP address is moved from the current node to another node.	Rebalancing of CES IP addresses.	N/A
move_cesip_to	INFO	INFO	The IP address {0} is moved from node {1} to this node.	A CES IP address is moved from another node to the current node.	Rebalancing of CES IP addresses.	N/A

Table 23. Events for the Network component (continued)

Event	EventType	Severity	Message	Description	Cause	User Action
move_cesips_infos	INFO	INFO	A CES IP movement is detected.	The CES IP addresses can be moved if a node failover from one node to one or more other nodes. This message is logged on a node monitoring this; not necessarily on any affected node.	A CES IP movement was detected.	N/A
network_connectivity_down	STATE_CHANGE	ERROR	The NIC {0} cannot connect to the gateway.	This network adapter cannot connect to the gateway.	The gateway does not respond to the sent connections-checking packets.	Check the network configuration of the network adapter, gateway configuration, and path to the gateway.
network_connectivity_up	STATE_CHANGE	INFO	The NIC {0} can connect to the gateway.	This network adapter can connect to the gateway.	The gateway responds to the sent connections-checking packets.	N/A
network_down	STATE_CHANGE	ERROR	Network is down.	This network adapter is down.	This network adapter is disabled.	Enable this network adapter.
network_found	INFO	INFO	The NIC {0} is detected.	A new network adapter is detected.	A new NIC, which is relevant for the IBM Spectrum Scale monitoring, is listed by the ip a command.	N/A
network_ips_down	STATE_CHANGE	ERROR	No relevant NICs detected.	No relevant network adapters detected.	No network adapters are assigned with the IPs that are the dedicated to the IBM Spectrum Scale system.	Find out, why the IBM Spectrum Scale-relevant IPs were not assigned to any NICs. "
network_ips_up	STATE_CHANGE	INFO	Relevant IPs are assigned to the NICs that are detected in the system.	Relevant IPs are assigned to the network adapters.	At least one IBM Spectrum Scale-relevant IP is assigned to a network adapter.	N/A
network_link_down	STATE_CHANGE	ERROR	Physical link of the NIC {0} is down.	The physical link of this adapter is down.	The flag LOWER_UP is not set for this NIC in the output of the ip a command.	Check the cabling of this network adapter.
network_link_up	STATE_CHANGE	INFO	Physical link of the NIC {0} is up.	The physical link of this adapter is up.	The flag LOWER_UP is set for this NIC in the output of the ip a command.	N/A
network_up	STATE_CHANGE	INFO	Network is up.	This network adapter is up.	This network adapter is enabled.	N/A

Table 23. Events for the Network component (continued)

Event	EventType	Severity	Message	Description	Cause	User Action
network_vanished	INFO	INFO	The NIC {0} could not be detected.	One of network adapters could not be detected.	One of the previously monitored NICs is not listed in the output of the <code>ip a</code> command.	N/A
no_tx_errors	STATE_CHANGE	INFO	The NIC {0} had no or an insignificant number of TX errors.	The NIC had no or an insignificant number of TX errors.	The <code>/proc/net/dev</code> folder lists no or insignificant number of TX errors for this adapter.	Check the network cabling and network infrastructure.

Object events

The following table lists the events that are created for the *Object* component.

Table 24. Events for the object component

Event	EventType	Severity	Message	Description	Cause	User Action
account-auditor_failed	STATE_CHANGE	ERROR	The status of the account-auditor process must be {0} but it is {1} now.	The account-auditor process is not in the expected state.	The account-auditor process is expected to be running on the singleton node only.	Check the status of openstack-swift-account-auditor process and object singleton flag.
account-auditor_ok	STATE_CHANGE	INFO	The account-auditor process status is {0} as expected.	The account-auditor process is in the expected state.	The account-auditor process is expected to be running on the singleton node only.	N/A
account-auditor_warn	INFO	WARNING	The account-auditor process monitoring returned unknown result.	The account-auditor process monitoring service returned an unknown result.	A status query for openstack-swift-account-auditor process returned with an unexpected error.	Check service script and settings.
account-reaper_failed	STATE_CHANGE	ERROR	The status of the account-reaper process must be {0} but it is {1} now.	The account-reaper process is not running.	The account-reaper process is not running.	Check the status of openstack-swift-account-reaper process.
account-reaper_ok	STATE_CHANGE	INFO	The status of the account-reaper process is {0} as expected.	The account-reaper process is running.	The account-reaper process is running.	N/A
account-reaper_warn	INFO	WARNING	The account-reaper process monitoring service returned an unknown result.	The account-reaper process monitoring service returned an unknown result.	A status query for openstack-swift-account-reaper returned with an unexpected error.	Check service script and settings.
account-replicator_failed	STATE_CHANGE	ERROR	The status of the account-replicator process must be {0} but it is {1} now.	The account-replicator process is not running.	The account-replicator process is not running.	Check the status of openstack-swift-account-replicator process.
account-replicator_ok	STATE_CHANGE	INFO	The status of the account-replicator process is {0} as expected.	The account-replicator process is running.	The account-replicator process is running.	N/A

Table 24. Events for the object component (continued)

Event	EventType	Severity	Message	Description	Cause	User Action
account-replicator_warn	INFO	WARNING	The account-replicator process monitoring service returned an unknown result.	The account-replicator check returned an unknown result.	A status query for openstack-swift-account-replicator returned with an unexpected error.	Check the service script and settings.
account-server_failed	STATE_CHANGE	ERROR	The status of the account-server process must be {0} but it is {1} now.	The account-server process is not running.	The account-server process is not running.	Check the status of openstack-swift-account process.
account-server_ok	STATE_CHANGE	INFO	The status of the account process is {0} as expected.	The account-server process is running.	The account-server process is running.	N/A
account-server_warn	INFO	WARNING	The account-server process monitoring service returned unknown result.	The account-server check returned unknown result.	A status query for openstack-swift-account returned with an unexpected error.	Check the service script and existing configuration.
container-auditor_failed	STATE_CHANGE	ERROR	The status of the container-auditor process must be {0} but it is {1} now.	The container-auditor process is not in the expected state.	The container-auditor process is expected to be running on the singleton node only.	Check the status of openstack-swift-container-auditor process and object singleton flag.
container-auditor_ok	STATE_CHANGE	INFO	The status of the container-auditor process is {0} as expected.	The container-auditor process is in the expected state.	The container-auditor process is running on the singleton node only as expected.	N/A
container-auditor_warn	INFO	WARNING	The container-auditor process monitoring service returned unknown result.	The container-auditor monitoring service returned an unknown result.	A status query for openstack-swift-container-auditor returned with an unexpected error.	Check service script and settings.
container-replicator_failed	STATE_CHANGE	ERROR	The status of the container-replicator process must be {0} but it is {1} now.	The container-replicator process is not running.	The container-replicator process is not running.	Check the status of openstack-swift-container-replicator process.
container-replicator_ok	STATE_CHANGE	INFO	The status of the container-replicator process is {0} as expected.	The container-replicator process is running.	The container-replicator process is running.	N/A
container-replicator_warn	INFO	WARNING	The status of the container-replicator process monitoring service returned unknown result.	The container-replicator check returned an unknown result.	A status query for openstack-swift-container-replicator returned with an unexpected error.	Check service script and settings.
container-server_failed	STATE_CHANGE	ERROR	The status of the container-server process must be {0} but it is {1} now.	The container-server process is not running.	The container-server process is not running.	Check the status of openstack-swift-container process.
container-server_ok	STATE_CHANGE	INFO	The status of the container-server is {0} as expected.	The container-server process is running.	The container-server process is running.	N/A

Table 24. Events for the object component (continued)

Event	EventType	Severity	Message	Description	Cause	User Action
container-server_warn	INFO	WARNING	The container-server process monitoring service returned unknown result.	The container-server check returned an unknown result.	A status query for openstack-swift-container returned with an unexpected error.	Check the service script and settings.
container-updater_failed	STATE_CHANGE	ERROR	The status of the container-updater process must be {0} but it is {1} now.	The container-updater process is not in the expected state.	The container-updater process is expected to be running on the singleton node only.	Check the status of openstack-swift-container-updater process and object singleton flag.
container-updater_ok	STATE_CHANGE	INFO	The status of the container-updater process is {0} as expected.	The container-updater process is in the expected state.	The container-updater process is expected to be running on the singleton node only.	N/A
container-updater_warn	INFO	WARNING	The container-updater process monitoring service returned unknown result.	The container-updater check returned an unknown result.	A status query for openstack-swift-container-updater returned with an unexpected error.	Check the service script and settings.
disable_Address_database_node	INFO	INFO	An address database node is disabled.	Database flag is removed from this node.	A CES IP with a database flag linked to it is either removed from this node or moved to this node.	N/A
disable_Address_singleton_node	INFO	INFO	An address singleton node is disabled.	Singleton flag is removed from this node.	A CES IP with a singleton flag linked to it is either removed from this node or moved from/to this node.	N/A
enable_Address_database_node	INFO	INFO	An address database node is enabled.	The database flag is moved to this node.	A CES IP with a database flag linked to it is either removed from this node or moved from/to this node.	N/A
enable_Address_singleton_node	INFO	INFO	An address singleton node is enabled.	The singleton flag is moved to this node.	A CES IP with a singleton flag linked to it is either removed from this node or moved from/to this node.	N/A
ibmobjectizer_failed	STATE_CHANGE	ERROR	The status of the ibmobjectizer process must be {0} but it is {1} now.	The ibmobjectizer process is not in the expected state.	The ibmobjectizer process is expected to be running on the singleton node only.	Check the status of the ibmobjectizer process and object singleton flag.
ibmobjectizer_ok	STATE_CHANGE	INFO	The status of the ibmobjectizer process is {0} as expected.	The ibmobjectizer process is in the expected state.	The ibmobjectizer process is expected to be running on the singleton node only.	N/A
ibmobjectizer_warn	INFO	WARNING	The ibmobjectizer process monitoring service returned unknown result.	The ibmobjectizer check returned an unknown result.	A status query for ibmobjectizer returned with an unexpected error.	Check the service script and settings.
memcached_failed	STATE_CHANGE	ERROR	The status of the memcached process must be {0} but it is {1} now.	The memcached process is not running.	The memcached process is not running.	Check the status of memcached process.

Table 24. Events for the object component (continued)

Event	EventType	Severity	Message	Description	Cause	User Action
memcached_ok	STATE_CHANGE	INFO	The status of the memcached process is {0} as expected.	The memcached process is running.	The memcached process is running.	N/A
memcached_warn	INFO	WARNING	The memcached process monitoring service returned unknown result.	The memcached check returned an unknown result.	A status query for memcached returned with an unexpected error.	Check the service script and settings.
obj_restart	INFO	WARNING	The {0} service is failed. Trying to recover.			
object-expirer_failed	STATE_CHANGE	ERROR	The status of the object-expirer process must be {0} but it is {1} now.	The object-expirer process is not in the expected state.	The object-expirer process is expected to be running on the singleton node only.	Check the status of openstack -swift-object-expirer process and object singleton flag.
object-expirer_ok	STATE_CHANGE	INFO	The status of the object-expirer process is {0} as expected.	The object-expirer process is in the expected state.	The object-expirer process is expected to be running on the singleton node only.	N/A
object-expirer_warn	INFO	WARNING	The object-expirer process monitoring service returned unknown result.	The object-expirer check returned an unknown result.	A status query for openstack -swift-object-expirer returned with an unexpected error.	Check the service script and settings.
object-replicator_failed	STATE_CHANGE	ERROR	The status of the object-replicator process must be {0} but it is {1} now.	The object-replicator process is not running.	The object-replicator process is not running.	Check the status of openstack -swift-object-replicator process.
object-replicator_ok	STATE_CHANGE	INFO	The status of the object-replicator process is {0} as expected.	The object-replicator process is running.	The object-replicator process is running.	N/A
object-replicator_warn	INFO	WARNING	The object-replicator process monitoring service returned unknown result.	The object-replicator check returned an unknown result.	A status query for openstack -swift-object-replicator returned with an unexpected error.	Check the service script and settings.
object-server_failed	STATE_CHANGE	ERROR	The status of the object-server process must be {0} but it is {1} now.	The object-server process is not running.	The object-server process is not running.	Check the status of the openstack -swift-object process.
object-server_ok	STATE_CHANGE	INFO	The status of the object-server process is {0} as expected.	The object-server process is running.	The object-server process is running.	N/A
object-server_warn	INFO	WARNING	The object-server process monitoring service returned unknown result.	The object-server check returned an unknown result.	A status query for openstack -swift-object-server returned with an unexpected error.	Check the service script and settings.
object-updater_failed	STATE_CHANGE	ERROR	The status of the object-updater process must be {0} but it is {1} now.	The object-updater process is not in the expected state.	The object-updater process is expected to be running on the singleton node only.	Check the status of the openstack -swift-object-updater process and object singleton flag.

Table 24. Events for the object component (continued)

Event	EventType	Severity	Message	Description	Cause	User Action
object-updater_ok	STATE_CHANGE	INFO	object-updater process as expected, state is {0} The status of the object-updater process is {0} as expected.	The object-updater process is in the expected state.	The object-updater process is expected to be running on the singleton node only.	N/A
object-updater_warn	INFO	WARNING	The object-updater process monitoring returned unknown result.	The object-updater check returned an unknown result.	A status query for openstack -swift-object-updater returned with an unexpected error.	Check the service script and settings.
openstack-object-sof_failed	STATE_CHANGE	ERROR	The status of the object-sof process must be {0} but is {1}.	The swift-on-file process is not in the expected state.	The swift-on-file process is expected to be running then the capability is enabled and stopped when disabled.	Check the status of the openstack -swift-object-sof process and capabilities flag in spectrum-scale -object.conf.
openstack-object-sof_ok	STATE_CHANGE	INFO	The status of the object-sof process is {0} as expected.	The swift-on-file process is in the expected state.	The swift-on-file process is expected to be running then the capability is enabled and stopped when disabled.	N/A
openstack-object-sof_warn	INFO	INFO	The object-sof process monitoring returned unknown result.	The openstack -swift-object-sof check returned an unknown result.	A status query for openstack -swift-object-sof returned with an unexpected error.	Check the service script and settings.
postIIPChange_info	INFO	INFO	The following IP addresses are modified: {0}	CES IP addresses have been moved and activated.		N/A
proxy-server_failed	STATE_CHANGE	ERROR	The status of the proxy process must be {0} but it is {1} now.	The proxy-server process is not running.	The proxy-server process is not running.	Check the status of the openstack -swift-proxy process.
proxy-server_ok	STATE_CHANGE	INFO	The status of the proxy process is {0} as expected.	The proxy-server process is running.	The proxy-server process is running.	N/A
proxy-server_warn	INFO	WARNING	The proxy-server process monitoring returned unknown result.	The proxy-server process monitoring returned an unknown result.	A status query for openstack-swift-proxy-server returned with an unexpected error.	Check the service script and settings.
ring_checksum_failed	STATE_CHANGE	ERROR	Checksum of the ring file {0} does not match the one in CCR.	Files for object rings have been modified unexpectedly.	Checksum of file did not match the stored value.	Check the ring files.
ring_checksum_ok	STATE_CHANGE	INFO	Checksum of the ring file {0} is OK.	Files for object rings were successfully checked.	Checksum of file found unchanged.	N/A
ring_checksum_warn	INFO	WARNING	Issue while checking checksum of the ring file {0}.	Checksum generation process failed.	The ring_checksum check returned an unknown result.	Check the ring files and the md5sum executable.

Performance events

The following table lists the events that are created for the *Performance* component.

Table 25. Events for the Performance component

Event	EventType	Severity	Message	Description	Cause	User Action
pmcollector_down	STATE_CHANGE	ERROR	The status of the pmcollector service must be {0} but it is {1} now.	The performance monitoring collector is down.	Performance monitoring is configured in this node but the pmcollector service is currently down.	Use the systemctl start pmcollector command to start the performance monitoring collector service or remove the node from the global performance monitoring configuration by using the mmchnode command.
pmsensors_down	STATE_CHANGE	ERROR	The status of the pmsensors service must be {0} but it is {1}now.	The performance monitor sensors are down.	Performance monitoring service is configured on this node but the performance sensors are currently down.	Use the systemctl start pmsensors command to start the performance monitoring sensor service or remove the node from the global performance monitoring configuration by using the mmchnode command.
pmsensors_up	STATE_CHANGE	INFO	The status of the pmsensors service is {0} as expected.	The performance monitor sensors are running.	The performance monitoring sensor service is running as expected.	N/A
pmcollector_up	STATE_CHANGE	INFO	The status of the pmcollector service is {0} as expected.	The performance monitor collector is running.	The performance monitoring collector service is running as expected.	N/A

Table 25. Events for the Performance component (continued)

Event	EventType	Severity	Message	Description	Cause	User Action
pmcollector_warn	INFO	INFO	The pmcollector process returned unknown result.	The monitoring service for performance monitor collector returned an unknown result.	The monitoring service for performance monitoring collector returned an unknown result.	Use the service orsystemctl command to verify whether the performance monitoring collector service is in the expected status. If there is no pmcollector service running on the node and the performance monitoring service is configured on the node, check with the <i>Performance monitoring</i> section in the IBM Spectrum Scale documentation.
pmsensors_warn	INFO	INFO	The pmsensors process returned unknown result.	The monitoring service for performance monitor sensors returned an unknown result.	The monitoring service for performance monitoring sensors returned an unknown result.	Use the service orsystemctl command to verify whether the performance monitoring sensor is in the expected status. Perform the troubleshooting procedures if there is no pmcollector service running on the node and the performance monitoring service is configured on the node. For more information, see the <i>Performance monitoring</i> section in the IBM Spectrum Scale documentation.

SMB events

The following table lists the events that are created for the *SMB* component.

Table 26. Events for the SMB component

Event	EventType	Severity	Message	Description	Cause	User Action
ctdb_down	STATE_CHANGE	ERROR	CTDB process is not running.	The CTDB process is not running.		Perform the troubleshooting procedures.
ctdb_recovered	STATE_CHANGE	INFO	CTDB Recovery finished CTDB recovery is completed.	CTDB completed database recovery.		N/A
ctdb_recovery	STATE_CHANGE	WARNING	CTDB recovery is detected.	CTDB is performing a database recovery.		N/A
ctdb_state_down	STATE_CHANGE	ERROR	CTDB state is {0}.	The CTDB state is unhealthy.		Perform the troubleshooting procedures.
ctdb_state_up	STATE_CHANGE	INFO	CTDB state is healthy.	The CTDB state is healthy.		N/A
ctdb_up	STATE_CHANGE	INFO	CTDB process is running.	The CTDB process is running.		N/A
ctdb_warn	INFO	WARNING	CTDB monitoring returned unknown result.	The CTDB check returned unknown result.		Perform the troubleshooting procedures.
smb_restart	INFO	WARNING	The SMB service is failed. Trying to recover.	Attempt to start the SMBD process.	The SMBD process was not running.	N/A
smbd_down	STATE_CHANGE	ERROR	The SMBD process is not running.	The SMBD process is not running.		Perform the troubleshooting procedures.
smbd_up	STATE_CHANGE	INFO	SMBD process is running.	The SMBD process is running.		N/A
smbd_warn	INFO	WARNING	The SMBD process monitoring returned unknown result.	The SMBD process monitoring returned an unknown result.		Perform the troubleshooting procedures.
smbport_down	STATE_CHANGE	ERROR	The SMB port {0} is not active.	SMBD is not listening on a TCP protocol port.		Perform the troubleshooting procedures.
smbport_up	STATE_CHANGE	INFO	The SMB port {0} is now active.	An SMB port was activated.		N/A
smbport_warn	INFO	WARNING	The SMB port monitoring {0} returned unknown result.	An internal error occurred while monitoring SMB protocol.		Perform the troubleshooting procedures.

Messages

This topic contains explanations for IBM Spectrum Scale RAID and ESS GUI messages.

For information about IBM Spectrum Scale messages, see the *IBM Spectrum Scale: Problem Determination Guide*.

Message severity tags

IBM Spectrum Scale and ESS GUI messages include message severity tags.

A severity tag is a one-character alphabetic code (**A** through **Z**).

For IBM Spectrum Scale messages, the severity tag is optionally followed by a colon (:) and a number, and surrounded by an opening and closing bracket ([]). For example:

[**E**] or [**E:nnn**]

If more than one substring within a message matches this pattern (for example, [**A**] or [**A:nnn**]), the severity tag is the first such matching string.

When the severity tag includes a numeric code (*nnn*), this is an error code associated with the message. If this were the only problem encountered by the command, the command return code would be *nnn*.

If a message does not have a severity tag, the message does not conform to this specification. You can determine the message severity by examining the text or any supplemental information provided in the message catalog, or by contacting the IBM Support Center.

Each message severity tag has an assigned priority.

For IBM Spectrum Scale messages, this priority can be used to filter the messages that are sent to the error log on Linux. Filtering is controlled with the **mmchconfig** attribute **systemLogLevel**. The default for **systemLogLevel** is **error**, which means that IBM Spectrum Scale will send all error [**E**], critical [**X**], and alert [**A**] messages to the error log. The values allowed for **systemLogLevel** are: **alert**, **critical**, **error**, **warning**, **notice**, **configuration**, **informational**, **detail**, or **debug**. Additionally, the value **none** can be specified so no messages are sent to the error log.

For IBM Spectrum Scale messages, alert [**A**] messages have the highest priority and debug [**B**] messages have the lowest priority. If the **systemLogLevel** default of **error** is changed, only messages with the specified severity and all those with a higher priority are sent to the error log.

The following table lists the IBM Spectrum Scale message severity tags in order of priority:

Table 27. IBM Spectrum Scale message severity tags ordered by priority

Severity tag	Type of message (systemLogLevel attribute)	Meaning
A	alert	Indicates a problem where action must be taken immediately. Notify the appropriate person to correct the problem.
X	critical	Indicates a critical condition that should be corrected immediately. The system discovered an internal inconsistency of some kind. Command execution might be halted or the system might attempt to continue despite the inconsistency. Report these errors to IBM.
E	error	Indicates an error condition. Command execution might or might not continue, but this error was likely caused by a persistent condition and will remain until corrected by some other program or administrative action. For example, a command operating on a single file or other GPFS object might terminate upon encountering any condition of severity E. As another example, a command operating on a list of files, finding that one of the files has permission bits set that disallow the operation, might continue to operate on all other files within the specified list of files.

Table 27. IBM Spectrum Scale message severity tags ordered by priority (continued)

Severity tag	Type of message (systemLogLevel attribute)	Meaning
W	warning	Indicates a problem, but command execution continues. The problem can be a transient inconsistency. It can be that the command has skipped some operations on some objects, or is reporting an irregularity that could be of interest. For example, if a multipass command operating on many files discovers during its second pass that a file that was present during the first pass is no longer present, the file might have been removed by another command or program.
N	notice	Indicates a normal but significant condition. These events are unusual, but are not error conditions, and could be summarized in an email to developers or administrators for spotting potential problems. No immediate action is required.
C	configuration	Indicates a configuration change; such as, creating a file system or removing a node from the cluster.
I	informational	Indicates normal operation. This message by itself indicates that nothing is wrong; no action is required.
D	detail	Indicates verbose operational messages; no action is required.
B	debug	Indicates debug-level messages that are useful to application developers for debugging purposes. This information is not useful during operations.

For ESS GUI messages, error messages ((E)) have the highest priority and informational messages (I) have the lowest priority.

The following table lists the ESS GUI message severity tags in order of priority:

Table 28. ESS GUI message severity tags ordered by priority

Severity tag	Type of message	Meaning
E	Error	Indicates a critical condition that should be corrected immediately. The system discovered an internal inconsistency of some kind. Command execution might be halted or the system might attempt to continue despite the inconsistency. Report these errors to IBM.
W	warning	Indicates a problem, but command execution continues. The problem can be a transient inconsistency. It can be that the command has skipped some operations on some objects, or is reporting an irregularity that could be of interest. For example, if a multipass command operating on many files discovers during its second pass that a file that was present during the first pass is no longer present, the file might have been removed by another command or program.
I	informational	Indicates normal operation. This message by itself indicates that nothing is wrong; no action is required.

IBM Spectrum Scale RAID messages

This section lists the IBM Spectrum Scale RAID messages.

For information about the severity designations of these messages, see “Message severity tags” on page 106.

6027-1850 [E] NSD-RAID services are not configured on node *nodeName*. Check the **nsdRAIDTracks** and **nsdRAIDBufferPoolSizePct** configuration attributes.

Explanation: A IBM Spectrum Scale RAID command is being executed, but NSD-RAID services are not initialized either because the specified attributes have not been set or had invalid values.

User response: Correct the attributes and restart the GPFS daemon.

6027-1851 [A] Cannot configure NSD-RAID services. The **nsdRAIDBufferPoolSizePct** of the **pagepool** must result in at least 128MiB of space.

Explanation: The GPFS daemon is starting and cannot initialize the NSD-RAID services because of the memory consideration specified.

User response: Correct the **nsdRAIDBufferPoolSizePct** attribute and restart the GPFS daemon.

6027-1852 [A] Cannot configure NSD-RAID services. **nsdRAIDTracks** is too large, the maximum on this node is *value*.

Explanation: The GPFS daemon is starting and cannot initialize the NSD-RAID services because the **nsdRAIDTracks** attribute is too large.

User response: Correct the **nsdRAIDTracks** attribute and restart the GPFS daemon.

6027-1853 [E] Recovery group *recoveryGroupName* does not exist or is not active.

Explanation: A command was issued to a RAID recovery group that does not exist, or is not in the active state.

User response: Retry the command with a valid RAID recovery group name or wait for the recovery group to become active.

6027-1854 [E] Cannot find declustered array *arrayName* in recovery group *recoveryGroupName*.

Explanation: The specified declustered array name was not found in the RAID recovery group.

User response: Specify a valid declustered array name within the RAID recovery group.

6027-1855 [E] Cannot find **pdisk** *pdiskName* in recovery group *recoveryGroupName*.

Explanation: The specified **pdisk** was not found.

User response: Retry the command with a valid **pdisk** name.

6027-1856 [E] **Vdisk** *vdiskName* not found.

Explanation: The specified **vdisk** was not found.

User response: Retry the command with a valid **vdisk** name.

6027-1857 [E] A recovery group must contain between *number* and *number* **pdisks**.

Explanation: The number of **pdisks** specified is not valid.

User response: Correct the input and retry the command.

6027-1858 [E] Cannot create declustered array *arrayName*; there can be at most *number* declustered arrays in a recovery group.

Explanation: The number of declustered arrays allowed in a recovery group has been exceeded.

User response: Reduce the number of declustered arrays in the input file and retry the command.

6027-1859 [E] Sector size of **pdisk** *pdiskName* is invalid.

Explanation: All **pdisks** in a recovery group must have the same physical sector size.

User response: Correct the input file to use a different disk and retry the command.

6027-1860 [E] **Pdisk** *pdiskName* must have a capacity of at least *number* bytes.

Explanation: The **pdisk** must be at least as large as the indicated minimum size in order to be added to this declustered array.

User response: Correct the input file and retry the command.

6027-1861 [W] Size of **pdisk** *pdiskName* is too large for declustered array *arrayName*. Only *number* of *number* bytes of that capacity will be used.

Explanation: For optimal utilization of space, **pdisks** added to this declustered array should be no larger than the indicated maximum size. Only the indicated portion of the total capacity of the **pdisk** will be available for use.

User response: Consider creating a new declustered

array consisting of all larger pdisks.

6027-1862 [E] Cannot add pdisk *pdiskName* to declustered array *arrayName*; there can be at most *number* pdisks in a declustered array.

Explanation: The maximum number of pdisks that can be added to a declustered array was exceeded.

User response: None.

6027-1863 [E] Pdisk sizes within a declustered array cannot vary by more than *number*.

Explanation: The disk sizes within each declustered array must be nearly the same.

User response: Create separate declustered arrays for each disk size.

6027-1864 [E] [E] At least one declustered array must contain *number* + vdisk configuration data spares or more pdisks and be eligible to hold vdisk configuration data.

Explanation: When creating a new RAID recovery group, at least one of the declustered arrays in the recovery group must contain at least $2T+1$ pdisks, where T is the maximum number of disk failures that can be tolerated within a declustered array. This is necessary in order to store the on-disk vdisk configuration data safely. This declustered array cannot have `canHoldVCD` set to no.

User response: Supply at least the indicated number of pdisks in at least one declustered array of the recovery group, or do not specify `canHoldVCD=no` for that declustered array.

6027-1866 [E] Disk descriptor for *diskName* refers to an existing NSD.

Explanation: A disk being added to a recovery group appears to already be in-use as an NSD disk.

User response: Carefully check the disks given to `tscrrecgroup`, `tsaddpdisk` or `tschcarrier`. If you are certain the disk is not actually in-use, override the check by specifying the `-v no` option.

6027-1867 [E] Disk descriptor for *diskName* refers to an existing pdisk.

Explanation: A disk being added to a recovery group appears to already be in-use as a pdisk.

User response: Carefully check the disks given to `tscrrecgroup`, `tsaddpdisk` or `tschcarrier`. If you are certain the disk is not actually in-use, override the check by specifying the `-v no` option.

6027-1869 [E] Error updating the recovery group descriptor.

Explanation: Error occurred updating the RAID recovery group descriptor.

User response: Retry the command.

6027-1870 [E] Recovery group name *name* is already in use.

Explanation: The recovery group name already exists.

User response: Choose a new recovery group name using the characters a-z, A-Z, 0-9, and underscore, at most 63 characters in length.

6027-1871 [E] There is only enough free space to allocate *number* spare(s) in declustered array *arrayName*.

Explanation: Too many spares were specified.

User response: Retry the command with a valid number of spares.

6027-1872 [E] Recovery group still contains vdisks.

Explanation: RAID recovery groups that still contain vdisks cannot be deleted.

User response: Delete any vdisks remaining in this RAID recovery group using the `tsdelvdisk` command before retrying this command.

6027-1873 [E] Pdisk creation failed for pdisk *pdiskName*: *err*=*errorNum*.

Explanation: Pdisk creation failed because of the specified error.

User response: None.

6027-1874 [E] Error adding pdisk to a recovery group.

Explanation: `tsaddpdisk` failed to add new pdisks to a recovery group.

User response: Check the list of pdisks in the `-d` or `-F` parameter of `tsaddpdisk`.

6027-1875 [E] Cannot delete the only declustered array.

Explanation: Cannot delete the only remaining declustered array from a recovery group.

User response: Instead, delete the entire recovery group.

6027-1876 [E] Cannot remove declustered array *arrayName* because it is the only remaining declustered array with at least *number* pdisks eligible to hold vdisk configuration data.

Explanation: The command failed to remove a declustered array because no other declustered array in the recovery group has sufficient pdisks to store the on-disk recovery group descriptor at the required fault tolerance level.

User response: Add pdisks to another declustered array in this recovery group before removing this one.

6027-1877 [E] Cannot remove declustered array *arrayName* because the array still contains vdisks.

Explanation: Declustered arrays that still contain vdisks cannot be deleted.

User response: Delete any vdisks remaining in this declustered array using the **tsdelvdisk** command before retrying this command.

6027-1878 [E] Cannot remove pdisk *pdiskName* because it is the last remaining pdisk in declustered array *arrayName*. Remove the declustered array instead.

Explanation: The **tsdelpdisk** command can be used either to delete individual pdisks from a declustered array, or to delete a full declustered array from a recovery group. You cannot, however, delete a declustered array by deleting all of its pdisks -- at least one must remain.

User response: Delete the declustered array instead of removing all of its pdisks.

6027-1879 [E] Cannot remove pdisk *pdiskName* because *arrayName* is the only remaining declustered array with at least *number* pdisks.

Explanation: The command failed to remove a pdisk from a declustered array because no other declustered array in the recovery group has sufficient pdisks to store the on-disk recovery group descriptor at the required fault tolerance level.

User response: Add pdisks to another declustered array in this recovery group before removing pdisks from this one.

6027-1880 [E] Cannot remove pdisk *pdiskName* because the number of pdisks in declustered array *arrayName* would fall below the code width of one or more of its vdisks.

Explanation: The number of pdisks in a declustered array must be at least the maximum code width of any

vdisk in the declustered array.

User response: Either add pdisks or remove vdisks from the declustered array.

6027-1881 [E] Cannot remove pdisk *pdiskName* because of insufficient free space in declustered array *arrayName*.

Explanation: The **tsdelpdisk** command could not delete a pdisk because there was not enough free space in the declustered array.

User response: Either add pdisks or remove vdisks from the declustered array.

6027-1882 [E] Cannot remove pdisk *pdiskName*; unable to drain the data from the pdisk.

Explanation: Pdisk deletion failed because the system could not find enough free space on other pdisks to drain all of the data from the disk.

User response: Either add pdisks or remove vdisks from the declustered array.

6027-1883 [E] Pdisk *pdiskName* deletion failed: process interrupted.

Explanation: Pdisk deletion failed because the deletion process was interrupted. This is most likely because of the recovery group failing over to a different server.

User response: Retry the command.

6027-1884 [E] Missing or invalid vdisk name.

Explanation: No vdisk name was given on the **tscrvdisk** command.

User response: Specify a vdisk name using the characters a-z, A-Z, 0-9, and underscore of at most 63 characters in length.

6027-1885 [E] Vdisk block size must be a power of 2.

Explanation: The **-B** or **--blockSize** parameter of **tscrvdisk** must be a power of 2.

User response: Reissue the **tscrvdisk** command with a correct value for block size.

6027-1886 [E] Vdisk block size cannot exceed *maxBlockSize* (*number*).

Explanation: The virtual block size of a vdisk cannot be larger than the value of the **maxblocksize** configuration attribute of the IBM Spectrum Scale **mmchconfig** command.

User response: Use a smaller vdisk virtual block size, or increase the value of **maxBlockSize** using **mmchconfig maxblocksize=*newSize***.

6027-1887 [E] Vdisk block size must be between *number* and *number* for the specified code.

Explanation: An invalid vdisk block size was specified. The message lists the allowable range of block sizes.

User response: Use a vdisk virtual block size within the range shown, or use a different vdisk RAID code.

6027-1888 [E] Recovery group already contains *number* vdisks.

Explanation: The RAID recovery group already contains the maximum number of vdisks.

User response: Create vdisks in another RAID recovery group, or delete one or more of the vdisks in the current RAID recovery group before retrying the `tscrvdisk` command.

6027-1889 [E] Vdisk name *vdiskName* is already in use.

Explanation: The vdisk name given on the `tscrvdisk` command already exists.

User response: Choose a new vdisk name less than 64 characters using the characters a-z, A-Z, 0-9, and underscore.

6027-1890 [E] A recovery group may only contain one log home vdisk.

Explanation: A log vdisk already exists in the recovery group.

User response: None.

6027-1891 [E] Cannot create vdisk before the log home vdisk is created.

Explanation: The log vdisk must be the first vdisk created in a recovery group.

User response: Retry the command after creating the log home vdisk.

6027-1892 [E] Log vdisks must use replication.

Explanation: The log vdisk must use a RAID code that uses replication.

User response: Retry the command with a valid RAID code.

6027-1893 [E] The declustered array must contain at least as many non-spare pdisks as the width of the code.

Explanation: The RAID code specified requires a minimum number of disks larger than the size of the declustered array that was given.

User response: Place the vdisk in a wider declustered array or use a narrower code.

6027-1894 [E] There is not enough space in the declustered array to create additional vdisks.

Explanation: There is insufficient space in the declustered array to create even a minimum size vdisk with the given RAID code.

User response: Add additional pdisks to the declustered array, reduce the number of spares or use a different RAID code.

6027-1895 [E] Unable to create vdisk *vdiskName* because there are too many failed pdisks in declustered array *declusteredArrayName*.

Explanation: Cannot create the specified vdisk, because there are too many failed pdisks in the array.

User response: Replace failed pdisks in the declustered array and allow time for rebalance operations to more evenly distribute the space.

6027-1896 [E] Insufficient memory for vdisk metadata.

Explanation: There was not enough pinned memory for IBM Spectrum Scale to hold all of the metadata necessary to describe a vdisk.

User response: Increase the size of the GPFS page pool.

6027-1897 [E] Error formatting vdisk.

Explanation: An error occurred formatting the vdisk.

User response: None.

6027-1898 [E] The log home vdisk cannot be destroyed if there are other vdisks.

Explanation: The log home vdisk of a recovery group cannot be destroyed if vdisks other than the log tip vdisk still exist within the recovery group.

User response: Remove the user vdisks and then retry the command.

6027-1899 [E] Vdisk *vdiskName* is still in use.

Explanation: The vdisk named on the `tsdelvdisk` command is being used as an NSD disk.

User response: Remove the vdisk with the `mmdelnsc` command before attempting to delete it.

6027-3000 [E] No disk enclosures were found on the target node.

Explanation: IBM Spectrum Scale is unable to communicate with any disk enclosures on the node serving the specified pdisks. This might be because there are no disk enclosures attached to the node, or it might indicate a problem in communicating with the disk enclosures. While the problem persists, disk maintenance with the **mmchcarrier** command is not available.

User response: Check disk enclosure connections and run the command again. Use **mmaddpdisk --replace** as an alternative method of replacing failed disks.

6027-3001 [E] Location of pdisk *pdiskName* of recovery group *recoveryGroupName* is not known.

Explanation: IBM Spectrum Scale is unable to find the location of the given pdisk.

User response: Check the disk enclosure hardware.

6027-3002 [E] Disk location code *locationCode* is not known.

Explanation: A disk location code specified on the command line was not found.

User response: Check the disk location code.

6027-3003 [E] Disk location code *locationCode* was specified more than once.

Explanation: The same disk location code was specified more than once in the **tschcarrier** command.

User response: Check the command usage and run again.

6027-3004 [E] Disk location codes *locationCode* and *locationCode* are not in the same disk carrier.

Explanation: The **tschcarrier** command cannot be used to operate on more than one disk carrier at a time.

User response: Check the command usage and rerun.

6027-3005 [W] Pdisk in location *locationCode* is controlled by recovery group *recoveryGroupName*.

Explanation: The **tschcarrier** command detected that a pdisk in the indicated location is controlled by a different recovery group than the one specified.

User response: Check the disk location code and recovery group name.

6027-3006 [W] Pdisk in location *locationCode* is controlled by recovery group id *idNumber*.

Explanation: The **tschcarrier** command detected that a pdisk in the indicated location is controlled by a different recovery group than the one specified.

User response: Check the disk location code and recovery group name.

6027-3007 [E] Carrier contains pdisks from more than one recovery group.

Explanation: The **tschcarrier** command detected that a disk carrier contains pdisks controlled by more than one recovery group.

User response: Use the **tschpdisk** command to bring the pdisks in each of the other recovery groups offline and then rerun the command using the **--force-RG** flag.

6027-3008 [E] Incorrect recovery group given for location.

Explanation: The **mmchcarrier** command detected that the specified recovery group name given does not match that of the pdisk in the specified location.

User response: Check the disk location code and recovery group name. If you are sure that the disks in the carrier are not being used by other recovery groups, it is possible to override the check using the **--force-RG** flag. Use this flag with caution as it can cause disk errors and potential data loss in other recovery groups.

6027-3009 [E] Pdisk *pdiskName* of recovery group *recoveryGroupName* is not currently scheduled for replacement.

Explanation: A pdisk specified in a **tschcarrier** or **tsaddpdisk** command is not currently scheduled for replacement.

User response: Make sure the correct disk location code or pdisk name was given. For the **mmchcarrier** command, the **--force-release** option can be used to override the check.

6027-3010 [E] Command interrupted.

Explanation: The **mmchcarrier** command was interrupted by a conflicting operation, for example the **mmchpdisk --resume** command on the same pdisk.

User response: Run the **mmchcarrier** command again.

6027-3011 [W] Disk location *locationCode* failed to power off.

Explanation: The **mmchcarrier** command detected an error when trying to power off a disk.

User response: Check the disk enclosure hardware. If the disk carrier has a lock and does not unlock, try running the command again or use the manual carrier release.

6027-3012 [E] Cannot find a pdisk in location *locationCode*.

Explanation: The `tschcarrier` command cannot find a pdisk to replace in the given location.

User response: Check the disk location code.

6027-3013 [W] Disk location *locationCode* failed to power on.

Explanation: The `mmchcarrier` command detected an error when trying to power on a disk.

User response: Make sure the disk is firmly seated and run the command again.

6027-3014 [E] Pdisk *pdiskName* of recovery group *recoveryGroupName* was expected to be replaced with a new disk; instead, it was moved from location *locationCode* to location *locationCode*.

Explanation: The `mmchcarrier` command expected a pdisk to be removed and replaced with a new disk. But instead of being replaced, the old pdisk was moved into a different location.

User response: Repeat the disk replacement procedure.

6027-3015 [E] Pdisk *pdiskName* of recovery group *recoveryGroupName* in location *locationCode* cannot be used as a replacement for pdisk *pdiskName* of recovery group *recoveryGroupName*.

Explanation: The `tschcarrier` command expected a pdisk to be removed and replaced with a new disk. But instead of finding a new disk, the `mmchcarrier` command found that another pdisk was moved to the replacement location.

User response: Repeat the disk replacement procedure, making sure to replace the failed pdisk with a new disk.

6027-3016 [E] Replacement disk in location *locationCode* has an incorrect type *fruCode*; expected type code is *fruCode*.

Explanation: The replacement disk has a different field replaceable unit type code than that of the original disk.

User response: Replace the pdisk with a disk of the same part number. If you are certain the new disk is a valid substitute, override this check by running the

command again with the `--force-fru` option.

6027-3017 [E] Error formatting replacement disk *diskName*.

Explanation: An error occurred when trying to format a replacement pdisk.

User response: Check the replacement disk.

6027-3018 [E] A replacement for pdisk *pdiskName* of recovery group *recoveryGroupName* was not found in location *locationCode*.

Explanation: The `tschcarrier` command expected a pdisk to be removed and replaced with a new disk, but no replacement disk was found.

User response: Make sure a replacement disk was inserted into the correct slot.

6027-3019 [E] Pdisk *pdiskName* of recovery group *recoveryGroupName* in location *locationCode* was not replaced.

Explanation: The `tschcarrier` command expected a pdisk to be removed and replaced with a new disk, but the original pdisk was still found in the replacement location.

User response: Repeat the disk replacement, making sure to replace the pdisk with a new disk.

6027-3020 [E] Invalid state change, *stateChangeName*, for pdisk *pdiskName*.

Explanation: The `tschpdisk` command received an state change request that is not permitted.

User response: Correct the input and reissue the command.

6027-3021 [E] Unable to change identify state to *identifyState* for pdisk *pdiskName*: *err=errorNum*.

Explanation: The `tschpdisk` command failed on an identify request.

User response: Check the disk enclosure hardware.

6027-3022 [E] Unable to create vdisk layout.

Explanation: The `tscrvdisk` command could not create the necessary layout for the specified vdisk.

User response: Change the vdisk arguments and retry the command.

6027-3023 [E] Error initializing vdisk.

Explanation: The `tscrvdisk` command could not initialize the vdisk.

User response: Retry the command.

6027-3024 [E] Error retrieving recovery group *recoveryGroupName* event log.

Explanation: Because of an error, the `tslsrecoverygroupevents` command was unable to retrieve the full event log.

User response: None.

6027-3025 [E] Device *deviceName* does not exist or is not active on this node.

Explanation: The specified device was not found on this node.

User response: None.

6027-3026 [E] Recovery group *recoveryGroupName* does not have an active log home vdisk.

Explanation: The indicated recovery group does not have an active log vdisk. This may be because the log home vdisk has not yet been created, because a previously existing log home vdisk has been deleted, or because the server is in the process of recovery.

User response: Create a log home vdisk if none exists. Retry the command.

6027-3027 [E] Cannot configure NSD-RAID services on this node.

Explanation: NSD-RAID services are not supported on this operating system or node hardware.

User response: Configure a supported node type as the NSD RAID server and restart the GPFS daemon.

6027-3028 [E] There is not enough space in declustered array *declusteredArrayName* for the requested vdisk size. The maximum possible size for this vdisk is *size*.

Explanation: There is not enough space in the declustered array for the requested vdisk size.

User response: Create a smaller vdisk, remove existing vdisks or add additional pdisks to the declustered array.

6027-3029 [E] There must be at least *number* non-spare pdisks in declustered array *declusteredArrayName* to avoid falling below the code width of vdisk *vdiskName*.

Explanation: A change of spares operation failed because the resulting number of non-spare pdisks would fall below the code width of the indicated vdisk.

User response: Add additional pdisks to the declustered array.

6027-3030 [E] There must be at least *number* non-spare pdisks in declustered array *declusteredArrayName* for configuration data replicas.

Explanation: A delete pdisk or change of spares operation failed because the resulting number of non-spare pdisks would fall below the number required to hold configuration data for the declustered array.

User response: Add additional pdisks to the declustered array. If replacing a pdisk, use `mmchcarrier` or `mmaddpdisk --replace`.

6027-3031 [E] There is not enough available configuration data space in declustered array *declusteredArrayName* to complete this operation.

Explanation: Creating a vdisk, deleting a pdisk, or changing the number of spares failed because there is not enough available space in the declustered array for configuration data.

User response: Replace any failed pdisks in the declustered array and allow time for rebalance operations to more evenly distribute the available space. Add pdisks to the declustered array.

6027-3032 [E] Temporarily unable to create vdisk *vdiskName* because more time is required to rebalance the available space in declustered array *declusteredArrayName*.

Explanation: Cannot create the specified vdisk until rebuild and rebalance processes are able to more evenly distribute the available space.

User response: Replace any failed pdisks in the recovery group, allow time for rebuild and rebalance processes to more evenly distribute the spare space within the array, and retry the command.

6027-3034 [E] The input pdisk name (*pdiskName*) did not match the pdisk name found on disk (*pdiskName*).

Explanation: Cannot add the specified pdisk, because the input *pdiskName* did not match the *pdiskName* that was written on the disk.

User response: Verify the input file and retry the command.

6027-3035 [A] Cannot configure NSD-RAID services. maxblocksize must be at least *value*.

Explanation: The GPFS daemon is starting and cannot initialize the NSD-RAID services because the **maxblocksize** attribute is too small.

User response: Correct the **maxblocksize** attribute and restart the GPFS daemon.

6027-3036 [E] Partition size must be a power of 2.

Explanation: The **partitionSize** parameter of some declustered array was invalid.

User response: Correct the **partitionSize** parameter and reissue the command.

6027-3037 [E] Partition size must be between *number* and *number*.

Explanation: The **partitionSize** parameter of some declustered array was invalid.

User response: Correct the **partitionSize** parameter to a power of 2 within the specified range and reissue the command.

6027-3038 [E] AU log too small; must be at least *number* bytes.

Explanation: The **auLogSize** parameter of a new declustered array was invalid.

User response: Increase the **auLogSize** parameter and reissue the command.

6027-3039 [E] A vdisk with disk usage **vdiskLogTip must be the first vdisk created in a recovery group.**

Explanation: The **--logTip** disk usage was specified for a vdisk other than the first one created in a recovery group.

User response: Retry the command with a different disk usage.

6027-3040 [E] Declustered array configuration data does not fit.

Explanation: There is not enough space in the pdisks of a new declustered array to hold the AU log area using the current partition size.

User response: Increase the **partitionSize** parameter or decrease the **auLogSize** parameter and reissue the command.

6027-3041 [E] Declustered array attributes cannot be changed.

Explanation: The **partitionSize**, **auLogSize**, and **canHoldVCD** attributes of a declustered array cannot be changed after the declustered array has been created. They may only be set by a command that creates the declustered array.

User response: Remove the **partitionSize**, **auLogSize**, and **canHoldVCD** attributes from the input file of the **mmaddpdisk** command and reissue the command.

6027-3042 [E] The log tip vdisk cannot be destroyed if there are other vdisks.

Explanation: In recovery groups with versions prior to 3.5.0.11, the log tip vdisk cannot be destroyed if other vdisks still exist within the recovery group.

User response: Remove the user vdisks or upgrade the version of the recovery group with **mmchrecoverygroup --version**, then retry the command to remove the log tip vdisk.

6027-3043 [E] Log vdisks cannot have multiple use specifications.

Explanation: A vdisk can have usage **vdiskLog**, **vdiskLogTip**, or **vdiskLogReserved**, but not more than one.

User response: Retry the command with only one of the **--log**, **--logTip**, or **--logReserved** attributes.

6027-3044 [E] Unable to determine resource requirements for all the recovery groups served by node *value*: to override this check reissue the command with the **-v no flag.**

Explanation: A recovery group or vdisk is being created, but IBM Spectrum Scale can not determine if there are enough non-stealable buffer resources to allow the node to successfully serve all the recovery groups at the same time once the new object is created.

User response: You can override this check by reissuing the command with the **-v** flag.

6027-3045 [W] Buffer request exceeds the non-stealable buffer limit. Check the configuration attributes of the recovery group **servers: pagepool, nsdRAIDBufferPoolSizePct, nsdRAIDNonStealableBufPct.**

Explanation: The limit of non-stealable buffers has been exceeded. This is probably because the system is not configured correctly.

User response: Check the settings of the **pagepool**, **nsdRAIDBufferPoolSizePct**, and

nsdRAIDNonStealableBufPct attributes and make sure the server has enough real memory to support the configured values.

Use the **mmchconfig** command to correct the configuration.

6027-3046 [E] The nonStealable buffer limit may be too low on server *serverName* or the pagepool is too small. Check the configuration attributes of the recovery group servers: **pagepool, **nsdRAIDBufferPoolSizePct**, **nsdRAIDNonStealableBufPct**.**

Explanation: The limit of non-stealable buffers is too low on the specified recovery group server. This is probably because the system is not configured correctly.

User response: Check the settings of the **pagepool**, **nsdRAIDBufferPoolSizePct**, and **nsdRAIDNonStealableBufPct** attributes and make sure the server has sufficient real memory to support the configured values. The specified configuration variables should be the same for the recovery group servers.

Use the **mmchconfig** command to correct the configuration.

6027-3047 [E] Location of pdisk *pdiskName* is not known.

Explanation: IBM Spectrum Scale is unable to find the location of the given pdisk.

User response: Check the disk enclosure hardware.

6027-3048 [E] Pdisk *pdiskName* is not currently scheduled for replacement.

Explanation: A pdisk specified in a **tschcarrier** or **tsaddpdisk** command is not currently scheduled for replacement.

User response: Make sure the correct disk location code or pdisk name was given. For the **tschcarrier** command, the **--force-release** option can be used to override the check.

6027-3049 [E] The minimum size for vdisk *vdiskName* is *number*.

Explanation: The vdisk size was too small.

User response: Increase the size of the vdisk and retry the command.

6027-3050 [E] There are already *number* suspended pdisks in declustered array *arrayName*. You must resume pdisks in the array before suspending more.

Explanation: The number of suspended pdisks in the

declustered array has reached the maximum limit. Allowing more pdisks to be suspended in the array would put data availability at risk.

User response: Resume one more suspended pdisks in the array by using the **mmchcarrier** or **mmchpdisk** commands then retry the command.

6027-3051 [E] Checksum granularity must be *number* or *number*.

Explanation: The only allowable values for the **checksumGranularity** attribute of a data vdisk are 8K and 32K.

User response: Change the **checksumGranularity** attribute of the vdisk, then retry the command.

6027-3052 [E] Checksum granularity cannot be specified for log vdisks.

Explanation: The **checksumGranularity** attribute cannot be applied to a log vdisk.

User response: Remove the **checksumGranularity** attribute of the log vdisk, then retry the command.

6027-3053 [E] Vdisk block size must be between *number* and *number* for the specified code when checksum granularity *number* is used.

Explanation: An invalid vdisk block size was specified. The message lists the allowable range of block sizes.

User response: Use a vdisk virtual block size within the range shown, or use a different vdisk RAID code, or use a different checksum granularity.

6027-3054 [W] Disk in location *locationCode* failed to come online.

Explanation: The **mmchcarrier** command detected an error when trying to bring a disk back online.

User response: Make sure the disk is firmly seated and run the command again. Check the operating system error log.

6027-3055 [E] The fault tolerance of the code cannot be greater than the fault tolerance of the internal configuration data.

Explanation: The RAID code specified for a new vdisk is more fault-tolerant than the configuration data that will describe the vdisk.

User response: Use a code with a smaller fault tolerance.

6027-3056 [E] Long and short term event log size and fast write log percentage are only applicable to log home vdisk.

Explanation: The `longTermEventLogSize`, `shortTermEventLogSize`, and `fastWriteLogPct` options are only applicable to log home vdisk.

User response: Remove any of these options and retry vdisk creation.

6027-3057 [E] Disk enclosure is no longer reporting information on location *locationCode*.

Explanation: The disk enclosure reported an error when IBM Spectrum Scale tried to obtain updated status on the disk location.

User response: Try running the command again. Make sure that the disk enclosure firmware is current. Check for improperly-seated connectors within the disk enclosure.

6027-3058 [A] GSS license failure - IBM Spectrum Scale RAID services will not be configured on this node.

Explanation: The Elastic Storage Server has not been installed validly. Therefore, IBM Spectrum Scale RAID services will not be configured.

User response: Install a licensed copy of the base IBM Spectrum Scale code and restart the GPFS daemon.

6027-3059 [E] The serviceDrain state is only permitted when all nodes in the cluster are running daemon version *version* or higher.

Explanation: The `mmchpdisk` command option `--begin-service-drain` was issued, but there are backlevel nodes in the cluster that do not support this action.

User response: Upgrade the nodes in the cluster to at least the specified version and run the command again.

6027-3060 [E] Block sizes of all log vdisks must be the same.

Explanation: The block sizes of the log tip vdisk, the log tip backup vdisk, and the log home vdisk must all be the same.

User response: Try running the command again after adjusting the block sizes of the log vdisks.

6027-3061 [E] Cannot delete path *pathName* because there would be no other working paths to pdisk *pdiskName* of RG *recoveryGroupName*.

Explanation: When the `-v yes` option is specified on

the `--delete-paths` subcommand of the `tschrecgroup` command, it is not allowed to delete the last working path to a pdisk.

User response: Try running the command again after repairing other broken paths for the named pdisk, or reduce the list of paths being deleted, or run the command with `-v no`.

6027-3062 [E] Recovery group version *version* is not compatible with the current recovery group version.

Explanation: The recovery group version specified with the `--version` option does not support all of the features currently supported by the recovery group.

User response: Run the command with a new value for `--version`. The allowable values will be listed following this message.

6027-3063 [E] Unknown recovery group version *version*.

Explanation: The recovery group version named by the argument of the `--version` option was not recognized.

User response: Run the command with a new value for `--version`. The allowable values will be listed following this message.

6027-3064 [I] Allowable recovery group versions are:

Explanation: Informational message listing allowable recovery group versions.

User response: Run the command with one of the recovery group versions listed.

6027-3065 [E] The maximum size of a log tip vdisk is *size*.

Explanation: Running `mmcrvdisk` for a log tip vdisk failed because the size is too large.

User response: Correct the size parameter and run the command again.

6027-3066 [E] A recovery group may only contain one log tip vdisk.

Explanation: A log tip vdisk already exists in the recovery group.

User response: None.

6027-3067 [E] Log tip backup vdisks not supported by this recovery group version.

Explanation: Vdisks with usage type `vdiskLogTipBackup` are not supported by all recovery group versions.

User response: Upgrade the recovery group to a later version using the `--version` option of `mmchrecoverygroup`.

6027-3068 [E] The sizes of the log tip vdisk and the log tip backup vdisk must be the same.

Explanation: The log tip vdisk must be the same size as the log tip backup vdisk.

User response: Adjust the vdisk sizes and retry the `mmcrvdisk` command.

6027-3069 [E] Log vdisks cannot use code *codeName*.

Explanation: Log vdisks must use a RAID code that uses replication, or be unreplicated. They cannot use parity-based codes such as 8+2P.

User response: Retry the command with a valid RAID code.

6027-3070 [E] Log vdisk *vdiskName* cannot appear in the same declustered array as log vdisk *vdiskName*.

Explanation: No two log vdisks may appear in the same declustered array.

User response: Specify a different declustered array for the new log vdisk and retry the command.

6027-3071 [E] Device not found: *deviceName*.

Explanation: A device name given in an `mmcrrecoverygroup` or `mmaddpdisk` command was not found.

User response: Check the device name.

6027-3072 [E] Invalid device name: *deviceName*.

Explanation: A device name given in an `mmcrrecoverygroup` or `mmaddpdisk` command is invalid.

User response: Check the device name.

6027-3073 [E] Error formatting pdisk *pdiskName* on device *diskName*.

Explanation: An error occurred when trying to format a new pdisk.

User response: Check that the disk is working properly.

6027-3074 [E] Node *nodeName* not found in cluster configuration.

Explanation: A node name specified in a command does not exist in the cluster configuration.

User response: Check the command arguments.

6027-3075 [E] The `--servers` list must contain the current node, *nodeName*.

Explanation: The `--servers` list of a `tscrregroup` command does not list the server on which the command is being run.

User response: Check the `--servers` list. Make sure the `tscrregroup` command is run on a server that will actually server the recovery group.

6027-3076 [E] Remote pdisks are not supported by this recovery group version.

Explanation: Pdisks that are not directly attached are not supported by all recovery group versions.

User response: Upgrade the recovery group to a later version using the `--version` option of `mmchrecoverygroup`.

6027-3077 [E] There must be at least *number* pdisks in recovery group *recoveryGroupName* for configuration data replicas.

Explanation: A change of pdisks failed because the resulting number of pdisks would fall below the needed replication factor for the recovery group descriptor.

User response: Do not attempt to delete more pdisks.

6027-3078 [E] Replacement threshold for declustered array *declusteredArrayName* of recovery group *recoveryGroupName* cannot exceed *number*.

Explanation: The replacement threshold cannot be larger than the maximum number of pdisks in a declustered array. The maximum number of pdisks in a declustered array depends on the version number of the recovery group. The current limit is given in this message.

User response: Use a smaller replacement threshold or upgrade the recovery group version.

6027-3079 [E] Number of spares for declustered array *declusteredArrayName* of recovery group *recoveryGroupName* cannot exceed *number*.

Explanation: The number of spares cannot be larger than the maximum number of pdisks in a declustered array. The maximum number of pdisks in a declustered array depends on the version number of the recovery group. The current limit is given in this message.

User response: Use a smaller number of spares or upgrade the recovery group version.

6027-3080 [E] Cannot remove pdisk *pdiskName* because declustered array *declusteredArrayName* would have fewer disks than its replacement threshold.

Explanation: The replacement threshold for a declustered array must not be larger than the number of pdisks in the declustered array.

User response: Reduce the replacement threshold for the declustered array, then retry the **mmdelepdisk** command.

6027-3084 [E] VCD spares feature must be enabled before being changed. Upgrade recovery group version to at least *version* to enable it.

Explanation: The vdisk configuration data (VCD) spares feature is not supported in the current recovery group version.

User response: Apply the recovery group version that is recommended in the error message and retry the command.

6027-3085 [E] The number of VCD spares must be greater than or equal to the number of spares in declustered array *declusteredArrayName*.

Explanation: Too many spares or too few vdisk configuration data (VCD) spares were specified.

User response: Retry the command with a smaller number of spares or a larger number of VCD spares.

6027-3086 [E] There is only enough free space to allocate *n* VCD spare(s) in declustered array *declusteredArrayName*.

Explanation: Too many vdisk configuration data (VCD) spares were specified.

User response: Retry the command with a smaller number of VCD spares.

6027-3087 [E] Specifying Pdisk rotation rate not supported by this recovery group version.

Explanation: Specifying the Pdisk rotation rate is not supported by all recovery group versions.

User response: Upgrade the recovery group to a later version using the **--version** option of the **mmchrecoverygroup** command. Or, don't specify a rotation rate.

6027-3088 [E] Specifying Pdisk expected number of paths not supported by this recovery group version.

Explanation: Specifying the expected number of active or total pdisk paths is not supported by all recovery group versions.

User response: Upgrade the recovery group to a later version using the **--version** option of the **mmchrecoverygroup** command. Or, don't specify the expected number of paths.

6027-3089 [E] Pdisk *pdiskName* location *locationCode* is already in use.

Explanation: The pdisk location that was specified in the command conflicts with another pdisk that is already in that location. No two pdisks can be in the same location.

User response: Specify a unique location for this pdisk.

6027-3090 [E] Enclosure control command failed for pdisk *pdiskName* of RG *recoveryGroupName* in location *locationCode*: **err errorNum. Examine **mmfs** log for **tsctlencslot**, **tsonosdisk** and **tsoffosdisk** errors.**

Explanation: A command used to control a disk enclosure slot failed.

User response: Examine the mmfs log files for more specific error messages from the **tsctlencslot**, **tsonosdisk**, and **tsoffosdisk** commands.

6027-3091 [W] A command to control the disk enclosure failed with error code *errorNum*. As a result, enclosure indicator lights may not have changed to the correct states. Examine the mmfs log on nodes attached to the disk enclosure for messages from the **tsctlencslot, **tsonosdisk**, and **tsoffosdisk** commands for more detailed information.**

Explanation: A command used to control disk enclosure lights and carrier locks failed. This is not a fatal error.

User response: Examine the mmfs log files on nodes attached to the disk enclosure for error messages from the **tsctlencslot**, **tsonosdisk**, and **tsoffosdisk** commands for more detailed information. If the carrier failed to unlock, either retry the command or use the manual override.

6027-3092 [I] Recovery group *recoveryGroupName* assignment delay *delaySeconds* seconds for safe recovery.

Explanation: The recovery group must wait before meta-data recovery. Prior disk lease for the failing manager must first expire.

User response: None.

6027-3093 [E] Checksum granularity must be *number* or *number* for log vdisks.

Explanation: The only allowable values for the checksumGranularity attribute of a log vdisk are 512 and 4K.

User response: Change the checksumGranularity attribute of the vdisk, then retry the command.

6027-3094 [E] Due to the attributes of other log vdisks, the checksum granularity of this vdisk must be *number*.

Explanation: The checksum granularities of the log tip vdisk, the log tip backup vdisk, and the log home vdisk must all be the same.

User response: Change the checksumGranularity attribute of the new log vdisk to the indicated value, then retry the command.

6027-3095 [E] The specified declustered array name (*declusteredArrayName*) for the new pdisk *pdiskName* must be *declusteredArrayName*.

Explanation: When replacing an existing pdisk with a new pdisk, the declustered array name for the new pdisk must match the declustered array name for the existing pdisk.

User response: Change the specified declustered array name to the indicated value, then run the command again.

6027-3096 [E] Internal error encountered in NSD-RAID command: *err=errorNum*.

Explanation: An unexpected GPFS NSD-RAID internal error occurred.

User response: Contact the IBM Support Center.

6027-3097 [E] Missing or invalid pdisk name (*pdiskName*).

Explanation: A pdisk name specified in an **mmcrrecoverygroup** or **mmaddpdisk** command is not valid.

User response: Specify a pdisk name that is 63 characters or less. Valid characters are: a to z, A to Z, 0 to 9, and underscore (_).

6027-3098 [E] Pdisk name *pdiskName* is already in use in recovery group *recoveryGroupName*.

Explanation: The pdisk name already exists in the specified recovery group.

User response: Choose a pdisk name that is not already in use.

6027-3099 [E] Device with path(s) *pathName* is specified for both new pdisks *pdiskName* and *pdiskName*.

Explanation: The same device is specified for more than one pdisk in the stanza file. The device can have multiple paths, which are shown in the error message.

User response: Specify different devices for different new pdisks, respectively, and run the command again.

6027-3800 [E] Device with path(s) *pathName* for new pdisk *pdiskName* is already in use by pdisk *pdiskName* of recovery group *recoveryGroupName*.

Explanation: The device specified for a new pdisk is already being used by an existing pdisk. The device can have multiple paths, which are shown in the error message.

User response: Specify an unused device for the pdisk and run the command again.

6027-3801 [E] [E] The checksum granularity for log vdisks in declustered array *declusteredArrayName* of RG *recoveryGroupName* must be at least *number* bytes.

Explanation: Use a checksum granularity that is not smaller than the minimum value given. You can use the **mmfspdisk** command to view the logical block sizes of the pdisks in this array to identify which pdisks are driving the limit.

User response: Change the checksumGranularity attribute of the new log vdisk to the indicated value, and then retry the command.

6027-3802 [E] [E] Pdisk *pdiskName* of RG *recoveryGroupName* has a logical block size of *number* bytes; the maximum logical block size for pdisks in declustered array *declusteredArrayName* cannot exceed the log checksum granularity of *number* bytes.

Explanation: Logical block size of pdisks added to this declustered array must not be larger than any log vdisk's checksum granularity.

User response: Use pdisks with equal or smaller

logical block size than the log vdisk's checksum granularity.

6027-3803 [E] [E] NSD format version 2 feature must be enabled before being changed. Upgrade recovery group version to at least *recoveryGroupVersion* to enable it.

Explanation: NSD format version 2 feature is not supported in current recovery group version.

User response: Apply the recovery group version recommended in the error message and retry the command.

6027-3804 [W] Skipping upgrade of pdisk *pdiskName* because the disk capacity of *number* bytes is less than the *number* bytes required for the new format.

Explanation: The existing format of the indicated pdisk is not compatible with NSD V2 descriptors.

User response: A complete format of the declustered array is required in order to upgrade to NSD V2.

6027-3805 [E] NSD format version 2 feature is not supported by the current recovery group version. A recovery group version of at least *rgVersion* is required for this feature.

Explanation: NSD format version 2 feature is not supported in the current recovery group version.

User response: Apply the recovery group version recommended in the error message and retry the command.

6027-3806 [E] The device given for pdisk *pdiskName* has a logical block size of *logicalBlockSize* bytes, which is not supported by the recovery group version.

Explanation: The current recovery group version does not support disk drives with the indicated logical block size.

User response: Use a different disk device or upgrade the recovery group version and retry the command.

6027-3807 [E] NSD version 1 specified for pdisk *pdiskName* requires a disk with a logical block size of 512 bytes. The supplied disk has a block size of *logicalBlockSize* bytes. For this disk, you must use at least NSD version 2.

Explanation: Requested logical block size is not supported by NSD format version 1.

User response: Correct the input file to use a different disk or specify a higher NSD format version.

6027-3808 [E] Pdisk *pdiskName* must have a capacity of at least *number* bytes for NSD version 2.

Explanation: The pdisk must be at least as large as the indicated minimum size in order to be added to the declustered array.

User response: Correct the input file and retry the command.

6027-3809 [I] Pdisk *pdiskName* can be added as NSD version 1.

Explanation: The pdisk has enough space to be configured as NSD version 1.

User response: Specify NSD version 1 for this disk.

6027-3810 [W] [W] Skipping the upgrade of pdisk *pdiskName* because no I/O paths are currently available.

Explanation: There is no I/O path available to the indicated pdisk.

User response: Try running the command again after repairing the broken I/O path to the specified pdisk.

6027-3811 [E] Unable to *action* vdisk MDI.

Explanation: The **tscrvdisk** command could not create or write the necessary vdisk MDI.

User response: Retry the command.

6027-3812 [I] Log group *logGroupName* assignment delay *delaySeconds* seconds for safe recovery.

Explanation: The recovery group configuration manager must wait. Prior disk lease for the failing manager must expire before assigning a new worker to the log group.

User response: None.

6027-3813 [A] Recovery group *recoveryGroupName* could not be served by node *nodeName*.

Explanation: The recovery group configuration manager could not perform a node assignment to manage the recovery group.

User response: Check whether there are sufficient nodes and whether errors are recorded in the recovery group event log.

6027-3814 [A] Log group *logGroupName* could not be served by node *nodeName*.

Explanation: The recovery group configuration manager could not perform a node assignment to manage the log group.

User response: Check whether there are sufficient nodes and whether errors are recorded in the recovery group event log.

6027-3815 [E] Erasure code not supported by this recovery group version.

Explanation: Vdisks with 4+2P and 4+3P erasure codes are not supported by all recovery group versions.

User response: Upgrade the recovery group to a later version using the **--version** option of the **mmchrecoverygroup** command.

6027-3816 [E] Invalid declustered array name (*declusteredArrayName*).

Explanation: A declustered array name given in the **mmcrrecoverygroup** or **mmaddpdisk** command is invalid.

User response: Use only the characters a-z, A-Z, 0-9, and underscore to specify a declustered array name and you can specify up to 63 characters.

6027-3817 [E] Invalid log group name (*logGroupName*).

Explanation: A log group name given in the **mmcrrecoverygroup** or **mmaddpdisk** command is invalid.

User response: Use only the characters a-z, A-Z, 0-9, and underscore to specify a declustered array name and you can specify up to 63 characters.

6027-3818 [E] Cannot create log group *logGroupName*; there can be at most *number* log groups in a recovery group.

Explanation: The number of log groups allowed in a recovery group has been exceeded.

User response: Reduce the number of log groups in the input file and retry the command.

6027-3819 [I] Recovery group *recoveryGroupName* delay *delaySeconds* seconds for assignment.

Explanation: The recovery group configuration manager must wait before assigning a new manager to the recovery group.

User response: None.

6027-3820 [E] Specifying canHoldVCD not supported by this recovery group version.

Explanation: The ability to override the default decision of whether a declustered array is allowed to hold vdisk configuration data is not supported by all recovery group versions.

User response: Upgrade the recovery group to a later version using the **--version** option of the **mmchrecoverygroup** command.

6027-3821 [E] Cannot set canHoldVCD=yes for small declustered arrays.

Explanation: Declustered arrays with less than 9+vcdSpares disks cannot hold vdisk configuration data.

User response: Add more disks to the declustered array or do not specify **canHoldVCD=yes**.

6027-3822 [I] Recovery group *recoveryGroupName* working index delay *delaySeconds* seconds for safe recovery.

Explanation: Prior disk lease for the workers must expire before recovering the working index metadata.

User response: None.

6027-3823 [E] Unknown node *nodeName* in the recovery group configuration.

Explanation: A node name does not exist in the recovery group configuration manager.

User response: Check for damage to the **mmsdrfs** file.

6027-3824 [E] The defined server *serverName* for recovery group *recoveryGroupName* could not be resolved.

Explanation: The host name of recovery group server could not be resolved by `gethostbyname()`.

User response: Fix host name resolution.

6027-3825 [E] The defined server *serverName* for node class *nodeClassName* could not be resolved.

Explanation: The host name of recovery group server could not be resolved by `gethostbyname()`.

User response: Fix host name resolution.

6027-3826 [A] Error reading volume identifier for recovery group *recoveryGroupName* from configuration file.

Explanation: The volume identifier for the named recovery group could not be read from the **mmsdrfs** file. This should never occur.

User response: Check for damage to the **mmsdrfs** file.

6027-3827 [A] Error reading volume identifier for vdisk *vdiskName* from configuration file.

Explanation: The volume identifier for the named vdisk could not be read from the **mmsdrfs** file. This should never occur.

User response: Check for damage to the **mmsdrfs** file.

6027-3828 [E] Vdisk *vdiskName* could not be associated with its recovery group *recoveryGroupName* and will be ignored.

Explanation: The named vdisk cannot be associated with its recovery group.

User response: Check for damage to the **mmsdrfs** file.

6027-3829 [E] A server list must be provided.

Explanation: No server list is specified.

User response: Specify a list of valid servers.

6027-3830 [E] Too many servers specified.

Explanation: An input node list has too many nodes specified.

User response: Verify the list of nodes and shorten the list to the supported number.

6027-3831 [E] A vdisk name must be provided.

Explanation: A vdisk name is not specified.

User response: Specify a vdisk name.

6027-3832 [E] A recovery group name must be provided.

Explanation: A recovery group name is not specified.

User response: Specify a recovery group name.

6027-3833 [E] Recovery group *recoveryGroupName* does not have an active root log group.

Explanation: The root log group must be active before the operation is permitted.

User response: Retry the command after the recovery group becomes fully active.

6027-3836 [I] Cannot retrieve MSID for device: *devFileName*.

Explanation: Command usage message for **tsgetmsid**.

User response: None.

6027-3837 [E] Error creating worker vdisk.

Explanation: The **tscrvdisk** command could not initialize the vdisk at the worker node.

User response: Retry the command.

6027-3838 [E] Unable to write new vdisk MDI.

Explanation: The **tscrvdisk** command could not write the necessary vdisk MDI.

User response: Retry the command.

6027-3839 [E] Unable to write update vdisk MDI.

Explanation: The **tscrvdisk** command could not write the necessary vdisk MDI.

User response: Retry the command.

6027-3840 [E] Unable to delete worker vdisk *vdiskName* **err=*errorNum*.**

Explanation: The specified vdisk worker object could not be deleted.

User response: Retry the command with a valid vdisk name.

6027-3841 [E] Unable to create new vdisk MDI.

Explanation: The **tscrvdisk** command could not create the necessary vdisk MDI.

User response: Retry the command.

6027-3843 [E] Error returned from node *nodeName* when preparing new pdisk *pdiskName* of RG *recoveryGroupName* for use: **err *errorNum***

Explanation: The system received an error from the given node when trying to prepare a new pdisk for use.

User response: Retry the command.

6027-3844 [E] Unable to prepare new pdisk *pdiskName* of RG *recoveryGroupName* for use: **exit *exitStatus*.**

Explanation: The system received an error from the **tspreparenewpdiskforuse** script when trying to prepare a new pdisk for use.

User response: Check the new disk and retry the command.

Notices

This information was developed for products and services offered in the U.S.A.

IBM may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not grant you any license to these patents. You can send license inquiries, in writing, to:

IBM Director of Licensing IBM Corporation North Castle Drive Armonk, NY 10504-1785 U.S.A.

For license inquiries regarding double-byte (DBCS) information, contact the IBM Intellectual Property Department in your country or send inquiries, in writing, to:

Intellectual Property Licensing Legal and Intellectual Property Law IBM Japan Ltd. 19-21,

Nihonbashi-Hakozakicho, Chuo-ku Tokyo 103-8510, Japan

The following paragraph does not apply to the United Kingdom or any other country where such provisions are inconsistent with local law:

INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

Any references in this information to non-IBM Web sites are provided for convenience only and do not in any manner serve as an endorsement of those Web sites. The materials at those Web sites are not part of the materials for this IBM product and use of those Web sites is at your own risk.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Licensees of this program who wish to have information about it for the purpose of enabling: (i) the exchange of information between independently created programs and other programs (including this one) and (ii) the mutual use of the information which has been exchanged, should contact:

IBM Corporation
Dept. 30ZA/Building 707
Mail Station P300

2455 South Road,
Poughkeepsie, NY 12601-5400
U.S.A.

Such information may be available, subject to appropriate terms and conditions, including in some cases, payment or a fee.

The licensed program described in this document and all licensed material available for it are provided by IBM under terms of the IBM Customer Agreement, IBM International Program License Agreement or any equivalent agreement between us.

Any performance data contained herein was determined in a controlled environment. Therefore, the results obtained in other operating environments may vary significantly. Some measurements may have been made on development-level systems and there is no guarantee that these measurements will be the same on generally available systems. Furthermore, some measurements may have been estimated through extrapolation. Actual results may vary. Users of this document should verify the applicable data for their specific environment.

Information concerning non-IBM products was obtained from the suppliers of those products, their published announcements or other publicly available sources. IBM has not tested those products and cannot confirm the accuracy of performance, compatibility or any other claims related to non-IBM products. Questions on the capabilities of non-IBM products should be addressed to the suppliers of those products.

This information contains examples of data and reports used in daily business operations. To illustrate them as completely as possible, the examples include the names of individuals, companies, brands, and products. All of these names are fictitious and any similarity to the names and addresses used by an actual business enterprise is entirely coincidental.

COPYRIGHT LICENSE:

This information contains sample application programs in source language, which illustrate programming techniques on various operating platforms. You may copy, modify, and distribute these sample programs in any form without payment to IBM, for the purposes of developing, using, marketing or distributing application programs conforming to the application programming interface for the operating platform for which the sample programs are written. These examples have not been thoroughly tested under all conditions. IBM, therefore, cannot guarantee or imply reliability, serviceability, or function of these programs. The sample programs are provided "AS IS", without warranty of any kind. IBM shall not be liable for any damages arising out of your use of the sample programs.

If you are viewing this information softcopy, the photographs and color illustrations may not appear.

Trademarks

IBM, the IBM logo, and ibm.com are trademarks or registered trademarks of International Business Machines Corp., registered in many jurisdictions worldwide. Other product and service names might be trademarks of IBM or other companies. A current list of IBM trademarks is available on the Web at "Copyright and trademark information" at www.ibm.com/legal/copytrade.shtml.

Intel is a trademark of Intel Corporation or its subsidiaries in the United States and other countries.

Java[™] and all Java-based trademarks and logos are trademarks or registered trademarks of Oracle and/or its affiliates.

Linux is a registered trademark of Linus Torvalds in the United States, other countries, or both.

Microsoft, Windows, and Windows NT are trademarks of Microsoft Corporation in the United States, other countries, or both.

UNIX is a registered trademark of The Open Group in the United States and other countries.

Glossary

This glossary provides terms and definitions for the ESS solution.

The following cross-references are used in this glossary:

- *See* refers you from a non-preferred term to the preferred term or from an abbreviation to the spelled-out form.
- *See also* refers you to a related or contrasting term.

For other terms and definitions, see the IBM Terminology website (opens in new window):

<http://www.ibm.com/software/globalization/terminology>

B

building block

A pair of servers with shared disk enclosures attached.

BOOTP

See Bootstrap Protocol (BOOTP).

Bootstrap Protocol (BOOTP)

A computer networking protocol that is used in IP networks to automatically assign an IP address to network devices from a configuration server.

C

CEC *See central processor complex (CPC).*

central electronic complex (CEC)

See central processor complex (CPC).

central processor complex (CPC)

A physical collection of hardware that consists of channels, timers, main storage, and one or more central processors.

cluster

A loosely-coupled collection of independent systems, or *nodes*, organized into a network for the purpose of sharing resources and communicating with each other. *See also GPFS cluster.*

cluster manager

The node that monitors node status using disk leases, detects failures, drives recovery, and selects file system

managers. The cluster manager is the node with the lowest node number among the quorum nodes that are operating at a particular time.

compute node

A node with a mounted GPFS file system that is used specifically to run a customer job. ESS disks are not directly visible from and are not managed by this type of node.

CPC *See central processor complex (CPC).*

D

DA *See declustered array (DA).*

datagram

A basic transfer unit associated with a packet-switched network.

DCM *See drawer control module (DCM).*

declustered array (DA)

A disjoint subset of the pdisks in a recovery group.

dependent fileset

A fileset that shares the inode space of an existing independent fileset.

DFM *See direct FSP management (DFM).*

DHCP *See Dynamic Host Configuration Protocol (DHCP).*

direct FSP management (DFM)

The ability of the xCAT software to communicate directly with the Power Systems server's service processor without the use of the HMC for management.

drawer control module (DCM)

Essentially, a SAS expander on a storage enclosure drawer.

Dynamic Host Configuration Protocol (DHCP)

A standardized network protocol that is used on IP networks to dynamically distribute such network configuration parameters as IP addresses for interfaces and services.

E

Elastic Storage Server (ESS)

A high-performance, GPFS NSD solution

made up of one or more building blocks that runs on IBM Power Systems servers. The ESS software runs on ESS nodes - management server nodes and I/O server nodes.

encryption key

A mathematical value that allows components to verify that they are in communication with the expected server. Encryption keys are based on a public or private key pair that is created during the installation process. See also *file encryption key (FEK)*, *master encryption key (MEK)*.

ESS See *Elastic Storage Server (ESS)*.

environmental service module (ESM)

Essentially, a SAS expander that attaches to the storage enclosure drives. In the case of multiple drawers in a storage enclosure, the ESM attaches to drawer control modules.

ESM See *environmental service module (ESM)*.

Extreme Cluster/Cloud Administration Toolkit (xCAT)

Scalable, open-source cluster management software. The management infrastructure of ESS is deployed by xCAT.

F

failback

Cluster recovery from failover following repair. See also *failover*.

failover

(1) The assumption of file system duties by another node when a node fails. (2) The process of transferring all control of the ESS to a single cluster in the ESS when the other clusters in the ESS fails. See also *cluster*. (3) The routing of all transactions to a second controller when the first controller fails. See also *cluster*.

failure group

A collection of disks that share common access paths or adapter connection, and could all become unavailable through a single hardware failure.

FEK See *file encryption key (FEK)*.

file encryption key (FEK)

A key used to encrypt sectors of an individual file. See also *encryption key*.

file system

The methods and data structures used to control how data is stored and retrieved.

file system descriptor

A data structure containing key information about a file system. This information includes the disks assigned to the file system (*stripe group*), the current state of the file system, and pointers to key files such as quota files and log files.

file system descriptor quorum

The number of disks needed in order to write the file system descriptor correctly.

file system manager

The provider of services for all the nodes using a single file system. A file system manager processes changes to the state or description of the file system, controls the regions of disks that are allocated to each node, and controls token management and quota management.

fileset A hierarchical grouping of files managed as a unit for balancing workload across a cluster. See also *dependent fileset*, *independent fileset*.

fileset snapshot

A snapshot of an independent fileset plus all dependent filesets.

flexible service processor (FSP)

Firmware that provides diagnosis, initialization, configuration, runtime error detection, and correction. Connects to the HMC.

FQDN

See *fully-qualified domain name (FQDN)*.

FSP See *flexible service processor (FSP)*.

fully-qualified domain name (FQDN)

The complete domain name for a specific computer, or host, on the Internet. The FQDN consists of two parts: the hostname and the domain name.

G

GPFS cluster

A cluster of nodes defined as being available for use by GPFS file systems.

GPFS portability layer

The interface module that each

installation must build for its specific hardware platform and Linux distribution.

GPFS Storage Server (GSS)
A high-performance, GPFS NSD solution made up of one or more building blocks that runs on System x servers.

GSS See *GPFS Storage Server (GSS)*.

H

Hardware Management Console (HMC)
Standard interface for configuring and operating partitioned (LPAR) and SMP systems.

HMC See *Hardware Management Console (HMC)*.

I

IBM Security Key Lifecycle Manager (ISKLM)
For GPFS encryption, the ISKLM is used as an RKM server to store MEKs.

independent fileset
A fileset that has its own inode space.

indirect block
A block that contains pointers to other blocks.

inode The internal structure that describes the individual files in the file system. There is one inode for each file.

inode space
A collection of inode number ranges reserved for an independent fileset, which enables more efficient per-fileset functions.

Internet Protocol (IP)
The primary communication protocol for relaying datagrams across network boundaries. Its routing function enables internetworking and essentially establishes the Internet.

I/O server node
An ESS node that is attached to the ESS storage enclosures. It is the NSD server for the GPFS cluster.

IP See *Internet Protocol (IP)*.

IP over InfiniBand (IPoIB)
Provides an IP network emulation layer on top of InfiniBand RDMA networks, which allows existing applications to run over InfiniBand networks unmodified.

IPoIB See *IP over InfiniBand (IPoIB)*.

ISKLM
See *IBM Security Key Lifecycle Manager (ISKLM)*.

J

JBOD array
The total collection of disks and enclosures over which a recovery group pair is defined.

K

kernel The part of an operating system that contains programs for such tasks as input/output, management and control of hardware, and the scheduling of user tasks.

L

LACP See *Link Aggregation Control Protocol (LACP)*.

Link Aggregation Control Protocol (LACP)
Provides a way to control the bundling of several physical ports together to form a single logical channel.

logical partition (LPAR)
A subset of a server's hardware resources virtualized as a separate computer, each with its own operating system. See also *node*.

LPAR See *logical partition (LPAR)*.

M

management network
A network that is primarily responsible for booting and installing the designated server and compute nodes from the management server.

management server (MS)
An ESS node that hosts the ESS GUI and xCAT and is not connected to storage. It can be part of a GPFS cluster. From a system management perspective, it is the central coordinator of the cluster. It also serves as a client node in an ESS building block.

master encryption key (MEK)
A key that is used to encrypt other keys. See also *encryption key*.

maximum transmission unit (MTU)

The largest packet or frame, specified in octets (eight-bit bytes), that can be sent in a packet- or frame-based network, such as the Internet. The TCP uses the MTU to determine the maximum size of each packet in any transmission.

MEK See *master encryption key (MEK)*.

metadata

A data structure that contains access information about file data. Such structures include inodes, indirect blocks, and directories. These data structures are not accessible to user applications.

MS See *management server (MS)*.

MTU See *maximum transmission unit (MTU)*.

N**Network File System (NFS)**

A protocol (developed by Sun Microsystems, Incorporated) that allows any host in a network to gain access to another host or netgroup and their file directories.

Network Shared Disk (NSD)

A component for cluster-wide disk naming and access.

NSD volume ID

A unique 16-digit hexadecimal number that is used to identify and access all NSDs.

node An individual operating-system image within a cluster. Depending on the way in which the computer system is partitioned, it can contain one or more nodes. In a Power Systems environment, synonymous with *logical partition*.

node descriptor

A definition that indicates how IBM Spectrum Scale uses a node. Possible functions include: manager node, client node, quorum node, and non-quorum node.

node number

A number that is generated and maintained by IBM Spectrum Scale as the cluster is created, and as nodes are added to or deleted from the cluster.

node quorum

The minimum number of nodes that must be running in order for the daemon to start.

node quorum with tiebreaker disks

A form of quorum that allows IBM Spectrum Scale to run with as little as one quorum node available, as long as there is access to a majority of the quorum disks.

non-quorum node

A node in a cluster that is not counted for the purposes of quorum determination.

O

OFED See *OpenFabrics Enterprise Distribution (OFED)*.

OpenFabrics Enterprise Distribution (OFED)

An open-source software stack includes software drivers, core kernel code, middleware, and user-level interfaces.

P

pdisk A physical disk.

PortFast

A Cisco network function that can be configured to resolve any problems that could be caused by the amount of time STP takes to transition ports to the Forwarding state.

R

RAID See *redundant array of independent disks (RAID)*.

RDMA

See *remote direct memory access (RDMA)*.

redundant array of independent disks (RAID)

A collection of two or more disk physical drives that present to the host an image of one or more logical disk drives. In the event of a single physical device failure, the data can be read or regenerated from the other disk drives in the array due to data redundancy.

recovery

The process of restoring access to file system data when a failure has occurred. Recovery can involve reconstructing data or providing alternative routing through a different server.

recovery group (RG)

A collection of disks that is set up by IBM Spectrum Scale RAID, in which each disk is connected physically to two servers: a primary server and a backup server.

remote direct memory access (RDMA)

A direct memory access from the memory of one computer into that of another without involving either one's operating system. This permits high-throughput, low-latency networking, which is especially useful in massively-parallel computer clusters.

RGD See *recovery group data (RGD)*.

remote key management server (RKM server)

A server that is used to store master encryption keys.

RG See *recovery group (RG)*.

recovery group data (RGD)

Data that is associated with a recovery group.

RKM server

See *remote key management server (RKM server)*.

S

SAS See *Serial Attached SCSI (SAS)*.

secure shell (SSH)

A cryptographic (encrypted) network protocol for initiating text-based shell sessions securely on remote computers.

Serial Attached SCSI (SAS)

A point-to-point serial protocol that moves data to and from such computer storage devices as hard drives and tape drives.

service network

A private network that is dedicated to managing POWER8 servers. Provides Ethernet-based connectivity among the FSP, CPC, HMC, and management server.

SMP See *symmetric multiprocessing (SMP)*.

Spanning Tree Protocol (STP)

A network protocol that ensures a loop-free topology for any bridged Ethernet local-area network. The basic function of STP is to prevent bridge loops and the broadcast radiation that results from them.

SSH See *secure shell (SSH)*.

STP See *Spanning Tree Protocol (STP)*.

symmetric multiprocessing (SMP)

A computer architecture that provides fast performance by making multiple processors available to complete individual processes simultaneously.

T

TCP See *Transmission Control Protocol (TCP)*.

Transmission Control Protocol (TCP)

A core protocol of the Internet Protocol Suite that provides reliable, ordered, and error-checked delivery of a stream of octets between applications running on hosts communicating over an IP network.

V

VCD See *vdisk configuration data (VCD)*.

vdisk A virtual disk.

vdisk configuration data (VCD)

Configuration data that is associated with a virtual disk.

X

xCAT See *Extreme Cluster/Cloud Administration Toolkit*.

Index

Special characters

/tmp/mmfs directory 9

A

array, declustered
background tasks 15

B

back up data 1
background tasks 15
best practices for troubleshooting 1, 5, 7

C

checksum
data 16
commands
errpt 9
gpfs.snap 9
lslpp 9
mmlsdisk 10
mmlsfs 10
rpm 9
comments viii
components of storage enclosures
replacing failed 22
contacting IBM 11

D

data checksum 16
declustered array
background tasks 15
diagnosis, disk 14
directed maintenance procedure 42
increase fileset space 45
replace disks 42
start gpfs daemon 44
start NSD 44
start performance monitoring collector service 45
start performance monitoring sensor service 46
synchronize node clocks 45
update drive firmware 43
update enclosure firmware 43
update host-adapter firmware 43
directories
/tmp/mmfs 9
disks
diagnosis 14
hardware service 17
hospital 14
maintaining 13
replacement 16
replacing failed 17, 36
DMP 42
replace disks 42
update drive firmware 43

DMP (*continued*)

update enclosure firmware 43
update host-adapter firmware 43
documentation
on web vii
drive firmware
updating 13

E

enclosure components
replacing failed 22
enclosure firmware
updating 13
errpt command 9
events 47

F

failed disks, replacing 17, 36
failed enclosure components, replacing 22
failover, server 16
files
mmfs.log 9
firmware
updating 13

G

getting started with troubleshooting 1
GPFS
events 47
RAS events 47
GPFS log 9
gpfs.snap command 9
GUI
directed maintenance procedure 42
DMP 42

H

hardware service 17
hospital, disk 14
host adapter firmware
updating 13

I

IBM Elastic Storage Server
best practices for troubleshooting 5, 7
IBM Spectrum Scale
back up data 1
best practices for troubleshooting 1, 5
events 47
RAS events 47
troubleshooting 1
best practices 2, 3
getting started 1
report problems 3

IBM Spectrum Scale (*continued*)
troubleshooting (*continued*)
 resolve events 2
 support notifications 2
 update software 2
warranty and maintenance 2
information overview vii

L

license inquiries 125
lslpp command 9

M

maintenance
 disks 13
message severity tags 106
mmfs.log 9
mmlsdisk command 10
mmlsfs command 10

N

node
 crash 11
 hang 11
notices 125

O

overview
 of information vii

P

patent information 125
PMR 11
preface vii
problem determination
 documentation 9
 reporting a problem to IBM 9
Problem Management Record 11

R

RAS events 47
rebalance, background task 15
rebuild-1r, background task 15
rebuild-2r, background task 15
rebuild-critical, background task 15
rebuild-offline, background task 15
recovery groups
 server failover 16
repair-RGD/VCD, background task 15
replace disks 42
replacement, disk 16
replacing failed disks 17, 36
replacing failed storage enclosure components 22
report problems 3
reporting a problem to IBM 9
resolve events 2
resources
 on web vii

rpm command 9

S

scrub, background task 15
server failover 16
service
 reporting a problem to IBM 9
service, hardware 17
severity tags
 messages 106
submitting viii
support notifications 2

T

tasks, background 15
the IBM Support Center 11
trademarks 126
troubleshooting
 best practices 1, 5, 7
 report problems 3
 resolve events 2
 support notifications 2
 update software 2
getting started 1
warranty and maintenance 2

U

update drive firmware 43
update enclosure firmware 43
update host-adapter firmware 43

V

vdisk
 data checksum 16

W

warranty and maintenance 2
web
 documentation vii
 resources vii



Printed in USA

SA23-1457-00

