



zEnterprise BladeCenter Extension
Installation Manual for Physical Planning
2458-002

GC27-2611-03

Level 03h





zEnterprise BladeCenter Extension
Installation Manual for Physical Planning
2458-002

GC27-2611-03

Note:

Before using this information and the product it supports, read the information in “Safety” on page v, Appendix G, “Notices,” on page 69, and *IBM Systems Environmental Notices and User Guide*, Z125–5823.

This edition, GC27-2611-03, applies to the IBM zEnterprise BladeCenter Extension (zBX) Model 002. This revision replaces GC27-2611-02.

There may be a newer version of this document in a **PDF** file available on **Resource Link**. Go to <http://www.ibm.com/servers/resourcelink> and click **Library** on the navigation bar. A newer version is indicated by a lowercase, alphabetic letter following the form number suffix (for example: 00a, 00b, 01a, 01b).

© Copyright IBM Corporation 2010, 2013.

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

Contents

Safety	v
Safety notices	v
World trade safety information	v
Laser safety information	v
Laser compliance	v

About this publication	vii
What is included in this publication	vii
Revisions	vii
Related publications	vii
Licensed Machine Code	vii
Accessibility	viii
How to send your comments	viii

Chapter 1. Introduction	1
System planning	1
ASHRAE declaration	2

Chapter 2. Environmental specifications	5
Conductive contamination	7

Chapter 3. Models and physical specifications	9
Physical dimensions	10
Shipping specifications	11
zBX Model 002 configurations	12
IBM WebSphere DataPower Integration	
Appliance XI50 for zEnterprise	12
Select IBM POWER7 blades	12
Select IBM System x blades	13
System upgrades	13
Other options	13
Plan view	15
Weight distribution	16
Weight distribution and multiple systems	18
Machine and service clearance areas	19
Cooling recommendations	21
Considerations for multiple system installations	22

Chapter 4. Guide for raised floor preparation	23
Casters	24
Procedure for cutting and placement of floor panels for raised floor	25
Raised floor with 610 mm (24 in) or 600 mm (23.5 in) floor panels	26

Chapter 5. Power requirements	27
Power installation considerations	28
Power specifications	29

Customer circuit breakers (CBs)	32
Power plugs and receptacles	33
Grounding specifications	34
Line cord specifications	35
Line physical protection	35
Service outlet (customer-supplied)	35

Chapter 6. Hardware Management Consoles	37
--	-----------

Chapter 7. Top-of-rack switch connections	39
SFP and SFP+ module descriptions and locations	39
SFP and SFP+ module feature codes	40
FC 0632	40
FC 0633	40
FC 0634	41
FC 0635	41
OSA to IEDN switch connections	42
IEDN zBX node-to-node connections	43

Appendix A. Top-of-rack switch ports worksheets	45
--	-----------

Appendix B. Fibre channel Storage Area Network information	49
---	-----------

Appendix C. IBM standard symbols	51
---	-----------

Appendix D. Acoustics	53
Acoustical noise emission levels	53
Relevant international standards	55

Appendix E. Dual power installation	57
--	-----------

Appendix F. Rear door heat exchanger	59
Secondary cooling loop specifications	61
Material considerations	61
Specifications for the water	61
Water delivery specifications	62
Layout and mechanical installation	66
Heat exchanger installation overview	66
Planning for heat exchangers in a raised floor environment	66

Appendix G. Notices	69
Trademarks	70
Electronic emission notices	70

Safety

Safety notices

Safety notices may be printed throughout this guide. **DANGER** notices warn you of conditions or procedures that can result in death or severe personal injury. **CAUTION** notices warn you of conditions or procedures that can cause personal injury that is neither lethal nor extremely hazardous. **Attention** notices warn you of conditions or procedures that can cause damage to machines, equipment, or programs.

World trade safety information

Several countries require the safety information contained in product publications to be presented in their translation. If this requirement applies to your country, a safety information booklet is included in the publications package shipped with the product. The booklet contains the translated safety information with references to the US English source. Before using a US English publication to install, operate, or service this IBM® product, you must first become familiar with the related safety information in the *Systems Safety Notices*, G229-9054. You should also refer to the booklet any time you do not clearly understand any safety information in the US English publications.

Laser safety information

All System z® models can use I/O cards such as PCI adapters, FICON®, Open Systems Adapter (OSA), InterSystem Coupling-3 (ISC-3), or other I/O features which are fiber optic based and utilize lasers or LEDs.

Laser compliance

All lasers are certified in the US to conform to the requirements of DHHS 21 CFR Subchapter J for Class 1 or Class 1M laser products. Outside the US, they are certified to be in compliance with IEC 60825 as a Class 1 or Class 1M laser product. Consult the label on each part for laser certification numbers and approval information.

CAUTION: Data processing environments can contain equipment transmitting on system links with laser modules that operate at greater than Class 1 power levels. For this reason, never look into the end of an optical fiber cable or open receptacle. (C027)

CAUTION: This product contains a Class 1M laser. Do not view directly with optical instruments. (C028)

About this publication

This publication contains information necessary for planning the physical installation of the IBM zEnterprise™ BladeCenter® Extension (zBX) Model 002 (FC 0501).

Figures included in this document illustrate concepts and are not necessarily accurate in content, appearance, or specific behavior.

What is included in this publication

This publication contains the following chapters and appendices:

- Chapter 1 provides an introduction to planning for your zBX Model 002.
- Chapter 2 provides environmental specifications for your zBX Model 002.
- Chapter 3 provides plan views, service clearances, weight distribution, and cooling information for the zBX Model 002.
- Chapter 4 contains information on preparation of the raised floor.
- Chapter 5 provides power requirements, specifications, and installation considerations.
- Chapter 6 provides the HMCs that are supported and HMC considerations.
- Chapter 7 provides top-of-rack switch connection information.
- The Appendices provide IBM standard symbols, environmental specifications, acoustics, power installation and power loads, a sample cabling schematic and upgrade paths.

Revisions

Technical changes to the text are indicated by a vertical line (|) to the left of the change.

Related publications

Other IBM publications that you will find helpful and that you should use along with this publication are in the following list. You can access these books from *Resource Link*® under the **Library** section.

- *Systems Safety Notices*, G229-9054
- *zEnterprise BladeCenter Extension Model 002 Installation Manual*, GC27-2610
- *zEnterprise System Ensemble Planning and Configuring Guide*, GC27-2608
- *System z Planning for Fiber Optic Links (ESCON, FICON, Coupling Links, and Open System Adapters)*, GA23-0367
- *Systems Environmental Notices and User Guide*, Z125-5823
- *Thermal Guidelines for Data Processing Environments*
- *American Society of Heating, Refrigeration, and Air Conditioning Engineers (ASHRAE) Handbook*

In addition to these references, there is general computer room planning information on IBM's Resource Link.

Licensed Machine Code

Licensed Machine Code is provided in accordance with the terms and conditions of the applicable IBM Customer Agreement or other applicable written agreement between the Customer and IBM.

Licensed Machine Code (LMC) is a fundamental component of the IBM zBX and is copyrighted and licensed by IBM. Each zBX is delivered with Licensed Machine Code that is customized to the specific machine ordered. The Licensed Machine Code enables the zBX to operate in accordance with its Official Published Specifications.

Model upgrades, feature additions, and system engineering changes may require updated Licensed Machine Code for the system. Updated Licensed Machine Code replaces the existing Licensed Machine Code.

Relocation of an zBX requires that the Licensed Machine Code be reinstalled at the new location. The procedure for relocating a zBX, "Discontinuing the System," is located in the *zEnterprise 196 Installation Manual* or *zEnterprise 114 Installation Manual*.

Accessibility

This publication is in Adobe Portable Document Format (PDF) and should be compliant with accessibility standards. If you experience difficulties using this PDF file you can request a web-based format of this publication. Go to Resource Link at <http://www.ibm.com/servers/resourcelink> and click **Feedback** from the navigation bar on the left. In the **Comments** input area, state your request, the publication title and number, choose **General comment** as the category and click **Submit**. You can also send an email to reslink@us.ibm.com providing the same information.

When you send information to IBM, you grant IBM a nonexclusive right to use or distribute the information in any way it believes appropriate without incurring any obligation to you.

How to send your comments

Your feedback is important in helping to provide the most accurate and high-quality information. Send your comments by using Resource Link at <http://www.ibm.com/servers/resourcelink>. Click **Feedback** on the navigation bar on the left. You can also send an email to reslink@us.ibm.com. Be sure to include the name of the book, the form number of the book, the version of the book, if applicable, and the specific location of the text you are commenting on (for example, a page number, table number, or a heading).

Chapter 1. Introduction

This chapter is intended to help you prepare your physical site for the installation of a zBX Model 002. Marketing and installation planning representatives are also available to help you with installation planning. Proper planning for your new zBX will facilitate a smooth installation and fast system startup.


System planning

As part of your system planning activity, you will make decisions about where to locate your equipment, who will operate the system, and so on. A good plan ensure that the equipment and materials are ready to use when the zBX arrives.

ASHRAE declaration

ASHRAE Declarations (Metric) for 2458-002 1, 2, 3, or 4 racks

ASHRAE Class 1	Typical Heat Release	Airflow Nominal	Airflow Maximum	Max Weight	Overall System Dimensions	Maximum Elevation (2)	Maximum Dry Bulb Temperature (2)	Maximum Dew Point (2)
Description	kBTU	m3/hr	m3/hr	kg	W x D x H (mm)	m	C°	C°
1 BladeCenter 7 Blades	12.3	898	1394	300	648 X 1099 X 2027	3048	35	21
1 BladeCenter 14 Blades	20.5	898	1394	400	648 X 1099 X 2027	3048	35	21
2 BladeCenters 28 Blades	39.9	1795	2788	738	648 X 1099 X 2027	3048	35	21
3 BladeCenters 42 Blades	59.3	2693	4182	987	1296 X 1099 X 2027	3048	35	21
4 BladeCenters 56 Blades	78.7	3590	5576	1237	1296 X 1099 X 2027	3048	35	21
5 BladeCenters 70 Blades	98.1	4488	6970	1486	1944 X 1099 X 2027	3048	35	21
6 BladeCenters 84 Blades	117.5	5386	8364	1736	1944 X 1099 X 2027	3048	35	21
7 BladeCenters 98 Blades	136.9	6283	9758	1985	2592 X 1099 X 2027	3048	35	21
8 BladeCenters 112 Blades	156.3	7181	11152	2235	2592 X 1099 X 2027	3048	35	21




Notes:

1. Maximum ambient reduces 1° C (1.8° F) for every 300 m (984 ft) over 900 m (2953 ft).
2. See the elevation label (🏔️) or tropical climate label (🌴) in the *Systems Safety Notices* document to determine if there are any elevation limitations or tropical climate limitations for your country.

ASHRAE Declarations (English) for 2458-002 1, 2, 3, or 4 racks

ASHRAE Class 1	Typical Heat Release	Airflow Nominal	Airflow Maximum	Max Weight	Overall System Dimensions	Maximum Elevation (2)	Maximum Dry Bulb Temperature (2)	Maximum Dew Point (2)
Description	kBTU	cfm	cfm	lbs	W x D x H (in)	ft	F °	F °
1 BladeCenter 7 Blades	12.3	528	820	660	25.6 X 43.3 X 79.9	10,000	95	69.8
1 BladeCenter 14 Blades	20.5	528	820	880	25.6 X 43.3 X 79.9	10,000	95	69.8
2 BladeCenters 28 Blades	39.9	1056	1640	1628	25.6 X 43.3 X 79.9	10,000	95	69.8
3 BladeCenters 42 Blades	59.3	1584	2460	2178	51.1 X 43.3 X 79.9	10,000	95	69.8
4 BladeCenters 56 Blades	78.7	2112	3280	2728	51.1 X 43.3 X 79.9	10,000	95	69.8
5 BladeCenters 70 Blades	98.1	2640	4100	3278	76.6 X 43.3 X 79.9	10,000	95	69.8
6 BladeCenters 84 Blades	117.5	3168	4920	3828	76.6 X 43.3 X 79.9	10,000	95	69.8
7 BladeCenters 98 Blades	136.9	3696	5740	4378	102.1 X 43.3 X 79.9	10,000	95	69.8
8 BladeCenters 112 Blades	156.3	4224	6560	4928	102.1 X 43.3 X 79.9	10,000	95	69.8

**Notes:**

1. Maximum ambient reduces 1° C (1.8° F) for every 300 m (984 ft) over 900 m (2953 ft).
2. See the elevation label (🏔️) or tropical climate label (🌴) in the *Systems Safety Notices* document to determine if there are any elevation limitations or tropical climate limitations for your country.

Chapter 2. Environmental specifications

Unless otherwise noted on individual specification pages, the following environmental specifications, based on an altitude from sea level to 900 meters (2953 feet), apply:

Note: These specifications are the same as for the z196 or z114. If your data center is operating properly, you already have acceptable environmental conditions for the 2458.

High Ambient Temperature	Long-term recommended 27°C (80.6°F)	Maximum ambient allowed 32°C (89.6°F)
Low Ambient Temperature	Long-term recommended 18°C (64.4°F)	Minimum ambient allowed 10°C (50°F)
Low end humidity	Long-term recommended 5.5°C (41.9°F) dew point	Minimum relative humidity allowed 8%
High end humidity	Long-term recommended 60% relative humidity and 15°C (59°F) dew point	Maximum relative humidity allowed 80% relative humidity and 17°C (62.6°F) dew point
Gaseous contamination	Class G1 as per ANSI/ISA S71.04–1985 ¹	
Particulate contamination	1. Room air must be filtered continuously using appropriate filters. 2. The deliquescent relative humidity of the particulate contamination shall be more than 80%. ²	
Environment, nonoperating:³		
Temperature	5°C (41°F) to 41°C (105.8°F)	
Relative humidity	8% - 80% R/H	
Maximum dew point	Less than 27.3°C (80.6°F)	
Gaseous contamination	Class G1 as per ANSI/ISA S71.04–1985 ³	
Environment, shippings:		
Temperature	-40°C (-40°F) to 60°C (140°F)	
Relative humidity	5% - 100% R/H (no condensation)	
Web bulb	Less than 29°C (84.2°F)	
Shipping package	IBM-approved vapor barrier bag with desiccant	
Environment, storage:		
Temperature	1°C (33.8°F) to 60°C (140°F)	
Relative humidity	5% - 80% R/H (no condensation)	
Web bulb	Less than 29°C (84.2°F)	
Shipping package	IBM-approved vapor barrier bag with desiccant	
Note:		
1. ANSI/ISA-S71.04. 1985. "Environmental conditions for process measurement and control systems: Airborne contaminants." Instrument Society of America, Research Triangle Park, NC, 1985.		
2. The deliquescent relative humidity of particulate contamination is the relative humidity at which dust absorbs enough water to become wet and promote ionic conduction.		
3. The machine should be in an environment that satisfies the operating environment specifications for at least one day before it is powered on.		

Note: Prior to the installation of an IBM system, careful consideration should be given to the computer room environment. If there is any question about potential corrosive gases or level of particulates, contact your IBM representative for assistance in monitoring the environment.

Beyond the specific information provided in this document, IBM recommends that the customer's facility meet the general guidelines published in the *American Society of Heating, Refrigeration, and Air Conditioning Engineers (ASHRAE) Handbook*.

Conductive contamination

Attention:

Semiconductors and sensitive electronics used in current Information Technology equipment have allowed for the manufacture of very high density electronic circuitry. While new technology allows for significant increases or capacity in a smaller physical space, it is susceptible to contamination, especially contamination particles that will conduct electricity. Since the early 1990s, it has been determined that data center environments may contain sources of conductive contamination. Contaminants include; carbon fibers, metallic debris such as aluminum, copper and steel filings from construction, and zinc whiskers from zinc-electroplated materials used in raised floor structures.

Although very small, and at times not easily seen without the visual aide of magnifying lenses, this type of contamination can have disastrous impact on equipment availability and reliability. Errors, component damage and equipment outages caused by conductive contamination can be difficult to diagnose. Failures may be at first attributed to other more common factors such as lightning events or electrical power quality or even just presumed to be defective parts.

The most common conductive contamination in raised-floor data centers is what is known as zinc whiskers. It is the most common because it is frequently found on the underside of certain types of access floor tiles. Typically, the wood core style floor tile has a flat steel bottom. The steel may be coated with zinc either by a hot dip galvanize process or by zinc electroplate. The zinc electroplate steel exhibits a phenomena which appears as whisker-like growths on the surface. These small particles of approximately 1-2 mm (.04-.08 in) in length, can break away from the surface and get pulled into the cooling air stream. Eventually they may be ingested by the equipment air, settle on a circuit board and create a problem. If you suspect that you may have this type of problem, contact your IBM Service representative.

Airborne particulates (including metal flakes or particles) and reactive gases acting alone or in combination with other environmental factors such as humidity or temperature might pose a risk to the zBX that is described in this document. Risks that are posed by the presence of excessive particulate levels or concentrations of harmful gases include damage that might cause the zBX to malfunction or cease functioning altogether. This specification sets forth limits for particulates and gases that are intended to avoid such damage. The limits must not be viewed or used as definitive limits because numerous other factors, such as temperature or moisture content of the air, can influence the impact of particulates or environmental corrosives and gaseous contaminant transfer. In the absence of specific limits that are set forth in this document, you must implement practices that maintain particulate or gas levels that are consistent with the protection of human health and safety. If IBM determines that the levels of particulates or gases in your environment have caused damage to the zBX IBM may condition provision of repair or replacement of zBX or parts on implementation of appropriate remedial measures to mitigate such environmental contamination. Implementation of such remedial measures is a customer responsibility.

Table 1. Contaminant Descriptions

Contaminant	Description
Gaseous contamination	Severity level G1 as per ANSI/ISA 71.04-1985 ¹ which states that the reactivity rate of copper coupons shall be less than 300 Angstroms per month ($\text{\AA}/\text{month}$, $\approx 0.0039 \mu\text{g}/\text{cm}^2\text{-hour}$ weight gain). ² In addition, the reactivity rate of silver coupons shall be less than 300 $\text{\AA}/\text{month}$ ($\approx 0.0035 \mu\text{g}/\text{cm}^2\text{-hour}$ weight gain). ³ The reactive monitoring of gaseous corrosivity should be conducted approximately 2 inches (5 cm) in front of the rack on the air inlet side at one-quarter and three-quarter frame height off the floor or where the air velocity is much higher.
Particulate contamination	<p>Data centers must meet the cleanliness level of ISO 14644-1 class 8. For data centers without airside economizer, the ISO 14644-1 class 8 cleanliness may be met simply by the choice of the following filtration:</p> <ul style="list-style-type: none"> • The room air may be continuously filtered with MERV 8 filters. Air entering a data center may be filtered with MERV 11 or preferably MERV 13 filters. • For data centers with airside economizers, the choice of filters to achieve ISO class 8 cleanliness depends on the specific conditions present at that data center. <p>The deliquescent relative humidity of the particulate contamination should be more than 60% RH.⁴</p> <p>Data centers must be free of zinc whiskers.⁵</p>


Note:

1. ANSI/ISA-71.04.1985. "Environmental conditions for process measurement and control systems: Airborne contaminants." Instrument Society of America, Research Triangle Park, NC, 1985.
2. The derivation of the equivalence between the rate of copper corrosion product thickness growth in $\text{\AA}/\text{month}$ and the rate of weight gain assumes that Cu_2S and Cu_2O grow in equal proportions.
3. The derivation of the equivalence between the rate of silver corrosion product thickness growth in $\text{\AA}/\text{month}$ and the rate of weight gain assumes that Ag_2S is the only corrosion product.
4. The deliquescent relative humidity of particulate contamination is the relative humidity at which the dust absorbs enough water to become wet and promote corrosion and/or ion migration.
5. Surface debris is randomly collected from 10 areas of the data center on a 1.5-cm diameter disk of sticky electrically conductive tape on a metal stub. If examination of the sticky tape in a scanning electron microscope reveals no zinc whiskers, the data center is considered free of zinc whiskers.

Chapter 3. Models and physical specifications

This chapter provides the following detailed information for the IBM zBX Model 002.

- Model and frame descriptions
- Shipping specifications
- Plan view and specifications
- Weight distribution data and service clearances information
- Cooling recommendations.



Facts you should know about the zBX:

- The 2458-002 can consist of one to four racks.
- The racks are shipped as separate units, fastened together at install time
- There are separate shipping containers for the covers for each rack
- The zBX Model 002 may be installed on a non-raised floor. In a non-raised floor environment, where cables are exposed, refer to local and national electric and safety codes for more information.
- **If you are planning an installation on a raised floor in Canada**, the installation must be in accordance with Section 12-020 of the CEC. In any country, refer to your national electric code if you have questions about routing data processing cables in exposed areas.

Physical dimensions

Frame-cover combination	Width mm (in)	Depth mm (in)	Height mm (in)
Frame B with covers	648 (25.6)	1099 (43.3)	2027 (79.9)
Frame B and C with covers	1296 (51.1)	1099 (43.3)	2027 (79.9)
Frame B, C, and D with covers	1944 (76.6)	1099 (43.3)	2027 (79.9)
Frame B, C, D, and E with covers	2592 (102.1)	1099 (43.3)	2027 (79.9)
Note: 1. The rear acoustic door adds 191 mm (7.6 in) to the depth of the rack. 2. The rear heat exchanger door adds 143 mm (5.7 in) to the depth of the rack.			

Shipping specifications

zBX racks are shipped mounted on pallets and use heavy external packaging requiring commercial lift transportation. This packaging is used for all zBX racks shipped anywhere.

Height reduction - FC 0570

If you have doorways with openings less than 2032 mm (80.0 in) high, you should order FC 0570. This feature reduces the frame height to 1754 mm (69.1 in). The top portion of the frames are shipped in a separate carton, as are the frame side covers.

Shipping dimensions

Palletized frames	Width mm (in)	Depth mm (in)	Height mm (in)	Max Weight kg (lb)
Americas	912 (36.0)	1295 (51.0)	2125 (83.7)	972 (2143.0)
Palletized frames	Width mm (in)	Depth mm (in)	Height mm (in)	Max Weight kg (lb)
World Trade	912 (36.0)	1295 (51.0)	2125 (83.7)	1002 (2209.1)

Important:

The zBX is comprised of some of the most sophisticated and complex electronic equipment ever integrated into one computer. As such, this hardware needs to be protected from negative environmental impacts to ensure the utmost reliability. One of the key factors affecting this reliability is moving the system from the loading dock into the controlled environment of your computer room on the day it is delivered.

To ensure that optimum environmental conditions are maintained, work with your marketing representative to schedule the delivery at a time when you can transport the system components from the point of delivery to the computer room destination without unnecessary delay. Prompt handling upon arrival will prevent any possibility of a problem caused by exposure to temperature extremes, severe weather, or high humidity.

zBX Model 002 configurations

The zBX Model 002 connects to only z196 and z114.

The following blades/optimizers can be installed in the 2458-002:

- Optimizers
 - IBM WebSphere® DataPower® Integration Appliance XI50 for zEnterprise
- IBM blades
 - Select IBM POWER7® blades
 - Select IBM System x® blades

IBM System x blades, IBM POWER7 blades, and IBM WebSphere DataPower Integration Appliance XI50 for zEnterprise optimizers may be installed together in the same BladeCenter, in any quantity, up to their maximum number.

IBM WebSphere DataPower Integration Appliance XI50 for zEnterprise

If you are ordering IBM WebSphere DataPower Integration Appliance XI50 for zEnterprise, you will use FC 0611 and a quantity, representing the number of optimizers you are ordering, as shown in the following table, to place your zBX order. You need only specify the number of optimizers. The BladeCenters and racks are generated by the optimizer quantity.

Feature code	Quantity	Minimum # of BladeCenters required
0611 IBM WebSphere DataPower Integration Appliance XI50 for zEnterprise	up to 07	1 BladeCenter containing 7 optimizers
0611 IBM WebSphere DataPower Integration Appliance XI50 for zEnterprise	up to 14	2 BladeCenters containing 14 optimizers
0611 IBM WebSphere DataPower Integration Appliance XI50 for zEnterprise	up to 21	3 BladeCenters containing 21 optimizers
0611 IBM WebSphere DataPower Integration Appliance XI50 for zEnterprise	up to 28	4 BladeCenters containing 28 optimizers

Select IBM POWER7 blades

If you are ordering the zBX Model 002 with select POWER7 blades, you are responsible for procuring and installing the blades. IBM will provide the racks and chassis. The feature code for select POWER7 blades is 0612, and you must supply the quantity of these blades to IBM, regardless of where you obtain them, so that the proper entitlement and enablement may be built to send with the racks and BladeCenters. Instructions for how to install a blade can be found in the “Planning for IBM blades” chapter in the *zEnterprise System Ensemble Planning and Configuring Guide*.

Feature code	Quantity	Minimum # of BladeCenters required
0612 select IBM POWER7 blades	01-14	1 BladeCenter
0612 select IBM POWER7 blades	15-28	2 BladeCenters
0612 select IBM POWER7 blades	29-42	3 BladeCenters
0612 select IBM POWER7 blades	43-56	4 BladeCenters
0612 select IBM POWER7 blades	57-70	5 BladeCenters
0612 select IBM POWER7 blades	71-84	6 BladeCenters
0612 select IBM POWER7 blades	85-98	7 BladeCenters
0612 select IBM POWER7 blades	99-112	8 BladeCenters

Select IBM System x blades

If you are ordering the zBX Model 002 with select IBM System x blades, you are responsible for procuring and installing the blades. IBM will provide the racks and chassis. The feature code for IBM System x blades is 0613, and you must supply the quantity of these blades to IBM, regardless of where you obtain them, so that the proper entitlement and enablement may be built to send with the racks and BladeCenters. Instructions for how to install a blade can be found in the “Planning for IBM blades” chapter in the *zEnterprise System Ensemble Planning and Configuring Guide*.

Feature code	Quantity	Minimum # of BladeCenters required
0613 select IBM System x blades	01-14	1 BladeCenter
0613 select IBM System x blades	15-28	2 BladeCenters
0613 select IBM System x blades	29-42	3 BladeCenters
0613 select IBM System x blades	43-56	4 BladeCenters

System upgrades

Upgrading a zBX consists of adding additional optimizers or IBM blades.

For IBM WebSphere DataPower Integration Appliance XI50 for zEnterprise blades, upgrades may be made in increments of one blade, up to a maximum of 28.


For select IBM Power7 blades, you can install up to 112 blades in four racks.

For select IBM System x blades, you can install up to 56 blades in four racks.


Other options

You may want to consider the following additional options:

- Height reduction (FC 0570). This feature separates the racks into a 36 EIA unit lower part and a removable 6 EIA unit upper part, allowing the rack to fit through doorways that are less than standard height.
- A Hardware Management Console (FC 0091). This console comes with a 6096 flat panel monitor. This may be appropriate if the zEC12 to which your zBX will be connected has different service provisions than the zBX.
- A rear acoustic door (FC 0543).
- A rear heat exchanger door to provide additional cooling for larger clusters of blades (FC 0540).




Acoustic door
FC 0543



Heat exchanger door
FC 0540

Plan view



Rack Entry/Exit	Cutout dimension for raised floor	
	(mm)	(in)
Rear	152 x 305	6 x 12

- Note:**
1. The rear acoustic door adds 191 mm (7.6 in) to the depth of the rack.
 2. The rear heat exchanger door adds 143 mm (5.7 in) to the depth of the rack.

Weight distribution

Rack B must be installed within 25 m (82 feet) of the managing z196 or z114 to which it will be connected. This is a service requirement. However, it is recommended that the zBX be placed as close as possible to the managing z196 or z114.

The following table shows weights and dimensions used to calculate floor loading for the zBX Model 002 (racks B and C). Floor loading calculations are intended for a raised floor environment.

Table 2. Floor loading calculations


Description	Weight kg (lbs)
IBM POWER7 - rack B with 28 blades	594 (1310)
IBM DataPower Integration Appliance XI50 for zEnterprise - rack B with 14 optimizers	575 (1268)
IBM System x - rack B with 28 blades	628 (1385)
IBM POWER7 - racks B and C with 56 blades	1169 (2578)
IBM DataPower Integration Appliance XI50 for zEnterprise - racks B and C with 28 optimizers	1131 (2494)
IBM System x - rack B and C with 56 blades	1242 (2739)
Description	Measurement - mm (in)
Width - rack B with 28 blades/optimizers	648 (25.6)
Width - racks B and C with 56 blades/optimizers	1296 (51.1)
Rack depth	1099 (43.3)
Service clearance - front	1219 (48.0)
Service clearance - rear	762 (30.0)
Notes: 1. Weight includes covers. Width and depth are indicated with covers. 2. For a two-rack zBX, weight is based on maximum configuration, not the addition of the maximum weight of each frame.	

Table 3. Weights for individual blades

Blade type	Weight
IBM WebSphere DataPower Integration Appliance XI50 for zEnterprise	7.4 kg (16.4 lb)
IBM POWER7	4.4 kg (9.6 lb)
IBM System x	5.6 kg (12.4 lb)

The following figure shows floor loading values for the zBX racks, fully populated.

Weight Distribution



Weight distribution and multiple systems

Under typical conditions, service clearances of adjacent products may be overlapped but weight distribution areas should not be overlapped. If weight distribution clearances are overlapped, the customer should obtain the services of a qualified consultant or structural engineer to determine floor loading. Regardless of floor loading, minimum service and aisle clearances must be observed.

For physical planning purposes, you must verify system placement considering:

- Weight distribution
- Power availability
- Power access
- Machine and service clearance area
- Air conditioning delivery
- Thermal interaction
- Cable locations
- Floor tile cutouts.


Machine and service clearance areas

Machine area is the actual floor space covered by the system. Service clearance area includes the machine area, plus additional space required to open the covers for service access to the system.

Number of Racks	Machine Area M ² (ft ²)	Service Clearance Area M ² (ft ²)
1 (B)	.72 (7.75)	2.0 (21.53)
2 (B + C)	1.43 (15.40)	4.0 (43.06)
3 (B + C + D)	2.14 (23.04)	6.0 (64.59)
4 (B + C + D + E)	2.85 (30.68)	8.0 (86.12)

Notes:

1. Machine area includes installed covers.
2. Service clearance area must be free of all obstacles. Units must be placed in a way that all service areas are accessible. The weight distribution clearance area extending beyond the service clearance area, such as the area at the outside corners of the units, may contain support walls and columns.




Minimum Service Clearances

d = 1219 mm (48 in) - front

e = 762 mm (30 in) - rear

g = 648 mm (25.5 in) - side to side




Minimum Service Clearances

d = 1219 mm (48 in) - front

e = 762 mm (30 in) - rear

g = 1296 mm (51 in) - side to side




Minimum Service Clearances

d = 1219 mm (48 in) - front

e = 762 mm (30 in) - rear

g = 1944 mm (77 in) - side to side



Minimum Service Clearances


d = 1219 mm (48 in) - front

e = 762 mm (30 in) - rear

g = 2592 mm (102.1 in) - side to side

Cooling recommendations

The following illustration does not represent any particular machine type, and is intended only to show hot and cold airflow and the arrangement of equipment on the raised floor.



A typical zBX uses chilled air, provided from under the raised floor, to cool the system. As shown, rows of servers must face front-to-front. Chilled air is usually provided through perforated floor panels placed in rows between the fronts of servers (the **cold** aisles shown in the figure). Perforated tiles generally are not be placed in the hot aisles. (If your particular computer room causes the temperature in the hot aisles to exceed limits of comfort for activities like system service, you may add as many perforated tiles as necessary to create a satisfactory comfort level.) Heated exhaust air exits the computer room above the computing equipment.

Considerations for multiple system installations

When integrating a zBX into an existing multiple-system environment, or when adding additional systems to an installed zBX, consider the following factors:

- **Thermal interactions**

Although computer room floor space is valuable, for optimal cooling, it is recommended that zBX have a 1220 mm (48.1 in) aisle between rows of systems to reduce surrounding air temperature. See “Cooling recommendations” on page 21.

- **Floor placement**

The zBX must be carefully placed for the cable openings to match the floor cutouts. Rack B must be installed within 25 m (82 feet) of the managing zEC12 to which it will be connected. This is a service requirement. However, it is recommended that the zBX be placed as close as possible to the managing zEC12.

- **Floor loading**

When trying to optimize floor space utilization, floor loading weight distribution rules may be inadvertently violated by overlapping weight distribution areas of adjacent machines. Obtain the services of a qualified structural engineer if you are uncertain of the floor load assessment for your computer room.

Chapter 4. Guide for raised floor preparation

This chapter provides recommendations and requirements for making the necessary openings in the raised floor for installation.


Rack B must be installed within 25 m (82 ft) of the zEnterprise to which it will be connected. This is a service requirement. However, it is recommended that the zBX be placed as close as possible to the managing zEnterprise.

The drawings on the following pages are intended only to show relative positions and accurate dimensions of floor cutouts. They are **not** machine templates and are **not** drawn to scale.

Raised floor cutouts should be protected by electrically nonconductive molding, appropriately sized, with edges treated to prevent cable damage and to prevent casters from rolling into the floor cutouts.

Casters

The following illustration shows the physical dimensions around the casters. When planning for both the movement and positioning of the system, be aware that each caster swivels in a circle slightly larger than 130 mm (5.1 in) in diameter. Exercise caution when working around floor cutouts.





Procedure for cutting and placement of floor panels for raised floor

Important:

Ensure adequate floor space is available to place the frames over the floor panels exactly as shown on the drawing.

1. Identify the panels needed, and list the total quantity of each panel required for the installation.
2. Cut the required quantity of panels. If you have existing equipment already installed over these panels, you do not have to cut them.
3. When cutting the panels, you must adjust the size of the cut for the thickness of the edge molding you are using. The dimensions shown are finished dimensions.
4. For ease of installation, number each panel as it is cut as shown on the panel specification pages.
5. Use the raised floor diagram to install the panels in the proper positions.

Raised floor with 610 mm (24 in) or 600 mm (23.5 in) floor panels



Frame Entry/Exit	Cutout dimensions for raised floor	
	(mm)	(in)
Front	152 x 305	6 x 12

Chapter 5. Power requirements

zBX Model 002 **may** require as many as **16** customer power feeds. A fully configured four-rack zBX has sixteen power distribution units (PDUs). If you are ordering a smaller configuration, but intend to grow the installation, be sure to plan for the full complement of power supplies now. In addition there should be at least two service outlets near the installation position. Service outlets require standard 100V to 130V or 200V to 240V, 50/60Hz, single-phase power.

zBX operates with:

- 50/60Hz AC power
- Voltages ranging from 200V to 415V

Note: The 32 amp wye 380V or 415V power option provides 220V or 240V line to neutral. BladeCenters operate on nominal 208 or 220V supplies.

- Both single-phase and three-phase wiring

Power installation considerations

zBX BladeCenters each operate from two fully-redundant power supplies (PDUs). These redundant PDUs each have their own line cords, allowing the system to survive the loss of customer power to either line cord. If power is interrupted to one of the PDUs, the other PDU will pick up the entire load and the BladeCenter will continue to operate without interruption.

Table 4. Power receptacles versus BladeCenters

Number of racks	Number of BladeCenters	Number of power receptacles needed
1	1	2
1	2	4
2	3	6
2	4	8
3	5	10
3	6	12
4	7	14
4	8	16

Therefore the line cord(s) for each PDU must be wired to support the entire power load of the BladeCenter to which that PDU supplies power.

Note: The power cord set(s) provided are for use only with this product.

For the most reliable availability, the line cords on each side of the racks should be powered from different building power distribution units. The left side line cords should be connected to one building power distribution unit. The right side line cords should be connected to a different building power distribution unit than the left side cords.

See Appendix E, "Dual power installation," on page 57 for examples of typical redundant wiring facilities.

The power supplies at the front end of the system use active resistive load synthesis. Harmonic distortion of the current waveform is small enough that it need not be considered in planning the installation. The power factor is typically 0.95 or higher.

Supply type	Nominal voltage range (V)	Voltage tolerance (V)	Frequency range (Hz)
Two to sixteen redundant 3-phase line cords	200-480	180-509	50-60

Source type	Frequency	Input voltage range (V)	Rated input current (A)
Three-phase (60A plug) (U.S.)*	50/60 Hz	208V	48A
Single-phase (60A plug) (U.S.)	50/60 Hz	208V	48A
Single-phase (63A plug) (W/T)	50/60 Hz	230V	63A
Three-phase (32A plug) (W/T)	50/60 Hz	380-415V	32A
Note: The 32 amp wye 380V or 415V power option provides 220V or 240V line to neutral. BladeCenters operate on nominal 208 or 220V supplies.			

* Power cord is permanently attached to the PDU.

Power specifications

The following table provides power values based on the number of blades.

Table 5. Blade power ratings

Number of zBX blades	Maximum utility power (in KW)	Heat output (in kBTU/hour)
14	12.1	41.14
28	21.7	73.78
42	31.3	106.42
56	40.9	139.06
70	50.5	171.70
84	60.1	204.34
98	69.7	236.98
112	79.3	269.62

Note:

1. The power factor is approximately unity.
2. Input power (kVA) equals heat output (kW).
3. For heat output expressed in kBTU per hour, multiply table entries by 3.4.
4. For 3-phase installations, phase balancing is accomplished with the power cable connections between the BladeCenters and the PDUs. Refer to Table 6 on page 30.
5. See Appendix E, “Dual power installation,” on page 57 for recommendations on utility connections that better balance the current for installations where multiple systems are connected to the same power panel.

Table 6. 3-phase power balancing (BladeCenter 1, BladeCenter 2, BladeCenter 3, BladeCenter 4)

Cable: BladeCenter to PDU (1-into-3 cable)	Label on the PDU ends of the cable
BladeCenter 1	
B10BPP2 to B06NP01	Blower 5.5A
B10BPP2 to B06NP04	PM 1/2 16A (PM= BladeCenter power module numbers)
B10BPP2 to B06NP07	PM 3/4 16A
B10BPP1 to B06ZP01	PM 1/2 16A
B10BPP1 to B06ZP04	PM 3/4 16A
B10BPP1 to B06ZP07	Blower 5.5A
BladeCenter 2	
B01BPP2 to B21NP01	Blower 5.5A
B01BPP2 to B21NP04	PM 1/2 16A
B01BPP2 to B21NP07	PM 3/4 16A
B01BPP1 to B21ZP01	PM 1/2 16A
B01BPP1 to B21ZP04	PM 3/4 16A
B01BPP1 to B21ZP07	Blower 5.5A
BladeCenter 3	
C10BPP2 to C06NP01	Blower 5.5A
C10BPP2 to C06NP04	PM 1/2 16A
C10BPP2 to C06NP07	PM 3/4 16A
C10BPP1 to C06ZP01	PM 1/2 16A
C10BPP1 to C06ZP04	PM 3/4 16A
C10BPP1 to C06ZP07	Blower 5.5A
BladeCenter 4	
C01BPP2 to C21NP01	Blower 5.5A
C01BPP2 to C21NP04	PM 1/2 16A
C01BPP2 to C21NP07	PM 3/4 16A
C01BPP1 to C21ZP01	PM 1/2 16A
C01BPP1 to C21ZP04	PM 3/4 16A
C01BPP1 to C21ZP07	Blower 5.5A

Table 7. 3-phase power balancing (BladeCenter 5, BladeCenter 6, BladeCenter 7, BladeCenter 8)

Cable: BladeCenter to PDU (1-into-3 cable)	Label on the PDU ends of the cable
BladeCenter 5	
D10BPP2 to D06NP01	Blower 5.5A
D10BPP2 to D06NP04	PM 1/2 16A
D10BPP2 to D06NP07	PM 3/4 16A
D10BPP1 to D06ZP01	PM 1/2 16A
D10BPP1 to D06ZP04	PM 3/4 16A
D10BPP1 to D06ZP07	Blower 5.5A
BladeCenter 6	
D01BPP2 to D21NP01	Blower 5.5A
D01BPP2 to D21NP04	PM 1/2 16A
D01BPP2 to D21NP07	PM 3/4 16A
D01BPP1 to D21ZP01	PM 1/2 16A
D01BPP1 to D21ZP04	PM 3/4 16A
D01BPP1 to D21ZP07	Blower 5.5A
BladeCenter 7	
E10BPP2 to E06NP01	Blower 5.5A
E10BPP2 to E06NP04	PM 1/2 16A
E10BPP2 to E06NP07	PM 3/4 16A
E10BPP1 to E06ZP01	PM 1/2 16A
E10BPP1 to E06ZP04	PM 3/4 16A
E10BPP1 to E06ZP07	Blower 5.5A
BladeCenter 8	
E01BPP2 to E21NP01	Blower 5.5A
E01BPP2 to E21NP04	PM 1/2 16A
E01BPP2 to E21NP07	PM 3/4 16A
E01BPP1 to E21ZP01	PM 1/2 16A
E01BPP1 to E21ZP04	PM 3/4 16A
E01BPP1 to E21ZP07	Blower 5.5A

Customer circuit breakers (CBs)

The following table shows the maximum circuit breaker ratings based on input voltage.

Input voltage range (V)	System rated current (A)	Circuit breaker
200V	48A	60 amps
208 - 240V	63A	63 amps
380-415V	32A	32 amps

It is recommended, for simplicity and ease of upgrades, that the circuit breaker ratings in this table be used on all power cords for all installations. The actual power drawn (heat load) by any configuration will not be affected.

Note: System z server design incorporates Electromagnetic Interference filter capacitors required to block electrical noise from penetrating the power grid. A characteristic of filter capacitors, during normal operation, is high leakage currents. Depending on the server configuration, this leakage current can reach 350mA (350 milliamps). For most reliable operation, **Ground Fault Circuit Interrupter (GFCI), Earth Leakage Circuit Breaker (ELCB) or Residual Current Circuit Breaker (RCCB) type circuit breakers are not recommended for use with System z servers.** By internal design and grounding, System z servers are fully certified for safe operation (compliance with IEC, EN, UL, CSA 60950-1).

However, if leakage detection circuit breakers are required by local electrical practice, **the breakers should be sized for a leakage current rating not less than 500mA** in order to reduce the risk of server outage caused by erroneous and spurious tripping.

Power plugs and receptacles


Plugs are shipped with the machine line cords in USA and Canada. The line cord lengths are 4250 mm (14 ft) except in Chicago, Illinois, USA where the length is 1830 mm (6 ft). Power plugs in the following table are approved for use with specified models and meet the relevant test laboratory or country/test-house standards. The power plug must be connected to a correctly wired and grounded receptacle. The customer is responsible for receptacle wiring.

For countries that require other types of plugs or receptacles, the system is shipped without plugs on the line cords, and you are responsible for supplying and installing both plugs and receptacles.

Feature code	Watertight plug	Watertight receptacle
0520	60A IEC-309 460P9W	60A IEC-309 460R9W or 460C9W
0531 used with 0521	60A IEC-309 360P6W	60A IEC-309 360R6W or 360C6W
0532 used with 0521	63A IEC-309 363P6W	63A IEC-309 363R6W
0533 used with 0521	32A IEC-309 532P6W	32A IEC-309 532R6W or 532C6W

Notes:

- IBM continues to strongly recommend the use of a metal backbox (example shown below) with our line cords using IEC-309 plugs. Although in-line connectors and nonmetallic backboxes are available and compatible, they are not recommended. These recommendations are based on the metal backbox providing:
 - An added level of protection against a mis-wired phase and ground reversal
 - In some cases, a metal backbox may be better for EMI mitigation



You may choose not to use a metal backbox. In this case, please check your local code for specific requirements.

- The customer must obtain the appropriate plugs and receptacles, based on existing electrical codes, where those plugs and receptacles are not provided with the system.

Grounding specifications

Every three-phase circuit must contain three-phase conductors and an insulated equipment-grounding conductor. Every single-phase 120 volt branch circuit (used for the service outlets) must contain one phase conductor, a neutral conductor, and an insulated equipment-grounding conductor.

For 208 VAC through 240 VAC installations worldwide, the equipment-grounding conductor must match local electrical codes and must be green with or without one or more yellow stripes on the insulation. IBM recommends that the ground wire be the same size as the phase conductor wires.

Conduit must not be used as the only grounding means. However, any conduit or cable shield must be connected at both ends in such a way that it is included in the grounding path in parallel with the grounding conductor it contains. Most electrical codes require that branch circuit wiring be located in metallic conduit, or be made from shielded cable, if located under a raised floor. Even when not required by local regulations, some form of shield around the branch circuit wiring is strongly recommended as a means of reducing coupling of high-frequency electrical noise into signal and control cables.

There is information about additional recommendations and requirements for equipment grounding on IBM **Resource Link** (<http://www.ibm.com/servers/resourcelink>) under **Planning --> Physical Planning --> General Information for Planning a Physical Site**.

Line cord specifications

Feature code	Description	Used in:
0520	IEC-309 208V 60A 3-phase (delta) Note: Line cord permanently connected to the PDU	USA, Canada, Japan, Taiwan, Philippines, Bahamas, Mexico, Trinidad, Bolivia, Brazil, Peru, Uruguay, Liberia, and other CCN and LA countries not specified
0531	IEC-309 208V 60A single-phase (P + P + G)	USA, Canada, Japan, Taiwan, Philippines, Bahamas, Mexico, Trinidad, Bolivia, Brazil, Peru, Uruguay, Liberia, and other CCN, LA, and AP countries not specified
0532	IEC-309 240V 63A single-phase (P + N+ G)	India, China, most of EMEA, Philippines, Bahamas, Curacao, Dominica, Grenada, Netherlands Antilles, St Kitts, St Lucia, St Vincent, Trinidad, Bolivia, Brazil, Argentina, Paraguay, Uruguay, Peru, Chile, and other AP countries not specified
0533	IEC-309 380-415V 32A 3-phase (wye)	India, China, Korea, most of EMEA, Philippines, Bahamas, Curacao, Dominica, Grenada, Netherlands Antilles, St Kitts, St Lucia, St Vincent, Trinidad, Bolivia, Brazil, Argentina, Paraguay, Uruguay, Peru, Chile, and other AP countries not specified
Note: 1. P=phase, N=neutral, G=ground 2. All power cords are 4.3 m (14 ft) long. 3. The customer must obtain the appropriate plugs and receptacles, based on existing electrical codes, where those plugs and receptacles are not provided with the system. 4. The power cord set(s) provided are for use only with this product. 5. The 32 amp wye 380V or 415V power option provides 220V or 240V line to neutral. BladeCenters operate on nominal 208 or 220V supplies.		

Line physical protection

In US installations, the line cord must meet National Electric Code (NEC) requirements. When line cords are run on the surface of the floor, they must be protected against physical damage (See NEC 645-5). For other countries, local codes apply.

Service outlet (customer-supplied)

A duplex service tool outlet should be installed within 1.5 m (5 ft) of the system frame. The power requirement is 110V/120V for USA and Canada (other power requirements are country dependent). The service tool outlets should be fed from the same power source as the system. The service tool outlet should be placed on a separate circuit breaker so it can be used when the processor frame circuit breaker is off.

Chapter 6. Hardware Management Consoles

The machine type of the primary HMC and alternate HMC must be identical. Both must be 7327s (FC 0091). Verify this information by viewing the label on top of the HMC hardware tower (i.e. MT-M: 7327-PAA).

You should know that one of these will be the primary HMC for both the z196 or z114 and the zBX. The other will be the alternate HMC, so placement of the alternate HMC close to the primary HMC is important.

If you already have HMCs (FC 0091) that you plan to use for this installation, you need not order additional consoles.

You must also know that both consoles have to be connected on the same Ethernet subnet, so that the alternate console can perform the backup function should anything happen to the primary.

Each HMC requires as many as two outlets to function properly: one for the processor unit and one for the monitor. You'll also need to provide a table or desk on which to place the monitor and keyboard for each console.

If the z196 or z114 to which this zBX is connected is not covered by a warranty, you must also order an additional HMC that will be assigned to the zBX serial number. This HMC will be used for servicing the zBX.


Chapter 7. Top-of-rack switch connections

SFP and SFP+ module descriptions and locations

SFP modules and SFP+ modules may be plugged into various ports in the top-of-rack switches at B10B32P and B10B30P. The ports on the switches are segmented by purpose. The illustration below shows how the ports on the IEDN switches are used. Customer ports are J31 through J37. SFP and SFP+ modules plugged into the customer ports require LC Duplex cables.

Planning worksheets for the IEDN switches are provided in Appendix A, “Top-of-rack switch ports worksheets,” on page 45. You must provide the installer with your customer SFP module and SFP+ module location information.

IEDN data network switch



- J00 - J07 **SFP+** reserved for host OSX IEDN connections
- ◈ J08 - J21 **DAC** reserved for BC IEDN, SMO7/SM09 connections
- ◈ J22 - J23 **1 meter DAC** reserved for switch-to-switch on z196 at GA1
- J24 - J30 **SFP+** reserved for zBX-to-zBX IEDN connections
- ✕ J31 - J37 **SFP+** or **SFP** reserved for customer IEDN connections
- ▨ J38 - J39 **SFP+** reserved for future use
- J40 console port
- J41 IEDN switch management port

SFP and SFP+ module feature codes

The following is a list of SFP+ and SFP module feature codes:

FC 0632



10 GbE LR SFP+

FC 0632 has a blue latch handle

10 GbE LR SFP+ module - 1310nm

- Data rate: 1000 Mbps (1 Gbps)
- Operating mode: Full duplex
- Defined as: CHPID type OSD
- Connector type: LC Duplex
- Port count: One small form/factor pluggable (SFP) optic
- Cable type: Single mode fiber optic cabling (9 micron)
- Unrepeated distance: 10 km (6.2 miles)

FC 0633




10 GbE SR SFP+

FC 0633 has a beige latch handle

10 GbE SR SFP+ module - 850nm

- Data rate: 1000 Mbps (1 Gbps)
- Operating mode: Full duplex
- Defined as: CHPID type OSD
- Connector type: LC Duplex
- Port count: One small form/factor pluggable (SFP) optic
- Cable type: Multimode fiber optic cabling (50 or 62.5 micron)
- Unrepeated distance: 50 micron fiber - at 2000 MHz-km (OM2) 300 meters (984 feet)
- Unrepeated distance: 50 micron fiber - at 500 MHz-km (OM2) 82 meters (269 feet)
- Unrepeated distance: 62.5 micron fiber - at 200 MHz-km: (OM1) 33 meters (108 feet)

FC 0634




1 GbE 1000BASE LX SFP

FC 0634 has a blue latch handle

1 GbE 1000BASE-LX SFP module - 1310nm

- Data rate: 1000 Mbps (1 Gbps)
- Operating mode: Full duplex
- Defined as: CHPID type OSD
- Connector type: LC Duplex
- Port count: One small form/factor pluggable (SFP) optic
- Cable type: Single mode fiber optic cabling (9 micron)
- Unrepeated distance: 10 km (6.2 miles)

FC 0635



1 GbE 1000BASE SX SFP

FC 0635 has a black latch handle

1 GbE 1000BASE-SX SFP module - 850nm

- Data rate: 1000 Mbps (1 Gbps)
- Operating mode: Full duplex
- Defined as: CHPID type OSD
- Connector type: LC Duplex
- Port count: One small form/factor pluggable (SFP) optic
- Cable type: Multimode fiber optic cabling (50 or 62.5 micron)
- Unrepeated distance: 50 micron fiber - at 500 MHz-km (OM2) 550 meters (1804 feet)
- Unrepeated distance: 62.5 micron fiber - at 200 MHz-km: (OM1) 275 meters (902 feet)

OSA to IEDN switch connections

Important:

The customer is responsible for having the OSA cables connected between the IEDN switches and the z196 or z114. It is necessary to plug these connections before the rest of the installation can continue.

Note: The OSA cards and cables used to connect the IEDN switches to the z196 or z114 CPCs may be either short range or long range OSA 10 GbE cables, type OSX.

The first two OSA cables must be connected to the managing z196 or z114 to provide a data path from the zBX to z196 or z114. All other OSA cables can connect to any z196 or z114.

Table 8. OSA cables to IEDN switch connections

OSA to IEDN switch connection
First z196 or z114 OSA 1A to B32PJ00
First z196 or z114 OSA 2A to B30PJ00
Second z196 or z114 OSA 1A to B32PJ01
Second z196 or z114 OSA 2A to B30PJ01
Third z196 or z114 OSA 1A to B32PJ02
Third z196 or z114 OSA 2A to B30PJ02
Fourth z196 or z114 OSA 1A to B32PJ03
Fourth z196 or z114 OSA 2A to B30PJ03
Fifth z196 or z114 OSA 1A to B32PJ04
Fifth z196 or z114 OSA 2A to B30PJ04
Sixth z196 or z114 OSA 1A to B32PJ05
Sixth z196 or z114 OSA 2A to B30PJ05
Seventh z196 or z114 OSA 1A to B32PJ06
Seventh z196 or z114 OSA 2A to B30PJ06
Eighth z196 or z114 OSA 1A to B32PJ07
Eighth z196 or z114 OSA 2A to B30PJ07

IEDN zBX node-to-node connections

The following illustration shows node-to-node connections for the IEDN. A node is defined as a zEnterprise server with a zBX attached. These cables connect the zBXs in each node to each other in the ensemble. Each node consists of a zEnterprise server, with its own zBX, running a single (local) platform management image.

IEDN node-to-node LIMITATIONS - multimode (Short Range Optics)

- 50 micron at 2000 MHz-km: 300 meters (984')
- 50 micron at 500 MHz-km: 82 meters (269')
- 62.5 micron at 200 MHz-km: 33 meters (108')

IEDN node-to-node LIMITATIONS - single mode (Long Range Optics)

- 10 km (6.2 miles)

| **Note:** If you have to connect several zBXs, check the IEDN node-to-node connections because the system will not report missing or incorrect plugged zBX-to-zBX connections. To view the status of these ports, use the **zBX Network Monitor** task from the Support Element or the **Network Monitors Dashboard** task from the HMC.


| The following illustration shows the IEDN node-to-node connections between the top-of-rack switches. The box at the bottom of the illustration shows the connections graphically.

| **Important:**

| When adding the second zBX, **the node number is 8, not 2.**

| The node-to-node connections are cumulative - each additional zBX must be connected in the following sequence.

Node-to-node ports on IEDN switches B32P and B30P



First zBX
Node 1

Add a second zBX
Node 8

Node 1 - B32PJ30 to Node 8 B32PJ30

Node 8 - B30PJ24 to Node 1 B30PJ24

Add a third zBX
Node 2

Node 1 - B32PJ30 to Node 8 B32PJ30
Node 1 - B32PJ24 to Node 2 B32PJ24

Node 8 - B30PJ24 to Node 1 B30PJ24
Node 8 - B30PJ25 to Node 2 B30PJ25

Add a fourth zBX
Node 3

Node 1 - B32PJ30 to Node 8 B32PJ30
Node 1 - B32PJ24 to Node 2 B32PJ24
Node 1 - B32PJ25 to Node 3 B32PJ25

Node 8 - B30PJ24 to Node 1 B30PJ24
Node 8 - B30PJ25 to Node 2 B30PJ25
Node 8 - B30PJ26 to Node 3 B30PJ26

Add a fifth zBX
Node 4

Node 1 - B32PJ30 to Node 8 B32PJ30
Node 1 - B32PJ24 to Node 2 B32PJ24
Node 1 - B32PJ25 to Node 3 B32PJ25
Node 1 - B32PJ26 to Node 4 B32PJ26

Node 8 - B30PJ24 to Node 1 B30PJ24
Node 8 - B30PJ25 to Node 2 B30PJ25
Node 8 - B30PJ26 to Node 3 B30PJ26
Node 8 - B30PJ27 to Node 4 B30PJ27

Add a sixth zBX
Node 5

Node 1 - B32PJ30 to Node 8 B32PJ30
Node 1 - B32PJ24 to Node 2 B32PJ24
Node 1 - B32PJ25 to Node 3 B32PJ25
Node 1 - B32PJ26 to Node 4 B32PJ26
Node 1 - B32PJ27 to Node 5 B32PJ27

Node 8 - B30PJ24 to Node 1 B30PJ24
Node 8 - B30PJ25 to Node 2 B30PJ25
Node 8 - B30PJ26 to Node 3 B30PJ26
Node 8 - B30PJ27 to Node 4 B30PJ27
Node 8 - B30PJ28 to Node 5 B30PJ28

Add a seventh zBX
Node 6


Node 1 - B32PJ30 to Node 8 B32PJ30
Node 1 - B32PJ24 to Node 2 B32PJ24
Node 1 - B32PJ25 to Node 3 B32PJ25
Node 1 - B32PJ26 to Node 4 B32PJ26
Node 1 - B32PJ27 to Node 5 B32PJ27
Node 1 - B32PJ28 to Node 6 B32PJ28

Node 8 - B30PJ24 to Node 1 B30PJ24
Node 8 - B30PJ25 to Node 2 B30PJ25
Node 8 - B30PJ26 to Node 3 B30PJ26
Node 8 - B30PJ27 to Node 4 B30PJ27
Node 8 - B30PJ28 to Node 5 B30PJ28
Node 8 - B30PJ29 to Node 6 B30PJ29

Add an eighth zBX
Node 7

Node 1 - B32PJ30 to Node 8 B32PJ30
Node 1 - B32PJ24 to Node 2 B32PJ24
Node 1 - B32PJ25 to Node 3 B32PJ25
Node 1 - B32PJ26 to Node 4 B32PJ26
Node 1 - B32PJ27 to Node 5 B32PJ27
Node 1 - B32PJ28 to Node 6 B32PJ28
Node 1 - B32PJ29 to Node 7 B32PJ29


Node 8 - B30PJ24 to Node 1 B30PJ24
Node 8 - B30PJ25 to Node 2 B30PJ25
Node 8 - B30PJ26 to Node 3 B30PJ26
Node 8 - B30PJ27 to Node 4 B30PJ27
Node 8 - B30PJ28 to Node 5 B30PJ28
Node 8 - B30PJ29 to Node 6 B30PJ29
Node 8 - B30PJ30 to Node 7 B30PJ30



Appendix A. Top-of-rack switch ports worksheets

Use the following illustration to fill in the worksheets for the top-of-rack switches B32P and B30P.

IEDN data network switch



- J00 - J07 **SFP+** reserved for host OSX IEDN connections
- ◈ J08 - J21 **DAC** reserved for BC IEDN, SMO7/SM09 connections
- ◈ J22 - J23 **1 meter DAC** reserved for switch-to-switch on z196 at GA1
- J24 - J30 **SFP+** reserved for zBX-to-zBX IEDN connections
- ⊗ J31 - J37 **SFP+** or **SFP** reserved for customer IEDN connections
- ▨ J38 - J39 **SFP+** reserved for future use
- J40 console port
- J41 IEDN switch management port

Table 9. Worksheet - TOR switch ports B32P J00-J07 for CPC to zBX connections

CPC name		10 GbE (SFP+) LR port #	10 GbE (SFP+) SR port #
CPC 1		J00- place checkmark here >	J00- place checkmark here >
CPC 2		J01- place checkmark here >	J01- place checkmark here >
CPC 3		J02- place checkmark here >	J02- place checkmark here >
CPC 4		J03- place checkmark here >	J03- place checkmark here >
CPC 5		J04- place checkmark here >	J04- place checkmark here >
CPC 6		J05- place checkmark here >	J05- place checkmark here >
CPC 7		J06- place checkmark here >	J06- place checkmark here >
CPC 8		J07- place checkmark here >	J07- place checkmark here >

Table 10. Worksheet - TOR switch ports B32P J24-J30 for zBX to zBX connections

CPC name		10 GbE (SFP+) LR port #	10 GbE (SFP+) SR port #
zBX 2		J24- place checkmark here >	J24- place checkmark here >
zBX 3		J25- place checkmark here >	J25- place checkmark here >
zBX 4		J26- place checkmark here >	J26- place checkmark here >
zBX 5		J27- place checkmark here >	J27- place checkmark here >
zBX 6		J28- place checkmark here >	J28- place checkmark here >
zBX 7		J29- place checkmark here >	J29- place checkmark here >
zBX 8		J30- place checkmark here >	J30- place checkmark here >

Table 11. Worksheet - TOR switch ports B32P J31-J37 to existing customer network connections

10 GbE (SFP+) LR port #	10 GbE (SFP+) SR port #	1 GbE (SFP) LX port #	1 GbE (SFP) SX port #
J31- checkmark here >	J31- checkmark here >	J31- checkmark here >	J31- checkmark here >
J32- checkmark here >	J32- checkmark here >	J32- checkmark here >	J32- checkmark here >
J33- checkmark here >	J33- checkmark here >	J33- checkmark here >	J33- checkmark here >
J34- checkmark here >	J34- checkmark here >	J34- checkmark here >	J34- checkmark here >
J35- checkmark here >	J35- checkmark here >	J35- checkmark here >	J35- checkmark here >
J36- checkmark here >	J36- checkmark here >	J36- checkmark here >	J36- checkmark here >
J37- checkmark here >	J37- checkmark here >	J37- checkmark here >	J37- checkmark here >

Table 12. Worksheet - TOR switch ports B30P J00-J07 for CPC to zBX connections

CPC name		10 GbE (SFP+) LR port #	10 GbE (SFP+) SR port #
CPC 1		J00- place checkmark here >	J00- place checkmark here >
CPC 2		J01- place checkmark here >	J01- place checkmark here >
CPC 3		J02- place checkmark here >	J02- place checkmark here >
CPC 4		J03- place checkmark here >	J03- place checkmark here >
CPC 5		J04- place checkmark here >	J04- place checkmark here >
CPC 6		J05- place checkmark here >	J05- place checkmark here >
CPC 7		J06- place checkmark here >	J06- place checkmark here >
CPC 8		J07- place checkmark here >	J07- place checkmark here >

Table 13. Worksheet - TOR switch ports B30P J24-J30 for zBX to zBX connections

CPC name		10 GbE (SFP+) LR port #	10 GbE (SFP+) SR port #
zBX 2		J24- place checkmark here >	J24- place checkmark here >
zBX 3		J25- place checkmark here >	J25- place checkmark here >
zBX 4		J26- place checkmark here >	J26- place checkmark here >
zBX 5		J27- place checkmark here >	J27- place checkmark here >
zBX 6		J28- place checkmark here >	J28- place checkmark here >
zBX 7		J29- place checkmark here >	J29- place checkmark here >
zBX 8		J30- place checkmark here >	J30- place checkmark here >

Table 14. Worksheet - TOR switch ports B30P J31-J37 to existing customer network connections

10 GbE (SFP+) LR port #	10 GbE (SFP+) SR port #	1 GbE (SFP) LX port #	1 GbE (SFP) SX port #
J31- checkmark here >	J31- checkmark here >	J31- checkmark here >	J31- checkmark here >
J32- checkmark here >	J32- checkmark here >	J32- checkmark here >	J32- checkmark here >
J33- checkmark here >	J33- checkmark here >	J33- checkmark here >	J33- checkmark here >
J34- checkmark here >	J34- checkmark here >	J34- checkmark here >	J34- checkmark here >
J35- checkmark here >	J35- checkmark here >	J35- checkmark here >	J35- checkmark here >
J36- checkmark here >	J36- checkmark here >	J36- checkmark here >	J36- checkmark here >
J37- checkmark here >	J37- checkmark here >	J37- checkmark here >	J37- checkmark here >

Appendix B. Fibre channel Storage Area Network information

For information about Fibre Channel specifications for Storage Area Networks (SANs), refer to *System z Planning for Fiber Optic Links (ESCON, FICON, Coupling Links, and Open System Adapters)* located on **Resource Link** (<http://www.ibm.com/servers/resourcelink>).

Appendix C. IBM standard symbols

In Plan Views:



Cable Entry and Exit Area in the base of the machine. Locating dimensions are measured from the edge of the frame, not the cover. This does not indicate the floor cutout.





Cable Exit Area, recommended



Power Cord exit, 50/60 Hz



Power Cord exit, 400 Hz

Power cords are supplied in 4.2 m (14 ft) lengths unless otherwise noted on the specification page. The length is measured from the symbol  or .



Swinging Gate



Standard equipment outline (shows the machine with covers closed)



Optional equipment outline



Customer Engineer Indicator Panel

In Cabling Schematics:



Indicates a cable group coming from a machine



Indicates a cable group going to a machine



Service Area Boundary
(Service clearances are measured from the machine with covers closed)



Casters
Locating dimensions are measured from the edge of the frame, not the cover.



Leveling pads or glides
(90 mm [3 1/2 in] typical diameter)
Locating dimensions are measured from the edge of the frame, not the cover.



Legs



Non-raised floor cable exit



Meter location



Unit Emergency Switch

Hinged Covers



Single



Bifold



Offset Bifold

Appendix D. Acoustics

This appendix provides information on acoustics for the zBX at nominal environmental ambient temperatures of 23°C plus or minus 2°C (73.4°F plus or minus 3.6°F).

Acoustical noise emission levels

Acoustical noise emission levels for 2458-002

Table 15. Acoustic information for IBM POWER7 blades

Product configuration	Declared A-weighted sound power level L_{WAd} (B)		Declared A-weighted sound pressure level L_{pAm} (dB)	
	Operating (B)	Idling (B)	Operating (dB)	Idling (dB)
Maximum Configuration : IBM blades <ul style="list-style-type: none"> Four racks 112 blade servers All air-moving devices at nominal speeds Front and rear standard doors. 	8.3 ⁽⁴⁾	8.3 ⁽⁴⁾	65	65
Maximum Configuration : IBM blades <ul style="list-style-type: none"> Four racks 112 blade servers All air-moving devices at nominal speeds Front and rear acoustic doors. 	7.9 ⁽⁵⁾	7.9 ⁽⁵⁾	61	61
Note: <ol style="list-style-type: none"> L_{WAd} is the (upper limit) A-weighted sound power level. Declared level L_{pAm} is the mean A-weighted sound pressure level measured at the 1-meter bystander positions. All measurements are made in accordance with ISO 7779, and declared in conformance with ISO 9296. B and dB are the abbreviations for bels and decibels, respectively. 1B = 10dB. Meets IT Product Noise Limits for "Generally Attended Data Center" per Statskontoret Technical Standard 26:6. Meets IT Product Noise Limits for "Generally Unattended Data Center" per Statskontoret Technical Standard 26:6. 				

Table 16. Acoustic information for IBM WebSphere® DataPower Integration Appliance XI50 for zEnterprise blades

Product configuration	Declared A-weighted sound power level L_{WAd} (B)		Declared A-weighted sound pressure level L_{pAm} (dB)	
	Operating (B)	Idling (B)	Operating (dB)	Idling (dB)
Maximum Configuration : <ul style="list-style-type: none"> Two racks 28 blade servers All air-moving devices at nominal speeds Front and rear standard doors. 	8.1 ⁽⁴⁾	8.1 ⁽⁴⁾	63	63
Maximum Configuration : <ul style="list-style-type: none"> Two racks 28 blade servers All air-moving devices at nominal speeds Front and rear acoustic doors. 	7.7 ⁽⁵⁾	7.7 ⁽⁵⁾	59	59
Note: <ol style="list-style-type: none"> L_{WAd} is the (upper limit) A-weighted sound power level. Declared level L_{pAm} is the mean A-weighted sound pressure level measured at the 1-meter bystander positions. All measurements are made in accordance with ISO 7779, and declared in conformance with ISO 9296. B and dB are the abbreviations for bels and decibels, respectively. 1B = 10dB. Meets IT Product Noise Limits for "Generally Attended Data Center" per Statskontoret Technical Standard 26:6. Meets IT Product Noise Limits for "Generally Unattended Data Center" per Statskontoret Technical Standard 26:6. 				

Table 17. Acoustic information for select IBM System x blades

Product configuration	Declared A-weighted sound power level L_{WAd} (B)		Declared A-weighted sound pressure level L_{pAm} (dB)	
	Operating (B)	Idling (B)	Operating (dB)	Idling (dB)
Maximum Configuration : <ul style="list-style-type: none"> Two racks 56 blade servers All air-moving devices at nominal speeds Front and rear standard doors. 	8.1 ⁽⁴⁾	8.1 ⁽⁴⁾	63	63
Maximum Configuration : <ul style="list-style-type: none"> Two racks 56 blade servers All air-moving devices at nominal speeds Front and rear acoustic doors. 	7.8 ⁽⁵⁾	7.8 ⁽⁵⁾	59	59
Note: <ol style="list-style-type: none"> L_{WAd} is the (upper limit) A-weighted sound power level. Declared level L_{pAm} is the mean A-weighted sound pressure level measured at the 1-meter bystander positions. All measurements are made in accordance with ISO 7779, and declared in conformance with ISO 9296. B and dB are the abbreviations for bels and decibels, respectively. 1B = 10dB. Meets IT Product Noise Limits for "Generally Attended Data Center" per Statskontoret Technical Standard 26:6. Meets IT Product Noise Limits for "Generally Unattended Data Center" per Statskontoret Technical Standard 26:6. 				

Relevant international standards:


- Measurements: ISO 7779
- Declaration: ISO 9296

Appendix E. Dual power installation

The zBX BladeCenter is designed with a fully redundant power system. Each BladeCenter has two line cords attached to two power input ports which, in turn, power a pair of fully redundant power distribution systems within the BladeCenter. To take full advantage of the redundancy/reliability that is built into the system, the equipment **must** be powered from two distribution panels. Following are three examples of redundancy.


Example 1 (redundant distribution panel and switch gear)

In this example, the computer receives power from two separate power distribution panels. Each distribution panel receives power from a separate piece of building switch gear. This level of redundancy is not available in most facilities.



Example 2 (redundant distribution panel)


In this example, the computer receives power from two separate power distribution panels. The two distribution panels receive power from the same piece of building switch gear. Most facilities should be able to achieve this level of redundancy. In this case, loss of switch gear (building power) will result in system outage, but loss of one distribution panel will not.



Example 3 (single distribution panel)

In this example, the computer receives power from two or four separate circuit breakers in a single power panel. This does not make use of the redundancy provided by the processor. It is, however, acceptable if a second power distribution panel is not available.

This type of power distribution will result in system outage in the event of a power failure at either the switch gear or the distribution panel.



Appendix F. Rear door heat exchanger

The heat exchanger is a water-cooled device that mounts on the rear of IBM 19-inch EIA-rail and 24-inch EIA-rail Enterprise racks to cool the air that is heated and exhausted by devices inside the rack. The heat exchanger can remove 50-60 percent of the heat load from an individual rack when water is supplied to at 18°C (64.4°F) and the door is running under optimum conditions.

The rear door heat exchanger may be installed on either a raised or non-raised floor.

For sizing purposes, consider a rack that produces a heat load of X watts. The heat exchanger can remove 0.5X watts before the heated air enters the room.

The heat exchanger feature kit consists of the components listed below:

- Door assembly (The hoses for the secondary cooling loop are not included with the heat exchanger kit.)
- Hinge kit
- Air-purge tool

A supply hose delivers chilled, conditioned water to the heat exchanger. A return hose delivers warmed water back to the water pump or chiller. This is referred to as a secondary cooling loop. The primary cooling loop supplies the building chilled water to secondary cooling loops, air conditioning units, and so on.

Each rear door heat exchanger can remove up to 50,000 Btu/hr (or approximately 15,000 watts) of heat from your data center.




Figure 1. Components of a water supply system for a heat exchanger

If you would like to procure IBM installation planning services for supplying conditioned water and installing a heat exchanger, contact your local IBM representative or business partner for additional information.

Following are the specifications for the heat exchanger.

Table 18. Operating specifications for 19-inch EIA-rail heat exchanger

<p>Door size</p> <ul style="list-style-type: none"> • Depth: 142.6 mm (5.6 in) • Height: 1945.4 mm (76.6 in) • Width: 639 mm (25.2 in) <p>Exchanger size</p> <ul style="list-style-type: none"> • Depth: 67 mm (2.7 in) • Height: 1791.3 mm (70.6 in) • Width: 438.6 mm (17.3 in) <p>Door assembly weight</p> <ul style="list-style-type: none"> • Empty: 29.9 kg (66 lb.) • Filled: 35.6 kg (78.5 lb.) <p>Door heat removal capacity</p> <ul style="list-style-type: none"> • Lab tests indicate 50 to 60 percent of total rack heat output can be removed by the door • Up to 15 kW (50 000 Btu/hr) heat removal possible 	<p>Air movement</p> <ul style="list-style-type: none"> • Provided by servers and other devices in the rack • No additional air moving devices required. <p>Air source for servers</p> <ul style="list-style-type: none"> • Room air for front of rack. Air exhausts servers, moves through rear door heat exchanger and exits into the room (open loop) <p>Air temperature drop</p> <ul style="list-style-type: none"> • The temperature drop can be up to 25°C (45°F) between the air exiting the rack devices and the air exiting the heat exchanger on high heat load products. <p>Air impedance</p> <ul style="list-style-type: none"> • Air pressure drop across the heat exchanger is equivalent to the IBM® acoustic 19-inch rear door 	<p>Water source</p> <ul style="list-style-type: none"> • User-supplied - compliant with the specifications in this document. • Couplings and inside diameter of the hoses are 19 mm (0.75 in). <p>Water pressure</p> <ul style="list-style-type: none"> • Normal operation: 137.93 kPa (20 psi) • Maximum: 689.66 kPa (100 psi) • Pressure drop across heat exchanger: approximately 48 kPa (7 psi) <p>Water volume</p> <ul style="list-style-type: none"> • Exchanger: 2.8 liters (0.74 gallons) • Exchanger plus supply and return hoses to the pump unit: Maximum of approximately 15.1 liters (4.0 gallons) excluding pump unit piping and reservoir <p>Water temperature</p> <ul style="list-style-type: none"> • If no dew point control is available from the secondary loop cooling distribution unit, 18°C +/- 1°C (64.4°F +/- 1.8°F) must be maintained • Lower temperature water is allowed as long as the water supply is monitored and adjusted to remain above room dew point (where heat exchanger is located) <p>Required water flow rate (as measured at the supply entrance to the heat exchanger)</p> <ul style="list-style-type: none"> • Minimum: 22.7 liters per minute (6 gallons per minute) • Maximum: 37.9 liters per minute (10 gallons per minute)
---	--	--

Secondary cooling loop specifications

It is important that the water being supplied to the heat exchanger meets the requirements described in this topic; otherwise, system failures might occur over time, as a result of:

- Leaks due to corrosion and pitting of the metal components of the heat exchanger or the water supply system
- Buildup of scale deposits inside the heat exchanger, which can cause the following problems:
 - A reduction of the heat exchanger's ability to cool the air that is exhausted from the rack.
 - Failure of mechanical hardware, such as a hose quick-connect adapter.
 - Organic contamination, such as bacteria, fungi, or algae. This contamination can also cause loss of cooling capability or failure of components.

The water used to fill, refill, and supply the heat exchanger must be particle-free deionized water or particle-free distilled water with appropriate controls for avoiding metal corrosion, bacterial fouling, and scaling. Because of typical water temperatures in the primary loop, water for the heat exchanger may not be able to originate from the building chilled-water system. Conditioned, warmer water for the heat exchanger should be supplied as part of a secondary, closed-loop system.

Material considerations

Recommended materials for use in supply lines, connectors, manifolds, pumps, hoses, and any other hardware that makes up the closed-loop water-supply include:

- Copper
- Brass with less than 30 percent zinc content
- Stainless steel – 303, 304, or 316
- Ethylene Propylene Diene Monomer (EPDM) rubber – peroxide cured, non-metal oxide.

Materials to avoid in secondary loops include:

- Oxidizing biocides, such as, chlorine, bromine, and chlorine dioxide
- Brass with greater than 30 percent zinc content
- Aluminum
- Irons (non-stainless steel) .

Specifications for the water

The following are the specific characteristics of the system that supplies the chilled conditioned water to the heat exchanger.

Temperature

The heat exchanger, its supply hose and return hoses are not insulated and do not have features designed to address the creation and collection water from condensate. Avoid any condition that could cause condensation. The temperature of the water inside the supply hose, return hose, and the heat exchanger must be kept above the dew point of the location where the heat exchanger is being used.

Attention:

Typical primary chilled water is too cold for use in this application because building chilled water can be as cold as 4 to 6°C (39.2 to 42.8°F).

Important:

If the system supplying the cooling water does not have the ability to measure the room dew point and automatically adjust the water temperature accordingly, the minimum water temperature that must be maintained is 18°C +/- 1°C (64.4°F +/- 1.8°F). This is consistent with the ASHRAE Class 1 Environmental Specification that requires a maximum dew point of 17°C (62.6°F). Refer to the ASHRAE document entitled *Thermal Guidelines for Data Processing Environments*. Information on obtaining this document is found at www.ashrae.org. Search on "Thermal Guidelines for Data processing Environments".

Pressure

Put your short description here; used for first paragraph and abstract.

The water pressure in the secondary loop must be less than the maximum 689.66 kPa (100 pounds per square inch). Somewhere in the water circuit, a pressure relief valve, set to this maximum value, is required for safety reasons. Normal operating pressure at the rear door heat exchanger should be 137.93 kPa (20 psi) or less.

Flow rate

Put your short description here; used for first paragraph and abstract.

The flow rate of the water in the system must be in the range of 23 - 38 liters per minute (6.1 - 10.1 gallons per minute). Pressure drop versus flow rate for heat exchangers (including quick-connect couplings) is defined as approximately 48 kPa (7 psi) at 30 liters per minute (8 gallons per minute). Adjustable flow valves are recommended for installation on all supply lines of the water circuit, to enable compliance, to this flow specification.

Water volume limits

Put your short description here; used for first paragraph and abstract.

The heat exchangers hold between 2.8 liters (0.74 gallons) and 5.3 liters (1.4 gallons). Fifteen meters (50 ft) of 19 mm (0.75 in) supply and return hoses hold approximately 9.4 liters (2.5 gallons). To minimize exposure to flooding in the event of leaks, the entire product cooling system (heat exchanger, supply hose and return hose) excluding any reservoir tank should have a maximum 15.1 liters (4 gallons) of water. This is a cautionary statement not a functional requirement. Also consider using leak detection methods on the secondary loop that supplies water to the heat exchanger.

Air exposure

Put your short description here; used for first paragraph and abstract.

The secondary cooling loop is a closed loop, with no continuous exposure to room air. After you fill the loop, remove all air from the loop. Air bleed valves are provided at the top of each heat exchanger manifold for purging all air from the system.

Water delivery specifications

The secondary loop delivery system provides chilled, conditioned water to the heat exchanger. The delivery system includes pipes, hoses and the required connection hardware to attach to the heat exchanger. Hose management on raised floor environments is also described.

The primary cooling loop is considered to be the low temperature building chilled-water supply or a modular chiller unit. The primary loop must not be used as a direct source of coolant for the heat exchanger for two main reasons.

- First, below-dew-point water will cause air moisture to form on the door heat exchanger as it operates (condensation will drip and gather under the rack).

- Second, if proper leak detection is not established (for example, monitored leak tape, hose-in-trough with leak sensors and automatic shut-off valves) and a leak in the door, hoses or manifolds occurs, the constant, large supply of primary loop water could result in large amounts of water leaking into the data center.

Water provided in a controlled and monitored secondary, closed loop, would limit the amount of water available in a leak situation, and prevent condensation from forming.

Procurement and the installation of the components needed to create the secondary cooling loop system are your responsibility. The following information provides examples of typical secondary loop set-ups and operating characteristics that are needed to provide an adequate, safe supply of water to the heat exchanger. Key components recommended for the water supply and return lines are:

- Couplings to match those provided on the heat exchanger
- Flexible hoses
- Thermal feedback to a flow valve that will adjust and control supply water temperature
- Shutoff valves for each line running to a door
- Adjustable flow valves for each supply line to a door
- Pressure relief valve. The overpressure safety device must meet the following requirements:
 - Comply with ISO 4126-1
 - Be installed so that it is easily accessed for inspection, maintenance and repair
 - Be connected as close as possible to the device that it is intended to protect
 - Be adjustable only with the use of a tool
 - Have a discharge opening directed so that the discharged water will not create a secondary hazard
 - Be of adequate capacity that the maximum working pressure is not exceeded
 - Be installed with a shutoff valve between the overpressure device and the heat exchanger.

The actual number of heat exchangers connected to a secondary loop depends on the capacity of the secondary loop to transfer heat to the primary loop. For example, if the secondary loop can remove 100 kW of heat load and you have multiple 25 kW racks, you could have 12.5 kW per rack (assuming 50 percent door heat removal) going into the water loop, and attach eight doors per secondary loop.

Manifolds and piping




Figure 2. An example of a manifold layout

Manifolds that accept large-diameter feed pipes from a pump unit are the preferred method for splitting the flow of water to smaller diameter pipes or hoses that are routed to individual heat exchangers. Manifolds must be constructed of materials compatible with the pump unit and related piping. The manifolds must provide enough connection points to allow a matching number of supply and return lines to be attached and the manifolds must match the capacity rating of the pumps and heat exchanger (between the secondary cooling loop and building chilled-water source). Anchor or restrain all manifolds to provide the required support to avoid movement when quick-connect couplings are plugged to the manifolds and when valves are opened or closed. Example manifold supply pipe sizes include:

Note: in the following examples, CDU=Cooling Distribution Unit

- Use a 50.8 mm (2 in) supply pipe to provide the correct flow to six (100 kW CDU) 19 mm (0.75 in) supply hoses.
- Use a 63.5 mm (2.5 in) supply pipe to provide the correct flow to eight (120 kW CDU) 19 mm (0.75 in) supply hoses.
- Use an 88.9 mm (3.5 in) supply pipe to provide the correct flow to twenty (300 kW CDU) 19 mm (0.75 in) supply hoses.

Shutoff valves are suggested for each supply and return line that exits the manifold to allow stopping the flow of water in individual lines of multiple circuit loops. This provides a way of servicing or replacing an individual heat exchanger without affecting the operation of other heat exchangers in the loop.

Adjustable flow valves (called circuit setters) are also suggested for each supply line that exits a supply manifold so changes can be made to the flow to each individual rack, in the event that door heat exchangers are added or removed from the secondary loop (this method keeps water flow within specification to each door heat exchanger).

Temperature and flow metering (monitoring) are suggested in secondary loops, to provide assurance that water specifications are being met and that the optimum heat removal is taking place.

Anchor or restrain all manifolds and pipes to provide the required support, and to avoid movement when quick-connect couplings are being attached to the manifolds.

Flexible hoses and connections to manifolds and heat exchangers




Figure 3. Flexible water supply hoses

Pipes and hose configurations can vary and are determined by analyzing the needs of your facilities, or a site preparation representative can provide this analysis.

Flexible hoses are needed to supply and return water between your hard plumbing (manifolds and cooling distribution units) and the heat exchanger, (allowing needed movement when opening and closing the rack rear door).

Hoses are available that provide water with acceptable pressure-drop characteristics and that help prevent depletion of some corrosion inhibitors. These hoses must be made of Ethylene Propylene Diene Monomer (EPDM) rubber - peroxide cured, non-metal oxide material and will have quick-connect couplings at each end. These couplings are defined below and are compatible with the heat exchanger couplings. Hose lengths from 3 to 15 m (9.9 ft to 49.3 ft), in increments of 3 m (10 ft) are available. Hoses longer than 15 m (49.3 ft) may create unacceptable pressure loss in the secondary circuit and reduce the water flow, and thus reduce the heat removal capabilities of the heat exchanger.

Use solid piping or tubing that has a minimum inner diameter of 19 mm (0.75 in) and the least number of joints possible between a manifold and a heat exchanger in each secondary loop.

Quick-connect couplings are used to attach the hoses or fixed pipes to the distribution manifolds and the rear door heat exchangers. Hose couplings that attach to the heat exchanger must have the following characteristics:

- The couplings should be constructed of passivated 300-L series stainless steel or brass couplings with less than 30 percent zinc content. The coupling size is 19 mm (0.75 in).
- The supply hose must have a (male) quick-coupling nipple part number SH6-63-W, or equivalent. The return hose must have a (female) quick-connect couplings part number SH6-62-W, or equivalent.
- At the opposite (manifold) end of the hoses, it is suggested that similar quick-connect couplings be used. However, if other types are desired, it is also suggested that positive locking mechanisms be used to prevent loss of water when the hoses are disconnected. The connections must minimize water spill and air inclusion into the system when they are disconnected.

Note: When creating supply and return loops, it is recommended to avoid placement of electrical connections directly below water connections. These would be areas prone to water drips or splash when working with the water loop. Water dripping or splashing onto electrical connections can cause electrical problems or an unsafe environment.

Layout and mechanical installation

The layout and mechanical installation of your heat exchanger is dependent upon several factors. Use the following information to plan for your specific configuration.

Heat exchanger installation overview

These are the major tasks you must complete in preparing for the installation of a heat exchanger:

1. Preparing your facility to provide water to the rack per the required specifications.
2. Routing flexible hoses, leaving enough length at the rack end to easily make connections to the heat exchanger.
3. Adjusting and inspecting the hoses to ensure there are no kinks in the hoses and that the hoses are not lying against any sharp edges.

Note: For safety reasons, trained service personnel (or qualified professionals) must perform the installation of the heat exchanger.

Planning for heat exchangers in a raised floor environment

On a raised floor, hoses are routed under the floor tiles and are brought up from beneath the rack through special tile cut outs. The hoses attach to the quick-connect couplings on the bottom of the heat exchanger.




Figure 4. Flexible hose routing for a raised floor

Note: Recommendations from the floor tile manufacturers for openings in reinforced pedestal or stringer type tiles versus non-reinforced pedestal tiles should always be followed. In general, hoses should pass through floor tiles at locations that will not put high forces on the hoses, or cause rubbing that will abrade the hose surface and lead to premature hose failure (leaks).

Each heat exchanger requires a special cut floor tile below and behind the rack. A portion of the tile is cut away and the cut opening is correctly covered to protect against sharp edges. The corner opening is placed directly under the hinge side of the rack rear door. The opening size of the cut is 152.4 mm wide and 190.5 mm long \pm 12.7 mm (6.0 in wide and 7.5 in long \pm 0.5 in) in the direction parallel to the door.

Lay hoses side-by-side as they run between the heat exchanger and the supply and return manifolds, and allow the hoses to freely move. Leave enough slack in the hoses below the rear door so that minimum forces are exerted on the door when the hoses are attached and operating. When routing hoses, avoid sharp bends that can cause hose kinks, and avoid hose contact with sharp edges.

Appendix G. Notices

This information was developed for products and services offered in the USA.

IBM may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not grant you any license to these patents. You can send license inquiries, in writing, to:

*IBM Director of Licensing
IBM Corporation
North Castle Drive
Armonk, NY 10504-1785 USA*

INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

Any references in this information to non-IBM websites are provided for convenience only and do not in any manner serve as an endorsement of those websites. The materials at those websites are not part of the materials for this IBM product and use of those websites is at your own risk.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Any performance data contained herein was determined in a controlled environment. Therefore, the results obtained in other operating environments may vary significantly. Some measurements may have been made on development-level systems and there is no guarantee that these measurements will be the same on generally available systems. Furthermore, some measurements may have been estimated through extrapolation. Actual results may vary. Users of this document should verify the applicable data for their specific environment.

Information concerning non-IBM products was obtained from the suppliers of those products, their published announcements or other publicly available sources. IBM has not tested those products and cannot confirm the accuracy of performance, compatibility or any other claims related to non-IBM products. Questions on the capabilities of non-IBM products should be addressed to the suppliers of those products.

All statements regarding IBM's future direction or intent are subject to change or withdrawal without notice, and represent goals and objectives only.

All IBM prices shown are IBM's suggested retail prices, are current and are subject to change without notice. Dealer prices may vary.

This information is for planning purposes only. The information herein is subject to change before the products described become available.

This information contains examples of data and reports used in daily business operations. To illustrate them as completely as possible, the examples include the names of individuals, companies, brands, and products. All of these names are fictitious and any similarity to the names and addresses used by an actual business enterprise is entirely coincidental.

If you are viewing this information softcopy, the photographs and color illustrations may not appear.

Trademarks

IBM, the IBM logo, and [ibm.com](http://www.ibm.com)® are trademarks of International Business Machines Corp., registered in many jurisdictions worldwide. Other product and service names might be trademarks of IBM or other companies. A current list of IBM trademarks is available on the web at "Copyright and trademark information" at <http://www.ibm.com/legal/copytrade.shtml>.

Adobe, the Adobe logo, PostScript, and the PostScript logo are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States, and/or other countries.

Other product and service names might be trademarks of IBM or other companies.

Electronic emission notices

The following statements apply to this IBM product. The statement for other IBM products intended for use with this product will appear in their accompanying manuals.

Federal Communications Commission (FCC) Statement

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions contained in the installation manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Properly shielded and grounded cables and connectors must be used in order to meet FCC emission limits. IBM is not responsible for any radio or television interference caused by using other than recommended cables and connectors, by installation or use of this equipment other than as specified in the installation manual, or by any other unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Canadian Department of Communications Compliance Statement

This Class A digital apparatus complies with Canadian ICES-003.

Avis de conformité aux normes du ministère des Communications du Canada

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

European Union (EU) Electromagnetic Compatibility Directive

This product is in conformity with the protection requirements of EU Council Directive 2004/108/EC on the approximation of the laws of the Member States relating to electromagnetic compatibility. IBM cannot accept responsibility for any failure to satisfy the protection requirements resulting from a non-recommended modification of the product, including the fitting of non-IBM option cards.

This product has been tested and found to comply with the limits for Class A Information Technology Equipment according to European Standard EN 55022. The limits for Class equipment were derived for commercial and industrial environments to provide reasonable protection against interference with licensed communication equipment.

Warning: This is a Class A product. In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures.

European Community contact:

IBM Deutschland GmbH
Technical Regulations, Department M372
IBM-Allee 1, 71139 Ehningen, Germany
Telephone: 0049 (0) 7032 15-2941
email: lugi@de.ibm.com

EC Declaration of Conformity (In German)

Deutschsprachiger EU Hinweis: Hinweis für Geräte der Klasse A EU-Richtlinie zur Elektromagnetischen Verträglichkeit

Dieses Produkt entspricht den Schutzanforderungen der EU-Richtlinie 89/336/EWG zur Angleichung der Rechtsvorschriften über die elektromagnetische Verträglichkeit in den EU-Mitgliedsstaaten und hält die Grenzwerte der EN 55022 Klasse A ein.

Um dieses sicherzustellen, sind die Geräte wie in den Handbüchern beschrieben zu installieren und zu betreiben. Des Weiteren dürfen auch nur von der IBM empfohlene Kabel angeschlossen werden. IBM übernimmt keine Verantwortung für die Einhaltung der Schutzanforderungen, wenn das Produkt ohne Zustimmung der IBM verändert bzw. wenn Erweiterungskomponenten von Fremdherstellern ohne Empfehlung der IBM gesteckt/eingebaut werden.

EN 55022 Klasse A Geräte müssen mit folgendem Warnhinweis versehen werden:

"Warnung: Dieses ist eine Einrichtung der Klasse A. Diese Einrichtung kann im Wohnbereich Funk-Störungen verursachen; in diesem Fall kann vom Betreiber verlangt werden, angemessene Maßnahmen zu ergreifen und dafür aufzukommen."

Deutschland: Einhaltung des Gesetzes über die elektromagnetische Verträglichkeit von Geräten

Dieses Produkt entspricht dem "Gesetz über die elektromagnetische Verträglichkeit von Geräten (EMVG)". Dies ist die Umsetzung der EU-Richtlinie 89/336/EWG in der Bundesrepublik Deutschland.

Zulassungsbescheinigung laut dem Deutschen Gesetz über die elektromagnetische Verträglichkeit von Geräten (EMVG) vom 18. September 1998 (bzw. der EMC EG Richtlinie 89/336) für Geräte der Klasse A.

Dieses Gerät ist berechtigt, in Übereinstimmung mit dem Deutschen EMVG das EG-Konformitätszeichen - CE - zu führen.

Verantwortlich für die Konformitätserklärung nach Paragraph 5 des EMVG ist die IBM Deutschland GmbH, 70548 Stuttgart.

Informationen in Hinsicht EMVG Paragraph 4 Abs. (1) 4:

Das Gerät erfüllt die Schutzanforderungen nach EN 55024 und EN 55022 Klasse A.

update: 2004/12/07

People's Republic of China Class A Compliance Statement

This is a Class A product. In a domestic environment, this product may cause radio interference in which case the user may need to perform practical actions.

声 明

此为 A 级产品,在生活环境中,
该产品可能会造成无线电干扰。
在这种情况下,可能需要用户对其
干扰采取切实可行的措施。

Japan Class A Compliance Statement

This is a Class A product based on the standard of the VCCI Council. If this equipment is used in a domestic environment, radio interference may occur, in which case, the user may be required to take corrective actions.

この装置は、クラスA情報技術装置です。この装置を家庭環境で使用する
と電波妨害を引き起こすことがあります。この場合には使用者が適切な
対策を講ずるよう要求されることがあります。 VCCI-A

Korean Class A Compliance Statement

이 기기는 업무용(A급)으로 전자파적합등록을 한 기기이오니
판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의
지역에서 사용하는 것을 목적으로 합니다.

Taiwan Class A Compliance Statement

Warning: This is a Class A product. In a domestic environment, this product may cause radio interference in which case the user will be required to take adequate measures.

警告使用者：
這是甲類的資訊產品，在
居住的環境中使用時，可
能會造成射頻干擾，在這
種情況下，使用者會被要
求採取某些適當的對策。

台灣IBM 產品服務聯絡方式：
台灣國際商業機器股份有限公司
台北市松仁路7號3樓
電話：0800-016-888



Printed in USA

GC27-2611-03

