# GA-8EGXDR-EL Dual Xeon™ Processor Motherboard

## **USER'S MANUAL**

Dual Xeon<sup>™</sup> Processor Motherboard Rev. 1001 25A08-08E GX-C 00

## **Table of Content**

Item Check	list	4
WARNING!		4
Chapter 1 Ir	ntroduction	5
Features	Summary	5
	KDR-EL Motherboard Layout	
	lardware Installation Process	
	stall the CPU (Central Processing Unit)	
'	Step 1-1: Installation Kit Preparation	
	Step 1-2: CPU Installation	
	Step 1-3: CPU Heat Sink Installation	11
Step 2: In	stalling memory modules	13
Step 3: In	stalling expansion cards	14
Step 4: C	onnect ribbon cables, cabinet wires, and power supply	15
	Step 4-1: I/O Back Panel Introduction	15
	Step 4-2: Connectors Introduction	17
	Step 4-3: PCI Slot Introduction	26
	Step 4-5: Jumper Setting Introduction	28
Chapter 3 B	IOS Setup	31
Main		33
Advanced	d	36
	Advanced Configuration	37
	Chipset Configuration	39
	Power Management Configuration	40
	Plug and Play Configuration	42
	Peripheral Configuration	45
	Hardware MonitorConfiguration	40

Security	52
Boot	54
Exit	56
Chapter 4 Technical Reference	58
Block Diagram	
Chapter 5 Appendix	
Appendix A: Intel Network Driver Installation	59
Appendix B: ATI Rage XL VGA Driver Installation	61
Appendix C: Utilities Installation	62
Appendix D: About Updating latest version of BIOS	62
Appendix E: Acronyms	
Technical Support/RMA Sheet	65

#### Item Checklist

- ☑ The GA-8EGXDR-EL motherboard
- ☑ IDE cable x 1/ Floppy cable x 1
- ☑ Driver CD for motherboard driver & utility
- ☑ GA-8EGXDR-EL user's manual
- ✓ I/O Back Panel
- ✓ USB Cable x 1(Optional)



Computer motherboards and expansion cards contain very delicate Integrated Circuit (IC) chips. To protect them against damage from static electricity, you should follow some precautions whenever you work on your computer.

- 1. Unplug your computer when working on the inside.
- Use a grounded wrist strap before handling computer components. If you do not have one, touch both of your hands to a safely grounded object or to a metal object, such as the power supply case.
- Hold components by the edges and try not touch the IC chips, leads or connectors, or other components.
- 4. Place components on a grounded antistatic pad or on the bag that came with the components whenever the components are separated from the system.
- 5. Ensure that the ATX power supply is switched off before you plug in or remove the ATX power connector on the motherboard.

#### Installing the motherboard to the chassis...

If themotherboard has mounting holes, but they don't line up with the holes on the base and there are no slots to attach the spacers, do not become alarmed you can still attach the spacers to the mounting holes. Just cut the bottom portion of the spacers (the spacer may be a little hard to cut off, so be careful of your hands). In this way you can still attach the motherboard to the base without worrying about short circuits. Sometimes you may need to use the plastic springs to isolate the screw from the motherboard PCB surface, because the circuit wire may be near by the hole. Be careful, don't let the screw contact any printed circuit write or parts on the PCB that are near the fixing hole, otherwise it may damage the board or cause board malfunctioning.

## Chapter 1 Introduction Features Summary

Form Factor	• 30.5cm x 33cm Extend ATX size form factor, 8 layers PCB.
CPU	Dual socket 604 for Intel® Xeon processor suopprts
	1.8 GB to 3.06GB and upper
	Intel Pentium® Xeon 533MHz FSB
	• 512KB internal cache depend on CPU
Chipset	Serverworks CMIC-SL Northbridge
	Serverworks CSB6 Southbridge
Memory	4 184-pin DDR DIMM sockets
	<ul> <li>Supports 4 ECC Registered DIMM DDR 266</li> </ul>
	<ul> <li>Supports up to 4 GB DRAM (Max)</li> </ul>
	Supports 2.5V DDR DIMM only
I/O Control	• NS PC87417
Slots	Support PCI 64/66 MHz x 5 Slots & PCI 32/33 MHz x 1 Slot
On-Board IDE	2 IDE bus master (ATA100) IDE ports for up to 4 ATAPI devices
On-Board Peripherals	<ul> <li>1 Floppy port supports 360K, 720K,1.2M, 1.44M and 2.88M bytes.</li> </ul>
	1 Parallel port supports Normal/EPP/ECP mode
	• 2 COM ports (COM1 & COM2; one at front and one at rear)
	1 LAN port (GLAN1: Gigabit Ethernet)
	• 2 USB 1.1
Hardware Monitor	CPU/Power/System Fan speed detection
	CPU/Power/System Fan Control
	CPU Overheat Warning


to be continued......

#### GA-8EGXDR-EL Motherboard

	System Intrution Detect
	3
	System Voltage Monitoring
On-Board LAN	<ul> <li>Build in Intel RC 82540EM 10/100/1000 Gigabit Ethernet</li> </ul>
	Chipset
On-Board VGA	Build in ATI Rage XL VGA PCI Chipset with 8M SDRAM on board
PS/2 Connector	PS/2 Key board interface and PS/2 Mouse interace
BIOS	<ul> <li>Licensed Award BIOS, 4Mb flash ROM</li> </ul>
Additional Features	Wake on LAN (GLAN2)
	<ul> <li>WOM (Wake on Modem, Wake on Ring)</li> </ul>
	AC Recovery
	IPMI V1.0 (Optioal)

◆ Please use the same speed CPU when your system runs in the dual CPU configuration. Whether your system can run under these specific bus frequencies properly, it will depend on your hardware configurations, including CPU, Chipsets, SDRAM, Cards... .etc.


## **GA-8EGXDR-EL Motherboard Layout**



## Chapter 2 Hardware Installation Process

To set up your computer, you must complete the following setups:

- Step 1- Install the CPU2 (If you are installing one CPU ONLY)
- Step 2- Install memory modules
- Step 3- Install expansion cards
- Step 4- Connect cables, cabinet wires, and power supply
- Step 5- Setup BIOS software



## Step 1: Install the CPU (Central Processing Unit)

#### **Step 1-1: Installation Kit Preparation**

You may use the 4 screws which come with the mainboard to reinforce the support between P4 CPU heat-sink on the mainboard and chassis.

Step1: The 4 new mounting holes on the chassis arefor additional support for P4 C PU heatsink on the mainboard.

Step2: Apppearance of mainboard.




Figure 1



Figure 2

Step 3: Preparing retention module kit.






Figure 3



Figure 4


#### Step 1-2: CPU Installation



CPU Top View



1. Pull the lever out, than lift up the Lever.



CPU Bottom View




- Locate Pin 1 in the socket and look for a (golden) cut edge on the CPU upper corner. Then insert the CPU into the socket.
   Press down the CPU socket lever and finish CPU installation.
- **♦** Please make sure the CPU type is supported by the motherboard.
- If you do not match the CPU socket Pin 1 and CPU cut edge well, it will cause improper installation. Please change the insert orientation.
- Warning: If your install one CPU ONLY, please refer to the Motherboard Layout (page 7) to install the CPU 2 frist.
- Note that if you insall two CPUs, please install the same speed CPUs.

### Step 1-3: CPU Heat Sink Installation




1. Use qualified fan approved by Intel.




2. Heat Sink



3. First step of assembling.



4. Completive picture for Step 3.



5. Second step of assembling.



6. Completive picture for Step 5.



7. Fan assembly.



8. Hook one end of the cooler bracket to the CPU socket first.



9. Picture of device set on the motherboard.

- You should apply the thermal paste to provide better heat conduction between your CPU and heatsink.
- Make sure the CPU fan power cable is plugged in to the CPU fan connector, this completes the installation.
- Please refer to CPU heat sink user's manual for more detail installation procedure.


#### Step 2: Installing memory modules




Before installing the processor and heatsink, adhere to the following warning: When DIMM LED is ON, do not install/remove DIMM from socket.

Please note that the DIMM module can only fit in one direction due to the one notches. Wrong orientation will cause improper installation. Please change the insert orientation.

The motherboard has 4 dual inline memory module (DIMM) sockets. The BIOS will automatically detects memory type and size. To install the memory module, just push it vertically into the DIMM Slot.





- The DIMM slot has a notch, so the DIMM memory module can only fit in one direction.
- 2. Insert the DIMM memory module vertically into the DIMM slot. Then push it down.
- Close the plastic clip at both edges of theDIMM slots to lock the DIMM module.
   Reverse the installation steps when you wish to remove the DIMM module.
- Please note that the DIMM module can only fit in one direction due to the one notches. Wrong orientation will cause improper installation. Please change the insert orientation.


### Step 3: Installing expansion cards

- 1. Discharge any static electricity from your body before handling the sensitive board of the card.
- 2. Turn off and unplug your computer before removing your computer's chassis. Failure do so may endamger you and damage the expansion card or computer.
- 3. Read the related expansion card's instruction document before install the expansion card into the computer.
- 4. Remove your computer's chassis cover, screws and slot bracket from the computer.
- 5. Press the expansion card firmly into expansion slot on motherboard.
- 6. Be sure the metal contacts on the card are indeed seated in the slot.
- 7. Replace the screw to secure the slot bracket of the expansion card.
- 8. Replace your computer's chassis cover.
- 9. Power on the computer, if necessary, setup BIOS utility of expansion card from BIOS.
- 10. Install related driver from the operating system.



## Step 4: Connect ribbon cables, cabinet wires, and power supply

Step 4-1: I/O Back Panel Introduction



#### PS/2 Keyboard and PS/2 Mouse Connector




PS/2 Mouse Connector (6 pin Female)



PS/2 Keyboard Connector (6 pin Female)


➤ This connector supports standard PS/2 key board and mouse.

#### USB2 Connector



➤ Before you connect your device(s) into USB connector(s), please make sure your device(s) such as USB keyboard, mouse, scanner, zip, speaker..etc. Have a standard USB interface. Also make sure your OS (Windows 2000, Win dows ME, Win NT with SP 6) supports USB controller. If your OS does not support USB controller, please contact the OS vendor for pos sible patch or driver upgrade. For more information please contact your OS or device(s) vendors.

#### ❸ Parallel Port / Serial Port / VGA Port (LPT/COMA/VGA)



➤ This connector supports 1 standard COM port ,1 Parallel port and 1 VGA port. Device like printercan be connected to Parallel port; mouse and modem etc can be connected to Serial ports.

#### **④** GLAN2






➤ GLAN 2: Giagbit Ethernet

#### GLAN1 / LAN1 LED Indicator Description


LAN Port	Status	Description
GLAN 2	Yellow LED Blink	GLAN1 active
	Yellow LED On	GLAN1 connected
	Green LED On	GLAN1 at Speed 100MB/1000MB
	Green LED Off	GLAN1 at speed 10MB

**Step 4-2: Connectors Introduction** 



A) ATX3	K) System FAN 2
B) ATX1	L) System FAN 3
C) ATX2	M) COM 2
D) BT1	N) CPU FAN 1
E) FDD1	O) CPU FAN 2
F) IDE1	P) WOM 1
G) IDE2	Q) WOL 1
H) SMBUS1	R) USB1
I) F_Panel1	S) CASEOPEN
J) System FAN 1	

#### A) ATX3 (ATX1 Power)







Pin No.	Definition
1	GND
2	+12v
3	GND
4	+12V
5	GND
6	+12V
7	GND
8	+12V

➤ This connector (ATX +12V) is used only for CPU Core Voltage.

#### B) ATX1 (2x12 Pin ATX Power)






AC power cord should only be connected to your power supply unit after ATX power cable and other related devices are firmly connected to the mainboard.

Definition
+3.3V
+3.3V
GND
+5V
GND
+5V
GND
POK
5VSB
+12V
+12V
+3.3V
+3.3V
-12V
GND
PSON
GND
GND
GND
-5V
+5V
+5V
+5V
GND

#### C) ATX2 (+12V Power Connector)






Pin No.	Definition
1	GND
2	GND
3	+12V
4	+12V

➤ This connector (ATX +12V) is used only for CPU Core Voltage.

### N / O) CPU FAN 1/2 Connectors






Pin No.	Definition
1	GND
2	+12v/Control
3	Sense

➤ Please note, a proper installation of the CPU cooler is essential to prevent the CPU from running under abnormal condition or damaged by overheating. The CPU fan connector supports Max. current up to 600mA.

#### $J\,/\,K\,/\,L)$ System FAN 1/2/3 Connectors

SYS\_FAN2




J34
1000

Pin No.	Definition
1	GND
2	+12v/Control
3	Sense

	J3	1
	apa	[
•	1	_

Pin No.	Definition
1	GND
2	+12v/Control
3	Sense


#### Q) WOL1 (Wake On LAN Connector)





Pin No.	Definition
1	+5VSB
2	GND
3	Signal


#### P) WOM1 (Wake on Ring Connector)






Pin No.	Definition
1	Signal
2	GND


#### M) COM 2 Connector






Pin No.	Definition
1	NDCDB
2	NSINB
3	NSOUTB
4	NDTRB
5	GND
6	NDSRB-
7	NRTSB-
8	NCTSB-
9	NRIB-
10	NC

#### F / G ) IDE 1/ IDE 2 [IDE1 / IDE2 / Connectors(Primary/Secondary)]







#### ➤ Important Notice:


Please connect first harddisk to IDE1 and connectCDROM to IDE2. The red stripe of the ribbon cable must be the same side with the Pin1.

#### E) FDD1 (Floppy Connector)





#### R) USB1 (Front USB Connector)






Pin No.	Definition	
1	Power	
2	GND	
3	USB D3-	
4	NC	_
5	USB D3+	
6	USB D2+	_
7	NC	
8	USBD2-	_
9	GND	
10	Power	_

➤ Be careful with the polarity of the front panel USB connector. Check the pin assignment while you connect the front panel USB cable. Please contact your nearest dealer for optional front panel USB cable.


#### H) SMBUS1





Pin	Definition
1	VCC
2	SDA
3	SCL
4	NC
5	GND

#### S) CASE OPEN






Pin No.	Definition
1	Signal
2	GND

➤This 2 pin connector allows your system to enable ordisable the "case open" item in BIOS if the system case begin remove.

#### D) BT1 (Battery)



Li-Battery 3V



CR2032


#### **CAUTION**


- Danger of explosion if battery is incorrectly replaced.
- Replace only with the same or equivalent type recommended by the manufacturer.
- Dispose of used batteries according to the manufacturer's instructions.

#### I) F\_PANEL1 (2x9 Pins Connector)



Please connect the power LED, PC speaker, reset switch and power switch etc of your chassis font panel to the F\_PANEL1 connector according to the pin assignment above.







HD (IDE Hard Disk Active LED)	Pin1: LED anode(+)
	Pin2: LED cathode(-)
GN (Green Switch)	Open: Normal
	Close: Entering green mode
GD (Green LED)	Pin1: LED anode(+)
	Pin2: LED cathode(-)
SPK(Speaker Connector)	Pin1: VCC(+)
	Pin2-Pin3: NC
	Pin4: Data(-)
PD+PDG-PDY-(Power LED)	Pin1: LED anode(-)
	Pin2: LED cathode(-)
	Pin3: LED cathode(-)
PW (Soft Power Connector)	Open: Normal opeartion
	Close: Power On/Off
RS (Reset Switch)	Open: Normal operation
	Close: Reset Hardware System

GA-8EGXDR-EL Motherboard


Step 4-3: PCI Slot Introduction




#### ① PCI\_X\_SLOT1 Supports PCI 64/66MHz




#### ③ PCISLOT3 Supports PCI 64/66MHz




S PCISLOT5 Supports PCI 64/66MHz




#### ② PCI\_X\_SLOT2 Supports PCI 64/66MHz




#### PCISLOT4 Supports PCI 64/66MHz



#### © PCISLOT6 Supports PCI 32/33MHz




**Step 4-5: Jumper Setting Introduction** 



Please note that the highlight white mark on the motherboard is presented as Pin 1

#### 1) JP2 (Onboard Gigabit LAN2 Enable Function)




- 1 1-2 close: Enable onboard GLAN 2 (Default)
- 1 2-3 close: Disable onboard GLAN2




Please note that the the highlight white mark is presented as Pin 1.

#### 2) JP3 (Onboard VGA Functon)



- 1 1-2 close: Onboard VGA Enabled (Default)
- 1 2-3 close: Onboard VGA Disabled

#### 3) JP4 (Clear CMOS Function)




- 1 1-2 close: Clear CMOS (Default)
- 1 2-3 close: Stay Normal



Please note, Youmay clear the CMOS data to its default values by this jumper

#### 4) JP10 (CPU Bus External Frequency Selection)



- 1 1-2 close: Set the fequency at 400MHz
- 1 2-3 close: Auto (400/533MHz) (Default)

## Chapter 3 BIOS Setup

BIOS Setup is an overview of the BIOS Setup Program. The program that allows users to modify the basic system configuration. This type of information is stored in battery-backed CMOS RAM so that it retains the Setup information when the power is turned off.

#### **ENTERING SETUP**

Power ON the computer and press <DEL> immediately will allow you to enter Setup.

#### CONTROL KEYS

COMING	AL KEIS
< <b>↑</b> >	Move to previous item
<√>	Move to next item
<←>	Move to the item in the left hand
< <b>→</b> >	Move to the item in the right hand
<esc></esc>	Main Menu - Quit and not save changes into CMOS Status Page Setup Menu and
	Option Page Setup Menu - Exit current page and return to Main Menu
<+/PgUp>	Increase the numeric value or make changes
<-/PgDn>	Decrease the numeric value or make changes
<f1></f1>	General help, only for Status Page Setup Menu and Option Page Setup Menu
<f2></f2>	Reserved
<f3></f3>	Reserved
<f4></f4>	Reserved
<f5></f5>	Restore the previous CMOS value from CMOS, only for Option Page Setup Menu
<f6></f6>	Reserved
<f7></f7>	Load the Optimized Defaults
<f8></f8>	Reserved
<f9></f9>	Reserved
<f10></f10>	Save all the CMOS changes, only for Main Menu

#### **GETTING HELP**

#### Main Menu

The on-line description of the highlighted setup function is displayed at the bottom of the screen.

#### Status Page Setup Menu / Option Page Setup Menu

Press F1 to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window press <Esc>.

#### Mair

This setup page includes all the items in standard compatible BIOS.

#### Advanced

This setup page includes all the items of AMT special enhanced features. (ex: Auto detect fan and temperature status, automatically configure hard disk parameters.)

#### Security

Change, set, or disable password. It allows you to limit access the system and setup.

#### Roo

This setup page include all the items of first boot function features.

#### • Exit

There are five options in this selection: Exit Saving Changes, Exit Discarding Changes, Load Optimal Defaults, Load Failsafe Defaults, and Discard Changes.

#### Main

Once you enter AMI BIOS Easy Setup Utility, the Main Menu (Figure 1) will appear on the screen. Use arrow keys to select among the items and press <Enter> to accept or enter the sub-menu.

AMIBIOS EASY SETUP Utility - VERSION		
Main Advanced	Security Boot	Exit
System Date:	Jan 30 2002	[Setup Help]
System Time:	[00:13:12]	
Floppy Drive A:	1.44MB 3 <sup>1/2</sup>	
Floppy Drive B:	Not Installed	
▶ Primary IDE Master	ST380021A	
▶ Primary IDE Slave		
► Secondary IDE Mast	er	
▶ Secondary IDE Slav	е	
➤ System Information		
'		nange Values F5: Setup Defaults
Esc: Exit $\longleftrightarrow$ :	Select Menu Enter: S	Select ➤ Sub-Menu F10: Save&Exit

Figure 1: Main

#### System Date

Set the System Date. Note that the "Day" automatically changed after you set the date. (Weekend: DD: MM: YY) (YY: 1099~2099)

#### ♡ System Time

The time is calculated based on the 24-hour military time clock. Set the System Time (HH:MM:SS)

#### ☐ Floppy Drive A/B

This category identifies the type of floppy disk drive A or drive B that have been installed in the computer.

None No floppy drive installed
▶1.2MB, 3.5 in. 3.5 inch AT-type high-density drive; 1.2M byte capacity
▶720K, 3.5 in. 3.5 inch double-sided drive; 720K byte capacity
▶1.44M, 3.5 in. 3.5 inch double-sided drive; 1.44M byte capacity
▶2.88M, 3.5 in. 3.5 inch double-sided drive; 2.88M byte capacity

#### ○ IDE Primary Master, Slave / Secondary Master, Slave

The category identifies the types of hard disk from driveC to F that has been installed in the computer. There are two types: auto type, and manual type. Manual type is user-definable; Auto type which will automatically detect HDD type.

Note that the specifications of your drive must match with the drive table. The hard disk will not work properly if you enter improper information for this category.

If you select User Type, related information will be asked to enter to the following items. Enter the information directly from the keyboard and press <Enter>. Such information should be provided in the documentation form your hard disk vendor or the system manufacturer.

#### TYPE

▶ 1-50: Predefined types.

▶ Users: Set parameters by User.

▶ Auto: Set parameters automatically. (Default Vaules)

▶ CD-ROM: Use for ATAPI CD-ROM drives.

Or double click [Auto] to set all HDD parameters automatically.

 ➤ Cy linders
 Number of cy linders

 ➤ Write Precompensation
 Write precompensation

 ➤ SECTORS
 Number of sectors

 ➤ Max imum Capacity
 Max imum Capacity

▶ LBA Mode This field shows if the device type in the specific IDE channel

support LBA Mode

▶ Block Mode This field only shows the information of Block Mode.

▶ Fast Programmed I/O Mode This field only shows the information of Fast Programmed

I/O Mode

▶ 32 Bit Transfer Mode Enables 32 bit access to maximize the hard disk data

transfer rate.

Option: On (Default Value); Off

If a hard disk has not been installed select NONE and press <Enter>.

#### **♡** System Information

This category displays the system information on **Processor type**, **speed**, **cache** and **Total Memory Size**.

#### **Advanced**




Figure 2: Advanced

#### About This Section: Advanced

This section "Advanced" will be divided into five sub-menus.

- Advanced Configuration
- Chipset Configuration
- **◆** Power Management Configuration
- ◆ Plug & Play Configuration
- **◆** Peripheral Configuration
- Hardware Monitor Configuration

With this section, allowing user to configure your system for basic operation. A user can change the system's default boot-up sequence, keyboard operation, shadowing and security, etc.

# **Advanced Configuration**

	AM	IBIOS EASY SET	UP Utility - \	VERSI	ON
Main	Adv anced	Security	Boot	Exit	
Advanced	Configuration				[Setup Help]
	m-Lock	[Enabled] [Disabled] 1.4 On [Enabled]			
F1: Help Esc: Exit	↑↓: Sele ←→: Se		+ -: Change Enter: Select		·

Figure 2-1: Advanced Configuration

#### **→ Advanced Configuration**

#### ▶ Show Full Screen Logo

This option allows user to set whether to show the Logo while boot.

▶ Enabled Set this option "Enable" to permit BIOS to show full screen logo. (Default

Value)

→ Disabled Disable this function.

#### ▶ S.M.A.R.T for Hard Disk

This filed shows if the device in the specific IDE channel supports S.M.A.R.T.

 $\label{eq:S.M.A.R.T} \textbf{S.M.A.R.T} \textbf{ stands for Self-Monitoring Analysis and Reporting Technology. Set this option "Enable" to permit BIOS to use S.M.A.R.T.$ 

▶ Enabled Set this option "Enable" to permit BIOS to use S.M.A.R.T.

▶ Disabled Disable S.M.A.R.T function. (Default Value)

#### ▶ MPS Version for O.S

This option allows a user to select MP (Multi Processors) system supported version.

**Note:** Some old MPS OS support 1.1 version only.

▶1.4 Support MPS Version 1.4. (Default Value)

▶1.1 Support MPS Version 1.1.

#### ▶ BootUp Num-Lock

Set this option "On" to turn the Num Lock On at a system boot.

→ON Set this option "On" to turn the Num Lock On at a system boot. (Default Value)

→OFF Disable this function.

#### ▶ Intel Hyer Threading

▶ Enabled Enable Intel Hyper Threading. (Default Value)

▶ Disabled Disable Inel Hyper Threading.

# **Chipset Configuration**

		AMIBIOS EASY SE	TUP Utility - VE	RSION
Main	Advanced	Security	Boot E	Exit
Chipset	Configuration			[Setup Help]
Memory	Scrubbing	Enabled		
F1: Help Esc: Exit		Select Item : Select Menu	+ -: Change Val Enter: Select >	· ·

Figure 2-2: Chipset Configuration

## **⇔** Chipset Configuration

## ▶ Memory Scrubbing

Enables this option to write back the ECC corrected memory data to the DRAM.

➤ Enabled Enabled Memory Srubbing (Default Value)

▶ Disabled Disable this function.

## **Power Management Configuration**

		AMIBIOS EASY SE	THP Hillih	- VERSION			
Main	Adv anced	Security	Boot	Exit			
Pow er M	Nanagement Co	nfiguration				[Setup Help]	
Soft Off I	By Power Butto	n Instant off					
3011-011	by Power Bullo	II IIISIAIIL UII					
Sleep Bu	utton	Enabled					
Wake Up	o On Ring	Enabled					
System	After AC Back	Off					
F1. Holp	<b>Λ1.</b> (	Calant Itam	Chan	ao Voluos	EE.	Cotup Dofoulto	
F1: Help		Select Item		ge Values		Setup Defaults	
Esc: Exit	←→:	Select Menu	Enter: Se	lect ▶ Sub-Me	enu	F10: Save&Exit	

Figure 2-3: Power Management Configuration

## $^{\circ}$ Power Management Configuration

The Power Management Configuration allows you to reduce system power consumption through different saving power methods for various devices.

## ▶ Soft-Off by Power Button

► Instant off Soft switch ON/OFF for Power Button. (Default Value)

→ Delay-4Sec Soft switch ON 4 Sec for Power off.

## ▶ Sleep Button

Leaves on the default for best compatibility

▶ Enabled Enables Sleep button(Default Value)

▶ Disabled Disabled this function.

## ▶ Wake Up On Ring

➤ Enabled Enabled Wake Up On Ring(Default Value)

▶ Disabled Disabled this function.

## ▶ System After AC Back

System power state when AC cord is re-plugged.

▶ Pre-State Set system power to the last state when AC power is removed.▶ OFF Do not power on system when AC power is back. (Default Value)

# **Plug and Play Configuration**

	AMIBIOS EA	SY SETUP Utility	y - VERSION	
Main Advar	nced Securi	ty Boot	Exit	
Plug and Play Co	onfiguration			[Setup Help]
•				
PCI Slot 1/5 IRQ	Priority Aut	0		
PCI Slot 2/6 IRQ	Priority Aut	0		
PCI Slot 3 IRQ Pr	riority Aut	0		
PCI Slot 4 IRQ Pr	riority Aut	0		
IRQ 3	PC	/PnP		
IRQ 4	PC	//PnP		
IRQ 5	PC	//PnP		
IRQ 7	PC	//PnP		
IRQ 9	PC	/PnP		
IRQ 10	PC	/PnP		
IRQ 11	PC	//PnP		
IRQ 14	PC	//PnP		
IRQ 15	PC	//PnP		
F1: Help	↑↓: Select Item		nge Values	F5: Setup Defaults
Esc: Exit	←→: Select Menu	Enter: Se	elect ▶ Sub-Me	enu F10: Save&Exit

Figure 2-4: Plug and Play Configuration

## Plug and Play Configuration

This option describes the configuration of PCI bus system, or Personal Conputer Interconnect, is a system which allows I/O devices to operate at a speeds nearing the speed the CPU itself uses when communicating withits own special components. This section covers some technical items and it si stongly recommended that only experienced users should make any changes to the default settings.

### ▶ PCI Slot 1/5 IRQ Priority

Select PCI Slot 1/5 IRQ Priority.

▶ Auto Auto assign IRQ to PCI 1/5 (Default Value)

**▶** 3, 4, 5, 7, 9, 10, 11 Set 3, 4, 5, 7, 9, 10, 11 to PCI 1/5

#### ▶ PCI Slot 2/6 IRQ Priority

Select PCI Slot 2/6 IRQ Priority.

→ Auto Auto assign IRQ to PCI 2/6 (Default Value)

**▶** 3, 4, 5, 7, 9, 10, 11 Set 3, 4, 5, 7, 9, 10, 11 to PCI 2/6

#### ▶ PCI Slot 3 IRQ Priority

Select PCI Slot 3 IRQ Priority.

→ Auto Auto assign IRQ to PCI 3 (Default Value)

**▶** 3, 4, 5, 7, 9, 10, 11 Set 3, 4, 5, 7, 9, 10, 11 to PCI 3

#### ▶ PCI Slot 4 IRQ Priority

Select PCI Slot 4 IRQ Priority.

→ Auto Auto assign IRQ to PCI 4 (Default Value)

▶ 3, 4, 5, 7, 9, 10, 11 Set 3, 4, 5, 7, 9, 10, 11 to PCI 4

## ▶ IRQ 3, 4, 5, 7, 9, 10, 11, 14, 15

This option allows a user to set if let BIOS detect the IRQ events. When the BIOS detects an IRQ trigger event being actived, the system will wake up and resumes its activities.

→ Option: PCI/PnP (Default Value); ISA

# **Peripheral Configuration**

	AMIBIO	S EASY SET	UP Utility - V	'ERSIO	N
Main Adv a	inced S	ecurity	Boot	Exit	
Peripheral Config	juration				[Setup Help]
OnBoard IDE		Both			
Tertiary IDE		Disabled			
OnBoard FDC		Enabled			
Onboard Serial P	Port A	3F8/COM1			
Onboard Serial P	Port B	2F8/COM2			
Onboard Parallel	Port	378			
Parallel Port	Mode	ECP			
Parallel Port	IRQ	7			
Parallel Port	DMA	3			
USB Function		Enabled			
USB Legacy Sup	pport	Disabled			
Port 64/60 Emula	ation	Disabled			
F1: Help Esc: Exit	↑↓: Select Ite		+ -: Change \ Enter: Select		F5: Setup Defaults Menu F10: Save&Exit

Figure 2-5: Peripheral Configuration

## **♡** Peripheral Configuration

#### ▶ OnBoard IDE

→ Option: Both (Default Value), Primary, Secondary, Disabled

## ▶ Tertiary IDE

This function allows users to enable the third IDE Channel in CSB6

⇒ Enable Enable the third IDE Channel in CSB6.

▶ Disable Disable this function.

#### ▶ OnBoard FDC

▶ Enabled Select "Enabled" to active Onboard Floppy Controller. (Default Value)

▶ Disabled Disable this function.

#### ▶ OnBoard Serial Port A

This option specifies the base I/O port address of serial prot A.

⇒ 3F8/COM1 Enable onboard serial port A and set I/O address to 3F8/COM1.

(Default value)

➤ 2F8/C OM2 Enable onboard serial port A and set I/O address to 2F8/C OM2.
 ➤ 3E8/C OM3 Enable onboard serial port A and set I/O address to 3E8/C OM3.
 ➤ 2E8/C OM4 Enable onboard serial port A and set I/O address to 2E8/C OM4.

#### ▶ OnBoard Serial Port B

This option specifies the base I/O port address of serial prot B.

**Note:** If one port address is assigned to serial portA, than that address will not be able to resign to serial port B.

→ 3F8/COM1 Enable onboard serial port A and set I/O address to 3F8/COM1.
 → 2F8/COM2 Enable onboard serial port A and set I/O address to 2F8/COM2.

(Default value)

⇒ 3E8/COM3 Enable onboard serial port A and set I/O address to 3E8/COM3.
 ⇒ 2E8/COM4 Enable onboard serial port A and set I/O address to 2E8/COM4.

#### ▶ OnBoard Parallel Port

This option specifies the base I/O address of the parallel prot on the motherboard.

▶ 378 Enable onboard LPT port and set I/O address to 378. (Default value)

▶278 Enable onboard LPT port and set I/O address to 278
 ▶3BC Enable onboard LPT port and set I/O address to 3BC

#### ▶ Parallel Port Mode

This option specifies the parallel mode.

**Normal** The normal parallel pro is used.

**▶ Bi-Directional** Use this setting to support bi-directional transfers on the parallel port.

**▶EPP** The parallel port can be used with devices that adhere to the

enhanced Parallel Port (EPP) specifications. EPP uses the existing parallel port signal to provide asymmetric bi-directional

data transfer driven by the host device.

**▶ECP** The parallel port can be used with devices that adhere to the

extended Capabilities Port specifications. ECP uses the DMA protocod to achieve data transfer rate up to 2.5Mbit/s. ECP provides the symmetric bi-directional communication. (Default value)

#### ▶ Parallel Port IRQ

This option is to select Parallel Port IRQ

→ Option: 7 (Default Value), 5

#### ▶ Parallel Port DMA

This option iallows user to select Parallel Port DMA.

→ Option: 3 (Default Value), 1

### **▶** USB Function

This option allows user to enable USB host controller.

▶ Enable Enable USB host controller (Default Value)

▶ Disabled Disable this function.

### ▶ USB Legacy Support

This option allows user to function support for legacy USB.

▶ Enabled Enables support for legacy USB

▶ Disabled Disables support for legacy USB (Default Value)

## ▶ Port 64/60 Emulation

This option allows user to enable or disable the Port 64/60 Emulation function.

▶ Enable Enables the Port 64/60 Emulation function▶ Disabled Disable this function. (Default Value)

Hardy	ware Monito	rConfigu IBIOS EASY S	ration SETUP Utilit	y - VERSION	V
Main	Adv anced	Security	Boot	Exit	
Hardw a	are Configuration				[Setup Help]
CPU T	emperature		-45°C/-4	9ºF	
System	Temperature		+75°C/+	167ºF	
CPU_F	AN Speed		RPM		
SYS_F	AN1 Speed		RPM		
SYS_F	AN2 Speed		RPM		
SYS_F	AN3 Speed		RPM		
SYS_F	AN4 Speed		RPM		
*VCC_	_P		1.475V		
*VCC	2.5		2.576V		
*VCC	3		3.376V		
*VCC	12		5.080V		
∗VBAT			11.840V		
<b></b> ≉5VSB			3.056V		
Hardw a	are Monitor Alarm		Disabled		
SYS. To	emp. Buzzer Alarm		Disabled		
CPU_F	AN Buzzer Alarm		Disabled		
SYS_F	AN1 Buzzer Alarm		Disabled		
SYS_F	AN2 Buzzer Alarm		Disabled		
SYS_F	AN3 Buzzer Alarm		Disabled		
SYS_F	AN4 Buzzer Alarm		Disabled		
VCC_P	Buzzer Alarm		Disabled		
Case C	pen Alarm		Disabled		
Case C	pen Status		Close		
Reset (	Case Open Status		No		
F1: Help	↑↓: Sele	ct Item	+ -: Cha	nge Values	F5: Setup Defaults
Esc: Exit	←→: Se	lect Menu	Enter: Se	elect ▶ Sub-M	Menu F10: Save&Exit

Figure 2-6: Hrdware Monitor Configuration

#### **☞** Hardware Monitor Configuration

This section provides the system hardware health information to user for reference.

#### **▶** CPU Temperature

This field only displlays the current CPU temperature.

#### **▶** System Temperature

This field only displlays the current system temperature.

#### ▶ CPU FAN Speed

This field indicates the RPM (Ratio Per Minute) of current CPU speed.

#### ▶ SYS FAN 1 / 2 / 3 / 4 Speed

This field indicates the RPM (Ratio Per Minute) of System Fan 1/2/3/4 speed.

#### ▶ VCC\_P / VCC 2.5 / VCC 3 / VCC 12 / VBAT / 5VSB

These fields only display the current CPU / System voltage.

#### ► Hardware Monitor Alarm

This field allows user to monitor and to ser the set the warning values to protect the system hardware health. Enable this function to active the following desired items.

#### ► SYS\_TEM. Buzzer Alarm

Enable this function is protecting the System temperature is under the set value. System will alarm when the system temperature is over the set value.

▶ Enabled Enable system temperature buzzer alarm.

▶ Disabled Disable this function.

### ► CPU\_FAN1/2 / SYS\_FAN1/2/3/4 Buzzer Alarm

When this function is enabled, system will alarm when CPU FAN1/2 or SYS\_FAN1/2/3/4 stop.

► Enabled Enable CPU FAN 1/2 or SYS\_FAN 1/2/3/4 buzzer alarm.

▶ Disabled Disable this function.

#### ▶ VCC\_P Buzzer Alarm

Enable this function is protecting the system voltage is under the set value. System will alarm when the voltage is over the set value.

▶ Enabled Enable VCC\_P buzzer alarm.

→ Disabled Disable this function.

#### ► Case Open Alarm

This optionallows user to set the case open alarm by physical warning alert. Once the chassis is opened, the system will rise warning beep to alarm user to close the case properly.

▶ Enabled Enable Case Open alarm.▶ Disabled Disable this function.

#### ▶ Case Status

This item displays the status of system case.

#### ▶ Reset Case Open Status

This function provides user to stop the case open warning beep. Once the case is opened, the system will rise waring alert. To stop the beep, user is required to enter the setup menu and rest the case open status to "Yes" option.

# **Security**

	AMII	BIOS EASY SE	TUP Utility -	VERSION	l
Main	Advanced	Security	Boot	Exit	
					[Setup Help]
Set Supe	rvisor Password:	[Enter]		ľ	
Set User	Password:	[Enter]			
Passwor	d Check	[Setup]			
F1: Help	↑↓: Selec	ct Item	+ -: Change	· Values	F5: Setup Defaults
Esc: Exit	←→: Sel	ect Menu	Enter: Sele	ct ▶ Sub-N	Menu F10: Save&Exit

Figure 3: Security

## About This Section: Security

In this section, user can set either supervisor or user passwords, or both for different level of password securities. In addition, user also can set the virus protection for boot sector.

#### **▽Set Supervis or Pass word**

You can install and change this options for the setup menus. Type the password up to 6 characters in length and press <Enter>. The password typed now will clear any previously entered password from the CMOS memory. You will be asked to confirm the entered password. Type the password again and press <Enter>. You may also press <Esc> to abort the selection and not enter a specified password or press <Enter> key to disable this option.

#### ○ Set User Password

You can only enter but do not have the right to change the options of the setup menus. When you select this function, the following message will appear at the center of the screen o assist you in creating a password.

Type the password up to 6 characters in lengh and press <Enter>. The password typed now will clear any previously entered password from the CMOS memory. You will be asked to confirm the entered password. Type the password again and press <Enter>. You may also press <Esc> to abort the selection and not enter a specified password.

#### Password Check

- ▶ Setup will check password while invlolking setup. (Default Value)
- ▶ Always will check the password while involking setup as well as on each boot.

## **Boot**

	AM	IBIOS EASY S	ETUP Utility - V	ERSION	
Main	Advanced	Security	Boot	Exit	
					[Setup Help]
Boot Dev	ice Priority				
Floppy:	1.44 MB 3 <sup>1/2</sup>				
CD/DVD	: C-540E				
IDE-0: S	T380021A				
OnBoard	I 82540 LAN Boot I	ROM	Enabled		
F1: Help	↑↓: Sele	ct Item	+ -: Change \	alues F5	: Setup Defaults
Esc: Exit	←→: Se	lect Menu	Enter: Select	▶ Sub-Menu	F10: Save&Exit

Figure 4: Boot

#### **d** About This Section: Boot

The "Boot" menu allows user to select among four possible types of boot devices listed using the up and down arrow keys. By applying <+> and <Space> key, you can promote devices and by using the <-> key, you can demote devices. Promotion or demotion of devices alerts the priority that the system uses to search for boot device on system power on.

## **⇔** Boot Device Priority

#### ▶ 1st / 2nd / 3 rd Boot Device

These three fields determines which type of device the system attempt to boot from after **AMIBIOS Post** completed. Specifies the boot sequence from the available devices. If the first device is not a bootable device, the system will seek for next available device.

- ▶ The Choice for 1st Boot Device: ,
- ▶ Removable Device (Default Value)
- → ATAPI CDROM
- → Hard Disk
- **→** Disabled.
- ▶ The Choice for 2nd Boot Device:
- → Removable Device
- ▶ ATAPI CDROM (Default Value)
- → Hard Disk
- **→** Disabled.

#### ▶ OnBoard 82540 LAN Boot ROM

► Enabled Enable OnBoard 82540 LAN Boot ROM. (Default Value)

Disabled Disable this function.

## **Exit**

	AM	IBIOS EASY SE	TUP Utility -	VERSION	l
Main	Advanced	Security	Boot	Exit	
Exit Disca Load Defa	ng Changes arding Changes aul Settings inal Values	[Enter] [Enter] [Enter]			[Setup Help]
F1: Help Esc: Exit	↑↓: Sele ←→: Se	ct Item lect Menu	+ -: Change Enter: Select		F5: Setup Defaults lenu F10: Save&Exit

Figure 5: Exit

## **d** About This Section: Security

Once you have changed all of the set values in the BIOS setup, you should save your changes and exit BIOS setup program. Select "Exit" from the menu bar, to display the following sub-menu.

- **◆** Exit Saving Changes
- **◆** Exit Discarding Changes
- **◆** Load Default Settings
- ◆ Load Original Values

#### **▽**Exit Saving Changes

This option allows user to exit system setup with saving the changes. Press <Enter> on this item to ask for the following confirmation message: Pressing  $\Upsilon'$  to store all the present setting values tha user made in this time into CMOS. Therefore, whenyou boot up your computer next time, the BIOS will re-configure your system according data in CMOS.

#### **▽**Exit Discarding Changes

This option allows user to exit system setup without changing any previous settings values in CMOS. The previous selection remain in effect. This will exit the Setup Utility and restart your compuetr when selecting this option. Press <Enter> on this item to ask for confirmation message.

#### **□** Load Default Settings

Press <Enter> on this item to load the default values for all the setup options. Enable this function you will get a confirmation dialog box with a message as below:

Press [Enter] to continue Or press [ESC] to Abort

Press [Enter] to load the default settings that are factory settings for default performance system operations.

### **□ Load Original Values**


Press <Enter> on this item to discard changes without exiting setup. Enable this function you will get a confirmation dialog box with a message as below:

Press [Enter] to continue Or press [ESC] to Abort

Press [Enter] to load the original values that are factory settings for factory original value system operations.

# Chapter 4 Technical Reference

# **Block Diagram**



# Chapter 5 Appendix

# Appendix A: Intel Network Driver Installation

(Note: Driver CD Ver.: 1.1)


Insert the driver CD-title that came with your motherboard into your CD-ROM driver, the driver CD-title will auto start and show a series of Setup Wizard dialog boxes. If not, please double click the CD-ROM device icon in "My computer", and execute the setup.exe.







(1)









**Step 5.** Note that user can select either **Typical** or **Custom** Setup Types. **Typical** setup type allows users to install basic connectivity and the adapter management utility. **Custom** setup type embraces installing features and subfeatures user selects, including modern utilities, manage ment components and drivers. Recommended for advanced users.





## Appendix B: ATI Rage XL VGA Driver Installation


Insert the driver CD-title that came with your motherboard into your CD-ROM driver, the driver CD-title will auto start and show the installation guide. If not, please double click the CD-ROM device icon in "My computer", and execute the setup.exe.





(2)





(4)

## Appendix C: Utilities Installation

Insert the driver CD-title that came with your motherboard into your CD-ROM driver, the driver CD-title will auto start and show the installation guide. If not, please double click the CD-ROM device icon in "My computer", and execute the setup.exe.

The Utilities item contains the utility of DirectX 8.1, Adabe Acrobate Reader V.5.0, and Norton Internet Security 2002





(2)

## Appendix D: About Updating latest version of BIOS

To update the latest BIOS version, please go to Gigabyte Networking official web site: **Http://networking.gigabyte.com.tw** 

• •	E: Acronyms	
Acronyms	Meaning	
ACPI	Advanced Configuration and Power Interface	
APM	Advanced Power Management	
AGP	Accelerated Graphics Port	
AMR	Audio Modem Riser	
ACR	Advanced Communications Riser	
BBS	BIOS Boot Specification	
BIOS	Basic Input / Output System	
CPU	Central Processing Unit	
CMOS	Complementary Metal Oxide Semiconductor	
CRIMM	Continuity RIMM	
CNR	Communication and Networking Riser	
DMA	Direct Memory Access	
DMI	Desktop Management Interface	
DIMM	Dual Inline Memory Module	
DRM	Dual Retention Mechanism	
DRAM	Dynamic Random Access Memory	
DDR	Double Data Rate	
ECP	Extended Capabilities Port	
ESCD	Extended System Configuration Data	
ECC	Error Checking and Correcting	
EMC	Electromagnetic Compatibility	
EPP	Enhanced Parallel Port	
ESD	Electrostatic Discharge	
FDD	Floppy Disk Device	
FSB	Front Side Bus	
HDD	Hard Disk Device	
IDE	Integrated Dual Channel Enhanced	
IRQ	Interrupt Request	
I/O	Input / Output	
IOAPIC	Input Output Advanced Programmable Input Controller	
ISA	Industry Standard Architecture	

## GA-8EGXDR-EL Motherboard

Acronyms	Meaning
LAN	Local Area Network
LBA	Logical Block Addressing
LED	Light Emitting Diode
MHz	Megahertz
MIDI	Musical Instrument Digital Interface
MTH	Memory Translator Hub
MPT	Memory Protocol Translator
NIC	Network Interface Card
OS	Operating System
OEM	Original Equipment Manufacturer
PAC	PCI A.G.P. Controller
POST	Power-On Self Test
PCI	Peripheral Component Interconnect
RIMM	Rambus in-line Memory Module
SCI	Special Circumstance Instructions
SECC	Single Edge Contact Cartridge
SRAM	Static Random Access Memory
SMP	Symmetric Multi-Processing
SMI	System Management Interrupt
USB	Universal Serial Bus
VID	Voltage ID
ZCR	Zero Channel RAID

BIOS version:  O.S./A.S.:  Hardware Mfs. Model name Size: Driver/Utility:  Configuration  CPU  Memory  Brand  Video Card  HDD  CD-ROM /  DVD-ROM  Modem  Network  AMR / CNR  Keyboard  Mouse  Power supply	Customer/Cour	ntry:	Company:		Phone No.:	
BIOS version:  O.S./A.S.:  Hardware Mfs. Model name Size: Driver/Utility:  Configuration  CPU  Memory  Brand  Video Card  Audio Card  HDD  CD-ROM /  DVD-ROM  Modem  Network  AMR / CNR  Keyboard  Mouse  Power supply	Contact Person	:	E-mail Add. :		<b>'</b>	
BIOS version:  O.S./A.S.:  Hardware Mfs. Model name Size: Driver/Utility:  Configuration  CPU  Memory  Brand  Video Card  Audio Card  HDD  CD-ROM /  DVD-ROM  Modem  Network  AMR / CNR  Key board  Mouse  Power supply						
Hardware Mfs. Model name Size: Driver/Utility:  Configuration CPU  Memory Brand Video Card Audio Card HDD CD-ROM / DVD-ROM Modem Network AMR / CNR Key board Mouse Power supply	Model name/Lo	t Number:			PCB revision:	
Configuration         CPU           Memory         Brand           Video Card         Audio Card           HDD         CD-ROM /           DVD-ROM         Modem           Network         AMR / CNR           Key board         Mouse	BIOS version:		O.S./A.S.:			
Configuration         CPU           Memory         Memory           Brand         Wideo Card           Audio Card         Memory           HDD         CD-ROM /           DVD-ROM         Modem           Network         AMR / CNR           Keyboard         Mouse           Power supply         Power supply						
CPU           Memory           Brand           Video Card           Audio Card           HDD           CD-ROM /           DVD-ROM           Modem           Network           AMR / CNR           Key board           Mouse           Power supply	I	Mfs.	Model name	Size:	Driver/Utility:	
Memory         Brand           Video Card         Image: Control of the co						
Brand         Video Card           Audio Card         ————————————————————————————————————						
Video Card	- 1					
Audio Card						
HDD						
C D-ROM / DVD-ROM						
DVD-ROM						
Modem	CD-ROM /					
Network	DVD-ROM					
AMR / CNR  Key board  Mouse  Power supply	Modem					
Key board  Mouse  Power supply	Network					
Mouse Power supply	AMR/CNR					
Power supply	Keyboard					
11.5	Mouse					
Other Device	Power supply					
	Other Device					
	_					_