GA-8EGXRP Series Processor Motherboard

# **USER'S MANUAL**

Pentium<sup>®</sup> Xeon<sup>™</sup> Processor Motherboard Rev. 1003 12ME-8EGXRP-1003

# Table of Content

| Revision History   | 4  |
|--|----|
| Item Checklist   | 4  |
| GA-8EGXRP Series Model List                                    | 4  |
| WARNING!   | 5  |
| Chapter 1 Introduction   | 6  |
| Features Summary   | 6  |
| GA-8EGXRP Series Motherboard Layout                            | 8  |
| Chapter 2 Hardware Installation Process                        |    |
| Step 1: Install the Central Processing Unit (CPU)              |    |
| Step 1-1: CPU Installation                                     |    |
| Step 1-2: CPU Heat Sink Installation                           |    |
| Step 2: Install memory modules                                 | 13 |
| Step 3: Install expansion cards                                | 14 |
| Step 4: Connect ribbon cables, cabinet wires, and power supply | 15 |
| Step 4-1: I/O Back Panel Introduction                          | 15 |
| Step 4-2: Connectors Introduction                              | 17 |
| Step 4-3: Jumper Setting Introduction                          | 23 |
| Chapter 3 BIOS Setup   | 27 |
| Advanced   | 32 |
| Advanced Configuration   | 33 |
| Chipset Configuration  | 35 |
| Power Management Configuration                                 |    |
| Plug and Play Configuration                                    |    |
| Peripheral Configuration                                       |    |
| Hardware Monitor Configuration                                 | 43 |
| Security   | 46 |
| Boot   | 48 |
| Exit   | 50 |

### Table of Content

| Chapter 4 Technical Reference | . 52 |
|-------------------------------|------|
| Block Diagram                 | 52   |
| Chapter 5 Appendix            | . 53 |

| Revisio  | on History   |           |
|----------|--|-----------|
| Revision | Revision Note  | Date      |
| 1.0      | Initial release of the GA-8EGXRP(C) motherboard user's manual. | OCT. 2002 |

# Item Checklist

- ☑ The GA-8EGXRP(C) motherboard
- ☑ IDE cable x 2/ Floppy cable x 1
- ${\ensuremath{\boxtimes}}$  Driver CD for motherboard driver & utility
- ☑ GA-8EGXRP Series user's manual
- ☑ I/O Back Panel
- SCSI Cable x 1 (Optional)

# GA-8EGXRP Series Model List

- ✓ GA-8EGXRP (Supports 400MHz / with SCSI function)
- ✓ GA-8EGXRP-C (Suppots 400MHz / without SCSI function)
- ✓ GA-8EGXRP-E (Supports 533MHz / with SCSI function)
- ✓ GA-8EGXRP-EC (Supports 533MHz / without SCSI function)

WARNING!



Computer motherboards and expansion cards contain very delicate Integrated Circuit (IC) chips. To protect them against damage from static electricity, you should follow some precautions whenever you work on your computer.

- 1. Unplug your computer when working on the inside.
- Use a grounded wrist strap before handling computer components. If you do not have one, touch both of your hands to a safely grounded object or to a metal object, such as the power supply case.
- Hold components by the edges and try not touch the IC chips, leads or connectors, or other components.
- 4. Place components on a grounded antistatic pad or on the bag that came with the components whenever the components are separated from the system.
- 5. Ensure that the ATX power supply is switched off before you plug in or remove the ATX power connector on the motherboard.


### Installing the motherboard to the chassis...

If themotherboard has mounting holes, but they don't line up with the hdes on the base and there are no slots to attach the spacers, do not become alarmed you can still attach the spacers to the mounting holes. Just cut the bottom portion of the spacers (the spacer may be a little hard to cut off, so be careful of your hands). In this way you can still attach the motherboard to the base without worrying about short circuits. Sometimes you may need to use the plastic springs to isolate the screw from the motherboard PCB surface, because the circuit wire may be near by the hole. Be careful, don't let the screw contact any printed circuit write or parts on the PCB that are near the fixing hole, otherwise it may damage the board or cause board malfunctioning.

| Form Factor          | • 30.48cm x 24.38cm ATX size form factor, 6 layers PCB.  |
|----------------------|--|
| СРИ                  | <ul> <li>Socket 603/604 for Intel<sup>®</sup> Micro FC-PGA2 Intel<sup>®</sup> Xeon<sup>™</sup> processo</li> </ul> |
|                      | <ul> <li>Intel Pentium<sup>®</sup> Xeon<sup>™</sup> 400/533MHz FSB</li> </ul>                                      |
|                      | • 512KB cache depend on CPU  |
|                      | GA-8EGXRP supports 400MHz  |
|                      | GA-8EGXRP-C suppots 400MHz   |
|                      | GA-8EGXRP-E supports 533MHz  |
|                      | GA-8EGXRP-EC supports 533MHz   |
| Chipset              | Serverworks CMIC-SL Northbridge  |
|                      | Serverworks CSB6 Southbridge   |
| Memory               | 4 184-pin DDR DIMM sockets   |
|                      | <ul> <li>Supports Up to 4 Register DIMM DDR200/266</li> </ul>  |
|                      | Supports up to 4 GB (Max)  |
|                      | Supports only 2.5V DDR DIMM  |
| I/O Control          | • NS PC87417   |
| Slots                | <ul> <li>Support PCI 64/33 MHz x 4 Slot</li> </ul>   |
|                      | PCI 32/33 MHz x 2 Slot   |
| On-Board IDE         | • 2 IDE bus master (ATA100) IDE ports for up to 4 ATAPI devices  |
| On-Board Peripherals | • 1 Floppy port supports 360K, 720K, 1.2M, 1.44M   |
|                      | and 2.88M bytes.   |
|                      | <ul> <li>1 Parallel port supports Normal/EPP/ECP mode</li> </ul>   |
|                      | <ul> <li>2 COM ports (COM1 &amp; COM2; one at front and one at rear)</li> </ul>                                    |
|                      | 4 USB ports (Two ar front and two at rear)   |
| Hardware Monitor     | CPU/System Fan Revolution detect   |
|                      | CPU/System Fan Fail Warning  |
|                      | CPU/System Overheat Warning  |
|                      | System Voltage Detect  |
|                      | Caseopen intrusion   |

|                     |   | Introduction  |
|---------------------|---|---|
| On-Board LAN        | • | Build in Intel® 82540EM 10/100/1000 Gigabit Ethernet            |
|                     |   | Chipset (Server Adaptec)  |
|                     | ٠ | Build-in Intel 82550PM 10/100 Fast Ethernet                     |
| On-Board VGA        | ٠ | Build in ATI Rage XL VGA PCI Chipset with 8M SDRAM on board     |
| On-Board SCSI       | ٠ | Adaptec 7899W SCSI Chipset ; Dual Channel Ultra 160             |
|                     | ٠ | For GA-8EGXRP & GA-8EGXRP-E Only                                |
| PS/2 Connector      | ٠ | PS/2 Keyboard interface and PS/2 Mouse interace                 |
| BIOS                | ٠ | Licensed AMI BIOS, 4M bit Flash ROM                             |
| Additional Features | ٠ | Wake on LAN (On board LAN 1 & LAN 2)                            |
|                     | ٠ | Wake on Moderm  |
|                     | ٠ | Support Intel ZCR and Adaptec ZCR card (Insert to the green PCI |
|                     |   | slot; For GA-8EGXRP & GA-8EGXRP-E Only)                         |

Please set the CPU host frequency in accordance with your processor's specifications. We don't recommend you to set the system bus frequency over the CPU's specification because these specific bus frequencies are not the standard specifications for CPU, chipset and most of the peripherals. Whether your system can run under these specific bus frequencies properly will depend on your hardware configurations, including CPU, Chipsets,SDRAM,Cards... .etc.



# GA-8EGXRP Series Motherboard Layout


 Note: the \* indicates the feature is available for GA-8EGXRP and GA-8EGXRP-E models only

Hardware Installation Process

# Chapter 2 Hardware Installation Process

To set up your computer, you must complete the following setups:

- Step 1- Install the CPU
- Step 2- Install memory modules
- Step 3- Install expansion cards
- Step 4- Connect ribbon cables, cabinet wires, and power supply
- Step 5- Setup BIOS software






# Step 1: Install the Central Processing Unit (CPU)

# Step 1-1: CPU Installation



CPU Top View



CPU Bottom View

1. Pull the lever out, than lift up the Lever.



- Locate Pin 1 in the socket and look for a (golden) cut edge on the CPU upper corner. Then insert the CPU into the socket.
- 3. Press down the CPU socket lever and finish CPU installation.
- Please make sure the CPU type is supported by the motherboard.
- If you do not match the CPU socket Pin 1 and CPU cut edge well, it will cause improper installation. Please change the insert orientation.



Hardware Installation Process

# Step 1-2: CPU Heat Sink Installation




1. Use qualified fan approved by Intel.




2. Heat Sink




3. First step of assembling.




4. Completive picture for first step.



5. Second step of assembling.



6. Completive picture for second step.



7. Fan assembly.



8. Hook one end of the cooler bracket to the CPU socket first.

- ♦<sup>™</sup> You should apply the thermal paste to provide better heat conduction between your CPU and heatsink.
- ●<sup>™</sup> Make sure the CPU fan power cable is plugged in to the CPU fan connector, this completes the installation.
- ◆<sup>™</sup> Please refer to CPU heat sink user's manual for more detail installation procedure.

12

Hardware Installation Process

# Step 2: Install memory modules

The motherboard has 4 dual inline memory module (DIMM) sockets. The BIOS will automatically detects memory type and size. To install the memory module, just push it vertically into the DIMM Slot.

The DIMM module can only fit in one direction due to the notch. Memory size can vary between sockets.




Registered DDR



- 1. The DIMM slot has a notch, so the DIMM memory module can only fit in one direction.
- Insert the DIMM memory module vertically into the DIMM slot. Then push it down.
- C lose the plastic clip at both edges of theDIMM slots to lock the DIMM module.
   Reverse the installation steps when you wish to remove the DIMM module.
- Please note that the DIMM module can only fit in one direction due to the one notches. Wrong orientation will cause improper installation. Please change the insert orientation.

# Step 3: Install expansion cards


- 1. Read the related expansion card's instruction document before install the expansion card into the computer.
- 2. Remove your computer's chassis cover, screws and slot bracket from the computer.
- 3. Press the expansion card firmly into expansion slot in motherboard.
- 4. Be sure the metal contacts on the card are indeed seated in the slot.
- 5. Replace the screw to secure the slot bracket of the expansion card.
- 6. Replace your computer's chassis cover.
- 7. Power on the computer, if necessary, setup BIOS utility of expansion card from BIOS.
- 8. Install related driver from the operating system.



Hardware Installation Process

# Step 4: Connect ribbon cables, cabinet wires, and power supply

### Step 4-1: I/O Back Panel Introduction



### PS/2 Keyboard and PS/2 Mouse Connector




PS/2 Mouse Connector (6 pin Female) PS/2 Keyboard Connector

(6 pin Female)

This connector supports standard PS/2 keyboard and PS/2 mouse.


USB Connector



Before you connect your device(s) into USB connector(s), please make sure your device(s) such as USB keyboard, mouse, scanner, zip, speaker..etc. Have a standard USB interface. Also make sure your OS (Windows 2000, Win dows ME, Win NT with SP 6) supports USB controller. If your OS does not support USB controller, please contact the OS vendor for pos sible patch or driver upgrade. For more information please contact your OS or device(s) vendors.




### Parallel Port / Serial Port / VGA Port (LPT/COMA/VGA)



This connector supports 1 standard COM port ,1 Parallel port and 1 VGA port. Device like printercan be connected to Parallel port; mouse and modem etc can be connected to Serial ports.

### ❺/④ LAN1 / LAN2 Port (Optional)




LAN 2: Giagbit Ethernet 10/100/100
 LAN 1: 10/100 Ethernet

### LAN1 / LAN2 LED Indicator Description

| LAN Port | Status           | Description              |  |  |
|----------|------------------|--------------------------|--|--|
| LAN 1    | Yellow LED Blink | LAN1 active              |  |  |
|          | Yellow LED On    | LAN1 connected           |  |  |
|          | Green LED On     | LAN1 at Speed 100MB      |  |  |
|          | Green LED Off    | LAN1 at speed 10MB       |  |  |
| LAN 2    | Yellow LED Blink | LAN2 active              |  |  |
|          | Yellow LED On    | LAN2 connected           |  |  |
|          | Green LED On     | LAN2 at speed 100/1000MB |  |  |
|          | Green LED Off    | LAN2 at speed 10MB       |  |  |






Step 4-2: Connectors Introduction


6 Note: the \* indicates the feature is available for GA-8EGXRP and GA-8EGXRP-E models only

### A) ATX1 (2x10 Pin ATX Power)



AC power cord should only be connected by our power supply unit after ATX power cable and other related devices are firmly connected to the mainboard.

### B) ATX2 (+12V Power Connector)



➤ This connector (ATX +12V) is used only for CPU Core Voltage.

### P) CPU FAN 1 Connector




Please note, a proper installation of the CPU cooler is essential to prevent the CPU from running under abnormal condition or damaged by overheating. The CPU fan connector supports Max. current up to 600mA.


Hardware Installation Process







### H) COM 2 Connector



Q) Wake On LAN Connector



### N / O) \*SCSI1/\*SCSI2 Connector


| ( ••••••• ) |
|-------------|
|             |
|             |
|             |

R) Wake On Ring Connector




 Note: the \* indicates the feature is available for GA-8EGXRP and GA-8EGXRP-E models only

### C / D) IDE 1/ IDE 2/ [IDE1 / IDE2 / Connectors(Primary/Secondary)]




### E) FDD1 (Floppy Connector)






### G) USB2



Be careful with the polarity of the front panel USB connector. Check the pin assignment while you connect the front panel USB cable. Please contact your nearest dealer for optional front panel USB cable.


Hardware Installation Process

### S) CASE OPEN



### T) BT1 (Battery)






➢ Please note that uder normal circumstance, the CASEOPEN connector is set at closed status. When it is at open status (for example, the chassis cover is opened) system will alarm warning beeping. Werecommend user to use the Normal-Close switch.

### CAUTION

- Danger of explosion if battery is incorrectly replaced.
- Replace only with the same or equivalent type recommended by the manufacturer.
- Dispose of used batteries according to the manufacturer's instructions.

GA-8EGXRP Series Motherboard


### F) F\_PANEL1 (2x12 Pins connector)



| 1) PD+ (Power LED)     | 2) FF (No Connect)         |
|------------------------|----------------------------|
| 3) KEY                 | 4) SK+ (Speaker)           |
| 5) PD- (Power LED)     | 6) NC (No Connect)         |
| 7) HD+ (HDD LED)       | 8) NC (No Connect)         |
| 9) HD- (HDD LED)       | 10) SK- (Speaker)          |
| 11) PW+ (Power Button) | 12) LD1+ (LAN1 LED Active) |
| 13) PW- (Power Button) | 14) LD1- (LAN1 LED Active) |
| 15) RS+ (Reset Button) | 16) I <sup>2</sup> C_SDA   |
| 17) RS- (Reset Button) | 18) I <sup>2</sup> C_SCL   |
| 19)GN+ (Sleep Button)  | 20) COP (CASEOPEN)         |
| 21)GN- (Sleep Button)  | 22) LD2+ (LAN2 LED Active) |
| 23) SMI (No Connect)   | 24) LD2- (LAN2 LED Active) |

Please connect the power LED, PC speaker, reset switch and power switch etc of your chassis front panel to the F\_PANEL1 connector according to the pin assignment above.






# Step 4-3: Jumper Setting Introduction

| 1) CLK_JP1    | 6) TERM_EN1  |
|---------------|--------------|
| 2) LAN1_EN1   | 7) VGA_EN1   |
| 3) LAN2_EN1   | 8) WRITE_P1  |
| 4) SCSI_EN1 * | 9) CMOS_CLR1 |
| 5) TERM_EN2   |              |


Please note that the highlight white mark on the motherboard is presented as
 Pin 1

 Note: the \* indicates the feature is available for GA-8EGXRP and GA-8EGXRP-E models only







1-2 close: Auto (Default)




1 000 None: CPU Speed at 400MHz


2) LAN1\_EN1 (LAN Function)









Jumper Setting




5) TERM\_EN2 (SCSI On-Board Terminator Function)







6) TERM\_EN1 (SCSI On-Board Terminator Function)




GA-8EGXRP Series Motherboard


### 7) VGA\_EN1 (VGA Function)






8) WRITE\_P1 (Write Protect Function)





(Default)

9) CMOS\_CLR1 (Clear CMOS Function)





1 1-2 close: Clear CMOS OOC 1 2-3 close: Normal (Default)

▶ Please note, You may clear the CMOS data to its default values by this jumper

# Chapter 3 BIOS Setup

BIOS Setup is an overview of the BIOS Setup Program. The program that allows users to modify the basic system configuration. This type of information is stored in battery-backed CMOS RAM so that it retains the Setup information when the power is turned off.

### **ENTERING SETUP**

Power ON the computer and press <DEL> immediately will allow you to enter Setup.

### CONTROL KEYS

| < <b>^</b> >    | Move to previous item  |  |  |  |  |
|-----------------|--|--|--|--|--|
| < <b>\</b> >    | Move to next item  |  |  |  |  |
| < <b>←</b> >    | Move to the item in the left hand  |  |  |  |  |
| < <b>&gt;</b> > | Move to the item in the right hand   |  |  |  |  |
| <esc></esc>     | Main Menu - Quit and not save changes into CMOS Status Page Setup Menu and |  |  |  |  |
|                 | Option Page Setup Menu - Exit current page and return to Main Menu         |  |  |  |  |
| <+/PgUp>        | Increase the numeric value or make changes                                 |  |  |  |  |
| <-/PgDn>        | Decrease the numeric value or make changes                                 |  |  |  |  |
| <f1></f1>       | General help, only for Status Page Setup Menu and Option Page Setup Menu   |  |  |  |  |
| <f2></f2>       | Reserved   |  |  |  |  |
| <f3></f3>       | Reserved   |  |  |  |  |
| <f4></f4>       | Reserved   |  |  |  |  |
| <f5></f5>       | Restore the previous CMOS value from CMOS, only for Option Page Setup Menu |  |  |  |  |
| <f6></f6>       | Reserved   |  |  |  |  |
| <f7></f7>       | Load the Optimized Defaults  |  |  |  |  |
| <f8></f8>       | Reserved   |  |  |  |  |
| <f9></f9>       | Reserved   |  |  |  |  |
| <f10></f10>     | Save all the CMOS changes, only for Main Menu                              |  |  |  |  |

#### **BIOS Setup**

### GEITING HELP

### Main Menu

The on-line description of the highlighted setup function is displayed at the bottom of the screen. Status Page Setup Menu / Option Page Setup Menu

Press F1 to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window press <Esc>.

• Main

This setup page includes all the items in standard compatible BIOS.

### • Advanced

This setup page includes all the items of AMI special enhanced features.

(ex: Auto detect fan and temperature status, automatically configure hard disk parameters.)

### • Security

Change, set, or disable password. It allows you to limit access the system and setup.

### • Boot

This setup page include all the items of first boot function features.

### • Exit

There are five options this selection: Exit Saving Changes, Exit Discarding Changes, Load Optimal Defaults, Load Failsafe Defaults, and Discard Changes.

# Main (For example: BIOS Ver. : F1)

Once you enter AMI BIOS CMOS Setup Utility, the Main Menu (Figure 1) will appear on the screen. Use arrow keys to select among the items and press <Enter> to accept or enter the sub-menu.

|                          |                  | AMI EAS    | Y Setup Utilit | y       |                        |
|--------------------------|------------------|------------|----------------|---------|------------------------|
| Main                     | Adv anced        | Security   | Boot           | Ex it   |                        |
| System                   | Date:            | Aug 14 2   | 002            |         | [Setup Help]           |
| System                   | Time:            | 00:13:12   |                |         |                        |
| Floppy [                 | Drive A:         | 1.44MB 3   | 31/2           |         |                        |
| Floppy [                 | Drive B:         | Not Instal | lled           |         |                        |
| ▶ Prima                  | ry IDE Master    | ST38002    | 1A             |         |                        |
| ► Prima                  | ary IDE Slave    |            |                |         |                        |
| <ul> <li>Seco</li> </ul> | ndary IDE Master |            |                |         |                        |
| <ul> <li>Seco</li> </ul> | ndary IDE Slave  |            |                |         |                        |
| ► Syste                  | em Information   |            |                |         |                        |
|                          |                  |            |                |         |                        |
|                          |                  |            |                |         |                        |
|                          |                  |            |                |         |                        |
|                          |                  |            |                |         |                        |
| F1: Help                 | ↑↓: Sele         |            | + -: Chang     |         |                        |
| Esc: Exit                | ←→: Se           | lect Menu  | Enter: Sele    | ct 🕨 Si | ub-Menu F10: Save&Exit |

Figure 1: Main

### 🗢 System Date

Set the System Date. Note that the "Day" automatically changed after you set the date. (Weekend: DD: MM: YY) (YY: 1099~2099)

### 🗢 System Time

The time is calculated based on the 24-hour military time clock. Set the System Time (HH:MM:SS)

**BIOS Setup** 

### ∽ Floppy Drive A/B

This category identifies the type of floppy disk drive A or drive B that have been installed in the computer.

| ► None          | No floppy drive installed                               |
|-----------------|---|
| ▶1.2MB, 3.5 in. | 3.5 inch AT-type high-density drive; 1.2M byte capacity |
| ▶720K, 3.5 in.  | 3.5 inch double-sided drive; 720K byte capacity         |
| ▶1.44M, 3.5 in. | 3.5 inch double-sided drive; 1.44M byte capacity.       |
| ▶2.88M, 3.5 in. | 3.5 inch double-sided drive; 2.88M byte capacity.       |

### ∽ IDE Primary Master, Slave / Secondary Master, Slave

The category identifies the types of hard disk from driveC to F that has been installed in the computer. There are two types: auto type, and manual type. Manual type is user-definable; Auto type which will automatically detect HDD type.

Note that the specifications of your drive must match with the drive table. The hard disk will not work properly if you enter improper information for this category.

If you select User Type, related information will be asked to enter to the following items. Enter the information directly from the keyboard and press <Enter>. Such information should be provided in the documentation form your hard disk vendor or the system manufacturer.

### ► TYPE

1-50: Predefined types.

Users: Set parameters by User.

Auto: Set parameters automatically. (Default Vaules)

CD-ROM: Use for ATAPI CD-ROM drives or double click [Auto] to set all HDD parameters automatically.

| ► Cy linders            | Number of cylinders  |  |  |
|-------------------------|--|--|--|
| ➡ Write Precompensation | Write precompensation  |  |  |
| ➡ Sectors               | Number of sectors  |  |  |
| ►Maximum Capacity       | Maximum Capacity   |  |  |
| ►LBA Mode               | This field shows if the device type in the specific IDE channel support LBA Mode |  |  |
| ➡Block Mode             | This field only shows the information of Block Mode.                             |  |  |

GA-8EGXRP Series Motherboard

|                        | This field only shows the information of Fast Programmed I/O Mode.  |
|------------------------|---|
| → 32 Bit Transfer Mode | Enables 32 bit access to maximize the hard disk data transfer rate. |
|                        | Option: On (Default Value); Off                                     |

If a hard disk has not been installed select NONE and press <Enter>.

## ∽ System Information

This category displays the system information on CPU and Memory.

BIOS Setup

# Advanced

| AMI EASY Setup Utility   |                                 |             |             |        |                    |  |  |  |
|--|---------------------------------|-------------|-------------|--------|--------------------|--|--|--|
| Main   | Adv anced                       | Security    | Boot        | Exit   |                    |  |  |  |
|  |                                 |             |             |        | [Setup Help]       |  |  |  |
| Adv an   | ► Advanced Configuration        |             |             |        |                    |  |  |  |
| ► Chipse   | ► Chipset Configuration         |             |             |        |                    |  |  |  |
| Power  | Management Co                   | nfiguration |             |        |                    |  |  |  |
| ▶ Plug &   | ► Plug & Play Configuration     |             |             |        |                    |  |  |  |
| ▶Periphe   | ▶ Peripheral Configuration      |             |             |        |                    |  |  |  |
| ► Hardw a  | ►Hardware Monitor Configuration |             |             |        |                    |  |  |  |
|  |                                 |             |             |        |                    |  |  |  |
|  |                                 |             |             |        |                    |  |  |  |
|  |                                 |             |             |        |                    |  |  |  |
|  |                                 |             |             |        |                    |  |  |  |
| F1: Help   | <b>↑↓</b> : Sel                 | ect Item    | + -: Change | Values | F5: Setup Defaults |  |  |  |
| Esc: Exit $\leftarrow \rightarrow$ : Select Menu Enter: Select $\blacktriangleright$ Sub-Menu F10: Save&Exit |                                 |             |             |        |                    |  |  |  |

Figure 2: Advanced

### About This Section: Advanced

This section "Advanced" is divided into six sub-menus.

- Advanced Configuration
- Chipset Configuration
- Power Management Configuration
- Plug & Play Configuration
- ✓ Peripheral Configuration

With this section, allowing user to configure your system for basic operation. A user can change the system's default boot-up sequence, keyboard operation, shadowing and security, etc.

## **Advanced Configuration**

| AMI EASY Setup Utility                   |                                       |                       |                           |      |  |  |
|--|---------------------------------------|-----------------------|---------------------------|------|--|--|
| Main                                     | Adv anced                             | Security              | Boot                      | Exit |  |  |
|  | Advanced Configu                      | uration               |                           |      | [Setup Help]                               |  |
|  | Full Screen Logo<br>R.T for Hard Disk |                       | Enabled<br>Disabled       |      |  |  |
|  | ersion for O.S                        |                       | 1.4                       |      |  |  |
| BootUp Num-Lock<br>Intel Hyper Threading |                                       | On<br>Enabled         |                           |      |  |  |
|  |                                       |                       |                           |      |  |  |
| F1: Help<br>Esc: Exi                     | t ←→: Sele                            | ect Item<br>Iect Menu | + -: Chang<br>Enter: Sele |      | F5: Setup Defaults<br>-Menu F10: Save&Exit |  |

Figure 2-1: Advanced Configuration

#### **BIOS Setup**

### Advanced Configuration

This category allow user to configure advanced functions .

### Show Full Screen Logo

- ➡ Enabled Enable Show Full Screen Logo function. (Default Value)
- ➡ Disabled Disable this function.

### S.M.A.R.T for Hard Disk

This filed shows if the device in the specific IDE channel supports S.M.A.R.T.

S.M.A.R.T stands for Self-Monitoring Analysis and Reporting Technology.

- ► Enabled Set this option "Enable" to permit BIOS to use S.M.A.R.T.
- ➡ Disabled Disable S.M.A.R.T function.(Default Value)

### MPS Version for O.S

This option allows a user to select MP (Multi Processors) system supported version. **Note:** Some old MPS OS support 1.1 version only.

▶ 1.4 Support MPS Version 1.4. (Default Value)

▶1.1 Support MPS Version 1.1.

### BootUp Num-Lock

► OFF Disable this function.

### ▶ Intel Hyer Threading

- ➡ Enabled Enable Inel Hyper Threading.(Default Value)
- ➡ Disabled Disable Inel Hyper Threading.

## **Chipset Configuration**

| AMI EASY Setup Utility |                 |            |   |       |              |  |
|------------------------|-----------------|------------|---|-------|--------------|--|
| Main                   | Adv anced       | Security   | Boot                                    | Ex it |              |  |
|                        |                 |            |   |       |              |  |
| Chipset Configuration  |                 |            |   |       | [Setup Help] |  |
| Memroy Scrubbing E     |                 |            | Enabled                                 |       |              |  |
| F1: Help               | <b>↑↓</b> : Sel | ect Item   | + -: Change Values F5: Setup Defaults   |       |              |  |
| Esc: Exi               | t ←→: S         | elect Menu | Enter: Select ► Sub-Menu F10: Save&Exit |       |              |  |
|                        |                 |            |   |       |              |  |

Figure 2-2: Chipset Configuration

## ◦ Chipset Configuration

## Memory Scrubbing

- ► Enabled Enable this option to write back the ECC corrected memory data to the DRAM. (Default Value)
- ► Disabled Disable this function.

BIOS Setup

| Power Management Configuration   |                 |                  |             |          |                    |  |  |
|--|-----------------|------------------|-------------|----------|--------------------|--|--|
| AMI EASY Setup Utility   |                 |                  |             |          |                    |  |  |
| Main   | Adv anced       | Security         | Boot        | Exit     |                    |  |  |
|  | Power Managem   | ent Configuratio | on          |          | [Setup Help]       |  |  |
| Soft-off b   | y Power Button  |                  | Instant-off |          |                    |  |  |
| Sleep Button Enabled   |                 |                  |             |          |                    |  |  |
| Wake Up On Ring 1.4  |                 |                  |             |          |                    |  |  |
| System After AC Back Off   |                 |                  |             |          |                    |  |  |
|  |                 |                  |             |          |                    |  |  |
|  |                 |                  |             |          |                    |  |  |
|  |                 |                  |             |          |                    |  |  |
| F1: Help   | <b>↑↓</b> : Sel | ect Item         | + -: Chang  | e Values | F5: Setup Defaults |  |  |
| Esc: Exit $\leftarrow \rightarrow$ : Select Menu Enter: Select $\blacktriangleright$ Sub-Menu F10: Save&Exit |                 |                  |             |          |                    |  |  |

Power Management Configuration

Figure 2-3: Power Management Configuration

### ∽ Power Management Configuration

The Power Management Configuration allows you to reduce system power consumption through different saving power methods for various devices.

### Soft-Off by Power Button

- ▶Instant-off Turn off system as soon as power button is pressed.
- ➤ Delay 4 Sec Turn off system when power button is pressed and hold for more than 4 seconds.

### Sleep Button

Leaves on the default for best compatibility

- ► Enabled Enable Sleep Button. (Default Value)
- ► Disabled Disable this function.



#### Wake Up Ring

System is waken up when Moderm-Ring is on.

- ► Enabled Enable Wake Up Ring. (Default Value)
- ➡ Disabled Disable this function.

# System After AC Back

System power state when AC cord is re-plugged.

- ▶ Pre-State Set system power to the last state when AC power is removed.
- ►OFF Do not power on system when AC power is back. (Default Value)

| -                     |                     | AMI EA                 | SY Setup Utility            | 1    |  |
|-----------------------|---------------------|------------------------|-----------------------------|------|--|
| Main                  | Adv anced           | Security               | Boot                        | Exit |  |
|                       | Plug and Play Co    | onfiguration           |                             |      | [Setup Help]                             |
| PCI Slo               | ot 1/5 IRQ Priority |                        | Auto                        |      |  |
| PCI Slo               | ot 2/6 IRQ Priority |                        | Auto                        |      |  |
| PCI Slo               | ot 3 IRQ Priority   |                        | Auto                        |      |  |
| PCI Slo               | ot 4 IRQ Priority   |                        | Auto                        |      |  |
| IRQ 3                 |                     |                        | PCI/PnP                     |      |  |
| IRQ 4                 |                     |                        | PCI/PnP                     |      |  |
| IRQ 5                 |                     |                        | PCI/PnP                     |      |  |
| IRQ 7                 |                     |                        | PCI/PnP                     |      |  |
| IRQ 9                 |                     |                        | PCI/PnP                     |      |  |
| IRQ 10                |                     |                        | PCI/PnP                     |      |  |
| IRQ 11                |                     |                        | PCI/PnP                     |      |  |
| IRQ 14                |                     |                        | PCI/PnP                     |      |  |
|                       |                     |                        |                             |      |  |
| F1: Help<br>Esc: Exit | 1↓: Sel<br>←→: Se   | ect Item<br>elect Menu | + -: Change<br>Enter: Selee |      | F5: Setup Defaults<br>enu F10: Save&Exit |

# Plug and Play Configuration

Figure 2-4: Plug and Play Configuration

#### ∽ Plug & Play Configuration

This option describes the configuration of PCI bus system, or Personal Conputer Interconnect, is a system which allows I/O devices to operate at a speeds nearing the speed the CPU itself uses when communicating with its own special components. This section covers some technical items and it is stongly recommended that only experienced users should make any changes to the default settings.

#### PCI Slot 1/5 IRQ Priority

Select PCI Slot 1/5 IRQ Priority.

| ► Auto                  | Auto assign IRQ to PCI 1/5 (Default Value) |
|-------------------------|--|
| ▶ 3, 4, 5, 7, 9, 10, 11 | Set 3, 4, 5, 7, 9, 10, 11 to PCI 1/5       |

#### PCI Slot 2/6 IRQ Priority

Select PCI Slot 2/6 IRQ Priority. Auto assign IRQ to PCI 2/6 (Default Value) ► Auto ▶ 3, 4, 5, 7, 9, 10, 11 Set 3, 4, 5, 7, 9, 10, 11 to PCI 2/6

#### PCI Slot 3 IRQ Priority

Select PCI Slot 3 IRQ Priority. ► Auto Auto assign IRQ to PCI 3 (Default Value) ▶ 3, 4, 5, 7, 9, 10, 11 Set 3, 4, 5, 7, 9, 10, 11 to PCI 3

#### PCI Slot 4 IRQ Priority

Select PCI Slot 4 IRQ Priority.

► Auto Auto assign IRQ to PCI 4 (Default Value) ▶ 3, 4, 5, 7, 9, 10, 11 Set 3, 4, 5, 7, 9, 10, 11 to PCI 4

#### ▶ IRQ 3, 4, 5, 7, 9, 10, 11, 14, 15

This option allows a user to set if let BIOS detect the IRQ events. When the BIOS detects an IRQ trigger event being actived, the system will wake up and resumes its activities. Option: PCI/PnP (Default Value); ISA



| _ • - <b>-</b> P     | lierar Coning     |            | SY Setup Utility | '       |                        |
|----------------------|-------------------|------------|------------------|---------|------------------------|
| Main                 | Adv anced         | Security   | Boot             | Exi     | t                      |
|                      | Peripheral Config | uration    |                  |         | [Setup Help]           |
| OnBoa                | rd IDE            |            | Both             |         |                        |
| OnBoa                | rd FDC            |            | Enabled          |         |                        |
| OnBoa                | rd Serial Port A  |            | 3F8/COM1         |         |                        |
| OnBoa                | rd Serial Port B  |            | 2F8/COM2         |         |                        |
| OnBoa                | rd Parallel Port  |            | 378              |         |                        |
| Pa                   | rallel Port Mode  |            | ECP              |         |                        |
| Pa                   | rallel Port IRQ   |            | 7                |         |                        |
| Pa                   | rallel Port DMA   |            | 3                |         |                        |
| USB F                | unction           |            | Enabled          |         |                        |
| USB L                | egacy             |            | Disabled         |         |                        |
| Port 64/60 Emulation |                   |            | Disabled         |         |                        |
|                      |                   |            |                  |         |                        |
| F1: Help             | ↑↓: Sel           | ect Item   | + -: Change      | e Value | s F5: Setup Defaults   |
| Esc: Exi             | t ←→: Se          | elect Menu | Enter: Selec     | et ► Su | ib-Menu F10: Save&Exit |

**Peripheral Configuration** 

Figure 2-5: Peripheral Configuration

# ◦ Peripheral Configuration

#### OnBoard IDE

Option: Both (Default Value), Primary, Secondary, Disabled

#### • OnBoard FDC

- ► Enabled Select "Enabled" to active Onboard Floppy Controller. (Default Value)
- ► Disabled Disable this function.

#### OnBoard Serial Port A

This option specifies the base I/O port address of serial prot A.

| ▶ 3F8/COM1 | Enable onboard serial port A and set I/O address to 3F8/COM1. (Default value) |
|------------|---|
| ▶2F8/COM2  | Enable onboard serial port A and set I/O address to 2F8/COM2.                 |
| ₩3E8/COM3  | Enable onboard serial port A and set I/O address to 3E8/COM3.                 |
| ▶2E8/COM4  | Enable onboard serial port A and set I/O address to 2E8/COM4.                 |

#### • OnBoard Serial Port B

This option specifies the base I/O port address of serial prot B.

| ▶3F8/COM1 | Enable onboard serial port A and set I/O address to 3F8/COM1.          |
|-----------|--|
| ▶2F8/COM2 | Enable onboard serial port A and set I/O address to 2F8/COM2. (Default |
|           | value)   |
| ▶3E8/COM3 | Enable onboard serial port A and set I/O address to 3E8/COM3.          |
| ▶2E8/COM4 | Enable onboard serial port A and set I/O address to 2E8/COM4.          |

#### OnBoard Parallel Port

This option specifies the base I/O address of the parallel prot on the motherboard.

- ▶ 378 Enable onboard LPT port and set I/O address to 378. (Default value)
- ▶ 278 Enable onboard LPT port and set I/O address to 278
- ➡ 3BC Enable onboard LPT port and set I/O address to 3BC

#### ▶ Parallel Port Mode

This option specifies the parallel mode.

| Normal         | The normal parallel pro is used.   |
|----------------|--|
| Bi-Directional | Use this setting to support bi-directional transfers on the parallel port. |
| ₩EPP           | The parallel port can be used with devices that adhere to the              |
|                | enhanced Parallel Port ( EPP ) specifications. EPP uses the                |
|                | existing parallel port signal to provide asymmetric bi-directional         |
|                | data transfer driven by the host device.                                   |
|                |  |



► ECP The parallel port can be used with devices that adhere to the extended Capabilities Port specifications. ECP uses the DMA protocd to achieve data transfer rate up to 2.5Mbit/s. ECP provides the symmetric bi-directional communication. (Default value)

#### ▶ Parallel Port IRQ

This option is to select Parallel Port IRQ Option: 7 (Default Value) , 5

#### ▶ Parallel Port DMA

This option iallows user to select Parallel Port DMA. Option: 3 (Default Value), 1

#### USB Function

This option allows user to enable USB host controller.

- ► Enable Enable USB host controller. (Default Value)
- ► Disabled Disable this function.

#### USB Legacy Support

This option allows user to function support for legacy USB.

- ► Enable Enable support for legacy USB.
- ➡ Disabled Disable support for legacy USB. (Default value)

#### ▶ Port 64/60 Emulation

This option allows user to enable or disable the Port 64/60 Emulation function.

- ► Enable Enables the Port 64/60 Emulation function
- ➡ Disabled Disable this function. (Default Value)

# Hardware Monitor Configuration

|                        |                    | AMI EA      | SY Setup Utilit | У        |                       |
|------------------------|--------------------|-------------|-----------------|----------|-----------------------|
| Main                   | Adv anced          | Security    | Boot            | Exit     |                       |
| Ha                     | rdware Monitor Co  | nfiguration |                 |          | [Setup Help]          |
| CPU Te                 | emperature         |             | +39°C/+10       | 2°F      |                       |
| System                 | Temperature        |             | +39°C/+10       | 2°F      |                       |
| CPU_F                  | AN Speed           |             | RPM             |          |                       |
| SYS_F                  | AN1 Speed          |             | RPM             |          |                       |
| SYS_F                  | AN2 Speed          |             | RPM             |          |                       |
| SYS_F                  | AN3 Speed          |             | RPM             |          |                       |
| SYS_F                  | AN4 Speed          |             | RPM             |          |                       |
| VCC_P                  |                    |             | 1.952V          |          |                       |
| VCC 2.                 | 5                  |             | 0.000V          |          |                       |
| VCC 3                  |                    |             | 0.000V          |          |                       |
| VCC 5                  |                    |             | 0.000V          |          |                       |
| VCC 12                 | 2                  |             | 0.000V          |          |                       |
| VBAT                   |                    |             | 0.000V          |          |                       |
| 5VSB                   |                    |             | 0.000V          |          |                       |
| Hardw a                | re Monitor Alarm   |             | Disabled        |          |                       |
| SYS_T                  | EM. Buzzer Alarm   |             | Disabled        |          |                       |
| CPU_F                  | AN1 Buzzer Alarm   |             | Disabled        |          |                       |
| SYS_F                  | AN1 Buzzer Alarm   |             | Disabled        |          |                       |
| SYS_F                  | AN2 Buzzer Alarm   |             | Disabled        |          |                       |
| SYS_F                  | AN3 Buzzer Alarm   |             | Disabled        |          |                       |
| SYS_F                  | AN4 Buzzer Alarm   |             | Disabled        |          |                       |
| VCC_P                  | VCC_P Buzzer Alarm |             |                 |          |                       |
| Case Open Alarm        |                    |             | Disabled        |          |                       |
| Case Open Status       |                    |             | Close           |          |                       |
| Reset Case Open Status |                    |             | No              |          |                       |
| F1: Help               | ↑↓: Sel            | ect Item    | + -: Chang      | e Values | F5: Setup Defaults    |
| Esc: Exit              | ←→: S              | elect Menu  | Enter: Sele     | ct 🕨 Sub | o-Menu F10: Save&Exit |

Figure 2-6: Hardware Monitor Configuration 42

#### ∽ Hardware Monitor Configuration

This section provides the system hardware health information to user for reference.

#### ▶ CPU Temperature

This field only displlays the current CPU temperature.

#### System Temperature

This field only displlays the current system temperature.

#### CPU FAN Speed

This field indicates the RPM (Ratio Per Minute) of current CPU speed.

#### SYS FAN 1/2/3/4 Speed

This field indicates the RPM (Ratio Per Minute) of System Fan 1/2/3/4 speed.

#### VCC\_P / VCC 2.5 / VCC 3 / VCC5 / VBAT/12V/5VSB

This field only displays the current CPU / System voltage.

#### ▶ Hardwae Monitor Alarm

This field allows user to monitor and to ser the set the warning values to protect the system hardware health. Enable this function to active the following desired items.

#### SYS\_TEM. Buzzer Alarm

Enable this function is protecting the System temperature is under the set value. System will alarm when the system temperature is over the set value.

► Enabled Enable system temperature buzzer alarm.

➡ Disabled Disable this function.

#### CPU\_FAN1/2/3/4 / SYS\_FAN1/2/3/4 Buzzer Alarm

When this function is enabled, system will alarm when CPU FAN1/2/3/4 stop.

- ► Enabled Enable CPU FAN1/2/3/4 buzzer alarm.
- ➡ Disabled Disable this function.

#### VCC\_P Buzzer Alarm

Enable this function is protecting the system voltage is under the set value. System will alarm when the voltage is over the set value.

► Enabled Enable VCC\_P buzzer alarm.

➡ Disabled Disable this function.

#### ► Case Open Alarm

This optionallows user to set the case open alarm by physical warning alert. Once the chassis is opened, the system will rise warning beep to alarm user to close the case properly.

► Enabled Enable Case Open alarm.

➡ Disabled Disable this function.

#### Case Status

This item displays the status of system case.

#### Reset Case Open Status

This function provides user to stop the case open warning beep. Once the case is opened, the system will rise waring alert. To stop the beep, user is required to enter the setupmenu and rest the case open status to "Yes" option.

# Security

|            |                 | AMI EASY S | Setup Utility |        |                      |
|------------|-----------------|------------|---------------|--------|----------------------|
| Main       | Advanced        | Security   | Boot          | Exit   |                      |
|            |                 |            |               |        | [Setup Help]         |
| Set Superv | isor Password   | [Enter]    |               | ľ      |                      |
| Set User P | assword         | [Enter]    |               |        |                      |
| Password   | Check           | Setup      |               |        |                      |
|            |                 |            |               |        |                      |
|            |                 |            |               |        |                      |
|            |                 |            |               |        |                      |
|            |                 |            |               |        |                      |
|            |                 |            |               |        |                      |
|            |                 |            |               |        |                      |
|            |                 |            |               |        |                      |
|            |                 |            |               |        |                      |
| F1: Help   | <b>↑↓</b> : Sel | act Itom   | + -: Change   | Naluos | s F5: Setup Defaults |
| Esc: Exit  |                 | elect Menu | Enter: Sele   |        |                      |

Figure 3: Security

#### **About This Section: Security**

In this section, user can set either supervisor or user passwords, or both for different level of password securities. In addition, user also can set the virus protection for boot sector.

#### ∽ Set Supervis or Password

You can install and change this options for the setup menus. Type the password up to 6 characters in lengh and press <Enter>. The password typed now will clear any previously entered password from the CMOS memory. You will be asked to confirm the entered password. Type the password again and press <Enter>. You may also press <Esc> to abort the selection and not enter a specified password or press <Enter> key to disable this option.

#### ∽ Set User Password

You can only enter but do not have the right to change the options of the setup menus. When you select this function, the following message will appear at the center of the screen o assist you in creating a password.

Type the password up to 6 characters in lengh and press <Enter>. The password typed now will clear any previously entered password from the CMOS memory. You will be asked to confirm the entered password. Type the password again and press <Enter>. You may also press <Esc> to abort the selection and not enter a specified password.

#### The Pass word Check

Setup will check passw ord while invloking setup. Always will check the password while involking setup as well as on each boot. Option: Setup (Default Value), Always

# Boot

|                          |                         | AMI EAS    | SY Setup Utility |        |     |                |
|--------------------------|-------------------------|------------|------------------|--------|-----|----------------|
| Main                     | Adv anced               | Security   | Boot             | Ex it  |     |                |
|                          |                         |            |                  |        |     | [Setup Help]   |
| Boot Dev                 | ice Priority            |            |                  |        | ŀ   |                |
| Floppy: 1                | .44 MB 3 <sup>1/2</sup> |            |                  |        |     |                |
| CD/DVD:                  | C-540E                  |            |                  |        |     |                |
| IDE-0: ST                | 380021A                 |            |                  |        |     |                |
| OnBoard                  | 82540 LAN Boot          | ROM        | Enabled          |        |     |                |
| OnBoard                  | 82550 LAN Boot          | ROM        | Enabled          |        |     |                |
| OnBoard SCSI ROM Enabled |                         |            |                  |        |     |                |
|                          |                         |            |                  |        |     |                |
|                          |                         |            |                  |        |     |                |
| F1: Help                 | ↑↓: Sel                 | ect Item   | + -: Change      | Values | F5: | Setup Defaults |
| Esc: Exit                | ←→: S                   | elect Menu | Enter: Selec     |        | nu  | F10: Save&Exit |

Figure 4: Boot

#### About This Section: Boot

The "Boot" menu allows user to select among four possible types of boot devices listed using the up and down arrow keys. By applying <+> and <Space> key, you can promote devices and by using the <-> key, you can demote devices. Promotion or demotion of devices alerts the priority that the system uses to search for boot device on system power on.

#### ☞ Boot Device Priority

#### 1st / 2nd / 3 rd Boot Device

These three fields determines which type of device the system attempt to boot from after **AMIBIOS Post** completed. Specifies the boot sequence from the available devices. If the first device is not a bootable device, the system will seek for next available device.

The Choice for 1st Boot Device: Removable Device (Default Value), ATAPI CDROM, Hard Disk, Disabled. The Choicefor 2nd Boot Device: Removable Device, ATAPI CDROM (Default Value), Hard Disk, Disabled. The Choice for 3rd Boot Device: Removable Device, ATAPI CDROM, Hard Disk (Default Value), Disabled.

#### OnBoard 82540 LAN Boot ROM

- ► Enabled Enable OnBoard 82540 LAN Boot ROM. (Default Value)
- ► Disabled Disable this function.

#### ▶ OnBoard 82550 LAN Boot ROM

- ⇒ Enabled Enable OnBoard 82550 LAN Boot ROM. (Default Value)
- ➡ Disabled Disable this function.

#### OnBoard SCSI ROM

- ► Enabled Enable OnBoard SCSI LAN Boot ROM. (Default Value)
- ➡ Disabled Disable this function.

# Exit

|                         | AMI EAS  | Y Setup Utility |          |                      |
|-------------------------|----------|-----------------|----------|----------------------|
| Main Advanced           | Security | Boot            | Ex it    |                      |
|                         |          |                 |          | [Setup Help]         |
| Exit Saving Changes     | Enter    |                 | ŀ        |                      |
| Exit Discarding Changes | Enter    |                 |          |                      |
| Load Default Settings   | Enter    |                 |          |                      |
| Load Original Values    | Enter    |                 |          |                      |
|                         |          |                 |          |                      |
|                         |          |                 |          |                      |
|                         |          |                 |          |                      |
|                         |          |                 |          |                      |
|                         |          |                 |          |                      |
|                         |          |                 |          |                      |
|                         |          |                 |          |                      |
| F1: Help ↑↓: Selec      |          | + -: Change     |          | F5: Setup Defaults   |
| Esc: Exit ←→: Sele      | ect Menu | Enter: Select   | t ▶ Sub- | -Menu F10: Save&Exit |

Figure 5: Exit

#### **About This Section: Security**

Once you have changed all of the set values in the BIOS setup, you should save your changes and exit BIOS setup program. Select **"Exit"** from the menu bar, to display the following sub-menu.

- Exit Saving Changes
- ✓ Exit Discarding Changes
- ✤ Load Default Settings
- Load Original Values

#### ◦ Exit Saving Changes

This option allows user to exit system setup with saving the changes. Press <Enter> on this item to ask for the following confirmation message: Pressing  $\Upsilon'$  to store all the present setting values tha user made in this time into CMOS. Therefore, whenyou boot up y our computer next time, the BIOS will re-configure your system according data in CMOS.

#### ∽ Exit Discarding Changes

This option allow s user to exit system setup without changing any previous settings values in CMOS. The previous selection remain in effect. This will exit the Setup Utility and restart your computer when selecting this option. Press <Enter> on this item to ask for confirmation message.

#### ℃ Load Default Settings

When you press <Enter> on this item, you will get a confirmation dialog box with a message as below:

[Load Default Settings] Press [Enter] to continue Or [ESC] to Abort

#### ∽ Load Original Values


When you press <Enter> on this item, you will get a confirmation dialog box with a message as below:

[Load Original Values] Press [Enter] to continue Or [ESC] to Abort

Press [Enter] to load the default values that are factory settings for optimal performance system operations.

Technical Reference

# Chapter 4 Technical Reference




# Chapter 5 Appendix

# Appendix A: Intel 82540EM 82550PM Network Driver Installation


#### (For example: Driver CD Ver. : 1.0)

Insert the driver CD-title that came with your motherboard into your CD-ROM driver, the driver CD-title will auto start and show a series of Setup Wizard dialog boxes. If not, please double click the CD-ROM device icon in "My computer", and execute the setup.exe.




Step 4. Note that user can select either Typical or Custom Setup Types. Typical setup type allows users to install basic connectivity and the adapter management utility. Custom setup type embraces installing features and subfeatures user selects, including modern utilities, manage ment components and drivers. Recommended for advanced users.





### Appendix B: ATI Rage XL VGA Driver Installation


Insert the driver CD-title that came with your motherboard into your CD-ROM driver, the driver CD-title will auto start and show the installation guide. If not, please double click the CD-ROM device icon in "My computer", and execute the setup.exe.



Appendix

# Appendix C: Adaptec SCSI Driver Installation


Insert the driver CD-title that came with your motherboard into your CD-ROM driver, the driver CD-title will auto start and show the installation guide. If not, please double click the CD-ROM device icon in "My computer", and execute the setup.exe.



#### Appendix D: Utilities Installation

Insert the driver CD-title that came with your motherboard into your CD-ROM driver, the driver CD-title will auto start and show the installation guide. If not, please double click the CD-ROM device icon in "My computer", and execute the setup.exe.

The Utilities item contains the utility of DirectX 8.1, Adabe Acrobate Reader V.5.0, and Norton Internet Security 2002



# Appendix E: About Updating latest version of BIOS

To update the latest BIOS version, please go to Gigabyte Networking official web site: Http://networking.gigabyte.com.tw

# Appendix G: Acronyms

| Acronyms | Meaning   |
|----------|---|
| ACPI     | Advanced Configuration and Power Interface          |
| APM      | Advanced Power Management                           |
| AGP      | Accelerated Graphics Port                           |
| AMR      | Audio Modem Riser                                   |
| ACR      | Advanced Communications Riser                       |
| BBS      | BIOS Boot Specification                             |
| BIOS     | Basic Input / Output System                         |
| CPU      | Central Processing Unit                             |
| CMOS     | Complementary Metal Oxide Semiconductor             |
| CRIMM    | Continuity RIMM                                     |
| CNR      | Communication and Networking Riser                  |
| DMA      | Direct Memory Access                                |
| DMI      | Desktop Management Interface                        |
| DIMM     | Dual Inline Memory Module                           |
| DRM      | Dual Retention Mechanism                            |
| DRAM     | Dynamic Random Access Memory                        |
| DDR      | Double Data Rate                                    |
| ECP      | Extended Capabilities Port                          |
| ESCD     | Extended System Configuration Data                  |
| ECC      | Error Checking and Correcting                       |
| EMC      | Electromagnetic Compatibility                       |
| EPP      | Enhanced Parallel Port                              |
| ESD      | Electrostatic Discharge                             |
| FDD      | Floppy Disk Device                                  |
| FSB      | Front Side Bus                                      |
| HDD      | Hard Disk Device                                    |
| IDE      | Integrated Dual Channel Enhanced                    |
| IRQ      | Interrupt Request                                   |
| I/O      | Input / Output                                      |
| IOAPIC   | Input Output Advanced Programmable Input Controller |
| ISA      | Industry Standard Architecture                      |
|          |   |

to be continued.....

| Acronyms | Meaning                              |  |  |  |
|----------|--------------------------------------|--|--|--|
| LAN      | Local Area Network                   |  |  |  |
| LBA      | Logical Block Addressing             |  |  |  |
| LED      | Light Emitting Diode                 |  |  |  |
| MHz      | Megahertz                            |  |  |  |
| MIDI     | Musical Instrument Digital Interface |  |  |  |
| MTH      | Memory Translator Hub                |  |  |  |
| MPT      | Memory Protocol Translator           |  |  |  |
| NIC      | Network Interface Card               |  |  |  |
| OS       | Operating System                     |  |  |  |
| OEM      | Original Equipment Manufacturer      |  |  |  |
| PAC      | PCI A.G.P. Controller                |  |  |  |
| POST     | Power-On Self Test                   |  |  |  |
| PCI      | Peripheral Component Interconnect    |  |  |  |
| RIMM     | Rambus in-line Memory Module         |  |  |  |
| SCI      | Special Circumstance Instructions    |  |  |  |
| SECC     | Single Edge Contact Cartridge        |  |  |  |
| SRAM     | Static Random Access Memory          |  |  |  |
| SMP      | Symmetric Multi-Processing           |  |  |  |
| SMI      | System Management Interrupt          |  |  |  |
| USB      | Universal Serial Bus                 |  |  |  |
| VID      | Voltage ID                           |  |  |  |
| ZCR      | Zero Channel RAID                    |  |  |  |

| Customer/Country:      |      | C ompany:     |       | Phone No.:      |  |
|------------------------|------|---------------|-------|-----------------|--|
| Contact Person:        |      | E-mail Add. : |       |                 |  |
|                        |      |               |       |                 |  |
| Model name/Lot Number: |      |               |       | PCB revision:   |  |
| BIOS version:          |      | 0.S./A.S.:    |       |                 |  |
|                        |      |               |       |                 |  |
| Hardware               | Mfs. | Model name    | Size: | Driver/Utility: |  |
| Configuration<br>CPU   |      |               |       |                 |  |
| Memory                 |      |               |       |                 |  |
| Brand                  |      |               |       |                 |  |
| Video Card             |      |               |       |                 |  |
| Audio Card             |      |               |       |                 |  |
| HDD                    |      |               |       |                 |  |
| CD-ROM /               |      |               |       |                 |  |
| DVD-ROM                |      |               |       |                 |  |
| Modem                  |      |               |       |                 |  |
| Network                |      |               |       |                 |  |
| AMR/CNR                |      |               |       |                 |  |
| Keyboard               |      |               |       |                 |  |
| Mouse                  |      |               |       |                 |  |
| Power supply           |      |               |       |                 |  |
| Other Device           |      |               |       |                 |  |
|                        |      |               |       |                 |  |
|                        |      |               |       |                 |  |
|                        |      |               |       |                 |  |