SCH-A850 Series

PORTABLE

All-Digital Mobile Phone

User Guide

Please read this manual before operating your phone, and keep it for future reference.



Intellectual Property

All Intellectual Property, as defined below, owned by or which is otherwise the property of Samsung or its respective suppliers relating to the SAMSUNG Phone, including but not limited to, accessories, parts, or software relating there to (the "Phone System"), is proprietary to Samsung and protected under federal laws, state laws, and international treaty provisions. Intellectual Property includes, but is not limited to, inventions (patentable or unpatentable), patents, trade secrets, copyrights, software, computer programs, and related documentation and other works of authorship. You may not infringe or otherwise violate the rights secured by the Intellectual Property. Moreover, you agree that you will not (and will not attempt to) modify, prepare derivative works of, reverse engineer, decompile, disassemble, or otherwise attempt to create source code from the software. No title to or ownership in the Intellectual Property is transferred to you. All applicable rights of the Intellectual Property shall remain with SAMSUNG and its suppliers.

Samsung Telecommunications America (STA), L.P.

Headquarters: Customer Care Center:

1301 E. Lookout Drive 1000 Klein St. Richardson, TX 75082 Plano, TX 75074

Fax: 972.761.7001 Toll Free Tel: 1.888.987.HELP (4357)

Fax: 972.801.6065

Internet Address: http://www.samsungusa.com

©2005 Samsung Telecommunications America, L.P. is a registered trademark of Samsung Electronics America, Inc. and its related entities.

Licensed by Qualcomm Incorporated under one or more of the following patents: U.S. Patent No. 4,901,307;5,056,109;5,099,204; 5, 101, 501; 5, 103, 459; 5, 107, 225; 5, 109, 390.

Printed in China

GH Code: GH68-06934A

Openwave® is a registered Trademark of Openwave, Inc.

RSA® is a registered Trademark RSA Security, Inc.

Disclaimer of Warranties; Exclusion of Liability

EXCEPT AS SET FORTH IN THE EXPRESS WARRANTY CONTAINED ON THE WARRANTY PAGE ENCLOSED WITH THE PRODUCT, THE PURCHASER TAKES THE PRODUCT "AS IS", AND SAMSUNG MAKES NO EXPRESS OR IMPLIED WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT, INCLUDING BUT NOT LIMITED TO THE MERCHANTABILITY OF THE PRODUCT OR ITS FITNESS FOR ANY PARTICULAR PURPOSE OR USE; THE DESIGN, CONDITION OR QUALITY OF THE PRODUCT; THE PERFORMANCE OF THE PRODUCT; THE WORKMANSHIP OF THE PRODUCT OR THE COMPONENTS CONTAINED THEREIN: OR COMPLIANCE OF THE PRODUCT WITH THE REQUIREMENTS OF ANY LAW, RULE, SPECIFICATION OR CONTRACT PERTAINING THERETO. NOTHING CONTAINED IN THE INSTRUCTION MANUAL SHALL BE CONSTRUED TO CREATE AN EXPRESS OR IMPLIED WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT. IN ADDITION, SAMSUNG SHALL NOT BE LIABLE FOR ANY DAMAGES OF ANY KIND RESULTING FROM THE PURCHASE OR USE OF THE PRODUCT OR ARISING FROM THE BREACH OF THE EXPRESS WARRANTY. INCLUDING INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES, OR LOSS OF ANTICIPATED PROFITS OR BENEFITS.

Table of Contents

Table of Contents		
	Tat	
Section 1: Getting Started5		
Turning Your Phone On and Off6	Table of Contents	
Setting Up Your Voicemail6	nte	
Understanding this User Manual7	nts	
Section 2: Understanding Your Phone9		
Features of Your Phone10		
Front Views of Your Phone11		
Command Keys14		
Understanding the Display Screen16		
Battery19		
Section 3: Call Functions23		
Making a Call24		
Answering a Call24		
Call History25		
Roaming28		
TTY29		
Voice Signal30		
Voice Signal Options37		
Section 4: Menu Navigation47		
Menu Navigation48		
Menu Outline50		
Section 5: Entering Text55		
Changing the Text Entry Mode56		
Using Word Mode57		
Entering Upper and Lower Case57		
Entering Symbols58		
Entering Numbers59		
Section 6: Understanding Your Contacts 61		
Opening Contacts Menu62		

Adding a Contact	63
Adding Pauses	65
Contacts Groups	65
Finding a Contacts Entry	69
Editing an Existing Contact List Entry	69
Deleting a Contact Entry	70
Storing Numbers After a Call	70
Speed Dialing	71
Finding My Phone Number	72
Section 7: Messaging	7 5
Types of Messages	76
Message Folders	76
Sending PIX Messages	76
Receiving a PIX Message	78
Retrieving New Messages	83
Voicemail	84
Creating and Sending New Messages	85
Mobile IM	88
Section 8: Changing Your Settings	89
Display Settings	
Short Cut Key	94
Security Settings	94
Voice Privacy	97
Location Settings	98
Changing Message Settings	100
Call Settings	103
Ringer Settings	105
Resetting Your Phone	106
Section 9: Multimedia	107
Get It Now	
Get Tunes & Tones	
Get PIX	

Get Fun & Games	112
Get News & Info	112
Get Going	113
How Keys Work	
Section 10: Organizer	117
Calendar	118
Alarm Clock	
World Clock	122
Notepad	
Calculator	124
Voice Services	125
Section 11: Mobile Web	127
Mobile Web	
Launch Mobile Web	128
Exit Mobile Web	
Navigate the Web	129
Mobile Web Soft Keys	129
Links	131
Place a Call While Using Mobile Web	131
Section 12: Health and Safety Information	133
Health and Safety Information	
Consumer Information on Wireless Phones	
Road Safety	146
Operating Environment	148
Using Your Phone Near Other Electronic Devices	149
Potentially Explosive Environments	151
Emergency Calls	152
FCC Notice and Cautions	153
Other Important Safety Information	
Product Performance	
Availability of Various Features/Ring Tones	
Battery Standby and Talk Time	156

Battery Precautions	157
Care and Maintenance	159
Section 13: Warranty Information	161
Standard Limited Warranty	162
Index	169

pection

Section 1: Getting Started

Topics Covered

- Turning Your Phone On and Off
- · Setting Up Voicemail
- . Understanding This User Manual
- Customer Support

This section allows you to start using your phone by activating your service, setting up your voicemail, contacting customer support, or getting an understanding of how this manual is put together.

Section 1: Getting Started

Turning Your Phone On and Off

Turning Your Phone On

- **1.** Open the flip, then press .
- Your service provider's name momentarily appears in the display and the phone begins searching for a network signal.
- Once the phone finds a signal, the time, date, and day appear in the display.
- 4. You're now ready to place and receive calls.

If the phone is outside of the Verizon Wireless coverage or roaming area, □ appears in the top of the display.

Turn Your Phone Off

Press and hold for two or more seconds. Your phone powers off.

Setting Up Your Voicemail

Voicemail allows callers to leave voice messages, which can be retrieved any time.

Note: Once your voicemail account has been set up, you can use the Voicemail selection 7 (under the Messaging menu) to view details of voice messages in your voicemail box.

Voicemail Setup

- 1. In standby mode, press and hold or enter or e
- Follow the prompts in the new user tutorial to setup your mailbox.

Listen to Voicemail

- 1. In standby mode, press and hold , enter \$\infty\$ \$\infty\$ \$\infty\$ \$\infty\$ \$\infty\$ \$\infty\$ \$\infty\$ to dial your own mobile number and press \$\infty\$ to dial voicemail.
- **2.** You are then prompted to enter your password.

Understanding this User Manual

The chapters of this manual generally follow the same order as the menus and sub menus in your phone. A robust index for quick reference to most features begins on page 169.

Also included is important safety information that you should know before using your phone. Most of this information is near the back of the guide, beginning on page 133.

Notes and tips

Throughout this guide are icons and text that are set apart from the rest. These are intended to point out important information, quick methods for activating features, to define terms, and more. The definitions for these methods are as follows:

- Notes: Explain alternative options within the current feature, menu, or sub menu.
- Tips: Provide quick or innovative methods for performing functions related to the subject at hand.
- Fast Facts: Are like snippets from the glossary. Fast facts provides definitions in context and proximity to the menu or feature in question.

Section 1: Getting Started

 Important: Points out important information about the current feature that could affect performance, or even damage your phone.

Section 2: Understanding Your Phone

Topics Covered

- · Features of Your Phone
- Front View of Your Phone
- · Command Keys
- . Understanding the Display Screen
- Battery

This section outlines some key features of your phone. It also displays the screen and the icons that are displayed when the phone is in use.

Section 2

Features of Your Phone

- Domestic and international voice and text messaging service (available on participating networks).
- High speed data (CDMA 2000 1x Technology)
- Global Positioning (GPS) Technology
- PIM Functions
- MMS Messaging
- TXT Messaging
- PIX Messaging
- E-mail Messaging
- Instant Messaging
- Built-in Digital Camera
- Voice Dial
- Speakerphone

Front Views of Your Phone

The following illustrations show the main elements of your phone:

Open View



Section 2

Features

1. Receiver: The receiver allows you to hear the other caller.

- Display Screen Icons: Indicates the status of your phone, including status icons, message indicators, signal strength, etc.
- Navigation Keys: This key allows you to scroll through the phone menu options.
- Left Soft Key: This key is used to navigate through menus and applications by selecting the choice available in the Left Soft key Option.
- Send Key: Allows you to place or receive a call. In standby mode, press the key once to access the recent call log.
- Camera Key: Allows you to launch the camera and take pictures.
- Special Function Keys: Enter's special characters. Performs various functions.
- 8. Power/Accessory Connector: The power/accessory interface connector is used to plug in the charging accessories and also connect any available accessory cables to your phone.
- **9.** Microphone: The Microphone allows the other caller to hear you clearly when you are speaking to them.
- 10. Voice Recognition Key: Launches VoiceSignal options.
- Alpha-numeric Keys: Use these keys to enter numbers, letters, and characters.

- 12. End Key: Ends a call. If you press and hold the END key, the power goes On or Off. When you receive an incoming call, press to mute the ringer and send the call to voicemail.
- 13. Clear Key: Deletes characters from the display when you are in text entry mode. Press to return to the previous menu or screen when navigating features on your phone.
- 14. Right Soft Key: This key is used to navigate through menus and applications by selecting the choice available in the Right Soft key Option.
- **15.** Center/OK Key: Pressing when navigating through a menu accepts the highlighted choice in a menu.

Closed View



Features

 Headset Jack: Allows you to plug in an optional headset for safe, convenient, hands-free conversations.

- 2. Volume Key: Allows you to adjust the master volume in standby mode (with the flip open) or adjust the voice volume during a call. To mute the ringer during an incoming call, press the volume key up or down.
- 3. Speaker Mode Key: Enables and disables speaker phone.
- **4.** Camera Key: Launches the Camera feature of your phone.
- 5. Camera Lens: The lens of your built-in camera.

Command Keys

Functions for the soft keys are defined by what appears above each in the display. There are two soft keys, the left soft key \longrightarrow and the right soft key \longrightarrow .

Left Soft Key

Some functions of the left soft key are as follows.

- In standby mode, press the Message (left) soft key is to open the Messaging menu.
- When the left soft key function is Settings, press the **Settings** (left) soft key 🖾 to view settings for the feature.
- When the left soft key function is Edit, press the Edit (left) soft key
 to edit a Contact.

Right Soft Key

Some functions of the right soft key are as follows.

- When the right soft key function is Options, press the **Options** (right) soft key and a pop-up screen displays.
- In standby mode, press the Contacts (right) soft key open your Contacts list.

Clear Key

The **CLR** key <u>io</u> is used to erase or clear numbers, text, or symbols from the display. You can also use <u>io</u> to return to a previous menu or to return to standby mode from any menu.

- 1. If you enter an incorrect character, briefly press obackspace (and delete) the character.
- 2. To erase the entire sentence, press and hold
- 3. To back up one menu level, briefly press
- To return to standby mode, press and hold until you return to standby mode.

End Key

- 1. Press and hold the **End** key ot turn on your phone.
- 2. Briefly press once to disconnect a call.
- 3. Press or to return to standby mode from any menu, or to cancel the last input.

Send Key

The **Send** key is used to answer calls, dial calls, and to recall the last number(s) dialed, received, or missed.

- 1. Press once to answer calls.
- 2. Enter a number and briefly press on to make a call.
- 3. Briefly press in standby mode to display a list of recent calls to and from your phone.
- 4. Press twice in standby mode to call the most recent number.

Section 2

5. Press to pick up a waiting call. Press again to switch back to the other call.

Navigation Key

Use the directional keys on the navigation key to browse menus, sub menus, and lists. Each key also acts as a shortcut to launch applications. The down navigation key is user-definable.

Speakerphone Key

Use the speakerphone key (located on the right side of your phone) to switch from using the earpiece to the speakerphone before or during a call. Use the volume keys (located on the left side of your phone) to adjust the volume. Press the speakerphone key to enable and disable the speakerphone option.

Understanding the Display Screen

The bottom line of the display is reserved for icons that indicate speakerphone, messaging and the top line is reserved for icons that indicate network status, battery power, signal strength, and more. The following table lists some display icons and their descriptions.

Display icons



Signal Strength: Always appears when your phone is on and indicates the current signal strength. More lines indicate a stronger signal.

- Roaming Indicator: Your phone is outside your home area. While roaming, another wireless provider may be handling your call. The service rate for the call may be higher than those made from within your home area. Please refer to Verizon Wireless for roaming rates.
- **Digital**: IS95-2G Protocol: Indicates your phone is using the IS95-2G protocol. This protocol is not capable of high speed data.
- **1X Protocol**: Indicates your phone is using the 1X protocol.

Note: 1X protocol is available only in the Verizon Wireless network.

- SSL: Indicates the secure socket layer is active transmits your communications over the internet in an encrypted format.
- **Voice Privacy**: When enabled (Enhanced), turns on advanced voice encryption.
- No service indicator: Your phone cannot find a signal because you're outside a service area. You cannot make or receive calls. Wait for a signal or move to an open area to find a signal. This indicator always appears when you first turn on your phone and disappears once service is located.
- Voice Call: Indicates a call in progress.
- Data Call: Indicates a call in progress.
- **E911:** Global Positioning Service (GPS) for 911 is set to On for emergency calls only.

- Location On: Global Positioning Service is set to On for location and 911 calls.
- Battery Level: More bars indicate a greater charge. When the battery is low, an empty battery icon flashes and the phone sounds an alert, which indicates your phone is about to shut down.
- TTY: Indicates that TTY is enabled.
- All Sounds Off: The ringer is silenced for all alerts, incoming calls, and incoming messages. The phone alerts you by vibration.
- Alarm Only: Your phone will only ring when the set alarm sounds.
- Vibrate On: Your phone vibrates upon receiving a call.
- **Speakerphone**: Your phone switches to speakerphone instead of earpiece.
- Missed Calls: Your phone displays this icon when calls are missed.
- Message: You've received a new text message. You're also notified of a new message by animations and sound. You have one or more unread voicemail messages in your voicemail box. (Only applicable on Verizon Wireless Network.)
- Calendar Appointment: Your phone displays this icon when you have a calendar appointment scheduled.
- **Voicemail**: You've received a voicemail message.
- Auto Answer: Automatic answer is enabled. Your phone automatically picks up any calls after the designated time.

Dialogue Boxes

Dialogue boxes prompt for action, inform you of status, or warn of situations such as low memory. Dialogue boxes and their definitions are outlined below.

- Choice
 - Example: "Save message draft?"
- Reconfirm
 - Example: Delete all received messages?"
- Performing
 - Example: "Sending..." "Connecting..."
- Completed
 - Example: "Message sent successfully!"
- Information
 - Example: "New Message"
- Error
 - Example: "System Error!"
- Warning
 - Example: "Battery Low," "Memory Full!"

Battery

Note: This phone comes packaged with a partially charged rechargeable standard Li-lon battery and travel charger.

Important: Although the phone can be used while the battery is charging, the battery must be fully charged before first use, otherwise you could damage the battery.


 Insert the bottom end of the battery into the phone housing with the label side down. The gold contacts on the end of the battery should match up with those on the phone.



2. Push the top end of the battery down until it snaps into place.

Remove the battery

- Pull the battery release latch toward the top of the phone. The top of the battery should pop up.
- 2. Use your finger to lift the battery (top end first) up and away from the phone.



Charge the Battery

Your phone is powered by a rechargeable standard Li-Ion battery. Only use Samsung-approved charging devices and batteries. Samsung accessories are designed to maximize battery life. Using other accessories may invalidate your warranty and may cause damage.

Use the Travel Charger

The travel charger operates from a 120/220 VAC wall outlet.

 Plug the AC plug from the desktop charger into a standard 120 VAC or 220 VAC wall outlet.

Note: You can use your phone while charging, however, the battery charges faster if the phone is turned off.

Battery Indicator

The battery indicator in the upper-right corner of the display indicates battery power level. Four bars indicate a full charge, while an empty icon indicates an almost empty battery. Two to three minutes before the battery becomes too low to operate, a blinking empty battery icon papears and a tone sounds. If you continue to operate the phone without charging, it shuts down.

Section 3: Call Functions

Topics Covered

- · Making a Call
- · Answering a Call
- · Call History
- Roaming
- TTY
- · Voice Signal

This section allows you to make or answer a call. It also includes the features and functionality associated with making or answering a call.

Making a Call

- In Standby Mode, enter the number you want to call using the keypad.
- 2. Press 🥯.

Making Calls Using Contacts

Contacts are entries that you create to store names, numbers, and other information for people or groups of interest. If you've already entered information into your Contacts list, you can recall and dial the contact easily. See "Adding a Contact" on page 63 for information on creating contacts.

- 1. At the standby screen, press the right soft key Contacts.
- Press ▲ or ▼ keys on the side of your phone until the contact that you want to call is highlighted.

Tip: To quickly locate a name, press (or multi-press) any key on the keypad that corresponds to the first, second, and/or third letters of the contact's name.

- If the entry contains more than one number, use ▲ or ▼ to highlight the desired number.
- **5.** Press **a** to call the number.

Answering a Call

When you receive an incoming call, the Incoming screen appears in the display, press the key to answer the call

Section 3

or Ignore to send the call to voicemail, or Quiet to silence the ringer.

Answering Call-Waiting Calls

- When you receive a call while on a call, the Incoming screen displays. You can press and answer the new call or let the new call go to your voicemail.
- If you choose and answer the incoming call, the original caller is placed on call waiting. To return to your original call when you finish with an incoming call, press the Send key.

Call History

When you make, dial, or miss a call, a record of the call is saved in Call History, which is a listing of the different types of calls you can either receive or make. These types of calls are listed below.

- Missed: Displays any missed calls.
- Received: Displays any received calls that were answered.
- **Dialed:** Displays all outgoing calls made from your phone.
- All: Displays all missed, received, and outgoing calls made from your phone.

Viewing Call Information

Call History retains information such as the duration, date and time, whether the call was received, dialed, or missed.

- **1.** At the standby screen, press the <a> Send key.
- Press the down navigation key to highlight the desired number.

- Once the desired number is highlighted, press OPEN.
- 4. The following options appear in the display.
 - "type" call: Where "type" indicates if the call was missed, dialed, or received.
 - Method: If the caller is in your Contacts list, the type of call is listed here (M-Mobile, W-Work, etc.). This option only appears if the caller is in your Contacts list.
 - Number: Displays the telephone number.
 - Date: The date of the call.
 - Time: The time of the call.
 - Duration: The duration of the call.
- 5. Press the right soft key Options to display the following options.
 - Save: Save the number to your Contacts list.
 - Details: Displays the contact information.
 - Erase: Delete the call from Call History.
 - Lock/Unlock: locks or unlocks the entry to prevent accidental deletion.
 - Erase All: Delete the entire Call History list at one time.
 - View Timers: Select to view the call timers for your phone.
- Press the down navigation key to highlight an option.Press of to enter the highlighted option's sub-menu.

Call History Icons

When you view Call History, an icon to the left of the number indicates the type of call.

Indicates a Missed call

- Indicates a Dialed call
- Indicates a Received call

Making Calls Using Call History

- 1. In Standby Mode, press then press up or down navigation key until the desired number is highlighted.
- 2. Press @ Open, then press @ to call the highlighted number.

Creating Contacts Using Call History

- At the standby screen, press then press up or down navigation key until the desired number is highlighted.
- 2. Press the right soft key Options. Use the up or down navigation key to highlight Save, press O. Create New is highlighted.
- **3.** Press or to select from the following options:
 - Mobile 1
 - Mobile 2
 - Home
 - Work
 - Fax
- **4.** Press of to add a new contact, and then enter information.
- 5. Press Save when finished.

Delete Call History Entries

1. At the standby screen, press Send, then press up or down navigation key until the desired number is

- highlighted.
- 2. Press the right soft key Options. A pop-up menu appears in the display.
- 3. Select Erase and press . Select Yes or No at the ERASE ENTRY? and press .

Delete All Call History Entries

- At the standby screen, press Send, then press up or down navigation key until the desired number is highlighted.
- 2. Press the **Open**.
- **3.** Press the right soft key **Options**. A pop-up menu appears in the display.
- 4. Press the down navigation key to highlight Erase All and press we key. Select Yes or No at the ERASE ALL ENTRIES? pop-up screen.
- 5. Press the key.

Roaming

What is Roaming?

Your phone can roam on other digital networks. Roaming occurs when you travel outside a predesignated coverage area. The roaming icon displays when roaming is active and extra charges may apply when making or receiving calls.

Note: Some features may be unavailable while roaming.

Roaming Options

The following roaming options are available:

- Home Only Your phone is available for normal operation only in the designated coverage area.
- Automatic-A: The preferred roaming list is used to acquire service. If no preferred systems are found, any digital "A" system is acquired.
- Automatic-B: The preferred roaming list is used to acquire service. If no preferred systems are found, any digital "B" system is acquired.

Note: Contact your service provider for information regarding preferred systems.

To change your Roaming option, follow these steps:

- 1. Press the Menu key. Use the right navigation key to highlight Settings & Tools.
- 2. Use the down navigation key to highlight 4 System and press the key. System Select is highlighted.
- 3. Press the w key. Use the up or down navigation keys to choose the setting you want, and press the w key.

TTY

Your phone is fully TTY compatible. Connect the TTY equipment to the headset jack, which is located on the left side of the phone. Before you can use your phone with a TTY device, you'll need to enable TTY functions in the phone.

 Press the Menu key. Use the right navigation key to highlight Settings & Tools.

- Use the down navigation key to highlight Call Settings and press the key.
- 3. Press 3 TTY Mode. The TTY Mode screen displays.
- **4.** Use the up or down navigation keys to choose from the following:
 - TTY Off
 - TTY + HEAR
 - TTY + TALK
 - TTY Full
- Press the key to make your selection. The TTY Mode Set screen displays.

Voice Signal

Voice Signal is advanced speech recognition software that can be used to activate a wide-variety of functions on your phone. Voice Signal software automatically voice activates all contacts for voice dialing and searching, no pre-recording or training needed. Speak phone numbers naturally to dial, and use voice commands to launch applications and navigate phone menus.

Voice Services Settings

You can adjust the settings and preferences for Voice Signal by opening Voice Services menu. Using this menu, you can change the following Voice Command features:

- Launch V.Command
- Voice Memo
- TTS
- Voice Settings

To access the Voice Services menu, follow these steps:

- 1. In Standby Mode, press Menu. Use the right navigation key to highlight Settings & Tools.
- 2. Press Tools, then 6 Voice Services.
- **3.** Use the navigation keys to select the setting you want to change.

Launch V.Command

This menu sets the Voice Dial options. Use the navigation key to select the option and press .

Voice Memo

You can record a phone number, parking location, or simple reminders using Voice Memos.

Recording Memos

- 1. In Standby Mode, press Menu. Use the right navigation key to highlight Settings & Tools.
- 2. Press Tools, then Som Voice Services.
- 3. Press 2 Voice Memo. Press the left soft key New.
- 4. Press the REC key to begin recording. Press the left soft key Pause or, if paused, press the Resume key to continue recording. Press the STOP key to stop recording.
- **5.** The new Voice Memo is saved with a system defined name. Press the right soft key **Options** to choose from the following:
 - **Detail Info**: provides the voice memo title, length, size, recorded date and time.
 - **Rename**: allows you to rename the voice memo.

- **Erase**: allows you to delete the memo.
- Erase All: allows you to delete all voice memos saved.

Renaming Recordings

- 1. In Standby Mode, press Menu. Use the right navigation key to highlight Settings & Tools.
- 2. Press Tools, then For Voice Services.
- 3. Press voice Memo. Use the navigation key until the recording you want to rename is highlighted.
- 4. Press the right soft key **Options**. Press **Rename** to rename the Voice Memo.
- **5.** Press and hold until the current name for the recording is deleted. Use the keypad to enter a new name for the recording.

Press the **Save** when finished or the right soft key **Back** to exit and return to the previous menu.

TTS

The Text To Speech (TTS) option allows you to listen to the options as you navigate through the menu options. To enable TTS, use the following steps:

- In Standby Mode, press Menu. Use the right navigation key to highlight Settings & Tools.
- 2. Press Tools, then For Voice Services.
- 3. Press **3.** TTS. Use the navigation key to turn TTS ON or TTS OFF.
- 4. Press or to save your setting.

Section 3

Voice Settings

You can adjust the settings and preferences for Voice Signal by opening the Voice Settings menu. Using this menu, you can change the following Voice Command features:

- Digit Dialing: Use the Digit Dialing menu to adapt digit dialing to your voice.
 - Adapt Digits: Lets you adapt digits, which can improve voice recognition of phone numbers. Adaptation takes about 60 seconds.
 - Reset Digits: Erases any digit adaptation you have done and resets digit recognition to the factory default. If you have not adapted digits, this option is grayed out.
- Sensitivity: In Voice Signal, sensitivity controls the balance between rejecting too much, which means the phone frequently does not recognize names, numbers, or commands, and rejecting too little, which means it frequently recognizes something even if nothing was said. When Voice Signal rejects an utterance, it displays a message such as "Please repeat..." or "No match found." If you frequently experience these messages, you might be able to get better recognition by adjusting the Sensitivity setting toward Reject Less. If you frequently experience false activations (Voice Signal detects a wrong match), you might be able to get better performance by adjusting the Sensitivity setting toward Reject More.
- Choice Lists: If Voice Signal is not absolutely confident that it
 has correctly identified a Name, Digit, or Contact it can
 display a choice list of up to three possibilities, and prompt you
 to confirm the correct one. You can control when choice lists
 appear by changing the Choice Lists setting to the following:
 - Automatic: Voice Signal displays a choice list when it is not confident it has identified the correct choice from among multiple alternatives.

Section 3

- Always On: When there are multiple alternatives, Voice Signal always displays a choice list.
- Always Off: Voice Signal never displays a choice list.
 Instead, the application picks the best from among the possible choices.
- Sound: You can customize the Voice Signal user interface by turning playback on or off for prompts, names, and numbers. You can also change the speed and volume of name playback.
 - Prompts: Turns playback on or off for prompts such as "Please say a command."
 - Digits: Turns playback on or off for digits, for example, when confirming a phone number.
 - Names: Turns playback on or off for names.
 - Name Settings: Adjusts the speed and volume of name playback.
- About: Displays information about Voice Signal including version number, build number, and device number.

Adapting Voice Signal

Voice dialing works well for most people without special adaptation. However, people with strong accents or unique voice characteristics may receive better results after adapting the system to match their voices.

You should adapt Digit Dial only if the system is frequently unable to recognize your speech. After you adapt Digit Dial, your phone is customized to your voice, and your voice only. Others will not be able to use it unless they reset the phone to factory defaults.

Adaptation involves recording several digit sequences to adapt the system to the unique properties of your voice. The adaptation process takes about three minutes.

Tips for adapting Digit Dial

- Adapt digits in a guiet place.
- Make sure you wait for the beep before starting to speak.
- Speak clearly, and say each digit distinctly.
- If you make a mistake while recording a sequence of digits, or if there is an unexpected noise that spoils the recording, rerecord that sequence.
- Only adapt digits if you regularly have problems with digit dialing. Once adapted, digit dialing will not work as well for other people using your phone.
- Adapt Digit Dial to your Voice

Digit Dial Adaptation

To access the Adapt Digits menu, follow these steps:

- 1. In Standby Mode, press Menu. Use the right navigation key to highlight Settings & Tools.
- 2. Press Tools, then For Voice Services.
- 3. Press Voice Settings. Press Digit Dialing.
- 4. Adapt Digits is highlighted. Press the Wev.
- 5. A short description of the Adapt Digits displays.
- **6.** Read the description until you are comfortable to proceed, then press ③.
- Your phone displays the first digit sequence and "Please say" plays through the speaker followed by the four digits appearing in the display.
 - Wait for the beep and repeat the digits using your normal tone of voice.

- 8. After a moment, the phone plays back the recording and prompts "Did the recording sound ok?" If the recording was good, say "Yes." If you need to re-record, say "No." If you say "No," the phone prompts you to pronounce the digits again. Wait for the beep and then re-record. Repeat this step until you're satisfied with the recording.
- 9. After confirming that the recording sounds ok, repeat the recording process with the next set of digits. After six sets of digits, the phone asks whether you want to do more adaptation. Answer "Yes."
- **10.** After the 10th set of digits, the phone indicates that adaptation is complete.

Reset Digit Dial Adaptation

This option erases an adaptation and resets Digit Dial to its original state.

- 1. In Standby Mode, press Menu. Use the right navigation key to highlight Settings & Tools.
- 2. Press Tools, then 6 Voice Services.
- 3. Press 4 Voice Settings. Press Digit Dialing.

Note: If you have not performed the Adapt Digits function, the Reset Digits option will not be accessible.

4. Highlight Reset Digits and press the key. The Reset Digit Adaptation screen displays requesting conformation of reset. Press to proceed. Digit Adaptation Reset is completed.

Voice Signal Options

The following options are used by the Voice Signal speech recognition on your phone.

Call Digit Dialing

Digit Dial allows you to dial any phone number by simply speaking the digits into the phone. No training is necessary, and Digit Dial is programmed to understand natural speech.

- 1. Press and hold of for two seconds.
- After a brief pause, a list of optional commands appears in the display and the audio prompt "Say a command" plays through the earpiece.



Speak clearly and say the command that you want to use. If, after a few seconds, the device has not recognized a command, it prompts you to repeat the command. If, after a few more seconds, it still has not recognized a command, it tells you "Sorry, no match found," and cancels voice recognition.

Using Voice Dial

Use the Voice Dial command to dial any number stored in your contact list by saying the name of the contact (Name

Dialing). You can also use Voice Dial to dial any valid telephone number, even numbers not stored in your contact list, by speaking the individual digits in the number (Digit Dialing).

Dialing a Name

To dial a name using Voice Dial:

- 1. Press and hold of for two seconds to start VoiceSignal.
- 2. Sav "Voice Dial."
- 3. VoiceSignal prompts you to "Say the name or number."



- 4. Speak clearly and say the name of a person in your contact list, first name followed by last name. For example, say "John Smith."
- 5. If VoiceSignal recognizes the name and there is one number stored with that name, VoiceSignal repeats the name and dials the number. If VoiceSignal is not sure which name you said, it displays a choice list of up to three names and prompts you with "Did you say?" followed by the first name on the list.



- Say "Yes" to confirm the name or "No" to hear the next name, or use the keypad to select the correct name from the list.
- 7. If the recognized name has multiple numbers stored for it (e.g., Mobile, Work, Home, etc.), VoiceSignal displays the possible choices and prompts you with "Which number?"



8. Indicate which number to call by saying one of the choices. For example, say "Mobile." VoiceSignal repeats what you said and then dials the number.

Note: If there is more than one Mobile number listed for an entry both **Mobile 1** and **Mobile 2** display.



Dialing a Number

To dial a number using Voice Dial:

- 1. Press and hold of for two seconds to start VoiceSignal.
- Say "Voice Dial." VoiceSignal prompts you to "Say the name or number."



Speak clearly and say a valid telephone number. For example, say "781 970 5200."

Section 3

4. If it recognizes the number, VoiceSignal repeats it and dials the number. If VoiceSignal is not sure it has recognized the number, it displays a choice list of up to three numbers and prompts you with "Did you say?" followed by the first number on the list.



5. Say "Yes" to confirm the number or "No" to hear the next one, or use the keypad to select the correct number from the list. (See the section "Using Choice Lists" for more information.)

Voice Memo

Voice Memo accesses the voice memo feature of your phone. See "Voice Memo" on page 31.

Calendar

Calendar accesses the Calendar feature of your phone. See "Calendar" on page 118.

Looking Up Contact Information

Use the Contacts command to retrieve contact information for any name stored in your contact list by

Section 3

saying the name. Contacts displays contact information on the screen but does not dial any phone numbers for the contact.

To look up information for a specific contact:

- 1. Start VoiceSignal.
- Say "Contacts." VoiceSignal prompts you to "Say the name."



- Speak clearly and say the name of a person in your contact list, first name followed by last name. For example, say "John Smith."
 - If VoiceSignal recognizes the name, it displays the contact information stored for that name. If it is not sure which name you said, VoiceSignal displays a choice list of up to three names and prompts you with "Did you say?" followed by the first name on the list.
- 4. Say "Yes" to confirm the name or "No" to hear the next name, or use the keypad to select the correct name from the list. (See the section, "Using Choice Lists" for more information.)

VoiceSignal displays the contact information stored for the name you selected.

Using Choice Lists

VoiceSignal uses choice lists when it is not confident it has correctly recognized a name or number. In this case, it can display a list of up to three possible choices, and prompt you to confirm the correct one.

You can change the way that VoiceSignal uses choice lists with name dialing, digit dialing, and contacts. For each feature, you can choose to always see a choice list (even if there is only one choice), or never see a choice list (even if there are multiple choices). If you leave the setting at "Automatic," VoiceSignal displays a choice list only when it is not confident it has correctly recognized the name or number.

To change the way VoiceSignal uses choice lists:

- 1. Start VoiceSignal.
- 2. Press Settings, and then select Choice Lists.
- 3. Select Name Dialing, Digit Dialing, or Contacts.
- 4. Click the button for the choice list you want:

Section 3



- Automatic VoiceSignal displays a choice list only when it is not sure if it has correctly recognized the name or number.
- Always On VoiceSignal always displays a choice list, even when there is only one choice.
- Always Off VoiceSignal never displays a choice list.
 - 5. Press **OK** to accept the new setting.

Call Name Dialing

To use Name Dial, you'll need to have entries stored in your Contacts list. See page 63 for information on creating a Contacts list.

- 1. Press and hold of for two seconds.
- After a brief pause, a list of optional commands appears in the display and the audio prompt "Say a command" plays through the speakerphone--if it is enabled.

Note: To activate the speakerphone option, press the

located on the side of your phone. You must enable the speakerphone option before you access the VoiceSignal options.

Sections

- Say "Voice Dial" at a distance of 3-12 inches from the phone in a natural voice.
- 4. "Say the Name or Number" plays through the earpiece.
- **5.** To use Name Dialing, say the name of the contact that you want to dial.
- **6.** The name that you said is repeated through the earpiece and your phone dials the number.
- 7. If VoiceSignal is not sure of the number that you said, a list of possible matches appears in the display.
- 8. You're asked to confirm the correct number as Voice Signal displays the results. Say "Yes" or "No" to confirm or reject the number when prompted.
- The location is repeated through the earpiece and your phone dials the number.

Contacts

To perform a name lookup, you'll need to have some entries in your Contacts list.

- 1. Press and hold of for two seconds.
- **2.** A list of commands appears in the display and the audio prompt "Say a command" plays through the earpiece.
- **3.** Say "Contacts" at a distance of 3-12 inches from the microphone. "Say the name" plays through the earpiece.
- **4.** Say the name exactly as it is displayed in your Contacts list, first name followed by last name.
- The contact name appears in the display with other information that you've entered for that contact.

Status lets you say a single command "Status" to check your phone's network coverage, signal strength, battery, GPS setting, and master volume.

Missed Calls

Missed Calls lets you say a single command "Missed Calls" and view your missed calls log.

Section 3

Topics Covered

- Menu Navigation
- · Menu Outline

This section explains the menu navigation for your phone. It also includes an outline of all the available menus associated with your phone.

Menu Navigation

Access menus using the navigation keys, two soft keys , or use a shortcut.

- 1. In Standby Mode press the Menu. The first of several menus appear in the display.
- 2. Use the navigation keys to browse phone menus.
- Press or to enter the menu or sub menu presently appearing in the display.

Return to the Previous Menu

Press to return to the previous menu.

Navigate Using Shortcuts

You can also access menus and sub menus using menu numbers. This method is often called a "shortcut." To shortcut to a menu or sub menu, press (Menu, then enter the menu and/or sub menu number(s) for the feature in question.

- In Standby Mode, press Menu. The Contacts menu is launched.
- Press the number of the menu, sub menu, and so on to arrive at the desired feature.

Navigation Key Shortcuts

In Standby Mode, press a navigation key (as illustrated below) to launch its corresponding application.



The Short Cut menu can be customized. In Standby Mode, press the Menu, use the right navigation key to highlight Settings Tools. Press Menus System Short Cut Key. The short cut key list displays. Use the navigation key to change the setting and press to save your selection.

The In-Use Option

Access numerous menus and features even while in a call.

Note: If the call is disconnected while accessing the In-Use Option, the In-Use Option disappears from the display and the phone eventually returns to standby mode.

- 1. While in a call, press the right soft key **CODITIONS**. The following menu items appear in the display.
 - **Send Message**: Opens the New TXT Message screen.
 - Contacts: Open the contacts to view.
 - Recent Calls: Display your recent incoming, missed and outgoing calls.
 - **Send DTMF**: Sends keypad tones.

- Voice Privacy: Prevent recipients of your calls from seeing your number on their display. Select from standard or enhanced options.
- Voice Memo: Record a voice memo.
- 2. Use the navigation key to highlight a menu. Press or to open the highlighted menu or to activate the feature.

Menu Outline

Use the menu shortcuts on the following pages to quickly access sub menus. Press the W key to access Menu, then use the navigation keys to highlight the menu. right of the menu to jump to that menu, sub menu, or feature.

CONTACTS

- 1: New Contact
- 2: Contact List
- 3: Groups
 - 1: No Group
 - 2: Business
 - 3: Colleague
 - 4: Family
 - 5: Friends
- 4: Speed Dials

🪅 GET IT NOW

- 1: Get Tunes & Tones
 - 1: Get New
 - 2: Record New
 - 3: Beep Once
 - 4: VZW Default Tone
 - 5: Bell 1
 - 6: Bell 2
 - 7: Melody 1

- 8: Melody 2
- 9: Melody 3
- 10: Melody 4
- 11: Melody 5
- 12: Melody 6
- 13: Melody 7
- 2: Get Fun & Games
 - 1: Get New
- 3: Get Pix
 - 1: Take PIX
 - 2: PIX Gallery
 - 3: PIX Place
 - 4: PIX Services
- 4: Get News & Info

5: Get Going

1: Get New

MESSAGING

- 1: New TXT Msg
 - 2: New PIX Msg
 - 3: New Hand.Msg
 - 4: Inbox
 - 5: Sent
 - 6: Drafts
 - 7: Voicemail
 - 8: E-Mail
 - 9: Mobile IM

RECENT CALLS

- 1: Missed
- 2: Received
- 3: Dialed
- 4: All
- 5: View Timers

SETTINGS & TOOLS

- 1: Tools
 - 1: Calendar
 - 2: Alarm Clock
 - 3: World Clock
 - 4: Notepad
 - 5: Calculator
 - 6: Voice Services
 - 1: Launch V.Command
 - 2: Voice Memo
 - 3: TTS
 - 4: Voice Settings
- 2: Sounds
 - 1: Master Volume

- 2: Call Sounds
- 3: Alert Sounds
- 4: Keypad Volume
- 5: Earpiece Volume
- 6: Service Alerts
- 7: Power On/Off
- 3: Display
 - 1: Banner
 - 2: Backlight
 - 3: Contrast
 - 4: Wallpaper
 - 5: Display Themes
 - 6: Power On/Off Animation
- 4: System
 - 1: System Select
 - 2: NAM Selection
 - 3: Device Info
 - 4: Location
 - 5: Security
 - 6: Language
 - 7: Short Cut Kev
 - 8: Standalone Mode
- 5: Call Settings
 - 1: Answer Options
 - 2: Auto Retry
 - 3: TTY Mode
 - 4: One Touch Dial
 - 5: Voice Privacy
 - 6: Data Settings
 - 7: DTMF Tones
- 6: Clock Format
 - - 1: Main Clock
 - 2: Front Clock
- 7: Ringer ID

8: Picture ID

Section

Section 5: Entering Text

Topics Covered

- · Changing the Text Entry Mode
- · Using Word Mode
- . Entering Upper and Lower Case
- . Entering Symbols
- · Entering Numbers

This section outlines how to select the desired text input mode when entering characters into your phone. This section also describes how to use the T9 predictive text entry system to reduce the amount of key strokes associated with entering text.

Changing the Text Entry Mode

- 1. In standby mode, press the key Menu, then press the left navigation key to Messaging, press New TXT Msg to compose a new text message. Or press the left soft key Message and press New TXT Msg.
- 2. Enter the phone number of the recipient, or press the right soft key **Options** to display a pop-up menu with the options listed
 - Entry Mode: Choose the method of text entry. Choose from
 - Word
 - Abc
 - ABC
 - 123
 - Symbols
 - Save As Draft: Save the message to your Draft folder.
- Priority Level: Save the message with a High or Normal priority.
- Validity Period: Save the message for the assigned period of time.
- Deferred Delivery: Save the message to be delivered at the assigned delivery date and time.
- Enh. Delivery Ack: Displays a pop-up screen notifying the message sent has been received.
- Press the left soft key Add to access the following options:
- Contacts: Launches the Contacts menu.
- Recent Calls: Lists all recent calls-dialed, received, or missed.

Using Word Mode

Word recognizes the most commonly used word for any sequence of key presses and inserts that word into your message. It's much faster than the traditional method of text entry (Abc) and requires only one key press per letter of the word that you're spelling.

- In Standby Mode, press the left soft key Message, then press New TXT Msg to compose a new text message.
- Enter the phone number or email address of the recipient, then press the down navigation key to move to the Text field.
- 3. Press the left soft key Abc to display a pop-up menu containing text entry mode options.
- ABC is highlighted. Use the up/down navigation keys to display Word, then press ow.

Now, for practice, enter the word "Samsung" into your message by pressing each of the following keys only once:

Word recognizes that the most frequently used word for the sequence that you just entered is "Samsung." If more than one word shares the same sequence, Word provides the most common of the two. Press of to display other words in the dictionary, if available.

Entering Upper and Lower Case

- Enter characters while in ABC mode by pressing the key that contains the desired characters
 Image: Ima
- Press the key repeatedly to cycle through other available characters for that key.
- Pause briefly when the desired character appears in the display to accept the character and therefore insert it into the message.
- Press # to enter a space.
- To cycle between uppercase, lower case, and initial caps for characters in ABC mode, briefly press .

Entering Symbols

Symbol mode enables you to enter symbols such as @ or% into a text message.

- 1. In Standby Mode, press the left soft key Message, New TXT Msg to compose a new text message.
- Enter the phone number of the recipient, then press the down navigation key to enter text.
- 3. Press the left soft key Abc to display a pop-up menu containing the following options.
- Word: Choose from the factory provided words or add to your personal dictionary.
- Abc: Enter text with initial capitalization at the beginning of each sentence.
- ABC: Enter text in all capital letters.
- **123:** Enter numbers.
- Symbols: Allows you to enter symbols.

- 4. Abc is highlighted. Use the up/down navigation keys to display Symbol. The first of four screens containing symbols appears in the display.
- Use the navigation left/right keys to page through the other symbols, if necessary.
- 6. Enter the key that corresponds with the symbol that you wish to enter. For example, press ← for an exclamation point (!).
- Repeat steps 5 through 6 to insert as many symbols into your message as desired.

Entering Numbers

Enter numbers into a text message while in number mode (123). See "Changing the Text Entry Mode" on page 56 for instructions on changing text entry modes.

 While in 123 mode, press the key containing the number that you wish to insert into your message.

Section (

Section 6: Understanding Your Contacts

Topics Covered

- . Opening Contacts Menu
- · Adding a Contact
- · Adding Pauses
- · Contact Groups
- Finding a Contact Entry
- . Editing an Existing Contact Entry
- . Deleting a Contact Entry
- Storing Numbers After a Call
- · Speed Dialing
- . Finding My Phone Number

This section allows you to manage your daily contacts by storing their name and number in your Contacts menu. Contact entries can be sorted by name, entry, or group.

Opening Contacts Menu

The Contacts menu provides access to powerful features such as adding Groups, creating and sending V-cards, and viewing the phone number assigned to your phone by Verizon Wireless.

- In standby mode, press Menu. The Contacts menu displays.
 - New Contact: Add a number, e-mail, or web address to your Contacts.
 - Contact List: Find a phone number by Name, by Entry, or by Group.
 - **Groups**: Add new or rename one of your five default groups.
 - Speed Dials: Set a speed dial for a contact.
- 2. Use the navigation key to highlight the Contacts submenu of your choice, then press .

Contacts Icons

You can assign multiple entries to a contact. The icons in the following table represent all available entry types

- Mobile 1 icon. Enter a mobile number for the entry in this field.
- Home icon. Enter a home number for the entry in this field
- Work icon. Enter the work number for the entry in this field.
- E-mail 1 icon. Enter an e-mail address for the entry in this field.

- **Group** icon. Select an available group to associate with the entry in this field.
- PIX icon. Select a PIX (graphic or photo) to assign to the contact entry.
- Ringtone icon. Select a ringtone to associate with the entry in this field.
- Mobile 2 icon. Enter a mobile number for the entry in this field.
- **Fax** icon. Enter a fax number for the entry in this field.
- E-mail 2 icon. Enter an e-mail address for the entry in this field.

Adding a Contact

When you add information to your Contacts, you can add it as a new entry or as an existing entry.

Method 1

- In standby mode, press Menu, the Contacts menu opens.
- 2. Press New Contact to enter the contact information.
- 3. Enter a name for the entry using the keypad.
- **4.** Use the navigation key to highlight the appropriate type (**Mobile**, **Home**, **Work**, **E-mail**, etc.). Once highlighted, use the keypad to enter required information.
- **5.** Use the navigation key to highlight other type fields, if desired. Enter information using the keypad.
- **6.** When you're finished entering information for the entry, press **Save** to save the entry to your Contacts.

Section 6

Method 2

You can add new numbers to the Contacts by simply entering the number while the phone is in standby mode, then following the necessary prompts to complete the process.

- In standby mode, enter the number that you wish to save using the keypad, then press the left soft key Save. You're prompted to select from Create New or Update Existing.
- Press to enter the number as a Create New, or press
 to append the number to Update Existing.
- If you selected Create New, the following types are available.
 - Mobile 1
 - Mobile 2
 - Home
 - 🗓 Work
- 4. If you selected **Update Existing**, proceed to step 8.
- 5. Use the up/down navigation keys to display the desired type, then press the wey.
- 6. Enter a name for the entry using the keypad. Press the left soft key Abc if you wish to select a different method of text entry, such as Word, Abc, ABC, 123, or Symbols.

- 7. When you're finished entering information for the entry, press Save. The entry is saved to your Contacts. If you selected Update Existing, the Contact List opens in Search mode. Use the navigation key to browse through entries, or enter the name of the entry using the keypad.
- 8. Once you've highlighted the entry you wish to append the number, press . An Update Existing pop-up screen with the new information displays. Press the . Key. The number is appended to the selected entry and saved to your Contacts.

Adding Pauses

Calls to automated systems often require a password or account number. Instead of manually entering numbers each time, store the numbers to your Contacts along with special characters called pauses.

- Pause: A hard pause stops the calling sequence until further input from you.
- Wait: A two-second pause stops the calling sequence for two seconds and then automatically sends the remaining digits.

Note: Entering multiple two-second pauses extends the length of a pause. For example, two consecutive two-second pauses cause a total pause time of four seconds. Keep in mind pauses count as digits towards the 48-digit maximum.

Contacts Groups

You can place any Contacts entry into one of five categories, called "**Groups**." Groups allow you to search your Contacts faster, quickly send messages to one or more group members, and more.

Section 6: Understanding Your Contacts

Note: By default, new entries to your Contacts are placed into the No Group unless another group is specified.

View Groups

- 1. In standby mode, press the key **Menu**, then press **Groups**. The following groups appear in the display.
 - No Group
 - Business
 - Colleague
 - Family
 - Friends
- 2. Use the navigation key to highlight the desired group, then press or to access the group and view its contents.

Move an Entry to Another Group

- In standby mode, press the right soft key Contacts. Use the navigation key to highlight the contact you wish to move.
- 2. Press the left soft key **Edit**. Use the up/down navigation key to scroll to the Group option.
- 3. Press the left soft key Set. Choose from the following groups:
 - No Group
 - Business
 - Colleague
 - Family
 - Friends

- **4.** Use the navigation key to highlight the group containing the entry that you wish to move, then press .
- Press Save. The selection has been saved to the designated group.

Create a New Group

In addition to the five groups already in your phone, you can create additional groups (a maximum of 30). New groups can be named anything you like as long as their names are within the 32-character limit.

- 1. In standby mode, press Menu, then press Groups. Your existing groups appear in the display.
- 2. Press the left soft key New. A New Group pop-up menu displays with the "Enter new name" highlighted.
- Press SAVE to save. The Groups list now displays the new group added.

Send a Text Message to Members of a Group

Use Send Message in the Group feature to send a message to as many as 10 members of a group at once.

Note: Text messaging availability varies when roaming off the Verizon Wireless Network

- 1. In standby mode, press Menu, then press Groups. Your existing groups appear in the display.
- 2. Press the right soft key Options and highlight Send TXT Msg. Press .

Section 6

- 3. Use the down navigation key to highlight the contacts in the group to which you want to send a message and press of to select the contact.
- 4. Press the left soft key Done.

Note: You can mark up to 10 members of a group for message distribution. If you try and mark an 11th member, you'll be notified that 10 addresses have already been selected.

- **5.** Press the right soft key **Options**.
- Press . A pop-up menu appears in the display with Text highlighted.
- 7. Enter the content of your message using the keypad.
- 8. To send the text message, press Send.

Send a PIX Msg to Members of a Group

Note: Only available within Verizon Wireless Enhanced Services Area.

- 1. Follow steps 1 through 4 in the previous section entitled "Send a Text Message to Members of a Group".
- 2. With **Text Msg** and **PIX Msg** appearing in the pop-up menu, use the navigation key to highlight **PIX Msg**, then press .
- The list of addresses (or numbers) to which the message will be delivered appears in the display.
- **4.** Press . The Create PIX Msg composer appears in the display with the options:
 - To: Enter the addresses (or numbers to which the message will be delivered.

- **Text**: Add text to the PIX Msq.
- **PIX**: Add an image from the PIX Gallery to the message.
- **Sound**: Add sound to the PIX Msq
- **Subject**: Add a subject to the PIX Msg.
- **5.** Once you've finished adding the desired content to your PIX Msg, you're returned to the PIX Msg composer.
- Press Send to send the PIX Msg. The PIX Msg is sent to the intended recipients.

Finding a Contacts Entry

From standby mode, you can quickly open the Contacts list. Contacts is a quick way of viewing entries you've stored in the Contacts list.

- In standby mode, press the right soft key Contacts. The Contact List displays.
- 2. In the Search field, enter the first and second letters of the name you wish to search until it is highlighted.

Editing an Existing Contact List Entry

- In standby mode, press the Menu, then press Gontact List.
- 2. Use the navigation key to display the contact list entry and press the left soft key A Edit.
- Use the navigation key to highlight the name, number, email address, or other field that you wish to edit.
- Press to backspace and delete numbers, text, or symbols.

- **5.** Press and hold <u>to erase all numbers in the highlighted field.</u>
- **6.** Use the keypad to re-enter numbers, text, or symbols.
- When you're finished editing the entry, press SAVE. Your changes are saved.

Deleting a Contact Entry

- In standby mode, press the Menu, then press Contact List.
- 2. Use the navigation key to display the contact list entry and press the w View key.
- 3. Press the left soft key Erase.
- 4. A pop-up "Erase Entry?" screen displays.
- 5. Highlight Yes or No, then press .

Storing Numbers After a Call

Once you've finished a call, you can store the number of the caller to your Contact List.

Note: If the call was incoming and Caller ID information was unavailable, then the store option is also unavailable.

- **1.** After you press to end your call, the call time, length of call and phone number appears in the display.
- 2. Press the right soft key Save. You're prompted to confirm this as a Create New, or Update Existing.
- **3.** Follow the on-screen prompts to designate other information.

Store a number in standby mode

Store a phone number by entering the number in standby mode, then press Save. Follow the screen prompts to assign number types and other information.

Speed Dialing

Note: 1-Touch, 2-Touch, and 3-Touch dialing allows you to call numbers stored in your Contact List quicker.

Speed dialing allows you to press and hold a key (or keys) to dial the number associated with those key(s). There are three types of speed dialing; **1-touch**, **2-touch**, and **3-touch** dialing.

Note: 1 is reserved for voicemail.

1-touch dialing

Call phone numbers assigned to memory locations 002 - 009 by pressing and holding the any of the 2 - 9 keys. For example, to speed dial the number assigned to location 2, press and hold a until the name and number appear in the display and the number is dialed.

2-touch dialing

Call phone numbers assigned to keys 010 through 099 by briefly pressing the first key, then pressing and holding the second key. For example, to speed dial the number assigned to 013, briefly press , then press and hold until the number dials.

3-touch dialing

Call phone numbers assigned to memory locations 100 through 500 by briefly pressing the first and second keys, then pressing and holding the third key. For example, to dial location number 113, briefly press , , then press and hold until the number dials.

Assign a speed dial location

- In standby mode, press the Menu, then press Menu, the Menu, then press Menu, the Menu, the
- 2. Use the navigation keys to highlight the number you wish to assign or enter the speed dial location using the keypad, press the Set key.
- 3. The Set Speed Dial screen displays.
- **4.** Use the navigation keys to highlight the entry you want, then press **3**.
- **5.** At the pop-up screen, use the navigation key to highlight **Yes** or **No** and press **3**.
- **6.** Continue to assign speed dial entries or press the key to return to standby mode.

Finding My Phone Number

My phone # displays the ten-digit number assigned to your phone.

- In standby mode, press the Menu, then press the right navigation key to Settings & Tools.
- 2. Press the 4 System key.

Section 7: Messaging

Topics Covered

- · Types of Messages
- · Message Folders
- · Sending PIX Messages
- · Receiving a PIX Messages
- · Retrieving a PIX Msg
- · Retrieving New Messages
- Voicemail
- · Creating and Sending Messages
- Mobile IM

This section allows you to send or receive different types of messages. It also includes the features and functionality associated with messaging.

Types of Messages

Your phone is capable of sending email and text messages. Send email or text messages by simply entering the email address or the phone number of the recipient in the To: <.........> or Send To field when creating a new message.

Message Folders

Your phone provides default message folders for your Inbox, Sent, Draft, Voicemail, E-mail messages.

Sending PIX Messages

Note: Only available within Verizon Wireless Enhanced Services Area.

You can add sounds and attach a Contact entry to your PIX Msg. This is also known as Multimedia Messaging (MMS).

- 1. In standby mode, press the left soft key Message then press Mew PIX Msg. Or in standby mode, press the Menu key and use the left navigation key to highlight Messaging then press Mew PIX Msg.
- Enter the phone number or e-mail address of the recipient (or recipients) using the keypad.
- 3. Press the right soft key Options to display a pop-up menu that provides the following options:
 - Entry Mode: Choose from Word, Abc, ABC, 123, and Symbols modes of text entry.
 - Preview: Shows the message before it is sent.
 - Save as Draft: Save the message to your Draft folder.

- Priority Level: Save the message with a High or Normal priority.
- Validity Period: Save the message for the assigned period of time.
- Deferred Delivery: Save the message to be delivered at the assigned delivery date and time.
- **Remove PIX**: Removes the selected PIX from the message.
- Remove Sound: Removes the sound attached from the message.
- 4. Press the left soft key Add to select from the following options:
 - **Contacts**: Choose a number from your contacts list or select the right soft key to select from the **Groups** menu.
 - Recent Calls: Choose a number from the recent calls list.
 - To PIX Place: Send the message to the PIX Place.
- **5.** Press or once you've finished entering the number.
- 6. Press the down navigation key to add a message. Compose your message, then press the down navigation key. PIX is highlighted.
- 7. Press the left soft key Gallery to add a PIX. Press OF.
- 8. Use the down navigation key to the **Sound** field, press the left soft key **Sounds** to select a sound. Press **3**.
- 9. Press the down navigation key to the **Subject** field press the left soft key Abc to change entry mode. Press the right soft key Doptions to **Add Quick Text**. Press O.
- **10.** Once all fields are complete, press or to send the message to the intended recipient(s).

Receiving a PIX Message

When you receive a message in standby mode, the message ringer sounds, (unless turned off), and a popup message appears in the display.

- 1. At the "DOWNLOAD COMPLETED, PLAY NOW?" prompt, use the navigation keys to highlight Yes or No. Press ...
- 2. Press the right soft key **Options** to choose from the following options:
 - Play Again: Replays the PIX message.
 - **Forward:** Forwards the message to another recipient.
 - **Erase**: Pop-up prompts with Yes or No for deletion.
 - **Save PIX**: Saves the picture to the PIX Gallery.
 - **Save Sound**: Saves the picture to the PIX Gallery.
 - Save Quick Text: Saves the text sent in the message to the Quick Text list.
 - Add To Contacts: Adds the sender's information to your contact list.
 - Lock/Unlock: Locks the message to prevent deletion.
 - Message Info: Provides the following information: TO Number, Priority, Msg Type, Size and if a Graphic, or Sound were included in the message.

Receive Messages While in a Call

When you receive a message while in a call, the New Message dialog box appears in the display along with the closed envelope icon (☑). You can view the message without disconnecting your call.

Section 7

View a PIX Msg Later

Note: Only available within Verizon Wireless Enhanced Services Area.

Note: When Auto Receive is set to Off in Message Settings, the message "View Later" displays.

- 1. In standby mode, press the left soft key Message then press Message Inbox.
- 2. To view the message, press the left soft key Message, Message,
- 3. Highlight the message and press Open.
 - Press left soft key **Erase** to delete the message.
 - Press the right soft key Later to download and view the message later.
 - Press Down to begin downloading the PIX message.
- **4.** Press to return to standby mode.

Inbox

Received messages of all types are stored in the Inbox folder.

- In standby mode, press the left soft key Message then press Inbox. Or in standby mode, press the Menu key and use the left navigation key to highlight Messaging then press Inbox.
- Use the navigation key to highlight the message that you wish to view.
- 3. Press **Open** to view contents of the highlighted message.

Section 7

- **4.** While viewing a message press the right soft key **Options** to display the options listed.
 - Play Again: Replays the PIX message.
 - Forward: Forward the message to another recipient.
 - **Erase**: Pop-up prompts with Yes or No for deletion.
 - Save Graphic: Saves the picture to the PIX Gallery.
 Save PIX will display if you are viewing a PIX message.
 - Save Sound: Saves the picture to the PIX Gallery.
 - Save Quick Text: Saves the text sent in the message to the Quick Text list.
 - Add To Contacts: Adds the sender's information to your contact list.
 - Lock/Unlock: Locks the message to prevent deletion.
 - Message Info: Provides the following information: TO Number, Priority, Msg Type, Size and if a Graphic, or Sound were included in the message.
- 5. Press **Reply** key to return a message to the sender.
- **6.** From the **Inbox** menu, press the left soft key **Erase** to delete the message from the Inbox. Highlight **Yes** to delete. or **No** to return to the Inbox menu.

Sent

Your phone stores messages in the Sent folder, regardless of whether the message was successfully transmitted. Verify if and when a message or e-mail was successfully transmitted by enabling the **Enh. Delivery Ack.** feature.

Review Messages in the Sent Folder

1. In standby mode, press the left soft key Message then press Sent. Or in standby mode, press the Menu key and use the left navigation key to highlight

Messaging then press **Sent**.

- 2. Use the navigation key to highlight the message that you wish to review, then press **OK**.
- 3. While viewing the message, press the right soft key **Options** to display the options listed.
 - Forward: Forwards the message to another recipient.
 - Play Again: Replays the PIX message.
 - **Resend**: Resends the message to the original recipient.
 - **Erase**: Erases the selected message.
 - Add To Contacts: Adds the sender's information to your contact list.
 - Lock/Unlock: Locks the message to prevent deletion.
 - Save Quick Text: Saves text to the choose from Quick Text message list.
 - Message Info: Provides the following information: TO Number, Day, Date, Time, Delivery Type, Msg Type, Priority, Size and if a Graphic, and Sound.
- 4. Use the navigation key to highlight the desired option.
- **5.** Press or to perform the function for the highlighted option.
- 6. From the SENT menu, press the left soft key Erase to delete the message from the SENT folder. Highlight Yes to delete, or No to return to the SENT menu.

Drafts

Draft messages are those that have been composed but never sent. You can return to the Drafts folder at any time to view, edit, or send a draft message.

17

Create a Draft Text Message

- In standby mode, press the left soft key Message then press New TXT Msg. Or in standby mode, press the Menu key and use the left navigation key to highlight Messaging then press New TXT Msg. Press New TXT Msg.
- 2. Enter the phone number of the recipient, then press the down navigation key.
- Compose your message using the keypad, then press the right soft key Options. A pop-up menu appears in the display.
- 4. Scroll down with the navigation key until Save As Draft is highlighted, then press . A confirmation message appears in the display and your message is saved to the Drafts folder.

View and Edit Draft Messages

- In standby mode, press the left soft key Message then press Drafts. Or in standby mode, press the Menu key and use the left navigation key to highlight Messaging then press Drafts.
- 2. Use the navigation key to highlight the message that you wish to view, then press of Edit. The message opens in the Text field with the message text displayed.
- 3. Press the CLR key to backspace and delete any current characters in the display, if desired. Press and hold to erase a word at a time.
- 4. Press . The Text field is highlighted.

- Press the right soft key Options. A pop-up menu appears in the display with the options listed.
 - Add: Add information from the following categories.
 - **Graphics:** Adds a graphic that is preloaded or downloaded.
 - Animation: Adds an animation that is preloaded or downloaded.
 - **Sound**: Adds a sound that is preloaded.
 - Quick Text: Choose from up to 12 pre-loaded messages.
 - Text Format: Choose the Size, Alignment, and Style of the text displayed in your message.
- Save as Draft: Save the message to your Draft folder.
- Priority Level: Save the message with a High or Normal priority.
- Validity Period: Save the message for the assigned period of time.
- Deferred Delivery: Save the message to be delivered at the assigned delivery date and time.
- Enh. Delivery Ack: Displays a pop-up screen notifying the message sent has been received.
- 6. Use the navigation key to highlight the desired option. Press of to perform the function for the highlighted option.
- Once you've returned to the message composer, press to send the message, if desired.

Retrieving New Messages

While text messages from other phones are delivered directly to your phone, PIX messages and Emails will be stored in the Inbox of the message server and the server

Section 7

will alert you to new messages. Therefore you need to retrieve new messages from your phone.

Retrieving a Text Message

When you receive a message in standby mode, the message ringer sounds, (unless turned off), and New Text Msg appears in the display along with the closed envelope icon (☑). The date and time of the message also appear in the display.

- Press the key to View now, or press the down navigation key to highlight View later and press the key. The message is saved to your inbox where you can view it later.
- 2. Press the right soft key Options to open the message, where you have the option to Forward, Erase, Save Graphic, Save Sound, Save Quick Text, Add To Contacts, Lock and Message Info.
- Press the REPLY key to return a message to the sender.

Voicemail

New voicemail alerts are sent via an SMS text message. These messages indicate how many new and urgent voicemail are in your box. When all voicemail has been listened to, a message is sent notifying you there are zero new messages waiting. Open the text message to view the number of new and urgent voice messages in your voicemail box. If a caller leaves a callback number, this number will also be sent via an SMS text message.

When you receive a new voicemail message you'll hear a sound and an SMS text message appears in the display.

- Press the up/down navigation keys to select Listen Now or Listen Later
- 2. Press the ok key.

View Voicemail Messages in the Inbox Folder

- In standby mode, press the key Menu, then press the left navigation key to Messaging, press Message and press Voicemail. Or press the left soft key Message and press Voicemail.
- Press OPEN to dial voicemail and retrieve your message(s).

Creating and Sending New Messages

This section guides you through the procedure to send various types of messages.

Creating and Sending Text messages

- In standby mode, press the key Menu, then press the left navigation key to Messaging, press New TXT Msg to compose a new text message. Or press the left soft key Message and press New TXT Msg.
- Enter the phone number of the recipient, or press the right soft key Options to display a pop-up menu with the options listed
 - Entry Mode: Choose from Word, Abc, ABC, 123, and Symbols modes of text entry.
 - Save as Draft: Save the message to your Draft folder.

oecuon 7

- Priority Level: Save the message with a High or Normal priority.
- Validity Period: Save the message for the assigned period of time.
- **Deferred Delivery**: Save the message to be delivered at the assigned delivery date and time.
- Enh. Delivery Ack: Displays a pop-up screen notifying the message sent has been received.
- After selecting or entering your recipients in the To field, use the down navigation key to move to the message composer.
- Press the right soft key Options. Press Add to acess the following options:
 - **Graphics**: Adds a graphic that is preloaded or downloaded.
 - Animation: Adds an animation that is preloaded or downloaded.
 - **Sound**: Adds a sound that is preloaded.
 - **Quick Text**: Choose from up to 12 pre-loaded messages.
- **4.** Use the navigation key to highlight an option. Press to perform the function for the option, or to enter its sub menu.
- **5.** To send the message, press .

Creating and Sending PIX Messages

1. In standby mode, press the key Menu, then press the left navigation key to Messaging, then press Mew PIX Msg to compose a new message. Or press the left soft key Message and press Mew PIX Msg.

- 2. Enter the phone number of the recipient, or press the right soft key Options to display a pop-up menu with the options listed:
- Entry Mode: Choose from Word, Abc, ABC, 123, Symbols and Shortcuts modes of text entry.
- **Preview**: Shows a preview of the message created.
- Save as Draft: Save the message to your Draft folder.
- Priority Level: Save the message with a High or Normal priority.
- Validity Period: Save the message for the assigned period of time.
- Deferred Delivery: Save the message to be delivered at the assigned delivery date and time.
- Remove PIX: Erases the attached picture or movie.
- Remove Sound: Erases the attached sound.
- 3. After selecting or entering your recipients in the **To** field, use the down navigation key to move to the Text field.
- 4. Compose your message using the keypad.
- **5.** Use the down navigation key to move to the PIX field. Press the left soft key Gallery.
- 6. Highlight the picture and press the w key.
- 7. Use the down navigation key to move to the Sound, Subject. Enter information if desired.
- 8. To send the message, press SEND.

Mobile IM

The Instant Messaging function allows you to send and receive instant messages using one of the following communities:

- AOL[®] Instant Messenger [™]
- MSN® Messenger Service
- Yahoo![®] Messenger

Note: You must first create the Instant Message account before accessing it on your phone.

Using Mobile IM

- 1. In standby mode, press the left soft key Message.
- 2. Highlight Mobile IM and press .
- 3. Select your instant message community using the left and right navigation keys and press .
- **4.** Use the on-screen application specific functions and options to use the instant message applications.

Section 8: Changing Your Settings

Topics Covered

- Display Settings
- Shortcut
- · Security Settings
- · Voice Privacy
- · Ringer Settings
- · Location Settings
- . Changing Message Settings
- · Call Settings
- · Resetting Your Phone

This section explains the sound and phone settings for your phone. It includes display settings, security settings, call settings, and other settings associated with your phone.

Display Settings

The **Display** sub menu affects the menu style, standby mode animation, backlight settings, and more.

- In standby mode, press the Menu, use the right navigation key to highlight Settings & Tools. Press
 Display. The Display sub menus listed in the display
 - Banner: Create your own personalized greeting that appears in the display when your phone is in standby mode or choose the ERI Banner which displays the network in which you have subscribed.
 - Backlight: Choose settings for the LCD, Keypad, and Power Save.
 - Contrast: Choose the contrast settings for the Main LCD and the Front LCD. Press to save changes.
 - Wallpaper: Choose PIX (Pre-loaded or personal) to use as the background display for your Main LCD. You may only choose from your personal PIX or pre-loaded PIX for the Front LCD.
 - Display Themes: Choose from 6 preset colors used for menu display.
 - Power On/Off Animation: Choose the media that appears in the display when you turn the phone on and off.
- 2. Use the navigation key to highlight the display sub menu that you wish to edit, then press .
- Use the navigation key to select from the sub menu options that appear in the display, then press . Your settings are saved.

Banner

Banner allows you to create your own personalized greeting that appears in the display while your phone is in standby mode.

- In standby mode, press the Menu, use the right navigation key to highlight Settings & Tools. Press Display. The Display sub menus listed in the display. Press Banner.
- 2. Press 🙀 to create a **Personal Banner** for your handset.

Note: Press and hold <u>each</u> to erase an existing banner, if necessary.

- Enter a word or short phrase (12 characters or less) to appear in your phone's display when the phone is in standby mode.
- **4.** Press or to save the new banner.
- 5. Highlight **ERI Banner** to turn **On** or **Off** the Enhanced Recognition Indicator (ERI) banner.

Backlight

Set the **backlight** for the display or keypad to remain on for a specified period of time or to remain on as long as the flip is open.

Note: Prolonged backlight use drains your battery faster.

In standby mode, press the Menu, use the right navigation key to highlight Settings & Tools. Press Display. The Display sub menus listed in the display. Press Backlight.

- 2. LCD is highlighted. Press or use the navigation key to highlight a **Keypad** press or.
 - Always On: The backlight is always on.
 - **Always Off**: The backlight is always off.
 - **5 Seconds**: The backlight is on for 5 seconds before it dims.
 - 15 Seconds: The backlight is on for 15 seconds before it dims.
 - 30 Seconds: The backlight is on for 30 seconds before it dims.
- Press of to enter the highlighted option's sub menu and change settings as desired.

Contrast

Choose the contrast settings for the Main LCD and Front LCD displays on your handset.

- In standby mode, press the Menu, use the right navigation key to highlight Settings & Tools. Press Display. The Display sub menus listed in the display. Press Contrast.
- 2. Main LCD is highlighted. Press . Use the right and left navigation keys to increase or decrease the contrast. Press .
- 3. Use the same procedures for the **Front LCD**.

Wallpaper

Choose the wallpaper displayed on your handset from the PIX Gallery or pre-loaded PIX.

Choose the Wallpaper

1. In standby mode, press the Menu, use the right navigation key to highlight Settings & Tools. Press

- Display. The Display sub menus listed in the display. Press Wallpaper.
- 2. Use the navigation key to highlight PIX Gallery or Preloaded PIX, then press .
- If you selected PIX Gallery, choose from the available pictures in the PIX Gallery. If you selected Pre-loaded PIX, choose from available wallpaper and press .

Display Themes

Choose from 6 preset colors (Default, Business, Tropical, Blue, Green, or Red) used for menu display. Use the up or down navigation keys to highlight your selection and press .

Power On/Off Animation

Animation allows you to choose the multi-media or pictures that appear in your phone's display when you turn it on, turn it off, and while the phone is in standby mode.

Choose Power On or Power Off Animation

- In standby mode, press the Menu, use the right navigation key to highlight Settings & Tools. Press Display. The Display sub menus listed in the display. Press Power On/Off Animation.
- 2. Use the navigation key to highlight **Power On** (or **Power Off**), then press .



Short Cut Key

Shortcut List allows you to select from up to eleven applications that appear in the display when you press the up navigation key in standby mode.

- In standby mode, press the Menu, use the right navigation key to highlight Settings & Tools. Press System. The System sub menus listed in the display. Press Mort Cut Key. The sub menus listed appear in the display.
- 2. A list of sub menus appears in the display, use the navigation key to highlight the desired sub menu, then press on. The shortcut is added to the list.

Security Settings

The **Security** sub menu allows you to lock your phone, set up emergency numbers, enable or disable voice privacy, set restrictions, and other security options.

- In standby mode, press the Menu, use the right navigation key to highlight Settings & Tools. Press
 System.
- 2. Use the navigation key to highlight **Security**, press .
- Enter the lock code (factory settings are the last four digits of your telephone number). The following options display:
 - Common Code: Common code On uses a common password for both device and location lock code. Common code Off uses separate passwords for both device and location.
 - Call Restrictions: Allows you to restrict the Outgoing, Incoming, or Contacts list for your phone.

- Lock Mode: Allows you to lock the **Device** or **Location**.
- Edit Code: Allows you to change the Lock Code for the Device or Phone.
- Reset Phone: All settings (except Contacts) are reset to factory default settings.

Lock Phone

Lock Phone restricts the use of your phone with the exception of outgoing calls to 911 and the three user-programmed emergency numbers. Lock Phone allows you to answer calls, but to place calls (except to emergency numbers) you have to unlock the phone.

- In standby mode, press the Menu, use the right navigation key to highlight Settings & Tools. Press System. The System sub menus listed in the display. Press Mecurity. You're prompted to enter the lock code. The default lock code is the last four digits of your telephone number.
- Enter the Lock Code. Several security sub menus appear in the display.
- 3. Press **Jock Mode**. Use the navigation key to highlight **Device** or **Location**. Press the **key**. The following options display.
 - **Unlock**: If locked, unlocks the device or phone, depending on your selection.
 - Lock: Your phone returns to standby mode. The the Lock Code is required immediately to access any functions.
 - On Power Up: The Lock Code is required whenever you
 power up the phone.

4. Press of to perform the function for the highlighted option.

Change Lock

The default lock code is the last four digits of your phone number. **Change Lock** allows you to change this code to a lock code of your preference.

- In standby mode, press the Menu, use the right navigation key to highlight Settings & Tools. Press System. The System sub menus listed in the display. Press Mecurity. You're prompted to enter the lock code. The default lock code is the last four digits of your telephone number.
- Press Edit Code. Two options are available Device and Location. Use the navigation keys to highlight your choice and press O.
- At the "Enter New Lock Code" prompt, enter the new lock code. You're prompted to confirm the new lock code.
- "Device or Location Lock Code Changed" message appears in the display confirming that your lock code has been changed.

Note: Your phone does not allow you to view the lock code for obvious security reasons. If you change the lock code, be sure to write down or memorize the new code.

Emergency

Note: Emergency number 911 is hard-coded into your phone. You can dial this number any time, even when the phone is locked or restricted. If you

call 911 an audible tone is heard and an emergency prompt appears in the display for the duration of the call.

Important: DO NOT depend on this phone as a primary method of calling 911 or for any other essential or emergency communications.

Remember to always turn your phone on and check for adequate signal strength before placing a call.

Call Emergency Numbers in Lock Mode

In Lock Mode, you can dial 911 to place an emergency call.

Note: If you dial 911, your phone dials the emergency number immediately (no prompt).

Voice Privacy

Note: This feature is only available on the Verizon Wireless network.

Voice Privacy when enabled (that is, set to Enhanced), turns on advanced voice encryption.

- In standby mode, press the Menu, use the right navigation key to highlight Settings & Tools. Press Call Settings. The Call Settings sub menus listed in the display.
- 2. Press Moice Privacy. The sub menus listed appear in the display. Standard and Enhanced appear in the display.
- Use the navigation key to highlight the Voice Privacy option of your choice, then press . Your settings are saved.

Restriction

Restriction allows you to restrict outgoing and incoming calls. You can also restrict access to your Contacts list.

- In standby mode, press the Menu, use the right navigation key to highlight Settings & Tools. Press System. The System sub menus listed in the display.
- Press Security.
- 3. Enter the lock code, then press **Call Restrictions**.
- Use the navigation key to select Outgoing, Incoming, or Contacts, then press .
- Use the navigation key to highlight On or Off, then pressYour settings are saved.

Location Settings

Note: This feature is only available on the Verizon Wireless network.

The **Location** (GPS) setting identifies your location to the network. You can fully enable this setting or set GPS to work only in the case that you dial 911 from your phone.

- In standby mode, press the Menu, use the right navigation key to highlight Settings & Tools. Press System. The System Settings sub menus listed in the display.
- 2. Press 4 Location. The Location screen displays.
 - Location On: GPS location setting is on wherever the feature is available.

- E911 Only: GPS location setting is on whenever you dial 911 only.
- 3. Use the navigation key to highlight an option.
- Press or to select the highlighted setting.

Device Info

The Device Info sub menu allows you to view the software and hardware information, your assigned number, and an icon glossary for your phone.

- In standby mode, press the Menu, use the right navigation key to highlight Settings & Tools. Press System. The System sub menu is listed in the display.
- Press Device Info. My Number is highlighted. Press to display the Mobile Device and Identification numbers.
- Press at to view the software, PRL, ERI, Browser, Get it Now, and Hardware versions available on your phone.
- **4.** Press 3⁻⁴ to view the list of icons with a brief description.
- 5. Press ow to return.

Language

Change the display language to English or Español using the **Language** sub menu.

In standby mode, press the Menu, use the right navigation key to highlight Settings & Tools. Press
 System. The System sub menus listed in the display. Press Language.

2. Use the navigation key to select the language of your choice, then press .

Changing Message Settings

This menu allows you to define settings for your messages sent or received on your phone. To access your message settings, use the following steps:

- In standby mode, press the Menu, then press the left navigation key to Messaging, press the left soft key Message and press the left soft key Message and press the left soft key Settings.
- 2. Use the navigation keys to access the following options:
- Auto Save: Saves all messages received or sent. Use the navigation keys to select On, Off, or Prompt.
- Auto Erase: Erases all messages received or sent. Choose from On or Off.
- Auto View TXT: Automatically displays the text message when received. Choose from On or Off.
- Auto Receive: Automatically receives messages into your Inbox. Choose from On or Off.
- Signature: Adds the signature text to each message sent.
 Choose from None or Custom.
- Callback #: Displays the callback number in the text message. Choose from On or Off.
- Voice Mail #: Enter the speed dial entry set for your voicemail.
- Block/unblock: Set Block, Set Unblock, and View Blocked List created for your messages. Enter the phone numbers you wish to block and unblock. The numbers you block create the Blocked List.

- Entry Mode: Sets the default entry mode for messaging.
 Choose from Word, Abc, ABC, or 123.
- Quick Text: Displays the Quick Text pre-defined entries for
 Text Msg and PIX Msg. Press the right soft key New to
 add to the Quick Text list. Enter your new text and press the
 key. The new Quick Text item shows in the first
 position of the list.
- Text Auto Scroll: When enabled, advances body text automatically one line at a time.

Entry Mode

Use Entry Mode to select the default method of text entry.

- In standby mode, press the Menu, use the left navigation key to Messaging. Use the down navigation key to highlight New PIX Msg. Press
- 2. Press the right soft key Options. Press Entry Mode. The options listed in the following table appear in the display.
 - Word: Enter text into messages using Word.
 - Abc: Enter initial capitalization text into messages using multiple key presses.
 - ABC: Enter all capitalization text into messages using multiple key presses.
 - **123**: Enter numeric values in a text message.
 - **Symbols**: Allows you to enter symbols.
- 3. Use the navigation key to highlight the default method of text entry, then press . Your settings are saved.

Callback

Use Callback # to view or modify the callback #. The Callback # can be inserted into all outgoing messages, thereby notifying the recipient(s) of your phone number.

- 1. In standby mode, press the Menu, use the left navigation key to Messaging.
- Press the left soft key Settings. Press Settings. Press Callback
 The callback # appears in the display.
- 3. Use the CLR key to backspace and delete numbers. Press and hold CLR to delete all characters from the display.

 Enter a new callback # number using the keypad, then

Auto Erase

Use Auto Erase to set the disposal method of messages after they are read.

press or to save your changes.

- In standby mode, press the Menu, use the left navigation key to Messaging.
- 2. Press the left soft key Settings. Press Auto Erase.
- 3. Use the navigation key to highlight On or Off.
- Press to select the highlighted option. Your changes are saved.

Voice Mail

Use Voice Mail # to view or modify your voicemail number.

1. In standby mode, press the Menu, use the left

- navigation key to Messaging.
- Press the left soft key Settings. Press Voice
 Mail #. The Enter Number field is highlighted and *86
 appears in the display.
- Use the CLR key to backspace and delete numbers. Press and hold CLR to delete all characters from the display.
- Enter a new number and press the key to save your changes.

Call Settings

This menu allows you to select the method for answering incoming calls, setting redial options, setting data rates for data calls, voice services, and more.

Answer Options

Answer Options contains the sub menus Call Answer and Auto Answer. Call Answer allows you to select the method for answering incoming calls, while Auto Answer allows you to select the delay time before a call is picked up.

Call Answer

- In standby mode, press the Menu, use the right navigation key to highlight Settings & Tools. Press
 Call Settings. The Call Settings sub menus listed in the display.
- 2. Press Answer Options. The following options appear in the display.

- Flip Open: Calls are answered when the folder is opened.
- Any Key: Calls are answered when any key is pressed.
- **Send Only**: Calls are answered when the key is pressed.
- Auto Answer: calls are answered automatically with a 1, 3 or 5 second delay.
- 3. Use the navigation key to highlight the method you wish to use for answering calls, then press .

Auto Retry

Auto Retry automatically redials busy numbers after a preset period of time.

- In standby mode, press the Menu, use the right navigation key to highlight Settings & Tools. Press Call Settings. The Call Settings sub menus listed in the display.
- Press Auto Retry. The following options appear in the display.
- Use the navigation key to highlight one of the following options
 - Off
 - · After 10 Seconds
 - · After 30 Seconds
 - After 60 Seconds
- Press of to select the option, or press to return to the Call Settings sub menu without making a selection.

Data Settings

- In standby mode, press the Menu, use the right navigation key to highlight Settings & Tools. Press Call Settings. The Call Settings sub menus listed in the display.
- 2. Press Data Settings. The following options appear in the display. Press the key to choose from the following options:
- Data Off: Phone operates in normal voice call mode.
- Data For Next Call: Data call is enabled for next call only.
 Phone will reset to Data Off mode after call.
- Data Until Powered Off: Phone will remain in Data Mode until phone is powered off.

Ringer Settings

- In standby mode, press the Menu, use the right navigation key to highlight Settings & Tools. Press Sounds. The Sounds sub menu is listed in the display.
- 2. Press the **Call Sounds**. Press **Call Ringtone**. Available options are:
 - Get New
 - Beep Once
 - VZW Default Tone
 - Bell 1
 - Bell 2
 - Melody 1-7
 - No Ring
- **3.** Press **Call Vibrate** to set the Call Sounds to vibrate.

 Press of to save the setting. The phone returns to Call Sounds submenu.

Resetting Your Phone

Reset Phone returns all setup options to their factory default.

- In standby mode, press the Menu, use the right navigation key to highlight Settings & Tools. Press
 System. The System sub menus listed in the display.
- 2. Press the Sa Security, and enter the lock code. Press Reset Phone. A prompt appears in the display asking if you wish to restore default settings (except for the Contacts).
- 3. Press No to return to the Security list.

Section 9: Multimedia

Topics Covered

- · Get It Now
- · Get Tunes & Tones
- Get PIX
- · Get Fun & Games
- Get News & Info
- · Get Going
- · How Keys Work

This section describes how you receive tunes, tones, images, games, news and information. You can also take and send pictures from your phone.

Get It Now

The Get It Now menu provides sub-menus to get tunes & tones, PIX, fun, games, news and information. You can also view memory info to see how much space you've used (and have left) for stored media. Use the following steps for each **Get It Now** sub menus.

- 1. In standby mode, press the Menu, use the left navigation key to highlight Get It Now. Press the right soft key Info.
- 2. The Get It Now Info menu displays with **SYSTEM INFO** highlighted. Press or to view the memory status. Press the wey to return.
- 3. Press 2 View Log to see the file transfer activity. Press the key to return.
- 4. Press Melp to display a list of frequently asked questions. Use the navigation key to highlight an item and press the key to display help text. Press the key to return.

Get Tunes & Tones

This menu allows you to get new, record new, and set tunes and tones as your ringtone.

- In standby mode, press the Menu, use the left navigation key to highlight Get It Now. The Get Tunes & Tones menu is highlighted, press .
- 2. To get new Tunes & Tones press Get New. Press New Provider, you are connected to the Get It Now server and presented with available provider applications.

- 3. To record a new tune or tone, press Record New.

 The New Voice Memo screen displays. Press the Record New key to begin recording. Press the left soft key Pause to pause or the Record key to stop. Your new voice memo is added to the current ringtone list.
- **4.** Use the down navigation key to highlight the new recording and press the right soft key Rename. Enter a name and press the key.
- 5. Press the left soft key Erase to delete the recording.

Get PIX

This menu allows you to get new PIX from the internet or take new PIX using your phone's camera. You can also view the saved pictures.

- In standby mode, press the Menu, use the left navigation key to highlight Get It Now. Press Get PIX.
- 2. Use the navigation key to choose from Take PIX, PIX Gallery, PIX Place, or PIX Services.

Take PIX

This menu launches the camera.

- In standby mode, press the Menu, use the left navigation key to highlight Get It Now. Press Get PIX.
- 2. Press Take PIX. The camera is now active.

- 3. Press the right soft key **Options**, to choose the specific camera settings. Use the right/left navigation keys to advance to each setting category, and the up/down navigation keys to make selections within each category. The following categories are available:
 - **Resolution**: (640X480), (320X240), (160X120),
 - **Self Timer**: Off, 5 Sec., 10 Sec.
 - White Balance: Auto, Sunny, Cloudy, Tungsten, and Fluorescent.
 - Quality: Fine, Normal, and Economy
 - Shutter Sound: Shutter, Okay, Chime, no Sound.
 - Color Effects: Normal, Monochrome, Sepia, Negative, Emboss. Sketch.
- **4.** Press **Take** to capture a picture. Press the right soft key **Erase** to delete it or press the left soft key **Save**. The picture is now saved to the Gallery.

PIX Gallery

This menu allows you to review the pictures you have taken or downloaded and stored into your phone.

- In standby mode, press the Menu, use the left navigation key to highlight Get It Now. Press Get PIX.
- 2. Press PIX Gallery to view PIX that have been stored on your phone.
- 3. Press of to view the pictures in thumbnail mode. Press view to expand the selected picture.

- Press the right soft key Options for the following options. Highlight an option and press to make your selection.
 - Send: Launches the Create PIX Msg screen.
 - **To PIX Place**: Transfers the file to the online gallery.
 - Create Postcard: Adds text to the selected picture in the PIX Gallery.
 - **Set As**: Set the picture as the main wallpaper. Picture ID.
 - **Rename**: Allows you to rename the picture.
 - **Lock**: Locks the picture to prevent deletion.
 - **Erase**: Erases the selected picture from the gallery.
 - Erase All: Erases all pictures from the gallery.
 - **PIX Info**: Provides the date, time, location, resolution, size and rights to the selected picture.

PIX Place

Send a PIX message to your online album.

Note: You must first setup your account on the Verizon Wireless website: www.verizonwireless.com before establishing a connection.

- In standby mode, press Menu, use the left navigation key to highlight Get It Now. Press Get PIX.
- Highlight PIX Place and press . The PIX Place sign-on screen displays.
- Enter your Mobile Number and Password. Use the navigation key to highlight LOGIN and press . You are now connected to your online album.

PIX Services

- In standby mode, press Menu, use the left navigation key to highlight Get It Now. Press Get PIX.
- 2. Press PIX Services. Press New Provider. Choose from the GET PIX list.

Get Fun & Games

Select from several fun and interesting applications or a broad category of games that you can play on your phone.

- In standby mode, press Menu, use the left navigation key to highlight Get It Now. Press Get Fun & Games.
- 2. Press Get New.
- 3. Use the navigation keys to make a selection and press
- **4.** Choose the charge either Subscription or Unlimited, then press **3.** Follow in screen prompts to apply.

Get News & Info

- In standby mode, press Menu, use the left navigation key to highlight Get It Now. Press Get News & Info.
- The browser is launched and a pop up screen with available applications is displayed.
- 3. Use the navigation key to browse the categories.
- **4.** Once the desired category is highlighted, press or to enter the category list.

When you use Get News & Info, some of the keys operate differently than during a normal phone call.

It presents on-screen items in any of the following ways:

- Text or numeric input
- Links (embedded in content)
- Numbered options (some options may not be numbered)
- Simple text

You can utilize the options or links by using the soft keys.

Get Going

Download applications that keep you in touch with the world, keep you organized, and help you find the coolest spots.

- In standby mode, press the Menu, use the left navigation key to highlight Get It Now. Press Get Going.
- 2. Get New is highlighted. Press .
- **3.** Highlight the application you wish to download and press .
- Highlight your selection and press . Follow on screen subscription prompts and press . The download process begins.
- At the "App installed successfully. Would you like to run it?" prompt, press Yes to launch application, or No to return to category list.

Note: The GET GOING menu will display all downloaded applications, with the most current download first.

How Keys Work

The following table lists keys and functions



Navigation Key: Use the navigation key to browse lists and highlight options.



CLR Key: A browser back-up key. Press once to back up one page. Press and hold to go back to home page.

Press to clear the last number, letter, or symbol entered. Press and hold to completely clear the display.



Asterisk/Shift Key: Press before entering text to enable upper case characters (in Abc mode).



O/Next Key: Press to enter a zero (0), or to display another word in the dictionary when in Word entry mode.



Pound/Space Key: Press to insert a space when entering text.



Numbers: Use the number keys to select items in a menu if they are numbered.1 - 9.



END Key: Press to exit VZW TODAY and return the phone to standby mode.



Left Soft Key: Press the left soft key to go to the highlighted web link and/or perform the function above it in the display.



Right Soft Key: The right soft key is the Menu key. Press this key to display a pop-up menu with several options.



SEND Key: Press to dial a highlighted number

Section 9: Multimedia

Section 10: Organizer

Topics Covered

- Calendar
- Alarm Clock
- World Clock
- Notepad
- Calculator
- Voice Services

The topics covered in this section allow you to schedule appointments, view the calendar, set an alarm, and perform simple math calculations.

Calendar

Schedule up to eight events for any day by indicating each event's start and end time. Set alarms for events so that you can be alerted before an event takes place. Events scheduled for future dates automatically appear on your Today events schedule.

Add a new event

- In standby mode, press the Menu, then press the right navigation key to Settings & Tools. Press Tools Calendar. The calendar appears in the display with the current date highlighted.
- 2. Press the right soft key Options. A pop-up menu appears in the display that contains the menu items..
 - Go To Date: Go to any date that you specify.
 - Go to Today: View today's events.
 - Erase Old: Select a past event to delete.
 - Erase All: Delete all events in your calendar
- 3. Press the left soft key 🗪 Add to add a new event.
- 4. The Appointment name field is highlighted. Enter the name and use the down navigation key to move to the following fields:
 - Start Date: Enter the start date for the event.
 - Start Time: Enter the start time for the event.
 - **AM/PM**: Select from A.M. or P.M. for the start time.
 - End Date: Enter the end date for the event.
 - End Time: Enter the end time for the event.
 - **AM/PM**: Select from A.M. or P.M for the end time.

- Ringer: Turn the alarm for the event on or off.
- **Reminder**: Set a reminder up to one day before the event.
- Fill in and select event details using the navigation keys and the alpha-numeric keypad.
- 6. Press (ox). The event is saved.

View an event

- In standby mode, press the Menu, then press the right navigation key to Settings & Tools. Press Tools
 Calendar.
- A calendar appears in the display with the current date highlighted.
- Use the navigation keys to highlight the date containing the event that you wish to view. If the event date is in another month, press the right soft key Options.

Tip: Use the volume key to move between months in the calendar.

- 4. In the pop-up menu that appears in the display, use the navigation key to highlight **Go To Date**, then press **3**.
- **5.** Enter the desired date in the box at the bottom of the display, then press . The month that you entered appears in the display with the event date highlighted.
- 6. Press View event details for the date.
- 7. To edit the event, press the left soft key Edit.
- 8. To save edits the selected event, press Save.
- **9.** Press the right soft key **Options**. A pop-up menu appears in the display.

Section 10: Organizer

10. To erase the current event, press ease. A pop-up menu appears with Yes highlighted. Press the key erase, or use the down navigation key to highlight No to cancel.

Alarm Clock

Your phone has an alarm clock that can be set to go off once, or recur daily at a specific time. Once set, the alarm clock is easy to change or turn off.

Set An Alarm

- In standby mode, press the Menu, then press the right navigation key to Settings & Tools. Press Tools Alarm Clock. The Alarm Clock menu displays with the Alarm 1 highlighted.
- 2. The following options appear in the display
 - Alarm 1
 - Alarm 2
 - Alarm 3
- 3. Use the navigation key to highlight the alarm that you wish to enable, then press . The Set Alarm (1, 2, or 3 depending on your selection) screen appears in the display.
- The Alarm field is highlighted. Use the left/right navigation key to select On or Off.
- Press the down navigation key to highlight the Time field, then enter the time that you wish for the alarm to sound.

- Press the down navigation key once to highlight the AM/ PM field. Use the left/right navigation keys to select AM or PM.
- 7. Press the down navigation key once to highlight the **Frequency** field. Use the left/right navigation keys to set the frequency (occurrence) of the alarm. Below lists and defines the options for this field.
 - **Once**: The alarm sounds only once, at the time specified.
 - **Daily**: The alarm sounds every day at the time specified.
 - Mon-Fri: The alarm sounds Monday through Friday at the time specified.
 - Weekends: The alarm sounds Saturday through Sunday at the time specified.
- Press the down navigation key once to highlight the Ringer field. Use the left/right navigation keys to set the alert tone.
- When all fields have correct information entered, press the SAVE key to save your settings.

Disable an alarm before it sounds

- In standby mode, press the Menu, then press the right navigation key to Settings & Tools. Press Tools Alarm Clock. The Alarm Clock menu displays with the Alarm 1 highlighted.
- 2. The following options appear in the display
 - Alarm 1
 - Alarm 2
 - Alarm 3

- The Alarm Clock menu displays with the Alarm 1 highlighted.
- **4.** Use the navigation key to highlight the alarm you wish to disable, then press the right soft key **Options**. A popup menu appears in the display.
- 5. Press and to reset the highlighted alarm or press of to reset all alarms.

Snooze

When an alarm sounds, a menu screen displays that allows you to either turn the alarm off or to have the alarm ring again after 5 minutes. This is called Snooze.

To use this feature follow these steps:

- Set one of your phone's 3 alarms. For more information about setting an alarm, see "Set An Alarm" on page 120.
- 2. When an alarm sounds, use the up/down navigation key to highlight Snooze or Dismiss. Press the left soft key Snooze to turn the alarm off and to set it to ring again after 5 minutes. Or, highlight Dismiss to turn the alarm off completely. The alarm turns off and the standby screen displays.

World Clock

World Clock allows you to view the time of day or night in any part of the world.

In standby mode, press the Menu, then press the right navigation key to Settings & Tools. Press World Clock.

- 2. Use the left soft key Cities to display the 45 supported cities. Press the key to save your entry.
- Press the right soft key Options to view the following options:
 - Set as Local Time: Sets the time according to the city chosen in the Cities field.
 - DST On: Sets the Daylight Savings time option.
- **4.** Press or to return to standby mode.

Notepad

Create and store notes in Notepad. You can prioritize or set an alert for stored notes. Return to Memo Pad anytime to review and edit your notes.

- In standby mode, press the Menu, then press the right navigation key to Settings & Tools. Press Tools Motepad. The Note Pad menu opens.
- If you have any stored notes, they appear as a list in the display. If this is your first time in Notepad, No Note displays.
- 3. To add a new memo, press the left soft key Add, then enter the memo using the keypad.
- 4. While entering a memo, press the left soft key Abc, to display a pop-up menu with the following text entry modes
 - Word
 - Abc
 - ABC
 - 123

Symbols

- **5.** Use the navigation keys to select the other available text entry modes of 123, Word, and Symbol, or press to exit the pop-up menu.
- When you're finished entering details for the note, pressThe note is saved.

Review, Add, Edit, and Erase Memos

- In standby mode, press the Menu, then press the right navigation key to Settings & Tools. Press Notepad. The Note Pad menu opens. If you have any stored notes, they appear as a list in the display.
- With a memo highlighted, press the right soft key for options. A pop-up menu with the options listed in the following table appears in the display:
 - Edit: Edit the note currently highlighted or appearing in the display.
 - Erase: Erase the note currently highlighted or appearing in the display.
 - Erase All: Erase all notes.
- 3. Use the navigation key to highlight an option or press to exit the pop-up menu.
- 4. Press or to perform the highlighted option's function.

Calculator

You can perform calculations, including addition, subtraction, multiplication and division using your phone.

- In standby mode, press the Menu, then press the right navigation key to Settings & Tools. Press Tools
 Calculator. The Calculator opens.
- 2. Enter the first number in your equation using the keypad. (Numbers can be up to nine digits long.)
- Press the right soft key Operator to display a pop-up menu which allows you to enter a Parenthesis or Power.
 Press the left soft key Clear to clear all data entered.
- **4.** Press 🖅 to change the sign for a number to a negative.
- **5.** Press the to add a decimal point.
- **6.** Use the navigation key to set the type of calculation that you wish to perform. Your choices are as follows.
 - [+] Addition
 - [-] Subtraction
 - [x] Multiplication
 - [÷] Division
- Use the keypad to enter the second number into your equation.
- 8. Press of to perform the calculation and view the result.

Voice Services

This menu set the voice services settings, create voice memos, and access Text To Speech (TTS). For more information about Voice Services, see "Voice Services Settings" on page 30.

Section 11: Mobile Web

Topics Covered

- · Mobile Web
- · Launching Mobile Web
- Exit Mobile Web
- · Navigate the Web
- · Mobile Web soft keys
- Links
- · Place a call while using Mobile Web

This section outlines the available gaming options and accessories for your phone. For more information, contact your service provider.

Section 11

Mobile Web

Note: This feature is currently unavailable outside of the United States. Only available within the Verizon Wireless Enhances Services Area.

Mobile Web allows you to surf the web from your wireless phone.

Note: If you receive a call while using Mobile Web, the application is put on hold during the call. Once the call ends, your Mobile Web session resumes where you left off. Only available within the Verizon Wireless Enhances Services Area

Note: Any time the service indicator icon is visible, you are connected to the Internet and billed accordingly. Rates and prices vary according to your service contract. For further information on billing contact Verizon Wireless. Only available within the Verizon Wireless Enhances Services Area

Launch Mobile Web

Note: This feature is currently unavailable outside of the United States. Only available within the Verizon Wireless Enhances Services Area.

- In standby mode, press the up navigation key. Mobile Web and a list of categories (representing one or more web sites) appears in the display.
- 2. Use the navigation key to browse the categories.
- 3. Once the desired category is highlighted, press or to enter the category list.

pection i

Exit Mobile Web

This feature is currently unavailable outside of the United States. Only available within the Verizon Wireless Enhances Services Area.

Press model to exit Mobile Web.

Navigate the Web

Note: This feature is currently unavailable outside of the United States. Only available within the Verizon Wireless Enhances Services Area.

When you use Mobile Web, some of the keys operate differently than during a normal phone call.

Mobile Web presents on-screen items in any of the following ways:

- Text or numeric input
- Links (embedded in content)
- Numbered options (some options may not be numbered)
- Simple text

You can act on the options or links by using the soft keys.

Mobile Web Soft Keys

Note: This feature is currently unavailable outside of the United States. Only available within the Verizon Wireless Enhances Services Area.

At the bottom of the Mobile Web display contains the browser commands. The left and right soft keys on the keypad are used to perform the commands in the display. These are called "soft keys" because their

Section 11: Mobile Web

function changes depending where you are in the application.

How Mobile Web keys work

The following table lists Mobile Web keys and functions.



Navigation Key: Use the navigation key to browse lists and highlight options.



CLR Key: A browser back-up key. Press once to back up one page. Press and hold to go back to Mobile Web home page.

Press to clear the last number, letter, or symbol entered. Press and hold to completely clear the display.



Asterisk/Shift Key: Press before entering text to enable upper case characters (in Abc mode).



O/Next Key: Press to enter a zero (0), or to display another word in the dictionary when in Word entry mode.



Pound/Space Key: Press to insert a space when entering text.



Numbers 1 - 9: Use the number keys to select items in a menu if they are numbered.



END Key: Press to exit Mobile Web and return the phone to standby mode.



Left Soft Key: Press the left soft key to go to the highlighted web link and/or perform the function above it in the display.

Section 11



Right Soft Key: The right soft key is the Menu key. Press this key to display a pop-up menu with several options.



SEND Key: Press to dial a highlighted number.

Links

Note: This feature is currently unavailable outside of the United States. Only available within the Verizon Wireless Enhances Services Area.

Links can serve several purposes, such as jumping to a different page, to a different site, or initiating a phone call. Links are shown inside of brackets ([]). Normally, the left soft key is used to select a highlighted link.

Place a Call While Using Mobile Web

Note: This feature is currently unavailable outside of the United States. Only available within the Verizon Wireless Enhances Services Area.

You can place a call while using Mobile Web if the website supports this feature. Press the appropriate soft key to call the number. In most cases you can also press to call the number. The Internet connection terminates when you initiate the call. After you end the call, your phone returns to standby mode.

0000001

Section 12: Health and Safety Information

Topics Covered

. Health and Safety Information

This section outlines the safety precautions associated with using your phone. These safety precautions should be followed to safety use your phone

Health and Safety Information

Exposure to Radio Frequency (RF) Signals

Certification Information (SAR)

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the exposure limits for radio frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. government. These FCC exposure limits are derived from the recommendations of two expert organizations, the National Counsel on Radiation Protection and Measurement (NCRP) and the Institute of Electrical and Electronics Engineers (IEEE). In both cases, the recommendations were developed by scientific and engineering experts drawn from industry, government, and academia after extensive reviews of the scientific literature related to the biological effects of RF energy.

The exposure limit set by the FCC for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate (SAR). The SAR is a measure of the rate of absorption of RF energy by the human body expressed in units of watts per kilogram (W/kg). The FCC requires wireless phones to comply with a safety limit of 1.6 watts per kilogram (1.6 W/kg). The FCC exposure limit incorporates a substantial margin of safety to give additional protection to the public and to account for any variations in measurements.

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC. Tests for each model phone are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC. Body-worn operations are restricted to Samsung-supplied, approved, or non-Samsung designated accessories that have no metal and must provide at least 1.5 cm separation between the device, including its antenna (whether extended or retracted) and the user's body. Non-compliance with the above restrictions may result in violation of FCC RF exposure guidelines.

The FCC has granted an Equipment Authorization for this mobile phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. The maximum SAR values for this model phone as reported to the FCC are:

- Head: 1.45 W/Kg.
- Body-worn: . 1.02 W/Kg.

SAR information on this and other model phones can be viewed on-line at www.fcc.gov/oet/fccid. To find information that pertains to a particular model phone, this site uses the phone FCC ID number which is usually printed somewhere on the case of the phone. Sometimes it may be necessary to remove the battery pack to find the number. Once you have the FCC ID number for a particular phone, follow the instructions on the website and it should provide values for typical or maximum SAR for a particular phone. Additional product specific SAR information can also be obtained at www.fcc.gov/cgb/sar.

Consumer Information on Wireless Phones

The U.S. Food and Drug Administration (FDA) has published a series of Questions and Answers for consumers relating to radio frequency (RF) exposure from wireless phones. The FDA publication includes the following information:

What kinds of phones are the subject of this update?

The term wireless phone refers here to hand-held wireless phones with built-in antennas, often called "cell," "mobile," or "PCS" phones. These types of wireless phones can expose the user to measurable radio frequency energy (RF) because of the short distance between the phone and the user's head. These RF exposures are limited by Federal Communications Commission safety guidelines that were developed with the advice of FDA and other federal health and

safety agencies. When the phone is located at greater distances from the user, the exposure to RF is drastically lower because a person's RF exposure decreases rapidly with increasing distance from the source. The so-called "cordless phones," which have a base unit connected to the telephone wiring in a house, typically operate at far lower power levels, and thus produce RF exposures well within the FCC's compliance limits.

Do wireless phones pose a health hazard?

The available scientific evidence does not show that any health problems are associated with using wireless phones. There is no proof, however, that wireless phones are absolutely safe. Wireless phones emit low levels of radio frequency energy (RF) in the microwave range while being used. They also emit very low levels of RF when in the stand-by mode. Whereas high levels of RF can produce health effects (by heating tissue), exposure to low level RF that does not produce heating effects causes no known adverse health effects. Many studies of low level RF exposures have not found any biological effects. Some studies have suggested that some biological effects may occur, but such findings have not been confirmed by additional research. In some cases, other researchers have had difficulty in reproducing those studies, or in determining the reasons for inconsistent results.

What is FDA's role concerning the safety of wireless phones?

Under the law, FDA does not review the safety of radiation-emitting consumer products such as wireless phones before they can be sold, as it does with new drugs or medical devices. However, the agency has authority to take action if wireless phones are shown to emit radio frequency energy (RF) at a level that is hazardous to the user. In such a case, FDA could require the manufacturers of wireless phones to notify users of the health hazard and to repair, replace or recall the phones so that the hazard no longer exists.

Although the existing scientific data do not justify FDA regulatory actions, FDA has urged the wireless phone industry to take a number of steps, including the following:

- "Support needed research into possible biological effects of RF of the type emitted by wireless phones;
- "Design wireless phones in a way that minimizes any RF exposure to the user that is not necessary for device function; and
- "Cooperate in providing users of wireless phones with the best possible information on possible effects of wireless phone use on human health.

FDA belongs to an interagency working group of the federal agencies that have responsibility for different aspects of RF safety to ensure coordinated efforts at the federal level. The following agencies belong to this working group:

- "National Institute for Occupational Safety and Health
- "Environmental Protection Agency

- "Federal Communications Commission
- "Occupational Safety and Health Administration
- "National Telecommunications and Information Administration

The National Institutes of Health participates in some interagency working group activities, as well.

FDA shares regulatory responsibilities for wireless phones with the Federal Communications Commission (FCC). All phones that are sold in the United States must comply with FCC safety guidelines that limit RF exposure. FCC relies on FDA and other health agencies for safety questions about wireless phones.

FCC also regulates the base stations that the wireless phone networks rely upon. While these base stations operate at higher power than do the wireless phones themselves, the RF exposures that people get from these base stations are typically thousands of times lower than those they can get from wireless phones. Base stations are thus not the primary subject of the safety questions discussed in this document.

What are the results of the research done already?

The research done thus far has produced conflicting results, and many studies have suffered from flaws in their research methods. Animal experiments investigating the effects of radio frequency energy (RF) exposures characteristic of wireless phones have yielded conflicting results that often cannot be repeated in other laboratories. A few animal studies, however, have suggested that low levels of RF could accelerate the development of cancer in laboratory animals. However, many of the studies that showed increased

tumor development used animals that had been genetically engineered or treated with cancer-causing chemicals so as to be pre-disposed to develop cancer in absence of RF exposure. Other studies exposed the animals to RF for up to 22 hours per day. These conditions are not similar to the conditions under which people use wireless phones, so we don't know with certainty what the results of such studies mean for human health.

Three large epidemiology studies have been published since December 2000. Between them, the studies investigated any possible association between the use of wireless phones and primary brain cancer, glioma, meningioma, or acoustic neuroma, tumors of the brain or salivary gland, leukemia, or other cancers. None of the studies demonstrated the existence of any harmful health effects from wireless phones RF exposures. However, none of the studies can answer questions about long-term exposures, since the average period of phone use in these studies was around three years.

What research is needed to decide whether RF exposure from wireless phones poses a health risk?

A combination of laboratory studies and epidemiological studies of people actually using wireless phones would provide some of the data that are needed. Lifetime animal exposure studies could be completed in a few years. However, very large numbers of animals would be needed to provide reliable proof of a cancer promoting effect if one exists. Epidemiological studies can provide data that is directly applicable to human populations, but ten or

more years' follow-up may be needed to provide answers about some health effects, such as cancer. This is because the interval between the time of exposure to a cancer-causing agent and the time tumors develop - if they do - may be many, many years. The interpretation of epidemiological studies is hampered by difficulties in measuring actual RF exposure during day-to-day use of wireless phones. Many factors affect this measurement, such as the angle at which the phone is held, or which model of phone is used.

What is FDA doing to find out more about the possible health effects of wireless phone RF?

FDA is working with the U.S. National Toxicology Program and with groups of investigators around the world to ensure that high priority animal studies are conducted to address important questions about the effects of exposure to radio frequency energy (RF).

FDA has been a leading participant in the World Health Organization international Electromagnetic Fields (EMF) Project since its inception in 1996. An influential result of this work has been the development of a detailed agenda of research needs that has driven the establishment of new research programs around the world. The Project has also helped develop a series of public information documents on EMF issues.

FDA and Cellular Telecommunications & Internet Association (CTIA) have a formal Cooperative Research and Development Agreement (CRADA) to do research on wireless phone safety. FDA provides the scientific oversight, obtaining input from experts in government, industry, and academic organizations.

CTIA-funded research is conducted through contracts to independent investigators. The initial research will include both laboratory studies and studies of wireless phone users. The CRADA will also include a broad assessment of additional research needs in the context of the latest research developments around the world.

What steps can I take to reduce my exposure to radio frequency energy from my wireless phone?

If there is a risk from these products - and at this point we do not know that there is - it is probably very small. But if you are concerned about avoiding even potential risks, you can take a few simple steps to minimize your exposure to radio frequency energy (RF). Since time is a key factor in how much exposure a person receives, reducing the amount of time spent using a wireless phone will reduce RF exposure.

 If you must conduct extended conversations by wireless phone every day, you could place more distance between your body and the source of the RF, since the exposure level drops off dramatically with distance. For example, you could use a headset and carry the wireless phone away from your body or use a wireless phone connected to a remote antenna.

Again, the scientific data do not demonstrate that wireless phones are harmful. But if you are concerned about the RF exposure from these products, you can use measures like those described above to reduce your RF exposure from wireless phone use.

What about children using wireless phones?

The scientific evidence does not show a danger to users of wireless phones, including children and teenagers. If you want to take steps to lower exposure to radio frequency energy (RF), the measures described above would apply to children and teenagers using wireless phones. Reducing the time of wireless phone use and increasing the distance between the user and the RF source will reduce RF exposure.

Some groups sponsored by other national governments have advised that children be discouraged from using wireless phones at all. For example, the government in the United Kingdom distributed leaflets containing such a recommendation in December 2000. They noted that no evidence exists that using a wireless phone causes brain tumors or other ill effects. Their recommendation to limit wireless phone use by children was strictly precautionary; it was not based on scientific evidence that any health hazard exists.

Do hands-free kits for wireless phones reduce risks from exposure to RF emissions?

Since there are no known risks from exposure to RF emissions from wireless phones, there is no reason to believe that hands-free kits reduce risks. Hands-free kits can be used with wireless phones for convenience and comfort. These systems reduce the absorption of RF energy in the head because the phone, which is the source of the RF emissions, will not be placed against the head. On the other hand, if the phone is mounted against the waist or other part of the body during use, then that part of the body will absorb more RF energy. Wireless phones marketed in the U.S. are required to meet safety requirements regardless of whether they are used against the head or against the body. Either

configuration should result in compliance with the safety limit.

Do wireless phone accessories that claim to shield the head from RF radiation work?

Since there are no known risks from exposure to RF emissions from wireless phones, there is no reason to believe that accessories that claim to shield the head from those emissions reduce risks. Some products that claim to shield the user from RF absorption use special phone cases, while others involve nothing more than a metallic accessory attached to the phone. Studies have shown that these products generally do not work as advertised. Unlike "hand-free" kits, these so-called "shields" may interfere with proper operation of the phone. The phone may be forced to boost its power to compensate, leading to an increase in RF absorption. In February 2002, the Federal trade Commission (FTC) charged two companies that sold devices that claimed to protect wireless phone users from radiation with making false and unsubstantiated claims. According to FTC, these defendants lacked a reasonable basis to substantiate their claim.

What about wireless phone interference with medical equipment?

Radio frequency energy (RF) from wireless phones can interact with some electronic devices. For this reason, FDA helped develop a detailed test method to measure electromagnetic interference (EMI) of implanted cardiac pacemakers and defibrillators from wireless telephones. This test method is now part of a standard

sponsored by the Association for the Advancement of Medical instrumentation (AAMI). The final draft, a joint effort by FDA, medical device manufacturers, and many other groups, was completed in late 2000. This standard will allow manufacturers to ensure that cardiac pacemakers and defibrillators are safe from wireless phone EMI. FDA has tested wireless phones and helped develop a voluntary standard sponsored by the Institute of Electrical and Electronic Engineers (IEEE). This standard specifies test methods and performance requirements for hearing aids and wireless phones so that no interference occurs when a person uses a compatible phone and a compatible hearing aid at the same time. This standard was approved by the IEEE in 2000.

FDA continues to monitor the use of wireless phones for possible interactions with other medical devices. Should harmful interference be found to occur, FDA will conduct testing to assess the interference and work to resolve the problem.

Additional information on the safety of RF exposures from various sources can be obtained from the following organizations:

- FCC RF Safety Program: http://www.fcc.gov/oet/rfsafety/
- Environmental Protection Agency (EPA): <u>http://www.epa.gov/radiation/</u>
- Occupational Safety and Health Administration's (OSHA): http://www.osha.slc.gov/SLTC/radiofrequencyradiation/index.html
- National institute for Occupational Safety and Health (NIOSH): http://www.cdc.gov/niosh/emfpg.html

- World health Organization (WHO): http://www.who.int/peh-emf/
- International Commission on Non-Ionizing Radiation Protection: http://www.icnirp.de
- National Radiation Protection Board (UK): http://www.nrpb.org.uk
- Updated 4/3/2002: US food and Drug Administration http://www.fda.gov/cellphones

Road Safety

Your wireless phone gives you the powerful ability to communicate by voice, almost anywhere, anytime. But an important responsibility accompanies the benefits of wireless phones, one that every user must uphold.

When driving a car, driving is your first responsibility. When using your wireless phone behind the wheel of a car, practice good common sense and remember the following tips:

- Get to know your wireless phone and its features, such as speed dial and redial. If available, these features help you to place your call without taking your attention off the road.
- 2. When available, use a hands-free device. If possible, add an additional layer of convenience and safety to your wireless phone with one of the many hands free accessories available today.
- Position your wireless phone within easy reach. Be able to access your wireless phone without removing your eyes from the road. If you get an incoming call at an inconvenient time, let your voice mail answer it for you.

- 4. Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions. Rain, sleet, snow, ice and even heavy traffic can be hazardous.
- Do not take notes or look up phone numbers while driving. Jotting down a "to do" list or flipping through your address book takes attention away from your primary responsibility, driving safely.
- 6. Dial sensibly and assess the traffic; if possible, place calls when you are not moving or before pulling into traffic. Try to plan calls when your car will be stationary. If you need to make a call while moving, dial only a few numbers, check the road and your mirrors, then continue.
- 7. Do not engage in stressful or emotional conversations that may be distracting. Make people you are talking with aware you are driving and suspend conversations that have the potential to divert your attention from the road.
- 8. Use your wireless phone to call for help. Dial 9-1-1 or other local emergeny number in the case of fire, traffic accident or medical emergencies. Remember, it is a free call on your wireless phone!
- 9. Use your wireless phone to help others in emergencies. If you see an auto accident, crime in progress or other serious emergency where lives are in danger, call 9-1-1 or other local emergency number, as you would want others to do for you.

10. Call roadside assistance or a special non-emergency wireless assistance number when necessary. If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency number.

"The wireless industry reminds you to use your phone safely when driving."

For more information, please call 1-888-901-SAFE, or visit our web-site www.wow-com.com

Provided by the Cellular Telecommunications & Internet Association

Operating Environment

Remember to follow any special regulations in force in any area and always switch your phone off whenever it is forbidden to use it, or when it may cause interference or danger. When connecting the phone or any accessory to another device, read its user's guide for detailed safety instructions. Do not connect incompatible products.

As with other mobile radio transmitting equipment, users are advised that for the satisfactory operation of the equipment and

for the safety of personnel, it is recommended that the equipment should only be used in the normal operating position (held to your ear with the antenna pointing over your shoulder).

Using Your Phone Near Other Electronic Devices

Most modern electronic equipment is shielded from radio frequency (RF) signals. However, certain electronic equipment may not be shielded against the RF signals from your wireless phone. Consult the manufacturer to discuss alternatives.

Pacemakers

Pacemaker manufacturers recommend that a minimum distance of 15 cm (6 inches) be maintained between a wireless phone and a pacemaker to avoid potential interference with the pacemaker.

These recommendations are consistent with the independent research and recommendations of Wireless Technology Research.

Persons with pacemakers:

- should always keep the phone more than 15 cm (6 inches) from their pacemaker when the phone is switched on.
- should not carry the phone in a breast pocket.
- should use the ear opposite the pacemaker to minimize potential interference.

If you have any reason to suspect that interference is taking place, switch your phone off immediately.

Hearing Aids

When some mobile phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise, and phones also vary in the amount of interference they generate.

The wireless telephone industry has developed ratings for some of their mobile phones, to assist hearing device users in finding phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that are rated have the rating on their box or a label on the box.

The ratings are not guarantees. Results will vary depending on the user's hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs.

M-Ratings: Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. M4 is the better/higher of the two ratings.

T-Ratings: Phones rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing device's telecoil ("T Switch" or "Telephone Switch") than unrated phones. T4 is the better/higher of the two ratings. (Note that not all hearing devices have telecoils in them.)

Hearing devices may also be measured for immunity to this type of interference. Your hearing device manufacturer or hearing health professional may help you find results for your hearing device. The more immune your hearing aid is, the less likely you are to experience interference noise from mobile phones.

Other Medical Devices

If you use any other personal medical devices, consult the manufacturer of your device to determine if it is adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information. Switch your phone off in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer or its representative regarding your vehicle. You should also consult the manufacturer of any equipment that has been added to your vehicle.

Posted Facilities

Switch your phone off in any facility where posted notices requireyou to do so.

Potentially Explosive Environments

Switch your phone off when in any area with a potentially explosive atmosphere and obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

Users are advised to switch the phone off while at a refueling point (service station). Users are reminded of

the need to observe restrictions on the use of radio equipment in fuel depots

(fuel storage and distribution areas), chemical plants or where blasting operations are in progress.

Areas with a potentially explosive atmosphere are often but not always clearly marked. They include below deck on boats, chemical transfer or storage facilities, vehicles using liquefied petroleum gas (such as propane or butane), areas where the air contains chemicals or particles, such as grain, dust or metal powders, and any other area where you would normally be advised to turn off your vehicle engine.

Emergency Calls

This phone, like any wireless phone, operates using radio signals, wireless and landline networks as well as user-programmed functions, which cannot guarantee connection in all conditions. Therefore, you should never rely solely on any wireless phone for essential communications (medical emergencies, for example).

Remember, to make or receive any calls the phone must be switched on and in a service area with adequate signal strength. Emergency calls may not be possible on all wireless phone networks or when certain network services and/or phone features are in use. Check with local service providers.

To make an emergency call:

1. If the phone is not on, switch it on.

- Key in the emergency number for your present location (for example, 911 or other official emergency number). Emergency numbers vary by location.
- 3. Press the <a> key.

If certain features are in use (call barring, for example), you may first need to deactivate those features before you can make an emergency call. Consult this document and your local cellular service provider.

When making an emergency call, remember to give all the necessary information as accurately as possible. Remember that your phone may be the only means of communication at the scene of an accident; do not cut off the call until given permission to do so.

Restricting Children's access to your Phone

Your phone is not a toy. Children should not be allowed to play with it because they could hurt themselves and others, damage the phone or make calls that increase your phone bill.

FCC Notice and Cautions

FCC Notice

The phone may cause TV or radio interference if used in close proximity to receiving equipment. The FCC can require you to stop using the phone if such interference cannot be eliminated.

Vehicles using liquefied petroleum gas (such as propane or butane) must comply with the National Fire Protection Standard (NFPA-58). For a copy of this standard, contact the National Fire Protection

Association, One Batterymarch Park, Quincy, MA 02269, Attn: Publication Sales Division.

Cautions

Any changes or modifications to your phone not expressly approved in this document could void your warranty for this equipment, and void your authority to operate this equipment. Only use approved batteries, antennas and chargers. The use of any unauthorized accessories may be dangerous and void the phone warranty if said accessories cause damage or a defect to the phone.

Although your phone is quite sturdy, it is a complex piece of equipment and can be broken. Avoid dropping, hitting, bending or sitting on it.

Other Important Safety Information

- Only qualified personnel should service the phone or install the phone in a vehicle. Faulty installation or service may be dangerous and may invalidate any warranty applicable to the device.
- Check regularly that all wireless phone equipment in your vehicle is mounted and operating properly.
- Do not store or carry flammable liquids, gases or explosive materials in the same compartment as the phone, its parts or accessories.
- For vehicles equipped with an air bag, remember that an air bag inflates with great force. Do not place objects, including both installed or portable wireless equipment in the area over the air bag or in the air bag deployment area. If wireless equipment is improperly installed and the air bag inflates, serious injury could result.

- Switch your phone off before boarding an aircraft. The use of wireless phone in aircraft is illegal and may be dangerous to the aircraft's operation.
- Failure to observe these instructions may lead to the suspension or denial of telephone services to the offender, or legal action, or both.

Product Performance

Getting the Most Out of Your Signal Reception

The quality of each call you make or receive depends on the signal strength in your area. Your phone informs you of the current signal strength by displaying a number of bars next to the signal strength icon. The more bars displayed, the stronger the signal.

If you're inside a building, being near a window may give you better reception.

Understanding the Power Save Feature

If your phone is unable to find a signal after 15 minutes of searching, a Power Save feature is automatically activated. If your phone is active, it periodically rechecks service availability or you can check it yourself by pressing any key.

Anytime the Power Save feature is activated, a message displays on the screen. When a signal is found, your phone returns to standby mode.

Understanding How Your Phone Operates

Your phone is basically a radio transmitter and receiver. When it's turned on, it receives and transmits radio frequency (RF) signals. When you use your phone, the system handling your call controls the power level.

This power can range from 0.006 watts to 0.2 watts in digital mode.

Maintaining Your Phone's Peak Performance

For the best care of your phone, only authorized personnel should service your phone and accessories. Faulty service may void the warranty.

There are several simple guidelines to operating your phone properly and maintaining safe, satisfactory service.

- Hold the phone with the antenna raised, fully-extended and over your shoulder.
- Try not to hold, bend or twist the phone's antenna.
- Don't use the phone if the antenna is damaged.
- Speak directly into the phone's receiver.
- Avoid exposing your phone and accessories to rain or liquid spills. If your phone does get wet, immediately turn the power off and remove the battery. If it is inoperable, call Customer Care for service.

Availability of Various Features/Ring Tones

Many services and features are network dependent and may require additional subscription and/or usage charges. Not all features are available for purchase or use in all areas. Downloadable Ring Tones may be available at an additional cost. Other conditions and restrictions may apply. See your service provider for additional information.

Battery Standby and Talk Time

Standby and talk times will vary depending on phone usage patterns and conditions. Battery power **156**

consumption depends on factors such as network configuration, signal strength, operating temperature, features selected, frequency of calls, and voice, data, and other application usage patterns.

Battery Precautions

- Avoid dropping the cell phone. Dropping it, especially on a hard surface, can potentially cause damage to the phone and battery. If you suspect damage to the phone or battery, take it to a service center for inspection.
- Never use any charger or battery that is damaged in any way.
- Use the battery only for its intended purpose.
- If you use the phone near the network's base station, it uses less power; talk and standby time are greatly affected by the signal strength on the cellular network and the parameters set by the network operator.
- Follow battery usage, storage and charging guidelines found in the user's guide.
- Battery charging time depends on the remaining battery charge and the type of battery and charger used. The battery can be charged and discharged hundreds of times, but it will gradually wear out. When the operation time (talk time and standby time) is noticeably shorter than normal, it is time to buy a new battery.
- If left unused, a fully charged battery will discharge itself over time.
- Use only Samsung-approved batteries and recharge your battery only with Samsung-approved chargers. When a charger is not in use, disconnect it from the power source. Do not leave the battery connected to a charger for more than a week, since overcharging may shorten its life.
- Do not use incompatible cell phone batteries and chargers.
 Some Web sites and second-hand dealers, not associated with reputable manufacturers and carriers, might be selling incompatible or even counterfeit batteries and chargers.

- Consumers should purchase manufacturer or carrier recommended products and accessories. If unsure about whether a replacement battery or charger is compatible, contact the manufacturer of the battery or charger.
- Extreme temperatures will affect the charging capacity of your battery: it may require cooling or warming first.
- Do not leave the battery in hot or cold places, such as in a car in summer or winter conditions, as you will reduce the capacity and lifetime of the battery. Always try to keep the battery at room temperature. A phone with a hot or cold battery may temporarily not work, even when the battery is fully charged. Li-ion batteries are particularly affected by temperatures below 0 °C (32 °F).
- Do not place the phone in areas that may get very hot, such as on or near a cooking surface, cooking appliance, iron, or radiator.
- Do not get your phone or battery wet. Even though they will dry and appear to operate normally, the circuitry could slowly corrode and pose a safety hazard.
- Do not short-circuit the battery. Accidental short- circuiting can occur when a metallic object (coin, clip or pen) causes a direct connection between the + and - terminals of the battery (metal strips on the battery), for example when you carry a spare battery in a pocket or bag. Short-circuiting the terminals may damage the battery or the object causing the short-circuiting.
- Do not permit a battery out of the phone to come in contact with metal objects, such as coins, keys or jewelry.
- Do not crush, puncture or put a high degree of pressure on the battery as this can cause an internal short-circuit, resulting in overheating.
- Dispose of used batteries in accordance with local regulations. In some areas, the disposal of batteries in household or business trash may be prohibited. For safe disposal options for Li-lon batteries, contact your nearest Samsung authorized service center. Always recycle. Do not dispose of batteries in a fire.

Care and Maintenance

Your phone is a product of superior design and craftsmanship and should be treated with care. The suggestions below will help you fulfill any warranty obligations and allow you to enjoy this product for many years

- Keep the phone and all its parts and accessories out of the reach of small children's.
- Keep the phone dry. Precipitation, humidity and liquids contain minerals that will corrode electronic circuits.
- Do not use the phone with a wet hand. Doing so may cause an electric shock to you or damage to the phone.
- Do not use or store the phone in dusty, dirty areas, as its moving parts may be damaged.
- Do not store the phone in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
- Do not store the phone in cold areas. When the phone warms up to its normal operating temperature, moisture can form inside the phone, which may damage the phone's electronic circuit boards.
- Do not drop, knock or shake the phone. Rough handling can break internal circuit boards.
- Do not use harsh chemicals, cleaning solvents or strong detergents to clean the phone. Wipe it with a soft cloth slightly dampened in a mild soap-and-water solution.
- Do not paint the phone. Paint can clog the device's moving parts and prevent proper operation.
- Do not put the phone in or on heating devices, such as a microwave oven, a stove or a radiator. The phone may explode when overheated

- Use only the supplied or an approved replacement antenna.
 Unauthorized antennas or modified accessories may damage the phone and violate regulations governing radio devices.
- If the phone, battery, charger or any accessory is not working properly, take it to your nearest qualified service facility. The personnel there will assist you, and if necessary, arrange for service.

Section 1:

Section 13: Warranty Information

Topics Covered

• Standard Limited Warranty

This section explains the warranty information for your new phone.

Standard Limited Warranty

What is Covered and For How Long? SAMSUNG

TELECOMMUNICATIONS AMERICA, L.P. ("SAMSUNG") warrants to the original purchaser ("Purchaser") that SAMSUNG's Phones and accessories ("Products") are free from defects in material and workmanship under normal use and service for the period commencing upon the date of purchase and continuing for the following specified period of time after that date:

Phone 1 Year
Batteries 1 Year
Leather Case/ Pouch 90 Days
Holster 90 Days
Other Phone Accessories 1 Year

What is Not Covered? This Limited Warranty is conditioned upon proper use of Product by Purchaser. This Limited Warranty does not cover: (a) defects or damage resulting from accident, misuse, abuse, neglect, unusual physical, electrical or electromechanical stress, or modification of any part of Product, including antenna, or cosmetic damage; (b) equipment that has the serial number removed or made illegible; (c) any plastic surfaces or other externally exposed parts that are scratched or damaged due to normal use; (d) malfunctions resulting from the use of Product in conjunction with accessories, products, or

ancillary/peripheral equipment not furnished or approved by SAMSUNG; (e) defects or damage from improper testing, operation, maintenance, installation, or adjustment; (f) installation, maintenance, and service of Product, or (g) Product used or purchased outside the United States or Canada. This Limited Warranty covers batteries only if battery capacity falls below 80% of rated capacity or the battery leaks, and this Limited Warranty does not cover any battery if (i) the battery has been charged by a battery charger not specified or approved by SAMSUNG for charging the battery, (ii) any of the seals on the battery are broken or show evidence of tampering, or (iii) the battery has been used in equipment other than the SAMSUNG phone for which it is specified.

What are SAMSUNG's Obligations? During the applicable warranty period, SAMSUNG will repair or replace, at SAMSUNG's sole option, without charge to Purchaser, any defective component part of Product. To obtain service under this Limited Warranty, Purchaser must return Product to an authorized phone service facility in an adequate container for shipping, accompanied by Purchaser's sales receipt or comparable substitute proof of sale showing the date of purchase, the serial number of Product and the sellers' name and address. To obtain assistance on where to deliver the Product, call Samsung Customer Care at 1-888-987-4357. Upon receipt, SAMSUNG will promptly repair or replace the defective Product. SAMSUNG may, at SAMSUNG's sole option, use rebuilt, reconditioned, or new parts or components when repairing any Product or replace Product with a rebuilt, reconditioned or new Product. Repaired/ replaced leather cases, pouches and holsters will be

warranted for a period of ninety (90) days. All other repaired/replaced Product will be warranted for a period equal to the remainder of the original Limited Warranty on the original Product or for 90 days, whichever is longer. All replaced parts, components, boards and equipment shall become the property of SAMSUNG. If SAMSUNG determines that any Product is not covered by this Limited Warranty, Purchaser must pay all parts, shipping, and labor charges for the repair or return of such Product.

WHAT ARE THE LIMITS ON SAMSUNG'S WARRANTY/LIABILITY? EXCEPT ASSET FORTH IN THE EXPRESS WARRANTY CONTAINED HEREIN, PURCHASER TAKES THE PRODUCT "AS IS," AND SAMSUNG MAKES NO WARRANTY OR REPRESENTATION AND THERE ARE NO CONDITIONS, EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT, INCLUDING BUT NOT LIMITED TO:

- "THE MERCHANTABILITY OF THE PRODUCT OR ITS FITNESS FOR ANY PARTICULAR PURPOSE OR USE;
- "WARRANTIES OF TITLE OR NON-INFRINGEMENT;
- "DESIGN, CONDITION, QUALITY, OR PERFORMANCE OF THE PRODUCT:
- "THE WORKMANSHIP OF THE PRODUCT OR THE COMPONENTS CONTAINED THEREIN; OR
- "COMPLIANCE OF THE PRODUCT WITH THE REQUIREMENTS OF ANY LAW, RULE, SPECIFICATION OR CONTRACT PERTAINING THERETO.

NOTHING CONTAINED IN THE INSTRUCTION MANUAL SHALL BE CONSTRUED TO CREATE AN

EXPRESS WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT. ALL IMPLIED WARRANTIES AND CONDITIONS THAT MAY ARISE BY OPERATION OF LAW, INCLUDING IF APPLICABLE THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY LIMITED TO THE SAME DURATION OF TIME AS THE EXPRESS WRITTEN WARRANTY STATED HEREIN. SOME STATES/PROVINCES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. IN ADDITION, SAMSUNG SHALL NOT BE LIABLE FOR ANY DAMAGES OF ANY KIND

RESULTING FROM THE PURCHASE, USE, OR MISUSE OF, OR INABILITY TO USE THE PRODUCT OR ARISING DIRECTLY OR INDIRECTLY FROM THE USE OR LOSS OF USE OF THE PRODUCT OR FROM THE BREACH OF THE EXPRESS WARRANTY, INCLUDING INCIDENTAL, SPECIAL, CONSEQUENTIAL OR SIMILAR DAMAGES, OR LOSS OF ANTICIPATED PROFITS OR BENEFITS, OR FOR DAMAGES ARISING FROM ANY TORT (INCLUDING NEGLIGENCE OR GROSS NEGLIGENCE) OR FAULT COMMITTED BY SAMSUNG, ITS AGENTS OR EMPLOYEES, OR FOR ANY BREACH OF CONTRACT OR FOR ANY CLAIM BROUGHT AGAINST PURCHASER BY ANY OTHER PARTY. SOME STATES/PROVINCES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO

YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE / PROVINCE TO PROVINCE. THIS LIMITED WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL PURCHASER OF THIS PRODUCT AND STATES PURCHASER'S EXCLUSIVE REMEDY, IF ANY PORTION OF THIS LIMITED WARRANTY IS HELD ILLEGAL OR UNENFORCEABLE BY REASON OF ANY LAW, SUCH PARTIAL ILLEGALITY OR UNENFORCEABILITY SHALL NOT AFFECT THE ENFORCEABILITY FOR THE REMAINDER OF THIS LIMITED WARRANTY WHICH PURCHASER ACKNOWLEDGES IS AND WILL ALWAYS BE CONSTRUED TO BE LIMITED BY ITS TERMS OR AS LIMITED AS THE LAW PERMITS. THE PARTIES UNDERSTAND THAT THE PURCHASER MAY USE THIRD-PARTY SOFTWARE OR **EQUIPMENT IN CONJUNCTION WITH THE** PRODUCT. SAMSUNG MAKES NO WARRANTIES OR REPRESENTATIONS AND THERE ARE NO CONDITIONS, EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, AS TO THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE OR SUITABILITY OF ANY THIRDPARTY SOFTWARE OR EOUIPMENT, WHETHER SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT IS INCLUDED WITH THE PRODUCT DISTRIBUTED BY SAMSUNG OR OTHERWISE, INCLUDING THE ABILITY TO INTEGRATE ANY SUCH SOFTWARE OR EOUIPMENT WITH THE PRODUCT. THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE AND SUITABILITY

OF ANY SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT LIE SOLELY WITH THE PURCHASER AND THE DIRECT VENDOR, OWNER OR SUPPLIER OF SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT, AS THE CASE MAY BE.

This Limited Warranty allocates risk of Product failure between Purchaser and SAMSUNG, and SAMSUNG's Product pricing reflects this allocation of risk and the limitations of liability contained in this Limited Warranty. The agents, employees, distributors, and dealers of SAMSUNG are not authorized to make modifications to this Limited Warranty, or make additional warranties binding on SAMSUNG. Accordingly, additional statements such as dealer advertising or presentation, whether oral or written, do not constitute warranties by SAMSUNG and should not be relied upon.

Samsung Telecommunications America, L.P.

1301 East Lookout Drive

Richardson, Texas 75082

Phone: 1-800-SAMSUNG

Phone: 1-888-987-HELP (4357)

©2005 Samsung Telecommunications America, L.P. All

rights reserved.

No reproduction in whole or in part allowed without prior written approval. Specifications and availability subject to change without notice.

subject to change without notice.

Printed in China

Index

	Call history
Numerics	calls using_ 27
2-touch dialing 71	definition_ 25
3-touch dialing 72	deleting entry_ 27
911, notes about 96	icons_ 26
A	new contact_ 27
· ·	Call Settings 103
Adding a New Contact En-	Callback # 102
try 63	Change lock 96
Alarm clock	Charger, travel 21
snooze 122	Clear key 15
turn off the alarm 121	Command Keys 14
All sounds off 18	Contacts
Answer options 103	pause 65
Auto answer 104	Contrast 92
Auto answer icon 18	Creating and Sending New
Auto delete 102	Messages 85
Auto retry 104	Creating and Sending Pix
В	=
Backlight settings 91	message 86
Backup to last menu 48	Creating and Sending Text
Banner, creating 91	message 85
•	D
Battery	Data sub menu 105
charging 20 indicator 21	Dialing
removing 20	one-touch 71
strength icon 18	three-touch 72
C	two-touch 71
Call Functions 23	Disable alarm 121
Answering a Call 24	Display
Alloworing a ball 24	animation 93

Call Histories 25 Roaming 28

backlight 91 language 99 screen icons 16 Display Themes 93 Draft messages 81 Drafts folder 81 E Emergency numbers	Get Pix 109 Get Tunes & Tones 108 Getting Started 5 Activating Your Phone 6 Understanding this User Manual 7 Voicemail 6 GPS icons 18
End key 15 Entering Text 55 Changing the Text Entry Mode 56 Entering Numbers 59 Entering Symbols 58 Entering Upper and Lower Case 57 Using Word Mode 57 Events, viewing calendar	creating 67 move entries from/to 66 send messages to 67 send pix msg to 68 viewing 66 H Hard pause 65 Health and Safety Information 133
Fast fact, description 7 Finding a Contacts Entry 69 Finding My Phone Number 72 Folder drafts 81 inbox 79 G	Icons All sounds off 18 battery strength 18 display 16 signal strength 16 TTY 18 Inbox folder 79 Indicator battery strength 18 new message 18 no service 17 roaming 17
Get News & Info 112	signal strength 16, 17 vibrate mode 18

Instant Messaging 88 In-use menu 49 L Language setting 99 Launch Mobile Web 128 Left soft key 14 Links 131 Location 98 Lock code, changing 96 Lock phone 95 M Memos, editing 124 Menu Navigation 47 Menu Outline 50	Multimedia 107 My phone # 72 N Navigate the Web 129 Navigation key 16 Navigation key shortcuts 48 New message icon 18 No service indicator 17 Note pad 123 Notes and tips 7 Notes, description 7 O Organizer
Menu shortcuts 48 Menu, in-use option 49 Message folder drafts 81	note pad 123 view an event 119 world time 122
inbox 79 Messages, receive in call 78 Messaging 75 Types of Messages 76 Mobile IM 88 Mobile Web 127 Keys 114 soft keys 129 Mode call answer 103 entry 101 Msg Setting 100	Personal Organizer 117 Alarm 120 Calculator 124 Calendar 118 Pix messages view later 79 PIX Services 112 Place a call while using Mobile Web 131 Planner add a new event 118 Powering off 6 Powering on 6

R	Set an alarm 120
Receive messages in call	Settings 89, 94
78	backlight 91
Receive text messages 83	banner 91
Receiving a PIX Message	change lock 96
•	Display Settings 90
78	language 99
Removing battery 20	lock phone 95
Reset phone 106	Resetting Your Phone 106
Restrict calls 98	Ringer Settings 105
Restriction 98	Security Settings 94
Retrieving a Message 84	Shortcut List 94
Retrieving New Message	Shortcut to menus 48
83	0.1101110111111111111111111111111111111
Return to last menu 48	Signal strength icon 16
Reviewing sent 80	Snooze 122
<u> </u>	Speakerphone Key 16
Right soft key 14	Speed dial, assigning 72
Roam option 28	Standard Limited Warran
Roaming	ty
Definition 28	Standard Limited War-
options 29	ranty 162
Roaming indicator 17	Store numbers, shortcuts
S	71
Security	Storing numbers after a
change lock 96	call 70
lock phone 95	T
restriction 98	•
voice privacy 97	Take Pix 109
Send key 15	Text messages, receiving
Sent, reviewing messages	83
80	Three-touch dialing 72
	Tip

Tip, description 7 Today 118 Travel charger 21 TTY mode 29 Turn your phone off 6 Turn your phone on 6 Turning Your Phone On and Off 6 Two-second pause 65 Two-touch dialing 71 U Understanding Your Contact List Finding a Contact Entry 65 Understanding Your Contacts 61 Adding a New Contact Entry 70 Editing an Existing Contact Entry 69 Finding My Phone Number 72 Speed Dialing 71 Understanding Your Phone Battery 19 Display Screen 16 Features of Your Phone Travel charger 21 Vibrate mode icon 18 View an event, calendar 119 View pix msg later 79 voice mail listening to 7 setup 6 Voice mail icon 18 Voice notes renaming 32 Voice Signal features 37 settings 33 Voice signal description 37 digit dial 37 name dial 44 settings 30 Voice signal menu 30 Voice mail 44 settings 33 Voice signal description 37 digit dial 37 name dial 44 settings 30 Voice mail icon 18 Voice mail listening to 7 setup 6 Voice signal features 37 settings 33 Voice signal description 37 digit dial 37 name dial 44 settings 30 Voice mail setures 92 Voice Signal description 37 digit dial 37 name dial 44 settings 30 Voice mail setures 93 Voice signal menu 30 Voice mail setures 94 Voice signal menu 92 Wallpaper 92 Wallpaper, choosing 92	find a name_ 24	10
Travel charger 21 TTY mode 29 Turn your phone off 6 Turn your phone on 6 Turning Your Phone On and Off 6 Two-second pause 65 Two-touch dialing 71 U Understanding Your Contact List Finding a Contact Entry 65 Understanding Your Contacts 61 Adding a New Contact Entry 70 Editing an Existing Contact Entry 69 Finding My Phone Number 72 Speed Dialing 71 Understanding Your Phone Battery 19 Display Screen 16 Eastures of Your Phone View an event, calendar 119 View an event ellendar 119 Voice mail listening to 7 setup 6 Voice Signal description 33 Voice signal features_ 37 settings 33 Voice signal f	Tip, description 7	Front View of Your Phone
TTY mode 29 Turn your phone off 6 Turn your phone on 6 Turning Your Phone On and Off 6 Two-second pause 65 Two-touch dialing 71 U Understanding Your Contact List Finding a Contact Entry 65 Understanding Your Contacts 61 Adding a New Contact Entry 70 Editing an Existing Contact Entry 69 Finding My Phone Number 72 Speed Dialing 71 Understanding Your Phone Battery 19 Display Screen 16 Battery 19 Display Screen 16 Egatures of Your Phone Vibrate mode icon 18 View an event, calendar 119 Voice mail Listening to 7 setup 6 Voice mail icon 18 Voice notes renaming 32 Voice Signal features_ 37 settings 33 Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal menu_ 30 Voicemail 84 Voicemail, viewing mes- sages 85 W Wallpaper 92 Wallpaper, choosing 92	Today 118	
Turn your phone off 6 Turn your phone on 6 Turning Your Phone On and Off 6 Two-second pause 65 Two-touch dialing 71 U Understanding Your Contact List Finding a Contact Entry 65 Understanding Your Contacts 61 Adding a New Contact Entry 70 Editing an Existing Contact Entry 69 Finding My Phone Number 72 Speed Dialing 71 Understanding Your Phone Battery 19 Display Screen 16 Eastures of Your Phone View an event, calendar 119 Voice mail Listening to 7 setup 6 Voice notes renaming 32 Voice Signal features_ 37 settings 33 Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal menu_ 30 Voicemail 84 Voicemail, viewing mes- sages 85 W Wallpaper 92 Wallpaper, choosing 92	Travel charger 21	•
Turn your phone on 6 Turning Your Phone On and Off 6 Two-second pause 65 Two-touch dialing 71 U Understanding Your Contact List Finding a Contact Entry 65 Understanding Your Contacts 61 Adding a New Contact Entry 62 Deleting a Contact Entry 70 Editing an Existing Contact Entry 69 Finding My Phone Number 72 Speed Dialing 71 Understanding Your Phone Battery 19 Display Screen 16 Eastures of Your Phone 119 view pix msg later 79 voice call icon 17 Voice mail listening to 7 setup 6 Voice mail con 18 Voice notes renaming 32 Voice Signal features_ 37 settings 33 Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal menu_ 30 Voice mail set voice on 18 Voice Signal Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice mail set voice notes renaming 32 Voice Signal Voice signal Voice signal Voice signal menu_ 30 Voice mail, viewing mes- sages 85 W Wallpaper 92 Wallpaper, choosing 92	TTY mode 29	Vibrate mode icon 18
Turning Your Phone On and Off 6 Two-second pause 65 Two-touch dialing 71 U Understanding Your Contact List Finding a Contact Entry 65 Understanding Your Contacts 61 Adding a New Contact Entry 70 Editing an Existing Contact Entry 69 Finding My Phone Number 72 Speed Dialing 71 Understanding Your Phone Battery 19 Display Screen 16 Eestures of Your Phone 119 view pix msg later 79 voice call icon 17 Voice mail listening to 7 setup 6 Voice mail icon 18 Voice notes renaming 32 Voice Signal features_ 37 settings 33 Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal menu_ 30 Voice signal menu_ 30 Voicemail 84 Voicemail, viewing messages 85 W Wallpaper 92 Wallpaper, choosing 92	Turn your phone off 6	View an event, calendar
Turning Your Phone On and Off 6 Two-second pause 65 Two-touch dialing 71 U Understanding Your Contact List Finding a Contact Entry 65 Understanding Your Contacts 61 Adding a New Contact Entry 70 Editing an Existing Contact Entry 69 Finding My Phone Number 72 Speed Dialing 71 Understanding Your Phone Battery 19 Display Screen 16 Beatures of Your Phone Voice mail Listening to 7 Setup 6 Voice mail icon 18 Voice notes renaming 32 Voice Privacy 97 Voice Signal features_ 37 Settings 33 Voice signal description_ 37 digit dial_ 37 name dial_ 44 Settings_ 30 Voice signal menu_ 30 Voice signal menu_ 30 Voice signal menu_ 30 Voice mail icon 18 Voice notes renaming 32 Voice Signal features_ 37 Settings 33 Voice signal Voice signal menu_ 30 Voicemail 84 Voicemail, viewing messages 85 W Wallpaper 92 Wallpaper, choosing 92		119
and Off 6 Two-second pause 65 Two-touch dialing 71 U Understanding Your Contact List Finding a Contact Entry 65 Understanding Your Contacts 61 Adding a New Contact Entry 70 Editing an Existing Contact Entry 69 Finding My Phone Number 72 Speed Dialing 71 Understanding Your Phone Battery 19 Display Screen 16 Eestures of Your Phone Voice mail listening to 7 setup 6 Voice mail icon 18 Voice notes renaming 32 Voice privacy 97 Voice Signal features_ 37 settings 33 Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal menu_ 30 Voice signal menu_ 30 Voice signal menu_ 30 Voice signal menu_ 30 Voice mail icon 18 Voice notes renaming 32 Voice privacy 97 Voice Signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice mail listening to 7 setup 6 Voice notes renaming 32 Voice Signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice mail listening to 7 setup 6 Voice notes renaming 32 Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice mail features_ 37 settings 33 Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice mail features_ 37 settings_ 33 Voice signal description_ 97 Woice signal description_ 97 Woice privacy 97 Voice Signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice mail icon 18 Voice notes renaming 32 Voice privacy 97 Voice Signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice mail features_ 17 Voice privacy 97 Voice Signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal description_ 97 Moice signal		view pix msg later 79
Two-touch dialing 71 U Understanding Your Contact List Finding a Contact Entry 65 Understanding Your Contacts 61 Adding a New Contact Entry 70 Editing an Existing Contact Entry 69 Finding My Phone Number 72 Speed Dialing 71 Understanding Your Phone Battery 19 Display Screen 16 Eestures of Your Phone Ilistening to 7 setup 6 Voice mail icon 18 Voice notes renaming 32 Voice Signal features_ 37 settings 33 Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal menu_ 30 Voice signal menu_ 30 Voice signal menu_ 30 Voicemail 84 Voicemail, viewing messages 85 W Wallpaper 92 Wallpaper, choosing 92	•	voice call icon 17
U Understanding Your Contact List Finding a Contact Entry 65 Understanding Your Contacts 61 Adding a New Contact Entry 70 Editing an Existing Contact Entry 69 Finding My Phone Number 72 Speed Dialing 71 Understanding Your Phone Battery 19 Display Screen 16 Eastures of Your Phone Voice mail icon 18 Voice notes renaming 32 Voice Signal features_ 37 settings 33 Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal menu_ 30 Voice signal Mescription_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice mail, viewing mes- sages 85 W Wallpaper 92 Wallpaper, choosing 92	Two-second pause 65	Voice mail
Understanding Your Contact List Finding a Contact Entry 65 Understanding Your Contacts 61 Adding a New Contact Entry 62 Deleting a Contact Entry 70 Editing an Existing Contact Entry 69 Finding My Phone Number 72 Speed Dialing 71 Understanding Your Phone Battery 19 Display Screen 16 Eastures of Your Phone Voice mail icon 18 Voice notes renaming 32 Voice Signal features_ 37 settings 33 Voice Signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal menu_ 30 Voice signal menu_ 30 Voicemail 84 Voicemail, viewing mes- sages 85 W Wallpaper 92 Wallpaper, choosing 92	-	6
Understanding Your Contact List Finding a Contact Entry 65 Understanding Your Contacts 61 Adding a New Contact Entry 62 Deleting a Contact Entry 70 Editing an Existing Contact Entry 69 Finding My Phone Number 72 Speed Dialing 71 Understanding Your Phone Battery 19 Display Screen 16 Eastures of Your Phone Voice notes renaming 32 Voice privacy 97 Voice Signal features_ 37 settings 33 Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal menu_ 30 Voice signal menu_ 30 Voice signal menu_ 30 Voicemail 84 Voicemail, viewing messages 85 W Wallpaper 92 Wallpaper, choosing 92	_	
tact List Finding a Contact Entry 65 Understanding Your Contacts 61 Adding a New Contact Entry 62 Deleting a Contact Entry 70 Editing an Existing Contact Entry 69 Finding My Phone Number 72 Speed Dialing 71 Understanding Your Phone Battery 19 Display Screen 16 Egatures of Your Phone Voice Rignal features_ 37 settings 33 Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal menu_ 30 Voice signal menu_ 30 Voicemail 84 Voicemail, viewing messages 85 W Wallpaper 92 Wallpaper, choosing 92	Understanding Your Con-	
Finding a Contact Entry 65 Understanding Your Contacts 61 Adding a New Contact Entry 62 Deleting a Contact Entry 70 Editing an Existing Contact Entry 69 Finding My Phone Number 72 Speed Dialing 71 Understanding Your Phone Battery 19 Display Screen 16 Egatures of Your Phone Voice privacy 97 Voice Signal features_ 37 settings 33 Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal menu_ 30 Voice signal menu_ 30 Voice signal menu_ 30 Voice signal menu_ 30 Voice signal menu_ 30 Voice signal menu_ 30 Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal vestings_ 38 Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal vestings_ 30 Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal vestings_ 30 Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal vestings_ 30 Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal vestings_ 30 Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal vestings_ 30 Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal vestings_ 30 Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal vestings_ 30 Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal vestings_ 30 Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal	_	
Understanding Your Contacts 61 Adding a New Contact Entry 62 Deleting a Contact Entry 70 Editing an Existing Contact Entry 69 Finding My Phone Number 72 Speed Dialing 71 Understanding Your Phone Battery 19 Display Screen 16 Egatures of Your Phone Voice Signal features_ 37 settings 33 Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal menu_ 30 Voice signal Menu_ 30 Voice signal menu_ 30 Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal description_ 37 digit dial_ 37 voice signal vestings_ 38 Voice signal description_ 37 digit dial_ 37 voice signal vestings_ 38 Voice signal description_ 37 digit dial_ 37 voice signal vestings_ 30 Voice signal vestings_ 37 vestings_ 33 Voice signal vestings_ 37 vestings_ 33 Voice signal vestings_ 37 vestings_ 33 Voice signal vestings_ 30 Voice signal vestings_ 37 vestings_ 30		•
Understanding Your Contacts 61 Adding a New Contact Entry 62 Deleting a Contact Entry 70 Editing an Existing Contact Entry 69 Finding My Phone Number 72 Speed Dialing 71 Understanding Your Phone Battery 19 Display Screen 16 Features of Your Phone Voice Signal features_ 37 settings 33 Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal menu_ 30 Voice signal menu_ 30 Voicemail 84 Voicemail, viewing messages 85 W Wallpaper 92 Wallpaper, choosing 92		• •
tacts 61 Adding a New Contact Entry 62 Deleting a Contact Entry 70 Editing an Existing Contact Entry 69 Finding My Phone Number 72 Speed Dialing 71 Understanding Your Phone Battery 19 Display Screen 16 Egatures 37 settings 33 Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal menu_ 30 Voicemail 84 Voicemail, viewing messages 85 W Wallpaper 92 Wallpaper, choosing 92	**	
Adding a New Contact Entry 62 Deleting a Contact Entry 70 Editing an Existing Contact Entry 69 Finding My Phone Number 72 Speed Dialing 71 Understanding Your Phone Battery 19 Display Screen 16 Features of Your Phone Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal menu_ 30 Voice signal description_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal menu_ 30 Voice signal m	_	· · · · · · · · · · · · · · · · · · ·
Entry 62 Deleting a Contact Entry 70 Editing an Existing Contact Entry 69 Finding My Phone Number 72 Speed Dialing 71 Understanding Your Phone Battery 19 Display Screen 16 Egatures of Your Phone Wescription_ 37 digit dial_ 37 name dial_ 44 settings_ 30 Voice signal menu_ 30 Voicemail 84 Voicemail, viewing messages 85 W Wallpaper 92 Wallpaper, choosing 92	Adding a New Contact	
Deleting a Contact Entry 70 Editing an Existing Contact Entry 69 Finding My Phone Number 72 Speed Dialing 71 Understanding Your Phone Battery 19 Display Screen 16 Features of Your Phone digit dial_ 37 name dial_ 44 settings_ 30 Voice signal menu_ 30 Voicemail 84 Voicemail, viewing messages 85 W Wallpaper 92 Wallpaper, choosing 92	Entry 62	_
Editing an Existing Contact Entry 69 Finding My Phone Number 72 Speed Dialing 71 Understanding Your Phone Battery 19 Display Screen 16 Features of Your Phone In ame dial_44 settings_30 Voice signal menu_30 Voicemail 84 Voicemail, viewing messages 85 W Wallpaper 92 Wallpaper, choosing 92	•	
tact Entry 69 Finding My Phone Number 72 Speed Dialing 71 Understanding Your Phone Battery 19 Display Screen 16 Features of Your Phone Settings 30 Voice signal menu 30 Voicemail 84 Voicemail, viewing messages 85 W Wallpaper 92 Wallpaper, choosing 92	· ·	
Finding My Phone Number 72 Speed Dialing 71 Understanding Your Phone Battery 19 Display Screen 16 Features of Your Phone Features of Your Phone Voice signal menu 30 Voicemail 84 Voicemail, viewing messages 85 W Wallpaper 92 Wallpaper, choosing 92		settings_ 30
ber 72 Speed Dialing 71 Understanding Your Phone Battery 19 Display Screen 16 Features of Your Phone Voicemail 84 Voicemail, viewing messages 85 W Wallpaper 92 Wallpaper, choosing 92	-	Voice signal menu_ 30
Understanding Your Phone 9 Battery 19 Display Screen 16 Features of Your Phone Wallpaper, choosing 92		Voicemail 84
9 W Battery 19 Wallpaper 92 Display Screen 16 Wallpaper, choosing 92 Features of Your Phone	Speed Dialing 71	Voicemail, viewing mes-
Battery 19 Wallpaper 92 Display Screen 16 Wallpaper, choosing 92 Features of Your Phone	Understanding Your Phone	sages 85
Display Screen 16 Features of Your Phone Wallpaper, choosing 92	9	W
Display Screen 16 Wallpaper, choosing 92	-	Wallpaper 92
	. ,	
Warranty Information 161	Features of Your Phone	Warranty Information 161
173		-

World time 122