




HP PB360t

Digital Camera


Quick Start Guide

For more details about the camera operation and troubleshooting, please read the User Manual located on the CDROM disc included with your camera or visit [**http://www.hp.com/support**](http://www.hp.com/support) and download it for the camera support page.


Getting Started



- 1. Shutter button
- 2. Flash
- 3. Stabilizer
- 4. LED indicator
- 5. Power button
- 6. Self-timer LED / AF Assist Lamp
- 7. Microphone
- 8. Zoom Lens



- 9. Zoom buttons
- 10. Strap ring
- 11. Playback button
- 12. DISP buttons
- 13. LCD screen



- 14. Battery / SD card compartment
- 15. USB
- 16. Tripod screw hole
- 17. Speaker

Initial Settings

When you turn on your camera for the first time, you will be asked to do the initial settings for language and date in your camera.

Setting the Language

1 Tap  ,  to move through the selection.

2 Tap to select language.

Setting the Date & Time

1 Tap the screen to move through date and time.

2 Tap  or  to select the correct value of date and time.

3

Tap **SET** to apply.

Using Quick-Set Bar

The **Quick-Set Bar** acts as a shortcut menu to adjust basic settings in Record and Playback Mode. The menu icons show the current settings for each function. The icons vary depending on the selected mode and its settings.

Tap  to launch Quick-Set Bar.

Tap  to close Quick-Set Bar.



Quick-Set Bar icon

Setting Shooting Mode Menu

The shooting mode menu allows you to adjust other capture settings. Some menu functions may be disabled depending on current scene mode.

In Snapshot mode

- 1 Tap  >  >  .
- 2 Tap  or  to move to the next/ previous page of menu selection.
- 3 Tap a submenu option to change submenu settings.
- 4 Tap  to exit submenu.



Setting Playback Menu

To go to Playback Menu

The Playback menu allows you to edit images, delete files, records voice memo, and setup other playback settings.

1 Tap  >  >  .

2 Tap  or  to move to the next/ previous page of menu selection.

3 To select an item, tap the icon.



4 To change the submenu settings, tap the icon of desired settings.

5 Tap  to exit submenu.

Using the Setting Menu

To go to Setting Menu

You can access the Setting menu whether you are in Record or Playback mode. The Setting menu allows you to configure general camera settings. Submenu options may vary depending on the current mode. Unavailable are disabled.

1 Tap  >  >  .

2 Tap  or  to move to the next/ previous page of menu selection.

3 To select an item, tap the icon.

4 To change the submenu settings, tap the icon of desired settings.

5 Tap  to exit submenu.



Setting Hot Key

The Hot Key function is available only in shooting mode. This function allows you to define the three shortcut icons on the shooting Mode Quick-Set Bar.

- 1 From the Setup Menu menu, tap **Hot Key**. The Hot key interface appears.
- 2 Tap an icon on the Quick-Set Bar to replace. A pop up selection appears.
- 3 Tap desired submenu.
- 4 To replace other icons, repeat steps 2-3.
- 5 Tap **SET** to save and apply changes



Getting Help

Should you have a technical support question or your HP Digital Camera require service within the warranty period, please contact the original point of purchase or an authorized HP reseller in your country. If service is not available at those locations, please contact an HP Branded Product warranty agent from the support contact list provided below. A service agent will work with you to troubleshoot your issue and if necessary, issue a Return Material Authorization (RMA) number in order to replace your HP Branded Product. For warranty claims, you will be required to provide a copy of your original dated sales receipt as proof of purchase and the issued RMA number. You will be responsible for shipping charges when shipping the product to the service center. The service agent will provide you with an address and you will also be responsible for any shipping charges to the warranty service center. Once your product is received by this service center, a replacement unit will be shipped back to you typically within 5 business days.

Email Support:	
Language	Email Address
Dutch	hollands@hpodd.com
Chinese	simp.chinese@hpodd.com
	trad.chinese@hpodd.com
English	english@hpodd.com
Français	français@hpodd.com
Deutsch	deutsch@hpodd.com
Italiano	italiano@hpodd.com
Japanese	nippon@hpodd.com
Korean	korean@hpodd.com
Portuguese	portugues@hpodd.com
Espanol	espanol@hpodd.com
Svenska	svensk@hpodd.com

Contact/phone Support:		
Country	Language	Number
Europe Region (EMEA)		
België	Dutch and German	+ 32 2700 1724
FRANCE	French	+ 33 171230454
DEUTSCHLAND	German	+ 49 6950073896
IRELAND	English	+ 353 1850882016
ITALIA	Italian	+ 39 269682189
NETHERLANDS	Dutch	+ 31 202015093
ESPAÑA	Spanish	+ 34 914533458
SWITZERLAND	German/French/Italian	+ 41 18009686
UK	English	+ 44 2073652400
North America		
United States	English	1.866.694.7633
Canada	English and French	1.866.694.7633

P/N: