



New Solution Series

NSK4400

At Antec, we continually refine and improve our products to ensure the highest quality. So it's possible that your new case may differ slightly from the descriptions in this manual. This isn't a problem; it's simply an improvement. As of the date of publication, all features, descriptions, and illustrations in this manual are correct.

Disclaimer

This manual is intended only as a guide for Antec's Computer Enclosures. For more comprehensive instructions on installing the motherboard and peripherals, please refer to the user's manuals which come with the components and drives.

New Solution Series User's Manual

NSK4400

Super Mini Tower Case

This case is designed to meet Intel's Thermally Advantaged Chassis (TAC) design guide requirements.

The Power Supply

NSK 4400 comes with a 380 Watt universal input, active PFC single 80 mm fan cooled power supply with the newest ATX12V version 2.0 specification and above. This includes dual +12V output rails that deliver safer and more reliable output to your system's components. Along with higher energy efficiency, which will reduce power consumption by up to 25% saving you money on your electricity bill. In addition there is a variety of industrial-grade protective circuitry: OPP (over power protection), OVP (over voltage protection), UVP (under voltage protection), and SCP (shot circuit protection).

The power supply comes with a main power switch. Make sure you turn the switch to the ON (I) position before you boot up the computer for the first time. Normally, you won't need to switch to the OFF (O) position, since the power supply includes a soft on/off feature. This lets you turn the computer on and off by using the soft switch on the computer case. If the computer crashes and you can't shut it down using the soft switch, you can switch the main power to the OFF (O) position, to clear the fault, then reboot.

For models designed for sale in the European Union:

Antec power supply models feature Power Factor Correction (PFC) circuitry in accordance with European standard regulation code EN61000-3-2. By altering the input current wave shape, PFC improves the power factor of the power supply. This results in increased energy efficiency, reduced heat loss, prolonged life for power distribution and consumption equipment, and improved output voltage stability. Together with the high efficiency design and the quiet 80 mm fan, the power supply delivers not only a cleaner but also a quieter operating environment.

Set Up

1. Take the case out of the box. Remove the styrofoam and plastic bag.
2. Place the case upright with the power supply fan at the back facing you on a stable flat surface.
3. Remove the two thumbscrews which fasten the top cover onto the case. These are the only screws you need to remove to open the case. Set these screws aside and keep them separate from the other screws.
4. Slide the top panel toward the rear of the case and lift it up to remove.
5. At the top of the each side panel, in front of the power supply, there is a 4" wide tab. Using this, lift and pull the side panels out to remove.
6. Inside the case you should see the power supply, some wiring (LED's, etc.), an installed I/O panel, a power cord and a plastic bag containing more hardware (screws, brass standoff, plastic stands, etc.).

Motherboard Installation

This manual is not designed to cover CPU, RAM, or expansion card installation. Please consult the motherboard manual for specific mounting instructions and troubleshooting.

1. Lay the case down so that the open side is up. You should be able to see the drive cage and power supply.
2. Make sure you have the appropriate I/O panel for the motherboard. If the panel provided is not suitable for the motherboard, please contact the motherboard manufacturer for the correct I/O panel.
3. Line up the motherboard with the standoff holes, and determine which ones line up and remember where they are. (Not all motherboards will match with all of the provided screw holes, and this is not necessary for proper functionality) Some standoffs may be pre-installed for your convenience.
4. Lift up and remove the motherboard.
5. Screw in the brass standoffs to the threaded holes that line up with the motherboard.
6. Place the motherboard on the brass standoffs.
7. Screw in the motherboard to the standoffs with the provided Phillips-head screws.
8. The motherboard is now installed.

Connecting the Power and LED

The power supply conforms to the ATX12V Version 2.01 standard. If the motherboard has a 20-pin power receptacle, detach the 4-pin attachment on the 24-pin power connector, see pictures 1 and 2. Before you connect the power supply to any devices, please consult the appropriate user manuals for the motherboard and other peripherals.

1. Connect the 24-pin Main Power Connector and the 4-pin or 8-pin connector to the motherboard as needed. If the motherboard uses a 20-pin connector; detach the 4-pin attachment on the 24-pin power connector (see pictures 1 and 2).
2. Connect the Reset switch (labeled RESET SW) to the motherboard at the RST connector. Make sure the label always faces the front of the case.

Picture 1



For 24-pin
motherboards

Picture 2




For 20-pin
motherboards

3. Power LED (labeled POWER LED) connector is located behind the Reset connector.
4. Power Switch (labeled POWER SW) connects to the PWR connector on the motherboard.
5. Hard Drive LED (labeled H.D.D. LED) connects to the IDE connector.

USB Connection

The USB2.0 connector going to the motherboard matches up with the Intel standard as follow: power, negative signal, positive signal, and ground consecutively. Before you connect the USB2.0 connector to the motherboard, please check the motherboard user manual for the correct pin layout.

Motherboard Pin Layout



Pin	Signal Names	Pin	Signal Names
1	USB Power 1	2	USB Power 2
3	Negative Signal 1	4	Negative Signal 2
5	Positive Signal 1	6	Positive Signal 2
7	Ground 1	8	Ground 2
9	Key (No Connection)	10	Empty Pin

3.5" Device Installation

There is one 3.5" drive cage inside the case. It can hold 2 external 3.5" drives and 3 internal 3.5" (HDD) drives.

1. Remove the screw which fasten the cage to the case. Slide the cage out of the case.
2. Mount your external 3.5" drives into the top two drive bays and the internal drives into the third drive bay down. Load the drives from the back, lining them up to the front of the drive cage.
3. With one hand supporting the drive, fasten the drive to the cage with the screws provided.
4. Slide and fasten the cage back to the case.
5. Find a small 4-pin white connector on the power supply and connect it to the male 4-pin connector on the floppy drive.
6. Connect a 4-pin large white connector from the power supply to the male 4-pin connector on each of the other internal devices.

5.25" Device Installation

There are three external 5.25" drive bays.

1. Looking from the rear of the case you can see metal grilles covering the 5.25" drive bays. Carefully push a screwdriver through the metal grille and gently push the plastic drive bay cover outwards until it comes off.
2. Using your hands, twist the metal plate back and forth until it breaks off. Note: Don't break off the metal grilles covering the drive bays that you are not using now. Be careful of the newly exposed metal where the grille was attached, as these areas are likely to be sharp.
3. Fasten the 5.25" device into the drive bay with screws provided.
4. Repeat the same procedure for other devices.
5. Connect a 4-pin large white connector from the power supply to the male 4-pin connector on each of the devices.

Chassis Air Guide

Your case includes a chassis air guide and vents, for improved cooling of your CPU and overall system. The air guide consists of three parts: an upper duct, flange, and lower duct. If you prefer, you can adjust the distance between the lower duct and your CPU for maximum cooling efficiency.

You can also install an 80mm intake fan between the air guide and the case's side panel. This will further improve your system's cooling airflow. To install the optional fan:

1. Remove Chassis Air Guide from the side panel
2. Attach the fan to the side panel (see picture 3).
3. Using the fan screws, lock the flange of the air guide to the fan (see picture 4).
4. Connect a large 4-pin peripheral connector from the power supply to the make 4-pin connector on the fan.



Picture 3



Picture 4

Cooling System

The Rear Exhaust TriCool™ Fan:

The NSK 4400 comes with one 120mm TriCool™ fan preinstalled. This fan has a three-speed switch that lets you choose between quiet, performance, or maximum cooling (See specifications below). The fan is installed so that the air is blowing out of the case. Connect a large 4-pin connector from the power supply to the male 4-pin connector on the fan.

Note: The default setting of the fan is Low. We recommend this speed for maximum quiet computing.

Note: The minimum voltage to start the fan is 5V. We recommend that our users to set the fan speed to High if you choose to connect the fan to a fan control device or to the Fan-Only connector found on some of Antec's power supplies. A fan-control device regulates the fan speed by varying the voltage to it. The voltage may start as low as 4.5 V to 5V. Connecting a TriCool™ set on Medium or Low to a fan-control device may result in the fan not being able to start. The already lowered voltage from the fan control device will be further reduced by the TriCool™ circuitry below 5V.

Specifications:

Size: 120 x 120 x 25.4mm
Rated Voltage: DC 12V
Operating Voltage: 10.2V ~ 13.8V

Speed	Input Current	Air Flow	Static Pressure	Acoustical Noise	Input Power
High 2000 RPM	0.24A (Max.)	2.24 m³ / min (79 CFM)	2.54 mm-H2O (0.10 inch-H2O)	30 dBA	2.9 W
Medium 1600 RPM	0.2A	1.59 m³ / min (56 CFM)	1.53 mm-H2O (0.06 inch-H2O)	28 dBA	2.4 W
Low 1200 RPM	0.13A	1.1 m³ / min (39 CFM)	0.92 mm-H2O (0.04 inch-H2O)	25 dBA	1.6 W

The Front 80 mm Fan Mount

1. Squeeze the upper right and left sides of the fan cage together to release the tabs. Once loose, you should be able to pull the cage back and out of the case.
2. Drop the fan into the cage and push it in until it clips in. No screws are needed. The front fan should be installed so that the air is blowing into the case.
3. Reattach the cage/fan assembly to the case paying attention to the wires of the fan. There are slots near each corner to put the wires through (any corner will work, find the one that's best for you).
4. If you're using a 4-pin fan, connect a 4-pin large white connector from the power supply. If you're using a 3-pin fan, connect the 3-pin connector to a motherboard fan header.

Antec, Inc.

47900 Fremont Blvd.
Fremont, CA 94538
USA

tel: 510-770-1200

fax: 510-770-1288

Antec Europe B.V.

Sydneystraat 33
3047 BP Rotterdam
The Netherlands

tel: +31 (0) 10 462-2060

fax: +31 (0) 10 437-1752

Technical Support:

US & Canada

1-800-22ANTEC

techsupport@antec.com

Europe

+31 (0) 10 462-2060

europe.support@antec.com

www.antec.com

© Copyright 2006 Antec, Inc. All rights reserved.

Reproduction in whole or in part without written permission is prohibited.

Printed in China.

Version 1.1 1/16/2006