## User's Manual Bedienungsanleitung Manuel d'utilisation

# FlexScan<sup>®</sup> L560T-CB

Touch Panel Color LCD Monitor LCD-Farbmonitor mit Touch-Panel Moniteur couleur LCD à écran tactile

### Important

Please read this User's Manual carefully to familiarize yourself with safe and effective usage. Please retain this manual for future reference.

### Wichtig

Bitte lesen Sie diese Bedienungsanleitung sorgfältig durch, um sich mit dem sicheren und rationellen Betrieb dieses Produkts vertraut zu machen. Bewahren Sie das vorliegende Handbuch zu Referenzzwecken auf.

### Important

Veuillez lire attentivement ce manuel d'utilisation pour utiliser pleinement votre appareil en toute sécurité. Veuillez conserver ce manuel pour référence ultérieure.



### For U.S.A, Canada, etc. (rated 100-120 Vac) Only

#### FCC Declaration of Conformity

We, the Responsible Party

EIZO NANAO TECHNOLOGIES INC. 5710 Warland Drive, Cypress, CA 90630 Phone: (562) 431-5011

declare that the product

<u>Trade name: EIZO</u> Model: FlexScan L560T-CB

is in conformity with Part 15 of the FCC Rules. Operation of this product is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- \* Reorient or relocate the receiving antenna.
- \* Increase the separation between the equipment and receiver.
- \* Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- \* Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### Note

Use the attached specified cable below or EIZO signal cable with this monitor so as to keep interference within the limits of a Class B digital device.

- AC Cord
- Shielded Signal Cable (enclosed)

#### **Canadian** Notice

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de le classe B est comforme à la norme NMB-003 du Canada.

## User's Manual

## FlexScan<sup>®</sup> L560T-CB Touch Panel Color LCD Monitor

It shall be assured that the final system is in compliance to IEC60601-1-1 requirements.

### SAFETY SYMBOLS

This manual uses the safety symbols below. They denote critical information. Please read them carefully.



### WARNING

Failure to abide by the information in a WARNING may result in serious injury and can be life threatening.



## CAUTION

Failure to abide by the information in a CAUTION may result in moderate injury and/or property or product damage.



Indicates a prohibited action.

Indicates to ground for safety.

- Product specifications may vary depending on the region. Confirm the specifications in the manual written in the language of the region of purchase.
- Power supplied equipment can emit electromagnetic waves, that could influence, limit or result in malfunction of the monitor. Install the equipment in a controlled environment, where such effects are avoided.
- This is a monitor intended for use in a medical image system.

Copyright© 2009 EIZO NANAO CORPORATION All rights reserved. No part of this manual may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, or otherwise, without the prior written permission of EIZO NANAO CORPORATION.

EIZO NANAO CORPORATION is under no obligation to hold any submitted material or information confidential unless prior arrangements are made pursuant to EIZO NANAO CORPORATION's receipt of said information. Although every effort has been made to ensure that this manual provides up-to-date information, please note that EIZO monitor specifications are subject to change without notice.

TouchWare is a trademark of 3M in the United States and other countries.

Mac OS is a registered trademark of Apple Inc.

VGA is a registered trademark of International Business Machines Corporation.

Windows and Windows Vista are registered trademarks of Microsoft Corporation in the United States and other countries.

VESA is a registered trademark or a trademark of Video Electronics Standards Association in the United States and other countries.

ScreenManager, FlexScan and EIZO are registered trademarks of EIZO NANAO CORPORATION in Japan and other countries.

## **TABLE OF CONTENTS**

	4
<b>1. INTRODUCTION</b> 1-1. Features 1-2. Package Contents 1-3. Controls & Connectors	<b>10</b> 10 10 11
2. CABLE CONNECTION	
<ul><li>2-1. Before connecting</li><li>2-2. Connecting the signal cable</li><li>2-3. Touch Operation</li><li>2-4. Connecting two PCs to the monitor</li></ul>	13 14 16 16
<b>3. ScreenManager</b>	<b>17</b> 17 18 19
<b>4. ADJUSTMENT</b> 4-1. Screen Adjustment 4-2. Color Adjustment	<b>21</b> 21 24
5. ATTACHING A STAND	
6. TROUBLESHOOTING	27
7. SPECIFICATIONS	
8. GLOSSARY	
APPENDIX/ANHANG/ANNEXE	i

## **APRECAUTIONS**

#### IMPORTANT

- This product has been adjusted specifically for use in the region to which it was originally shipped. If the product is used outside the region, it may not operate as specified in the specifications.
- To ensure personal safety and proper maintenance, please read carefully this section and the caution statements on the monitor.

#### [Location of the Caution Statements]



#### [Symbols on the unit]

Symbol	This symbol indicates			
	Power button			
~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	Alternating current			
Â	Alerting electrical hazard			
Â	Caution Refer to SAFETY SYMBOLS section in this manual.			

## 

#### If the unit begins to emit smoke, smells like something is burning, or makes strange noises, disconnect all power connections immediately and contact your dealer for advice.

Attempting to use a malfunctioning unit may result in fire, electric shock, or equipment damage.

#### Do not open the cabinet or modify the unit.

Opening the cabinet or modifying the unit may result in fire, electric shock, or burn.

#### Refer all servicing to qualified service personnel.

Do not attempt to service this product yourself as opening or removing covers may result in fire, electric shock, or equipment damage.

#### Keep small objects or liquids away from the unit.

Small objects accidentally falling through the ventilation slots into the cabinet or spillage into the cabinet may result in fire, electric shock, or equipment damage.

If an object or liquid falls/spills into the cabinet, unplug the unit immediately. Have the unit checked by a qualified service engineer before using it again.

#### Place the unit at the strong and stable place.

A unit placed on an inadequate surface may fall and result in injury or equipment damage.

If the unit falls, disconnect the power immediately and ask your dealer for advice. Do not continue using a damaged unit. Using a damaged unit may result in fire or electric shock.

#### Use the unit in an appropriate location.

Not doing so may result in fire, electric shock, or equipment damage.

- \* Do not place outdoors.
- \* Do not place in the transportation system (ship, aircraft, trains, automobiles, etc.)
- \* Do not place in a dusty or humid environment.
- \* Do not place in a location where water is splashed on the screen (bathroom, kitchen, etc.).
- \* Do not place in a location where the steam comes directly on the screen.
- \* Do not place near heat generating devices or a humidifier.
- \* Do not place in an inflammable gas environment.











## 

To avoid danger of suffocation, keep the plastic packing bags away from babies and children.

## Use the enclosed power cord and connect to the standard power outlet of your country.

Be sure to remain within the rated voltage of the power cord.

Not doing so may result in fire or electric shock.

Power Supply: 100-120/200-240 Vac 50/60Hz

**To disconnect the power cord, grasp the plug firmly and pull.** Tugging on the cord may damage and result in fire or electric shock.

#### The equipment must be connected to a grounded main outlet.

Failure to do so may result in fire or electric shock.

#### Use the correct voltage.

\* The unit is designed for use with a specific voltage only. Connection to another voltage than specified in this User's Manual may cause fire, electric shock, or equipment damage.

Power Supply: 100-120/200-240 Vac 50/60Hz

\* Do not overload your power circuit, as this may result in fire or electric shock.

#### Handle the power cord with care.

- \* Do not place the cord underneath the unit or other heavy objects.
- \* Do not pull on or tie the cord.

If the power cord becomes damaged, stop using it. Use of a damaged cord may result in fire or electric shock.

#### Never touch the plug and power cord if it begins to thunder.

Touching them may result in electric shock.

## When attaching an arm stand, please refer to the user's manual of the arm stand and install the unit securely.

Not doing so may cause the unit to become unattached, which may result in injury or equipment damage. When the unit is dropped, please ask your dealer for advice. Do not continue using a damaged unit. Using a damaged unit may result in fire or electric shock. When reattaching the tilt stand, please use the same screws and tighten them securely.







## 

#### Do not touch a damaged LCD panel directly with bare hands.

The liquid crystal that may leak from the panel is poisonous if it enters the eyes or mouth.

If any part of the skin or body comes in direct contact with the panel, please wash thoroughly.

If some physical symptoms result, please consult your doctor.

Lamps contain mercury, dispose according to local, state or federal laws.

## 

#### Handle with care when carrying the unit.

Disconnect the power cord and cables when moving the unit. Moving the unit with the cord attached is dangerous. It may result in injury.

## When handling the unit, grip the bottom of the unit firmly with both hands ensuring the panel faces outward before lifting.

Dropping the unit may result in injury or equipment damage.

#### Do not block the ventilation slots on the cabinet.

- \* Do not place any objects on the ventilation slots.
- \* Do not install the unit in a closed space.
- \* Do not use the unit laid down or upside down.

Blocking the ventilation slots prevents proper airflow and may result in fire, electric shock, or equipment damage.

#### Do not touch the plug with wet hands.

Doing so may result in electrical shock.

#### Use an easily accessible power outlet.

This will ensure that you can disconnect the power quickly in case of a problem.

#### Periodically clean the area around the plug.

Dust, water, or oil on the plug may result in fire.

#### Unplug the unit before cleaning it.

Cleaning the unit while it is plugged into a power outlet may result in electric shock.

If you plan to leave the unit unused for an extended period, disconnect the power cord from the wall socket after turning off the power button for the safety and the power conservation.



OK



#### Notice for this monitor

This product is suited to creating documents, viewing multimedia content, and other general purposes.

This product may not be covered by warranty for uses other than those described in this manual.

The specifications noted in this manual are only applicable for power cords and signal cables specified by us.

Use optional products manufactured or specified by us with this product.

As it takes about 30 minutes for the performance of electrical parts to stabilize, adjust the monitor 30 minutes or more after the monitor power has been turned on.

In order to suppress the luminosity change by long-term use and to maintain the stable luminosity, use of a monitor in lower brightness is recommended.

When the screen image is changed after displaying the same image for extended periods of time, an afterimage may appear. Use the screen saver or timer to avoid displaying the same image for extended periods of time.

Periodic cleaning is recommended to keep the monitor looking new and to prolong its operation lifetime. (Refer to "Cleaning" on the next page.)

The LCD panel is manufactured using high-precision technology. However, missing pixels or lit pixels may appear on the LCD panel, this is not malfunction. Percentage of effective pixels : 99.9994% or higher.

The backlight of the LCD panel has a fixed life span. When the screen becomes dark or begins to flicker, please contact your dealer.

Do not scratch or press on the panel with any sharp objects, such as a pencil or pen as this may result in damage to the panel. Do not attempt to brush with tissues as this may scratch the panel.

When the monitor is cold and brought into a room or the room temperature goes up quickly, dew condensation may occur inside and outside the monitor. In that case, do not turn the monitor on and wait until dew condensation disappears, otherwise it may cause some damages to the monitor.

#### Cleaning

#### Attention

- Never use any solvents or chemicals, such as thinner, benzene, wax, alcohol, disinfectant, and abrasive cleaner, which may damage the cabinet or panel.
- Never use spray for preventing static electricity, as it may influence the sensibility of the touch panel.
- Do not soak liquid into the clearance between the panel and the panel frame.

[Panel]

- Clean the panel with a soft cloth such as cotton cloth or lens cleaning paper.
- Remove persistent stains gently with a cloth dampened with a little water, and then clean the panel again with a dry cloth for better finishing.

#### NOTE

• Optional ScreenCleaner is recommended for cleaning the panel surface.

[Cabinet]

• Clean the cabinet with a soft cloth dampened with a little mild detergent.

#### To use the monitor comfortably

An excessively dark or bright screen may affect your eyes. Adjust the brightness of the monitor according to the environmental conditions.

Staring at the monitor for a long time tires your eyes. Take a 10-minute rest every hour.

## **1. INTRODUCTION**

Thank you very much for choosing an EIZO Color Monitor.

## 1-1. Features

- Dual inputs compliant
- DVI (p.34) Digital input (TMDS (p.35)) compliant.
- Horizontal scanning frequency:

Vertical scanning frequency:

Analog input 30 - 81 kHz Digital input 30 - 65 kHz Analog input 49.5 - 75.5 Hz Digital input 59 - 61 Hz (VGA TEXT: 70 Hz) 1 M pixels (1280 dots x 1024 lines)

Resolution:

- Auto Adjustment compliant
- Support to sRGB (p.35) standard
- The height adjustable stand incorporated
- Touch Panel provided (USB serial communication)
- Touch Panel Pointer "TP1" is available (optional, p.16)

### 1-2. Package Contents

Please contact your local dealer for assistance if any of the listed items are missing or damaged.

- LCD Monitor
- Power Cord
- Signal Cable (MD-C87)
- USB Cable (MD-C93)
- User's Manual
- ScreenManager Quick Reference
- LIMITED WARRANTY
- Recycling Information
- EIZO Touch Panel Disk (CD-ROM) (Contents: touch panel drivers TouchWare (for Windows 2000/XP) and MT 7 (for Windows Vista), and Installation Guides)

#### NOTE

- Please retain the packing materials for future transference.
- Regarding installing touch panel drivers and cautions, please refer to the Installation Guides in the CD-ROM.

### **1-3. Controls & Connectors**

#### Front





(8) Hole for TP1		Hole for installing the lead of the TP1 (Optional Touch Panel Pointer).	
(9) Stand (Detachable)		The LCD monitor can be used with an other stand by removing the stand (p.26).	
(10) 🔀	Security Lock Slot	Allows for connection of a security cable. This lock supports Kensington's MicroSaver security system.	
(11)	Power Connector (POWER INPUT)	Connect the power cord.	
(12) 🕞	DVI-D Connector (DVI)	Connect the optional digital cable.	
(13) 🗖	D-Sub mini 15 pin Connector (D-SUB)	Connect the enclosed analog cable (MD-C87).	
(14) 🔫	USB port	Connect the enclosed touch panel cable (MD-C93).	

## **2. CABLE CONNECTION**

### 2-1. Before connecting

Before connecting your monitor to the PC, change the display screen settings (resolution (p.35) and frequency) in accordance with the charts below.

#### NOTE

- The lower display modes like 640x 480, automatically enlarge to the maximum display mode (1280 x 1024), and some lines of the characters may become fuzzy. In this case, use <Smoothing> function (p.23) to make the lines clear.
- When your computer and display support VESA DDC, the suitable resolution and the refresh rate are set by just plugging your display into the computer without any manual settings.

#### **Analog Input**

Resolution	Frequency	Dot Clock	Remarks
320 x 200	70 Hz	135 MHz (Max)	VGA Graphics
640 x 480	~75 Hz		VGA, VESA
720 x 400	70 Hz		VGA TEXT
800 x 600	~75 Hz		VESA
1024 x 768	~75 Hz		VESA
1152 x 864	75 Hz		VESA
1280 x 960	60 Hz		VESA
1280 x 1024	~75 Hz		VESA

#### **Digital Input**

Resolution	Frequency	Dot Clock	Remarks
640 x 480	60 Hz	109 MHz (Max)	VGA
720 x 400	70 Hz		VGA TEXT
800 x 600	60 Hz		VESA
1024 x 768	60 Hz		VESA
1280 x 1024	60 Hz		VESA

## 2-2. Connecting the signal cable

#### NOTE

• Be sure that the powers of the PC and the monitor are OFF.

**1.** Plug the signal cable into the connector at the rear of the monitor and the other end of the cable into the video connector on the PC.

After connecting, secure the connection with the screw-in fasteners.



Digital Signal Input Connecter Analog Signal Input Connecter

### **Analog Input**

Signal Cable	Connector of PC
Signal Cable (enclosed, MD- C87)	Video Output Connector/ D-Sub mini 15 pin Input Connector (monitor)/ D-Sub mini 15 pin

### **Digital Input**

Signal Cable	Connector of PC
FD-C39 (Optional)	Video Output Connector DVI-I
	Input Connector (monitor)/ DVI

**2.** Plug the power cord into the power connector on the rear of the monitor. Then, plug the other end of the cord into a power outlet.

## 

## Use the enclosed power cord and connect to the standard power outlet of your country.

Be sure to remain within the rated voltage of the power cord. Not doing so may result in fire or electric shock.

Power Supply: 100-120/200-240 Vac 50/60Hz

The equipment must be connected to a grounded main outlet.





**3.** Turn on the monitor's main power and then switch on the PC's power.

The monitor's power indicator will light up (blue).

If an image does not appear, refer to the "6. TROUBLESHOOTING" (p.27) for advice.

**4.** Install the touch panel driver TouchWare (for Windows 2000/XP) or MT 7 (for Windows Vista) depending on your OS.

#### NOTE

- Regarding installing touch panel drivers and cautions, please refer to the Installation Guides in the CD-ROM.
- **5.** Connect the upstream port of the monitor to the downstream port of the USB compliant PC by using the USB cable (MD-C93).

After connecting the USB cable, the USB function can be set up automatically.

#### NOTE

- Do your part to conserve energy, turn off the monitor when you are finished using it. Disconnecting the monitor from the power supply is recommended to save energy completely.
- Adjust brightness of the screen depending on the brightness of your environment (p. 24). Too dark or too bright of a screen can cause eyestrain.
- Be sure to take adequate rests. A 10-minute rest period each hour is suggested.

### 2-3. Touch Operation

Point and touch with one finger only.

#### NOTE

- Do not touch the screen while turning on the PC and the monitor. Touch the screen five seconds later after appearing the image.
- Touch the screen five seconds later after connecting the USB cable.
- For the users with gloves, we recommend to use touch panel pointer, "TP1" (optional). Regarding the installation, please refer to the User's Manual of TP1.

### 2-4. Connecting two PCs to the monitor

Two PCs can be connected to the monitor through the DVI and the D-Sub mini 15 pin connector on the back of the monitor.

#### NOTE

• The touch panel operation is effective for one computer only.

#### Selecting the active input

The Input Signal Selection Button on the control panel can be used to select either Signal 1 or Signal 2 as the active input at any time. Every time the Input Signal Selection Button is pressed, the input changes. When switching the signal, the kind of the input signal (Analog or Digital) is displayed for a few seconds on the right top corner of the screen.



## 3. ScreenManager

## 3-1. How to use the ScreenManager



#### **1.** Entering the ScreenManager

Press the Enter Button once to display the main menu of the ScreenManager.

#### **2.** Making Adjustments and Settings

- (1) Select the desired sub menu icon using the Control Buttons and press the Enter Button. The sub menu appears.
- (2) Use the Control Buttons to select the desired setting icon and press the Enter Button. The setting menu appears.
- (3) Use the Control Buttons to make all required adjustments and press the Enter Button to save the settings.

#### **3.** Exiting the ScreenManager

- (1) To return to the main menu, select the <Return> icon or press the Down Button twice, followed by the Enter Button.
- (2) To exit the ScreenManager, select <Exit> icon or press the Down Button twice, followed by the Enter Button.

#### NOTE

• Double clicking the Enter Button at any time also exits the ScreenManager menu.

### 3-2. Adjustments and Settings

The following table shows all the ScreenManager's adjustment and setting menus. "\*" indicates adjustments of analog input only.

Main menu	Sub menu		Reference	
Screen	Clock	*	4-1. Screen Adjustment (p.21)	
	Phase	*		
	Position	*		
	Range Adjustment	*		
	Smoothing			
Color	Brightness		4-2. Color Adjustment (p.24)	
	Color Mode			
	Custom			
	Temperature			
	Gamma			
	Gain			
	Reset			
	• sRGB			
Others	Input Signal		Set the input signal selection of automatic or manual (p.20)	
	Off Timer		Set the power save (p.19)	
	VGA Selection		Select the display mode. (p.28)	
	Menu Position		Adjust the menu position.	
	Translucent		Set the transparency of the menu.	
	Menu Off Timer		Set the menu displaying time.	
	Reset		Return to the factory default settings. (p.32)	
Information	Information		Review the ScreenManager's settings, model name, serial number and usage time <sup>-1</sup> .	
Language	English, German, French, Spanish, Italian, Swedish and Japanese		Select the ScreenManager's language.	

<sup>\*1</sup> Due to the inspection on the factory, the usage time may not "0 hour" at shipping.

### 3-3. Useful Functions

#### **Adjustment Lock**

Use the "Adjustment Lock" function to prevent any accidental changes.

Locked function	<ul> <li>Adjustments and settings in the ScreenManager</li> </ul>			
	Auto Adjustment Button			
Unlocked function	<ul> <li>Adjustment of brightness by the Control Buttons</li> </ul>			
	<ul> <li>Input Signal Selection Button</li> </ul>			

[To lock]

- (1) Turn off the monitor's power by the power button on the control panel.
- (2) Press on the Auto adjustment button while switching on the monitor's power.

#### [To unlock]

- (1) Turn off the monitor's power by the power button on the control panel.
- (2) Hold down the Auto adjustment button once again and turn the power back on.

#### **Off Timer**

The off timer function causes the monitor to automatically enter a power off state after a predetermined amount of time has lapsed. This function was created to reduce afterimage characteristics that are particular to LCD monitors when the monitor screen is left on for a long period without use.

#### [Procedure]

- (1) Select <Off Timer> in the ScreenManager <Others> menu.
- (2) Select "Enable" and press the Right and Left Buttons to adjust the "On Period" (1 to 23 hours).

#### [Off timer system]

Timer	Monitor	Power Indicator
On Period (1H - 23H)	Operation	Blue
Last 15 min. in "On period"	Advance Notice <sup>*1</sup>	Blue Flashing
"On period" expired	Power off	Flashing orange slowly

<sup>1</sup> Advance notice (Power Indicator flashing blue) will be given 15 minutes before the monitor automatically enters the "Power Off" mode. Pressing the power button during the advanced notice period can reset "On Period" for another 90 minutes. It is possible to reset "On Period" as many times as needed.

#### [Power Resumption Procedure]

Press the power button to return a normal screen.

#### **EIZO Logo display**

Enables to display the EIZO logo for a while when switching on the monitor (Default is no logo). If you desire to display or undisplay this logo, use this function.

#### [To display]

- (1) Turn off the monitor's power by the Power button on the control panel.
- (2) Hold down the Enter button once again and turn the power back on.

#### [To undisplay]

- (1) Turn off the monitor's power by the Power button.
- (2) Hold down the Enter button once again and turn the power back on.

### Automatically selecting the input signal function

The monitor will automatically detect the inputted signal of either the connection for display.

#### Connecting two PCs to the monitor

When the one computer is switched off, the monitor will automatically dislay the other signal.

Use the ScreenManager to switch the input selection to manual.

#### [Procedure]

- (1) Select <Input Signal> in the <Others> menu.
- (2) Select "Manual".

## 4. ADJUSTMENT

The monitor displays the digital input image correctly based on its pre-setting data. Adjust the brightness (p.24).

## 4-1. Screen Adjustment

Screen adjustments for the LCD monitor should be used in suppressing screen flickering and also for adjusting the screen to its proper position. There is only one correct position for each display mode. It is also recommended to use the ScreenManager function when first installing the display or whenever changing the system.

#### **Adjustment Procedure**

#### NOTE

- Allow the LCD monitor to stabilize for at least 30 minutes before making image adjustments.
- **1.** Press the Auto Adjustment Button on the control panel.

The message "Your setting will be lost, if you press again now." appears and remains on the screen for 5 seconds. While the message is on the screen, press the Auto Adjustment Button again to automatically adjust the clock, phase, and screen position. If you do not wish to do adjust the screen, do not press the Auto Adjustment Button again.

#### NOTE

 The Auto Adjustment function is intended for use on AT-compatible PC running Windows. It may not work properly in either of the following cases.
 When running an AT-compatible PC on MS-DOS (Not windows).
 The background color for the wall paper" or "desktop" pattern is set to black.

If the appropriate screen can not be made by using the Auto Adjustment Button, adjust the screen through the following procedures. If the appropriate screen can be made, proceed to step 4. **2.** We recommend setting the desktop pattern to that as shown in the diagram below.



#### NOTE

• More precise adjustment is available for using the "Screen Adjustment program" software. It can be downloaded from the EIZO homepage (http://www.eizo.com).

#### **3.** Adjust by using <Screen> menu in the ScreenManager.

- (1) Vertical bars appear on the screen
  - $\rightarrow$  O Use the <Clock> (p.34) adjustment.

Select the <Clock> and eliminate the vertical bars by using the Right and Left of the Control Buttons.

Do not continuously press the Control Buttons, as the adjustment value will change quickly and make it difficult to locate the most suitable adjustment point. If the horizontal flickering, blur or bars appear, proceed to <Phase> adjustment as follows.



#### (2) Horizontal bars appear on the screen.

 $\rightarrow$  ( Use the <Phase> (p.34) adjustment.

Select the <Phase> and eliminate the horizontal flickering, blurring or bars by using the Right and Left Buttons.



#### NOTE

 Horizontal bars may not completely disappear from the screen depending on the PC. (3) The screen position is incorrect.

 $\rightarrow$  Use the <Position> adjustment.

The correct displayed position of the monitor is decided because the number and the position of the pixels are fixed. The "Position" adjustment moves the image to the correct position.

Select <Position> and adjust the position by using the Up, Down, Right and Left Buttons.

If vertical bars of distortion appear after finishing the <Position> adjustment, return to <Clock> adjustment and repeat the previously explained adjustment procedure. Clock $\rightarrow$  Phase $\rightarrow$  Position



4. To adjust the output signal range (Dynamic Range) of the signal.  $\rightarrow \mathbf{adjust}$  Use the <Range Adjustment> (p.34).

This controls the level of output signal range to display the whole color gradation (256 colors).

#### [Procedure]

Press the Auto Adjustment Button on the control panel while displaying the <Range Adjustment> menu to automatically adjust the range. The screen blanks for a moment, and adjusts the color range to display the whole color gradation of the current output signal.

## **5.** To smooth the blurred texts of the enlarged screen of the lower resolutions.

#### $\rightarrow$ **II** Switch the <Smoothing> setting.

<Smoothing> is clear-cut the letters or lines.

Select <Smoothing> in the screen menu and select the suitable level from 1 ~ 5.

#### NOTE

- The "Smoothing" is disabled in the resolution 1280 x 1024.
- Since the displayed image is enlarged, the blurred texts may not be necessarily lost completely.

### 4-2. Color Adjustment

## In the analog input, perform the "Range Adjustment" (p.23) before making the color adjustments.

The <Color> menu in the ScreenManager enables to change the color of the screen. By using the <Color Mode>, the adjustment mode can be selected from <Custom> mode (to adjust the color settings according to your preference) and <sRGB> mode.

#### NOTE

- Allow the LCD monitor to stabilize for at least 30 minutes before making image adjustments. (Allow the monitor to warm up for at least 30 minutes before making adjustments.)
- Performing the <Reset> of the <Color> menu returns the color settings to the default settings.
- The values shown in percentages represent the current level within the specific adjustment. They are available only as a reference tool. (To create an uniform white or black screen, the percentages for each will probably not be the same.)

Menu	Color Mode		Function Descriptions	Adjustable range
	Custom	sRGB		
Brightness	$\checkmark$	$\checkmark$	To set the brightness of the screen	0 ~ 100%
· Ŧ、			NOTE	
			• The values shown in the "%" reference.	are available only as
			<ul> <li>Direct pressing the up and do can adjust the brightness. Af Enter button to save the data</li> </ul>	own control button also ter the adjustment, press
Temperature	$\checkmark$	-	To set the color temperature	4000 ~ 10000 K
(p.34) <b>⊥</b> K				in 500 K increments (including 9300 K).
e			NOTE	
			<ul> <li>The values shown in the Kelv reference tool.</li> </ul>	rin are available only as a
			<ul> <li>While color temperature is adjusted, <gain> is adjusted automatically according to the color temperature.</gain></li> </ul>	
			• Setting the temperature under 4000 K or over 10000 K invalidates the color temperature setting. (The color temperature's setting turns "Off".)	
			<ul> <li>Setting the <gain> invalidates the <temperature> adjustment.</temperature></gain></li> </ul>	

#### **Adjustment Contents**

Menu	Color	Mode	Function Descriptions	Adjustable range
	Custom	sRGB		
Gamma	$\checkmark$	-	To set the gamma value	1.8 ~ 2.6
(p.or)			<ul> <li>NOTE</li> <li>If setting the gamma value, the digital signal input is reco</li> </ul>	ne using the monitor in mmended.
			If using the monitor in the ana gamma value from 1.8 to 2.2	alog input signal, set the
			NOTE	
			<ul> <li>The <hue> adjustment may on tone.</hue></li> </ul>	cause undisplayable color
Gain (p.34)	$\checkmark$	-	To change each color (red,	0 ~ 100%
0			green and blue)	By adjusting the red, green and blue color tones for each mode, custom colors can be defined. Display a white or gray background image and adjust the <gain>.</gain>
			NOTE	
	1		<ul> <li>The values shown in the percentage are available only as a reference tool.</li> <li>Setting the <temperature> (p.34) invalidates the <gain> adjustment. The <gain> setting varies with color temperature.</gain></gain></temperature></li> </ul>	
Reset 😱	$\checkmark$	-	To return the color settings to the default settings	Select the <reset>.</reset>

## **5. ATTACHING A STAND**

The LCD monitor can be used with other stand by removing the tilt stand and attaching the stand to the LCD monitor.

#### NOTE

- When attaching an arm or stand, follow the instructions of their user's manual.
- When using another manufacturer's arm or stand, confirm the following in advance and select one conforming to the VESA standard.
  - Clearance between the screw holes: 100 mm x 100 mm
  - Thickness of plate: 2.6 mm
  - Strong enough to support weight of the monitor unit (except the stand) and attachments such as cables.
- Attach an arm or stand to meet the following tilt angles of the monitor.
   Up 45 degrees, down 0 degrees (Within operating range)
- Please connect cables after attaching a stand.

#### **Setup Procedure**

- **1.** Lay the LCD monitor down. Do not scratch the panel.
- **2.** Remove the tilt stand by loosening the 4 screws.
- **3.** Attach a stand to the LCD monitor securely with the same screws.



4 Mounting Screws: M4 x 12 mm

## **6. TROUBLESHOOTING**

If a problem persists even after applying the suggested remedies, contact an EIZO dealer. The latest FAQ information is supplied on EIZO homepage (http://www.eizo.com).

• No Picture Problems

Problems	Points to check with possible solutions		
<ol> <li>No picture</li> <li>Indicator status: Off</li> </ol>	□ Check that the power cord is correctly connected. If the problem persists, turn off the monitor power for a few minutes, then turn it back on and try again.		
• Indicator status: Blue	□ Check the "Brightness" setting.		
• Indicator status: Orange Flashing	<ul> <li>Switch the signal input by pressing the Input Signal Selection Button on the front control panel.</li> <li>Try pressing the power button.</li> </ul>		
2. Following messages appear. (Error messages shown below will remain on the screen for 40	These message appear when the signal is not inputted correctly, even if the monitor functions properly.		
seconds.)	When the image is displayed correctly after a short time, there is no problem with the		
Signal Check Analog	monitor. (Some PCs do not output the signal soon after powering on.)		
No Signal	$\Box$ Check that the PC is turned ON.		
No orginar	□ Check that the signal cable is properly connected to the PC or graphics board.		
	Switch the signal input by pressing the Input Signal Selection Button on the front control panel.		
• The message below shows that the input signal is out of the specified frequency range. (Such signal	□ Check whether the signal setting of your PC matches the resolution and the vertical frequency settings for the monitor(p.13).		
frequency is displayed in red.)	□ Reboot the PC.		
Signal Error Digital	Select an appropriate display mode using the graphics board's utility. Refer to the manual of the graphics board for details.		
fD: 70.0MHz fH: 40.0kHz fV: 60.0Hz	fD: Dot Clock (Displayed only when the digital signal inputs) fH: Horizontal Frequency		
	fV: Vertical Frequency		

#### • Imaging problems

Problems	Points to check with possible solutions
3. Display position is incorrect.	□ Adjust the image position using the <position> (p.23)</position>
	□ The two display modes, VGA 720 x 400 (70 Hz) and 320 x 200 (70 Hz), have the same signal timings. Using this adjustment selects the appropriate display mode. (This function effects only when the resolution is VGA 720 x 400 (70 Hz) or 320 x 200 (70 Hz).
	□ If the problem persists, use the graphics board's utility software to change the display position if available.
4. Vertical bars of distortion appear.	□ Decrease the vertical bars using the <clock>. (p.22)</clock>
5. Horizontal bars of distortion appear.	□ Decrease the horizontal bars using the <phase>. (p.22)</phase>
6. Letters and lines appear blurred.	$\Box$ Switch the <smoothing> mode. (p.23)</smoothing>
7. The screen is too bright or too dark.	□ Adjust the <brightness> (The backlight of the LCD monitor has a fixed life span. When the screen becomes dark or begins to flicker, please consult your dealer.)</brightness>
8. Afterimages appear.	Do you use the screen saver or timer (p.19) when displaying the same image for extended periods of time?
	□ Afterimages are particular to LCD monitors. Avoid displaying the same image for extended periods of time. (p.19)
<ol> <li>The screen has defective pixels (e.g. slightly light or dark).</li> </ol>	□ This is due to the characteristics of the panel itself, and not the LCD product.

#### • Other problems

Problems	Points to check with possible solutions
10.The <smoothing> cannot be selected.</smoothing>	□ <smoothing> is disabled when the screen is displayed in the 1280 x 1024.</smoothing>
11.The Enter Button does not operate.	□ The adjustment lock is probably on. To unlock: switch the LCD monitor off. Then, while pressing the Auto Adjustment Button switch, the power on. (p.19)
12.The Auto Adjustment Button does not operate.	□ The adjustment lock is probably on. To unlock: switch the LCD monitor off. Then, while pressing the Auto Adjustment Button switch, the power on. (p.19)
	<ul> <li>The Auto adjustment function is intended for use on the AT-compatible PC running Windows. It may not work properly in either of the following cases.</li> </ul>
	• When running an AT-compatible PC on MS- DOS (Not Windows).
	• The background color for the "wall paper" or "desktop" pattern is set to black.
	□ Some signals from a graphics board may not function properly.

#### • Touch Panel Problems

Problems	Points to check with possible solutions
13.Cursor is jittery. / Drawing lines are not straight and smooth.	<ul> <li>The influence of metal may cause jittery cursor.</li> <li>When multiple monitors are placed close to each other, leave space between monitors.</li> </ul>
14.Cursor position is not correct. / Cursor jumps.	□ When cursor position is incorrect or cursor jumps, turn off and on the monitor. If the symptom is not improved, perform the calibration on the monitor.
	• Do not touch the screen while turning on the PC and the monitor. Touch the screen five seconds later after appearing the image.
	• Touch the screen five seconds later after connecting the USB cable.
	• Changing the position or angle of the monitor will cause cursor jump.
	□ The drawing touch and dragging the finger on the touch panel to draw the picture may cause incorrect cursor position.
	□ Keep metals away from the panel surface.
	□ Touch with one finger only. Keep other fingers away from the touch screen. Do not rest the hand in the monitor or bezel while touching the screen.
	□ The spray for preventing static electricity may infl uences the sensibility of the touch panel. Do not use it on cleaning.
15.No touch sound.	□ The touch sound may not be output from the external line out of the PC depending on the hardware configuration.

## 7. SPECIFICATIONS

LCD Panel		43 cm (17.0 inch), TFT color LCD panel with Anti-Glare Hard Coating, Viewing Angle: H: 178°, V: 178° (CR≥10)		
Dot Pitch		0.264 mm		
Horizontal Scan Frequency		Analog: 30 ~ 81 kHz (Automatic) Digital: 30 ~ 65 kHz		
Vertical Scan F	requency	Analog: 49.5 ~ 75.5 Hz (Automatic) Digital:  59 ~ 61 Hz, (VGA TEXT : 70Hz)		
Resolution		1 M pixels (1280 dots x 1024 lines)		
Dot Clock (Max	(.)	Analog: 135 MHz Digital: 109 MHz		
Display Colors		16.77 million colors (max.)		
Display Area		337.9 mm (H) x 270.3 mm (V) (13.3" (H) x 10.6" (V)) (Viewable image size: 432 mm (17.0"))		
Touch Panel	OS	Microsoft Windows 2000 Service Pack 4		
		Microsoft Windows XP Service Pack 3 (32 bit)		
		Microsoft Windows Vista Service Pack 1 (32 bit) (Not compatible with Mac OS)		
	Communication protocol	USB		
Communication Speed		Full speed		
Detective method		Analog capacitive technology, finger touch		
Power Supply		100-120/200-240 VAC±10%, 50/60 Hz, 0.55-0.5 A/0.35-0.3 A		
Power Consum	ption	Max.: 32 W		
Input Connecto	or	D-Sub mini 15 pin, DVI-D		
Analog Input Si	ignal (Sync)	Separate, TTL, Positive/Negative		
Analog Input Si	ignal (Video)	0.7Vp-p/75Ω Positive		
Input Signal (D	igital)	TMDS (Single Link)		
Signal registrat	ion	Analog: 45 (Factory preset: 16)		
Plug & Play		VESA DDC 2B / EDID structure 1.3		
Dimensions with stand		380 mm (W) x 432.5 ~514.5mm(H) x 208.5 mm (D) (15.0"(W) x 17.0" ~ 20.3"(H) x 8.2"(D))		
	without stand	380 mm (W) x 353 mm (H) x 58 mm (D) (15.0"(W) x 13.9"(H) x 2.28" (D))		
Weight	with stand	8.2 kg (18.1 lbs.)		
	without stand	5.2 kg (11.5 lbs.)		
Environment conditions	Temperature	Operating: 0 °C ~ 35 °C (32 °F ~ 95 ° F) Storage: -20 °C ~ 60 °C (-4 °F ~ 140 ° F)		
	Humidity	Operating: 20% to 80% R.H. Non-condensing Storage: 10% to 80% R.H. Non-condensing		
	Pressure	Operating: 700 hPa to 1060 hPa		
		Storage: 200 hPa to 1060 hPa		

Classification of Equipment	Type of protection against electric shock: Class I
	EMC class: EN60601-1-2:2001+A1:2006 Group1 Class B
	Classification of medical device (MDD 93/42/EEC): Class I

#### **Default settings**

Brightness	100%
Smoothing	3
Temperature	Off (normal white: approx. 6500 K)
Input Signal	Auto
Off Timer	Disable
Language	English

#### Optional

Touch Panel Pointer	TP1
Signal Cable	FD-C39
Cleaning kit	EIZO "ScreenCleaner"

#### Dimensions

Unit:mm (inches)



#### **Pin Assignment**

## D-Sub mini 15 pin connector

60000 0000000	Pin No.	Signal	Pin No.	Signal	Pin No.	Signal
	1	Red video	6	Red video ground	11	Ground
	2	Green video	7	Green video ground	12	Data (SDA)
	3	Blue video	8	Blue video ground	13	H. Sync
	4	Ground	9	NC*	14	V. Sync
	5	NC*	10	Ground	15	Clock (SCL)

(\*NC: No Connection)

#### **DVI-D** Connector

9 101111213141516
-------------------

Pin No.	Signal	Pin No.	Signal	Pin No.	Signal
1	TMDS Data2-	9	TMDS Data1-	17	TMDS Data0-
2	TMDS Data2+	10	TMDS Data1+	18	TMDS Data0+
3	TMDS Data2/4	11	TMDS Data1/3	19	TMDS Data0/5
	Shield		Shield		Shield
4	NC*	12	NC*	20	NC*
5	NC*	13	NC*	21	NC*
6	DDC Clock (SCL)	14	+5V Power	22	TMDS Clock shield
7	DDC Data (SDA)	15	Ground (For +5V)	23	TMDS Clock+
8	NC*	16	Hot Plug Detect	24	TMDS Clock-
				(	*NC: No Connection)

\*NC: No Connection)

#### **USB** Port

#### Upstream



Series B

No.	Signal	Signal
1	VCC	Cable power
2	- Data	Serial data
3	+ Data	Serial data
4	Ground	Cable Ground

## 8. GLOSSARY

#### Clock

With the analog input signal display, the analog signal is converted to a digital signal by the LCD circuitry. To convert the signal correctly, the LCD monitor needs to produce the same number clock pulse as the dot clock of the graphics system. When the clock pulse is not correctly set, some vertical bars of distortion are displayed on the screen.

#### **Color Temperature (Temperature)**

Color Temperature is a method to measure the white color tone, generally indicated in degrees Kelvin. At high temperatures the white tone appears somewhat blue, while at lower temperatures it appears somewhat red. Computer monitors generally give best performance at high temperature settings.

5000 K: Slightly reddish white.

6500 K: White called daylight color.

9300 K: Slightly bluish white.

#### **DVI (Digital Visual Interface)**

A digital flat panel interface. DVI can transmit digital data from the PC directly without loss with the signal transition method "TMDS".

There are two kinds of DVI connectors. One is DVI-D connector for digital signal input only. The other is DVI-I connector for both digital and analog signal inputs.

#### Gain

Adjusts each color parameter for red, green and blue. The color of the LCD monitor is displayed through the color filter of the LCD panel. Red, green and blue are the three primary colors. The colors on the monitor are displayed by combining these three colors. The color tone can change by adjusting the illumination amount passed through each color's filter.

#### Gamma

Generally, the relationship that the light intensity values of a monitor change nonlinearly to the input signal level is called "Gamma Characteristic". On the monitor, low gamma values display the whitish images and high gamma values display the high contrast images.

#### Phase

The phase adjustment decides the sampling timing point for converting the analog input signal to a digital signal. Adjusting the phase after the clock adjustment will produce a clear screen.

#### Range Adjustment

The Range Adjustment controls the level of output signal range to display the whole color gradation.

#### Resolution

The LCD panel consists of a fixed number of pixel elements which are illuminated to form the screen image. The display panel of this monitor consists of 1280 horizontal pixels and 1024 vertical pixels. At a resolution of 1280 x 1024, images are displayed as a full screen (1:1).

#### sRGB (Standard RGB)

"International Standard for Red, Green, and Blue color space"

A color space was defined with the aim of the color matching between applications and hardware devices, such as monitors, scanners, printers and digital cameras. As a standard default space, sRGB allows Internet users to closely match colors.

#### TMDS (Transition Minimized Differential Signaling)

A signal transition method for the digital interface.

## **APPENDIX/ANHANG/ANNEXE**

#### Preset Timing Chart for Analog input Timing-Übersichten für Analog Eingang Synchronisation des Signaux pour Analog numerique

Based on the signal diagram shown below factory presets have been registered in the monitor's microprocessor.

Der integrierte Mikroprozessor des Monitors unterstützt werkseitige Standardeinstellungen (siehe hierzu die nachfolgenden Diagramme).

Signaux ont été enregistrés en usine dans le microprocesseur du moniteur, conformément au diagramme de synchronisation ci-dessous.

Mada	Dot Clock MHz	Sync Polarity		Frequencies	
Mode		н	v	H kHz	V Hz
VGA Graphics 320 x 200	25.2	Nega.	Nega.	31.47	70.09
VGA 640 x 480	25.2	Nega.	Nega.	31.47	59.94
VGA TEXT 720 x 400	28.3	Nega.	Posi.	31.47	70.09
VESA 640 x 480	31.5	Nega.	Nega.	37.86	72.81
VESA 640 x 480	31.5	Nega.	Nega.	37.50	75.00
VESA 800 x 600	36.0	Posi.	Posi.	35.16	56.25
VESA 800 x 600	40.0	Posi.	Posi.	37.88	60.32
VESA 800 x 600	50.0	Posi.	Posi.	48.08	72.19
VESA 800 x 600	49.5	Posi.	Posi.	46.88	75.00
VESA 1024 x 768	65.0	Nega.	Nega.	48.36	60.00
VESA 1024 x 768	75.0	Nega.	Nega.	56.48	70.07
VESA 1024 x 768	78.8	Posi.	Posi.	60.02	75.03
VESA 1152 x 864	108.0	Posi.	Posi.	67.50	75.00
VESA 1280 x 960	108.0	Posi.	Posi.	60.00	60.00
VESA 1280 x 1024	108.0	Posi.	Posi.	63.98	60.02
VESA 1280 x 1024	135.0	Posi.	Posi.	79.98	75.03

## **EMC Information**

Essential performance of FlexScan L560T-CB is to display images and operate functions normally.

## 

The FlexScan L560T-CB requires special precautions regarding EMC and need to be installed, put into service and used according to the following information.

Do not use any cables other than the cables that provided or specified by us. Using other cables may cause the increase of emission or decrease of immunity.

Do not put any portable and mobile RF communications equipment close to the FlexScan L560T-CB. Doing so may affect the FlexScan L560T-CB.

The FlexScan L560T-CB should not be used adjacent to or stacked with other equipment. If adjacent or stacked use is necessary, the equipment or system should be observed to verify normal operation in the configuration in which it will be used.

Guidance and manufacturer's declaration - electromagnetic emissions				
The FlexScan L560T-CB is intended for use in the electromagnetic environment specified below. The customer or the user of the FlexScan L560T-CB should assure that it is used in such an environment.				
Emission test	Compliance	Electromagnetic environment - guidance		
RF emissions EN55011	Group 1	The FlexScan L560T-CB uses RF energy only for its internal function. Therefore, its RF emission are very low and are not likely to cause any interference in nearby electronic equipment.		
RF emissions EN55011	Class B	The FlexScan L560T-CB is suitable for use in all establishments, including domestic establishments and those directly connected		
Harmonic emissions EN61000-3-2	Not applicable	to the public low-voltage power supply network that supplies buildings used for domestic purposes.		
Voltage fluctuations / flicker emissions EN61000-3-3	Complies			

Guidance and manufacturer's declaration - electromagnetic immunity				
The FlexScan L560T-CB is intended for use in the electromagnetic environment specified below.				
Immunity test	IEC60601 test level	Compliance level	Electromagnetic environment - guidance	
Electrostatic discharge (ESD) EN61000-4-2	±6kV contact ±8kV air	±6kV contact ±8kV air	Floors should be wood, concrete or ceramic tile. If floors are covered with synthetic material, the relative humidity should be at least 30%.	
Electrical fast transient / burst EN61000-4-4	±2kV for power supply lines ±1kV for input/output lines	±2kV for power supply lines ±1kV for input/output lines	Mains power quality should be that of a typical commercial or hospital environment.	
Surge EN61000-4-5	±1kV line(s) to line(s) ±2kV line(s) to earth	±1kV line(s) to line(s) ±2kV line(s) to earth	Mains power quality should be that of a typical commercial or hospital environment.	
Voltage dips, short interruptions and voltage variations on power supply input lines EN61000-4-11	<5% UT (>95% dip in UT) for 0.5 cycle 40% UT (60% dip in UT) for 5 cycles 70% UT (30% dip in UT) for 25 cycles <5% UT (>95% dip in UT) for 5sec	<5% UT (>95% dip in UT) for 0.5 cycle 40% UT (60% dip in UT) for 5 cycles 70% UT (30% dip in UT) for 25 cycles <5% UT (>95% dip in UT) for 5sec	Mains power quality should be that of a typical commercial or hospital environment. If the user of the FlexScan L560T-CB requires continued operation during power mains interruptions, it is recommended that the FlexScan L560T-CB be powered from an uninterruptible power supply or a battery.	
Power frequency (50/60Hz) magnetic field EN61000-4-8	3A/m	3A/m	Power frequency magnetic fields should be at levels characteristic of a typical location in a typical commercial or hospital environment.	

**NOTE** UT is the a.c. mains voltage prior to application of the test level.

Г

.

Guidance and manufacturer's declaration - electromagnetic immunity				
The FlexScan L560T-	CB is intended for use in	the electromagnetic envi	ronment specified below. The	
customer or the user of	of the FlexScan L560T-Cl	3 should assure that it is	used in such an environment.	
Immunity test	IEC60601 test level	Compliance level	Electromagnetic environment - guidance	
Conducted RF EN61000-4-6 Radiated RF EN61000-4-3	3Vrms 150kHz to 80MHz 3V/m 80MHz to 2.5GHz	3V 3V/m	Portable and mobile RF communications equipment should be used no closer to any part of the FlexScan L560T-CB, including cables, than the recommended separation distance calculated from the equation applicable to the frequency of the transmitter. Recommended Separation distance $d = 1.2 \sqrt{P}$ $d = 1.2 \sqrt{P}$ , 80MHz to 800MHz $d = 2.3 \sqrt{P}$ , 800MHz to 2.5GHz Where "P" is the maximum output power rating of the transmitter in watts (W) according to the transmitter manufacturer and "d" is the recommended separation distance in meters (m). Field strengths from fixed RF transmitters, as determined by an electromagnetic site survey <sup>a</sup> , should be less than the compliance level in each frequency range <sup>b</sup> . Interference may occur in the vicinity of equipment marked with the following symbol.	
	1			

NOTE 1 At 80 MHz and 800 MHz, the higher frequency range applies.

NOTE 2 These guidelines may not apply in all situations. Electromagnetic propagation is affected by absorption and reflection from structures, objects and people.

<sup>a</sup> Field strengths from fixed transmitters, such as base stations for radio (cellular/cordless) telephones and land mobile radios, amateur radio, AM and FM radio broadcast and TV broadcast cannot be predicted theoretically with accuracy. To assess the electromagnetic environment due to fixed RF transmitters, an electromagnetic site survey should be considered. If the measured field strength in the location in which the FlexScan L560T-CB is used exceeds the applicable RF compliance level above, the FlexScan L560T-CB should be observed to verify normal operation. If abnormal performance is observed, additional measures may be necessary, such as reorienting or relocating the FlexScan L560T-CB.
 <sup>b</sup> Over the frequency range 150 kHz to 80 MHz, field strengths should be less than 3 V/m.

## Recommended separation distances between portable and mobile RF communications equipment and the FlexScan L560T-CB

The FlexScan L560T-CB is intended for use in an electromagnetic environment in which radiated RF disturbances are controlled. The customer or the user of the FlexScan L560T-CB can help prevent electromagnetic interference by maintaining a minimum distance between portable and mobile RF communications equipment (transmitters) and the FlexScan L560T-CB as recommended below, according to the maximum output power of the communications equipment.

× *				
Rated maximum output	Separation distance according to frequency of transmitter			
	111			
W	150kHz to $80$ MHz d = $1.2 \sqrt{P}$	80MHz to 800MHz d = $1.2 \sqrt{P}$	800MHz to 2.5GHz d = $2.3 \sqrt{P}$	
0.01	0.12	0.12	0.23	
0.1	0.38	0.38	0.73	
1	1.2	1.2	2.3	
10	3.8	3.8	7.3	
100	12	12	23	

For transmitters rated at a maximum output power not listed above, the recommended separation distance "d" in meters (m) can be estimated using the equation applicable to the frequency of the transmitter, where "P" is the maximum output power rating of the transmitter in watts (W) according to the transmitter manufacturer.

NOTE 1 At 80 MHz and 800 MHz, the separation distance for the higher frequency range applies.

NOTE 2 These guidelines may not apply in all situations. Electromagnetic propagation is affected by absorption and reflection from structures, objects and people.

Cable length		
Power Cord :	Accessary	2.0m
Signal Cable (MD-C87) :	Accessary	1.8m
USB Cable (MD-C93) :	Accessary	1.8m
Signal Cable (FD-C39) :	Option	2.0m



#### EIZO NANAO CORPORATION

153 Shimokashiwano, Hakusan, Ishikawa 924-8566 Japan Phone: +81 76 277 6792 Fax: +81 76 277 6793

EIZO GmbH

Siemensallee 84, 76187 Karlsruhe, Germany Phone: +49 721 595 2614 Fax: +49 721 595 4558



This document is printed on recycled chlorine free paper.

http://www.eizo.com

1st Edition-March, 2009 Printed in Japan. 00N0L507A1 (U.M-L560T-CB-EU)