

CIC MegaCore Function User Guide



101 Innovation Drive San Jose, CA 95134 www.altera.com Software Version: Document Date: 11.0 May 2011

Copyright © 2011 Altera Corporation. All rights reserved. Altera, The Programmable Solutions Company, the stylized Altera logo, specific device designations, and all other words and logos that are identified as trademarks and/or service marks are, unless noted otherwise, the trademarks and service marks of Altera Corporation in the U.S. and other countries. All other product or service names are the property of their respective holders. Altera products are protected under numerous U.S. and foreign patents and pending applications, maskwork rights, and copyrights. Altera warrants performance of its semiconductor products to current specifications in accordance with Altera's standard warranty, but reserves the right to make changes to any products and services at any time without notice. Altera assumes no responsibility or liability arising out of the application or use of any information, product, or service described herein except as expressly agreed to in writing by Altera Corporation. Altera customers are advised to obtain the latest version of device specifications before relying on any published information and before placing orders for products or services.





Contents

Chapter 1. About This MegaCore Function

Features	1–1
Release Information	1–2
Device Family Support	1–2
MegaCore Verification	1–3
Performance and Resource Utilization	1–3
Installation and Licensing	1–5
OpenCore Plus Evaluation	1–5
OpenCore Plus Time-Out Behavior	1–6

Chapter 2. Getting Started

Design Flows	. 2–1
DSP Builder Flow	. 2–1
MegaWizard Plug-In Manager Flow	. 2–2
Generated Files	. 2–6
Simulate the Design	. 2–7
Simulating in Third-Party Simulation Tools Using NativeLink	. 2–7
Compile the Design and Program a Device	. 2–8

Chapter 3. Parameter Settings

Parameter Setting Exam	ples	 	 	
Parameter Descriptions		 	 	

Chapter 4. Functional Description

Cascaded Integrator Comb Filters	4–1
Typical Frequency Response	4–2
Data Storage	4–3
Output Options	4–3
Output Data Width	4–3
Output Rounding	4–4
Hogenauer Pruning	4–4
Multi-Channel Support	4–4
Multiple Input Single Output (MISO)	4–5
Single Input Multiple Output (SIMO)	4–6
Variable Rate Change Factors for Decimation and Interpolation	4–7
FIR Filter Compensation Coefficients	4–7
Avalon Streaming Interface	4–9
Avalon-ST Interface Data Transfer Timing	4–11
Packet Data Transfers	4–11
Signals	4–12
Referenced Documents	4–13

Additional Information

Revision History	Info-1
How to Contact Altera	Info-1
Typographic Conventions	Info-2

1. About This MegaCore Function



This document describes the Altera[®] CIC MegaCore[®] function. The Altera CIC MegaCore function implements a cascaded integrator-comb filter with data ports that are compatible with the Avalon[®] Streaming (Avalon-ST) interface. CIC filters (also known as Hogenauer filters) are computationally efficient for extracting baseband signals from narrow-band sources using decimation, and for constructing narrow-band signals from processed baseband signals using interpolation.

CIC filters use only adders and registers, and require no multipliers to handle large rate changes. Therefore, CIC is a suitable and economical filter architecture for hardware implementation, and is widely used in sample rate conversion designs such as digital down converters (DDC) and digital up converters (DUC).

For a more detailed description, refer to "Cascaded Integrator Comb Filters" on page 4–1.

Features

The Altera CIC MegaCore function supports the following features:

- Support for interpolation and decimation filters with variable rate change factors (2 to 32,000), a configurable number of stages (1 to 12), and two differential delay options (1 or 2).
- Single clock domain with selectable number of interfaces and a maximum of 1,024 channels.
- Selectable data storage options with an option to use pipelined integrators.
- Configurable input data width (1 to 32 bits) and output data width (1 to full resolution data width).
- Selectable output rounding modes (truncation, convergent rounding, rounding up, or saturation) and Hogenauer pruning support.
- Optimization for speed by specifying the number of pipeline stages used by each integrator.
- Compensation filter coefficients generation.
- Easy-to-use MegaWizardTM interface for parameterization and hardware generation.
- IP functional simulation models for use in Altera-supported VHDL and Verilog HDL simulators.
- DSP Builder ready.

Release Information

Table 1–1 provides information about this release of the Altera CIC MegaCore function.

Item	Description
Version	11.0
Release Date	May 2011
Ordering Code	IP-CIC
Product ID(s)	00BB
Vendor ID(s)	6AF7

Table 1–1. CIC MegaCore Function Release Information

For more information about this release, refer to the *MegaCore IP Library Release Notes and Errata*.

Altera verifies that the current version of the Quartus[®] II software compiles the previous version of each MegaCore function. The *MegaCore IP Library Release Notes and Errata* report any exceptions to this verification. Altera does not verify compilation with MegaCore function versions older than one release.

Device Family Support

Table 1–2 defines the device support levels for Altera IP cores.

 Table 1–2.
 Altera IP Core Device Support Levels

FPGA Device Families	HardCopy Device Families
Preliminary support —The IP core is verified with preliminary timing models for this device family. The IPcore meets all functional requirements, but might still be undergoing timing analysis for the device family. It can be used in production designs with caution.	HardCopy Companion —The IP core is verified with preliminary timing models for the HardCopy companion device. The IP core meets all functional requirements, but might still be undergoing timing analysis for the HardCopy device family. It can be used in production designs with caution.
Final support —The IP core is verified with final timing models for this device family. The IP core meets all functional and timing requirements for the device family and can be used in production designs.	HardCopy Compilation —The IP core is verified with final timing models for the HardCopy device family. The IP core meets all functional and timing requirements for the device family and can be used in production designs.

Table 1–3 shows the level of support offered by the CIC MegaCore function to each Altera device family.

Table 1–3.	Device Family Support	(Part 1 of 2)
------------	-----------------------	---------------

Device Family	Support
Arria® GX	Final
Arria II GX	Final
Arria II GZ	Final
Cyclone®	Final

Device Family	Support
Cyclone II	Final
Cyclone III	Final
Cyclone III LS	Final
Cyclone IV GX	Final
HardCopy [®] II	HardCopy Compilation
HardCopy III	HardCopy Compilation
HardCopy IV E	HardCopy Compilation
HardCopy IV GX	HardCopy Compilation
Stratix®	Final
Stratix II	Final
Stratix II GX	Final
Stratix III	Final
Stratix IV GT	Final
Stratix IV GX/E	Final
Stratix V	Preliminary
Stratix GX	Final
Other device families	No support

Table 1–3. Device Family Support (Part 2 of 2)

MegaCore Verification

Before releasing a version of the CIC MegaCore function, Altera runs comprehensive regression tests to verify its quality and correctness.

Custom variations of the CIC MegaCore function are generated to exercise its various parameter options, and the resulting simulation models are thoroughly simulated with the results verified against master simulation models.

Performance and Resource Utilization

This section shows typical expected performance for a CIC MegaCore function using the Quartus II software with Cyclone III and Stratix IV devices.

The following general settings apply to all parameterizations:

- Number of stages: 5
- Rate change factor: 8
- Differential delay: 1
- Integrator data storage: Memory (whenever possible)
- Differentiator data storage: Memory (whenever possible)
- Input data width: 16
- **Output data width**: 16 (unless specified otherwise in table)
- Output rounding: Truncation

Cyclone III devices use combinational look-up tables (LUTs) and logic registers; Stratix IV devices use combinational adaptive look-up tables (ALUTs) and logic registers.

Table 1–4 shows the performance figures for the CIC MegaCore function, with a target $f_{\rm MAX}$ set to 1GHz.

 Table 1–4.
 CIC MegaCore Function Performance

Dovice	Combinational	Logio		Memory <i>(3)</i>		
Family	LUTS/ALUTS	Registers	Bits	M9K	ALUTs	(MHz)
Decimator, Full ou	utput resolution (C	output data width	= 31),1 channel p	er interface, 1 inte	rface	
Cyclone III (1)	480	806				288
Stratix IV (2)	391	725	128		16	502
Decimator, Hogen	auer pruning on,	output data width	= 16, 1 channel p	er interface, 1 inte	erface	
Cyclone III (1)	388	606	—	—	—	312
Stratix IV (2)	314	525	128	—	16	526
Interpolator, Full of	output resolution	Output data width	n = 29), 1 channel	per interface, 1 in	terface	
Cyclone III (1)	401	582	—	—	—	304
Stratix IV (2)	297	501	128	—	16	509
Interpolator, Conv	vergent rounding,	1 channel per inte	rface, 1 interface			
Cyclone III (1)	408	560	—	—	—	292
Stratix IV (2)	315	479	128	—	16	470
Decimator, Hogen	auer pruning on,	5 channels per int	erface, 1 interface)	·	-
Cyclone III (1)	763	893	875	11	—	268
Stratix IV (2)	537	952	1,003	8	74	492
Decimator, Hogen	auer pruning on,	5 channels per int	erface, 3 interface	S	·	-
Cyclone III (1)	1,357	1,411	3,211	21	—	261
Stratix IV (2)	890	1,497	3,211	24	12	459
Decimator, Hogen	auer pruning off,	Truncation, 1 chai	nnel per interface,	1 interface		
Cyclone III (1)	465	746	—	—	—	302
Stratix IV (2)	391	665	128	—	16	509
Interpolator, Trun	cation, 5 channels	per interface, 1 ir	nterface			-
Cyclone III (1)	738	847	660	10	—	283
Stratix IV (2)	512	938	788	6	90	486
Interpolator, Trun	cation, 5 channels	per interface, 3 ir	nterfaces			
Cyclone III (1)	1,501	1,657	2,426	17	_	188
Stratix IV (2)	913	1,753	2,426	20	16	345

Notes to Table 1-4:

(1) Using EP3C10F256C6 devices.

(2) Using EP4SGX70DF29C2X devices.

(3) It may be possible to significantly reduce memory utilization by setting a lower target f_{MAX} .

Installation and Licensing

The CIC MegaCore function is part of the MegaCore IP Library, which is distributed with the Quartus[®] II software and can be downloaded from the Altera[®] website, www.altera.com.



For system requirements and installation instructions, refer to the *Altera Software Installation and Licensing* manual.

Figure 1–1 shows the directory structure after you install the CIC MegaCore function, where *<path>* is the installation directory for the Quartus II software.



The default installation directory on Windows is **c:\altera***<version>*; or on Linux is */opt/altera<version>*.

OpenCore Plus Evaluation

With Altera's free OpenCore Plus evaluation feature, you can perform the following actions:

- Simulate the behavior of a megafunction (Altera MegaCore function or AMPPSM megafunction) within your system.
- Verify the functionality of your design, as well as evaluate its size and speed quickly and easily.
- Generate time-limited device programming files for designs that include megafunctions.
- Program a device and verify your design in hardware.

You only need to purchase a license for the CIC MegaCore function when you are completely satisfied with its functionality and performance, and want to take your design to production.

After you purchase a license, you can request a license file from the Altera website at **www.altera.com/licensing** and install it on your computer. When you request a license file, Altera emails you a **license.dat** file. If you do not have Internet access, contact your local Altera representative.

Figure 1–1. Directory Structure

For more information about OpenCore Plus hardware evaluation, refer to *AN320: OpenCore Plus Evaluation of Megafunctions.*

OpenCore Plus Time-Out Behavior

OpenCore Plus hardware evaluation supports the following operation modes:

- *Untethered*—the design runs for a limited time.
- Tethered—requires a connection between your board and the host computer. If tethered mode is supported by all megafunctions in a design, the device can operate for a longer time or indefinitely.

All megafunctions in a device time-out simultaneously when the most restrictive evaluation time is reached. If there is more than one megafunction in a design, a specific megafunction's time-out behavior might be masked by the time-out behavior of the other megafunctions.

The untethered time-out for the CIC MegaCore function is one hour; the tethered time-out value is indefinite.

The data output signal is forced to zero when the hardware evaluation time expires.

2. Getting Started



Design Flows

The CIC MegaCore[®] function supports the following design flows:

- **DSP Builder**: Use this flow if you want to create a DSP Builder model that includes a CIC MegaCore function variation.
- **MegaWizard**TM **Plug-In Manager**: Use this flow if you would like to create a CIC MegaCore function variation that you can instantiate manually in your design.

This chapter describes how you can use a CIC MegaCore function in either of these flows. The parameterization is the same in each flow and is described in Chapter 3, Parameter Settings.

After parameterizing and simulating a design in either of these flows, you can compile the completed design in the Quartus II software.

DSP Builder Flow

Altera's DSP Builder product shortens digital signal processing (DSP) design cycles by helping you create the hardware representation of a DSP design in an algorithmfriendly development environment.

DSP Builder integrates the algorithm development, simulation, and verification capabilities of The MathWorks MATLAB® and Simulink® system-level design tools with Altera Quartus® II software and third-party synthesis and simulation tools. You can combine existing Simulink blocks with Altera DSP Builder blocks and MegaCore function variation blocks to verify system level specifications and perform simulation.

In DSP Builder, a Simulink symbol for the MegaCore function appears in the MegaCore Functions library of the Altera DSP Builder Blockset in the Simulink library browser.

You can use the CIC MegaCore function in the MATLAB/Simulink environment by performing the following steps:

- 1. Create a new Simulink model.
- 2. Select the cic_<version> block from the MegaCore Functions library in the Simulink Library Browser, add it to your model, and give the block a unique name.
- Double-click the cic_<version> block in your model to display the MegaWizard interface and parameterize the MegaCore function variation. For an example of setting parameters for the CIC MegaCore function, refer to Chapter 3, Parameter Settings.
- 4. Click **Finish** in the MegaWizard interface to complete the parameterization and generate your CIC MegaCore function variation. For information about the generated files, refer to Table 2–1 on page 2–6.
- 5. Connect your CIC MegaCore function variation to the other blocks in your model.

- 6. Simulate the CIC MegaCore function variation in your DSP Builder model.
- **•** For more information about the DSP Builder flow, refer to the Using MegaCore *Functions* chapter in the DSP Builder User Guide.
- When you are using the DSP Builder flow, device selection, simulation, Quartus II compilation and device programming are all controlled within the DSP Builder environment.

DSP Builder supports integration with SOPC Builder using Avalon® Memory-Mapped (Avalon-MM) master/slave and Avalon Streaming (Avalon-ST) source/sink interfaces.

For more information about these interface types, refer to the Avalon Interface Specifications.

MegaWizard Plug-In Manager Flow

The MegaWizard[™] Plug-in Manager flow allows you to customize a CIC MegaCore function, and manually integrate the MegaCore function variation into a Quartus II design.

Follow the steps below to use the MegaWizard Plug-in Manager flow.

- 1. Create a new project using the **New Project Wizard** available from the File menu in the Quartus II software.
- 2. Launch **MegaWizard Plug-in Manager** from the Tools menu, and select the option to create a new custom megafunction variation (Figure 2–1).

Figure 2–1. MegaWizard Plug-In Manager

*	The MegaWizard Plug-In Manager helps you create or modify design files that contain custom variations of megafunctions.
	Which action do you want to perform?
<u>_</u> ∖	Create a new custom megafunction variation
	O Edit an existing custom megafunction variation
	Copy an existing custom megafunction variation
	Copyright (C) 1991-2010 Altera Corporation

3. Click Next and select CIC *<version>* from the DSP>Filters section in the Installed Plug-Ins tab. (Figure 2–2 on page 2–3).

🐇 MegaWizard Plug-In Manager [page 2a]		2
Which megafunction would you like to customize? Select a megafunction from the list below Installed Plug-Ins Altera SOPC Builder Arithmetic Communications DSP Filters CIC v10.0 FIR Compiler II v10.0 FIR Compiler v10.0 FIR Compiler v10.0 Gates JIAG-accessible Extensions Memory Compiler	 Which device family will you be using? Which type of output file do you want to AHDL VHDL Verilog HDL What name do you want for the output file of the output for the	Stratix II create? ile? te operation the Quartus II software, your design a library specified in the Libraries page of a library specified in the Libraries page menu).
	Cancel	Back Next > Finish

- 4. Verify that the device family is the same as you specified in the **New Project Wizard**.
- 5. Select the top-level output file type for your design; the wizard supports VHDL and Verilog HDL.
- 6. Specify the top level output file name for your MegaCore function variation and click **Next** to display the MegaWizard interface **Parameter Settings** page. Use the MegaWizard interface to specify the required parameters for the MegaCore function variation. For an example of setting parameters for the CIC MegaCore function, refer to Chapter 3, Parameter Settings.
- 7. Click **Next** to complete the parameterization and display the **EDA** page (Figure 2–3 on page 2–4).

MegaCore'	<u>About</u> <u>D</u> ocumentation
1 Parameter 2 EDA 3 Settings	Summary
Simulation Libraries	
To properly simulate the gen	erated design files, the following simulation model file(s) ar
File	Description
altera_mf	Altera megafunction simulation library
altera_mf_component	VHDL component declaration for altera_mf
220model	Altera LPM version 2.2.0 simulation library
220pack	VHDL component declaration for 220model
sgate	IP functional simulation library
sgate_pack	VHDL component declaration for sgate
Timing and Resource Estimation	ation
Timing and Resource Estima If you are synthesizing your generate a netlist for the sy megafunction.	ation design with a third-party EDA synthesis tool, you can nthesis tool to estimate timing and resource usage for this
Timing and Resource Estim. If you are synthesizing your generate a netlist for the sy megafunction. Generate netlist	ation design with a third-party EDA synthesis tool, you can nthesis tool to estimate timing and resource usage for this
 Timing and Resource Estimative synthesizing your generate a netlist for the sy megafunction. Generate netlist Jinfo: Device family Stratix II 	ation design with a third-party EDA synthesis tool, you can nthesis tool to estimate timing and resource usage for this
Timing and Resource Estim If you are synthesizing your generate a netlist for the sy megafunction. Generate netlist	ation design with a third-party EDA synthesis tool, you can nthesis tool to estimate timing and resource usage for this is targeted

Figure 2–3. EDA Page

8. On the **EDA** page, turn on **Generate Simulation Model**.

An IP functional simulation model is a cycle-accurate VHDL or Verilog HDL model produced by the Quartus II software.



Use the simulation models only for simulation and not for synthesis or any other purposes. Using these models for synthesis creates a non-functional design.

- 9. Some third-party synthesis tools can use a netlist that contains only the structure of the MegaCore function, but not detailed logic, to optimize performance of the design that contains the MegaCore function. If your synthesis tool supports this feature, turn on **Generate netlist**.
- 10. Click Next to display the **Summary** page (Figure 2–4).

Figure 2–4. Summary Page

4	
CIC	About Documentation
egaCore" Deremeter DEDA DESumme	
Settings	
Turn on the files you wish to gen automatically generated; all othe selected files. The MegaWizard following directory: C3mydesigns110.00cic	erate. A gray check box indicates a file that is r files are optional. Click Finish to generate the Plug-In Manager creates the selected files in the
Additional files may be generated a complete list of generated files	d. Please see the MegaCore function report file for 3.
FILE	Description
Mycic.vhd	Variation file
mycic.qip	Quartus II IP file
∐ mycic.bsf	Quartus II symbol file
mycic.cmp	VHDL component declaration file
l poucio biblu) (orilog UDL block box filo
 Mycic_bb.v ✓ mycic.html 	MegaCore function report file
✓ mycic.html	MegaCore function report file
inycic_bb.v ✓ mycic.html	MegaCore function report file
innycic_bb.v i mycic.html	MegaCore function report file
iniyete_bb.v i mycic.html	MegaCore function report file
intycic_bb.v impoie.html	MegaCore function report file
 mycic_b0.v mycic.html 	MegaCore function report file
 mycic_b0.v mycic.html 	MegaCore function report file
 mycic_b0.v mycic.html 	MegaCore function report file
 mycic_bb.v ✓ mycic.html 	MegaCore function report file
 mycic_b0.v mycic.html 	MegaCore function report file
 mycic_bt.nl ✓ mycic.html 	MegaCore function report file
nfo: Device family Stratix II is targ	Vering HDL blackborne MegaCore function report file
nfo: Device family Stratix II is targ	eted
nfo: Device family Stratix II is targ	eted
nfo: Device family Stratix II is targ	eted

- 11. On the **Summary** tab, turn on the check boxes for the files you want to generate. A grey checkmark indicates a file that is automatically generated. All other files are optional.
- 12. Click **Finish** to generate the MegaCore function and supporting files. The generation phase may take several minutes to complete. The generation progress and status is displayed in a report window.

- 13. Click **Exit** to close the progress report window. Then click **Yes** on the **Quartus II IP Files** prompt to add the .**qip** file describing your custom MegaCore function variation to the current Quartus II project.
- Refer to the Quartus II Help for more information about the MegaWizard Plug-In Manager.

Generated Files

Table 2–1 describes the generated files and other files that may be in your project directory.

The names and types of files vary depending on the variation name and HDL type you specify during parameterization For example, a different set of files are created based on whether you create your design in Verilog HDL or VHDL.

 Table 2–1.
 Generated Files
 (Note 1) & (Note 2)

Filename	Description
<entity name="">.ocp</entity>	Encrypted OpenCore Plus file.
<entity name="">.vhd or .v</entity>	A VHDL or Verilog HDL file that defines the design entity.
<variation name="">.bsf</variation>	Quartus II block symbol file for the MegaCore function variation. You can use this file in the Quartus II block diagram editor.
<variation name="">.cmp</variation>	A VHDL component declaration file for the MegaCore function variation. Add the contents of this file to any VHDL architecture that instantiates the MegaCore function. (3)
<variation name="">.html</variation>	MegaCore function report file in hypertext markup language format which contains lists of the generated files and ports for the MegaCore function variation. (3)
<variation name="">.qip</variation>	A single Quartus II IP file is generated that contains all of the assignments and other information required to process your MegaCore function variation in the Quartus II compiler. You are prompted to add this file to the current Quartus II project when you exit from the MegaWizard.
<variation name="">.log</variation>	Log file.
< <i>variation name</i> >. vhd or . v	A VHDL or Verilog HDL file that defines a VHDL or Verilog HDL top-level description of the custom MegaCore function variation. Instantiate the entity defined by this file inside of your design. Include this file when compiling your design in the Quartus II software.
<variation name="">.vho or .vo</variation>	A VHDL or Verilog HDL output file that defines the IP functional simulation model.
<variation name="">_bb.v</variation>	Verilog HDL black-box file for the MegaCore function variation. Use this file when using a third-party EDA tool to synthesize your design. (3)
<variation name="">_fir_comp_coeff.m</variation>	A MATLAB script for generating compensation FIR filter coefficients.
<variation name="">_syn.vhd or _syn.v</variation>	A timing and resource estimation netlist for use in some third-party synthesis tools. <i>(4)</i>
<variation name="">_nativelink.tcl</variation>	A Tcl script that can be used to assign NativeLink simulation testbench settings to the Quartus II project.
<variation name="">_quartus.tcl</variation>	A Tcl script that can be used to run compilation in the Quartus II software.
<variation name="">_tb_input.txt</variation>	A text file containing input data for the testbench.

Table 2–1. Generated Files (Note 1) & (Note 2)

Filename	Description
<pre>variation name>_tb.vhd, or .v</pre>	A VHDL or Verilog HDL testbench file for the CIC MegaCore function variation. The VHDL file is generated when a VHDL top level has been chosen or the Verilog HDL file when a Verilog HDL top level has been chosen.

Notes to Table 2-1:

(1) The *<variation name>* prefix is added automatically using the base output file name you specified in the MegaWizard Plug-In Manager.

- (2) The *<entity name>* prefix is added automatically. The VHDL code for each MegaCore instance is generated dynamically when you click **Finish** so that the *<entity name>* is different for every instance. It is generated from the *<variation name>* by appending **_cic**.
- (3) The .cmp, _bb.v and .html files are only generated when enabled in the Summary page of the MegaWizard interface.
- (4) The _syn.vhd or _syn.v file is only generated when enabled in the EDA page of the MegaWizard interface.
 - A MegaCore function report file containing a list of the design files and ports defined for your MegaCore function variation is saved as a HTML file if you turn on the **MegaCore function report file** check box in the MegaWizard **Summary** page.

For a full description of the signals supported on external ports for your MegaCore function variation, refer to Table 4–3 on page 4–12.

Simulate the Design

You can simulate your design using the MegaWizard-generated VHDL or Verilog HDL IP functional simulation models and testbench.

The IP functional simulation model is either a .vo or .vho file, depending on the output language you specified. Compile the .vo or .vho file in your simulation environment to perform functional simulation of your custom variation of the MegaCore function.

For more information about IP functional simulation models, refer to the *Simulating Altera Designs* chapter in volume 3 of the *Quartus II Handbook*.

Simulating in Third-Party Simulation Tools Using NativeLink

You can perform a simulation in a third-party simulation tool from within the Quartus II software, using NativeLink.

The Tcl script file *<variation name>_nativelink.tcl* can be used to assign default NativeLink testbench settings to the Quartus II project.

To perform a simulation in the Quartus II software using NativeLink, perform the following steps:

- 1. Create a custom MegaCore function variation as described earlier in this chapter but ensure you specify your variation name to match the Quartus II project name.
- 2. Verify that the absolute path to your third-party EDA tool is set in the **Options** page under the Tools menu in the Quartus II software.
- 3. On the Processing menu, point to Start and click Start Analysis & Elaboration.
- 4. On the Tools menu, click **Tcl scripts**. In the **Tcl Scripts** dialog box, select the *<variation name>_nativelink.tcl* Tcl script and click **Run**. Check for a message confirming that the Tcl script was successfully loaded.

- On the Assignments menu, click Settings, expand EDA Tool Settings, and select Simulation. Select a simulator under Tool name then in NativeLink Settings, select Compile test bench and click Test Benches.
- 6. On the Tools menu, point to **EDA Simulation Tool** and click **Run EDA RTL Simulation**.

The Quartus II software selects the simulator, and compiles the Altera libraries, design files, and testbenches. The testbench runs and the waveform window shows the design signals for analysis.



For more information, refer to the *Simulating Altera Designs* chapter in volume 3 of the *Quartus II Handbook*.

Compile the Design and Program a Device

You can use the Quartus II software to compile your design. After a successful compilation, you can program the targeted Altera device and verify the design in hardware.



For instructions on compiling and programming your design, and more information about the MegaWizard Plug-In Manager flow, refer to the Quartus II Help.



This chapter gives an example of how to parameterize a CIC MegaCore function.

The **Parameter Settings** page provides the same options whether the MegaWizard interface has been opened from the DSP Builder or MegaWizard Plug-In Manager flow. However, the **EDA** and **Summary** tabs are not visible when you are using the DSP Builder flow.

For information about opening the MegaWizard interface, refer to the "Design Flows" on page 2–1.

The MegaWizard interface only allows you to select legal combinations of parameters, and warns you of any invalid configurations.

Parameter Setting Examples

To parameterize your CIC MegaCore function, follow these steps:

1. Specify your required values in the **Parameter Settings: Architecture** page. For example Figure 3–1 on page 3–2 shows the parameter setting listed in Table 3–1.

Parameter	Value
Filter type	Decimator
Number of stages	3
Differential delay	1
Rate change factor	4
Enable variable rate change factor	Off
Number of interfaces	1
Number of channels per interface	7
Integrator data storage	Memory
RAM type of integrator data storage	AUTO
Differentiator data storage	Memory
RAM type of differentiator data storage	AUTO
Use pipelined integrators	On
Number of pipeline stages per integrator	2

Table 3-1. Example Parameters for the CIC MegaCore Function Architecture Tab

If you enable the variable rate change factor option you can also specify minimum and maximum values instead of specifying an actual rate change factor. The data storage options are only available when the number of channels per interface is greater than 4.

For more information about these parameters, refer to Table 3–3 on page 3–4.

Figure 3–1. Architecture Page

KegaWizard Plug-In Manager - CIC	
CIC	
MegaCore'	<u>About</u> <u>Documentation</u>
1 Parameter 2 EDA 3 Summary Settings	
Architecture > Input/Output Options >	
- Device Family	
Target:	Stratix II
Filter Specifications	Desimates
Fliter type:	Decimator
Number of stages:	3
Differential delay:	1
Rate change factor:	4
Variable Rate Change Factor Options	
Enable variable rate change factor	
Minimum: 2	Maximum: 3
Multi alconnel Ontiene	
Number of interfaces:	1
Number of channels ner interface:	7
Data Storage Options	
Integrator data storage:	Memory 🗸
RAM type of integrator data storage:	AUTO 🔽
Differentiator data storage:	Memory 🔽
RAM type of differentiator data storage:	AUTO
Optimize for Speed	
✓ Use ninelined integrators	
E 1990 Mitorinou integratoroj	
Number of pipeline stages per integrator:	1 🗸
Info: Device family Stratix II is targeted	
	Cancel < Back Next > Finish

- The **Parameter Settings Architecture** page displays the target device family as a read-only field showing the current selection. The target device can be specified in Signal Compiler if you are using the DSP Builder flow, or the **New Project Wizard** if you are using the MegaWizard Plug-In Manager flow.
- 2. Click **Next** to display the **Parameter Settings: Input/Output Options** page (Figure 3–2).

CIC CIC	
MegaCore*	About Documentation
1 Parameter 2 EDA 3 Summary Settings	
Architecture / Input/Output Options	>
Input Options	
Input data width:	8 V Bits
Output Options	
Full output resolution	
Output data width:	8 Sits
Output Rounding Options	
 Truncation 	
 Convergent rounding 	
 Rounding up 	
 Saturation 	
Info: Device family Stratix II is targeted	ł

Figure 3–2. Input/Output Options Page

3. Use the **Parameter Settings: Input/Output Options** page to specify the values listed in Table 3–2.

Parameter	Value
Input data width	8
Full output resolution	Off
Output data width	8
Output rounding options	Truncation
Apply Hogenauer pruning across filter stages	On

Table 3–2. Example Parameters for the CIC MegaCore Function Input/Output Options Tab

For more information about these parameters, refer to Table 3–4 on page 3–5.

Parameter Descriptions

This section describes the CIC MegaCore function parameters, which can be set in the MegaWizard interface (Refer to "Parameter Setting Examples" on page 3–1).

Table 3–3 shows the parameters that can be set in the **Architecture** page.

Parameter	Value	Description
Target	Refer to Table 1–3 on page 1–2 for the list of supported devices	Displays the target device family that you specified when you created the Quartus II project.
Filter type	Decimator, Interpolator	You can select whether to implement a decimator or interpolator.
Number of stages	1–12	Specifies the required number of stages.
Differential delay	1, 2	Specifies the differential delay in cycles.
Rate change factor	2–32000	Specifies the rate change factor.
Enable variable rate change factor	On or Off	Turn on to enable a variable rate change factor that can be changed at runtime. When this option is on, the Rate change factor parameter is not available but you can specify minimum and maximum values.
Number of interfaces	1–128	Specifies the number of MISO inputs or SIMO outputs. (1)
Number of channels per interface	1–1024	Specifies the number of channels per interface. (1)
Integrator data storage	Logic Element, Memory	You can select whether to implement the integrator data storage as logic elements or memory. (2)
RAM type of integrator data storage	AUTO, M512, M4K, M9K, M144K, MLAB	When Memory is selected, you can select the RAM type used for integrator data storage. (4)
Differentiator data storage	Logic Element, Memory	You can select whether to implement the differentiator data storage as logic elements or memory. (3)
RAM type of differentiator data storage	AUTO, M512, M4K, M9K, M144K, MLAB	When Memory is selected, you can select the RAM type used for differentiator data storage. (4)

 Table 3–3.
 CIC MegaCore Function Architecture Page (Part 1 of 2)

|--|

Parameter	Value	Description
Use pipelined integrators	On or Off	Turn on to use pipelined integrators. This option is available when the Number of channels per interface is greater than or equal to 2 (or greater than or equal to 6, when the Memory option is selected for integrator data storage).
		Use this option for multichannel designs that have large input bit width and require high f_{MAX} . This option is recommended for designs targeting Stratix family devices, but not for Cyclone family devices.
Number of pipeline stages per integrator	1–4	Specifies the number of pipeline stages used by each integrator. Adding additional integrators can improve f_{MAX} but increases the resource utilization.
		The maximum number of pipeline stages, that can be used, is dependent on the number of channels and whether Memory or Logic Cells is selected for integrator data storage. When Memory is selected, the maximum number of pipeline stages equals the number of channels minus 5. When Logic Cells is selected, the maximum number of pipeline stages equals the number of pipeline stages equals the number of pipeline stages.

Notes to Table 3-3:

- (1) The product of the **Number of interfaces** and the **Number of channels per interface** must be no more than 1024.
- (2) The Memory option is available for integrator data storage when the Number of channels per interface is greater than 4.
- (3) The Memory option is available for differentiator data storage when the product of the Differential delay, Number of channels per interface and Number of interfaces is greater than 4.
- (4) The options available depend on the target device family. When AUTO is selected, the Quartus II software automatically selects the optimum RAM type for the currently selected device family.

Table 3–4 shows the parameters that can be set in the Input/Output Options page.

S

Parameter	Value	Description
Input data width	1–32	Specifies the input data width in bits.
Full output resolution	On, Off	Turn on to enable full output resolution. When selected, the output data width is set to its maximum and the output rounding options are disabled.
Output data width	1 to calculated maximum data width	Specifies the output data width in bits.
Output Rounding Options	Truncation, Convergent rounding, Rounding up, Saturation	Select the required rounding output mode. Note that the saturation limit is the maximum value for overflow or the minimum value for negative overflow. (1)
Apply Hogenauer pruning across filter stages	On, Off	This option is available only when a Decimator filter type is selected in the Architecture page. Turn on if you want to apply Hogenauer pruning across the filter stages.

Note for Table 3-4:

(1) Refer to "Output Rounding" on page 4-4 for more information about these options.



Cascaded Integrator Comb Filters

Cascaded Integrator Comb (CIC) filters are widely used in modern communication systems. Using CIC filters provides a silicon efficient architecture for performing sample rate conversion. This is achieved by extracting baseband signals from narrowband sources using decimation, and constructing narrow-band signals from processed baseband signals using interpolation. The key advantage of CIC filters is that they use only adders and registers, and do not require multipliers to implement in hardware for handling large rate changes.

A CIC filter (also known as a Hogenauer filter) can be used to perform either decimation or interpolation. A decimation CIC filter comprises a cascade of integrators (called the integrator section), followed by a down sampling block (decimator) and a cascade of differentiators (called the differentiator or comb section). Similarly an interpolation CIC filter comprises a cascade of differentiators, followed by an up sampling block (interpolator) and a cascade of integrators.

In a CIC filter, both the integrator and comb sections have the same number of integrators and differentiators. Each pairing of integrator and differentiator is called a stage. The number of stages (N) has a direct effect on the frequency response of a CIC filter. The response of the filter is determined by configuring the number of stages N, the rate change factor R and the number of delays in the differentiators (called the differential delay) M. In practice, the differential delay is set to 1 or 2.

Figure 4–1 shows an integrator.

Figure 4–1. Integrator



Figure 4–2 shows a differentiator.

Figure 4–2. Differentiator



Figure 4–3 shows three integrators and three differentiators combined using a decimator to make a three stage decimation CIC filter.

Figure 4-3. Three Stage Decimation CIC Filter



Figure 4–4 shows three differentiators and three integrators combined using an interpolator to make a three stage interpolation CIC filter.

Figure 4-4. Three Stage Interpolation Filter



Typical Frequency Response

Figure 4–5 shows the frequency response for a CIC decimation filter with N = 3, M = 2 and R = 32.





Data Storage

Data storage in the integrators and differentiators can utilize either logic cells, or memory blocks. The type of data storage can be selected in the MegaWizard interface when the data storage options are enabled. The memory types are then selected automatically by the Quartus II software depending on the chosen device.

For information about when the memory option is enabled, refer to Table 3–3 on page 3–4.

Output Options

You can select output options for the output data bit width and rounding options.

Output Data Width

For a decimation filter, the gain at the output of the filter is:

$$G = (RM)^N$$

Therefore, the data width at the output stage for if full resolution is:

$$B_{out} = \left\lceil B_{in} + N \log_2(RM) \right\rceil$$

where *Bin* is the input data width.

A data width of *Bout* is required for each integrator and differentiator for no data loss.

If you have selected an output data width that is smaller than the full output resolution data width, the Hogenauer pruning technique can be applied to reduce the data widths across the filter stages and hence the overall resource utilization.

For an interpolation filter, the gain at each filter stage is:

$$G_{i} = \begin{cases} 2^{i} & i = 1, 2, ..., N \\ \frac{2^{2N-1} (RM)^{i-N}}{R} & i = N+1, ..., 2N \end{cases}$$

Hence the required data width at the *i*th stage is:

$$W_i = \left[B_{in} + log_2(G_i) \right]$$

and the data width at the output stage is:

$$B_{out} = [B_{in} + Nlog_2(RM) - log_2(R)]$$

where *Bin* is the input data width.

When the differential delay is one, the bit width at each integrator stage is increased by one to ensure stability.

 For more information about these calculations, refer to Hogenauer, Eugene. An Economical Class of Digital Filters For Decimation and Interpolation, IEEE Transactions on Acoustics, Speech and Signal Processing, Vol. ASSP-29, pp. 155-162, April 1981.

Output Rounding

For high rate change factors, the maximum required data width for no data loss is large for many practical cases. To reduce the output data width to the input level, quantization is normally applied at the end of the output stage. In this case, the following rounding or saturation options are available:

- **Truncation**: The LSBs are dropped. (This is equivalent to rounding to minus infinity.)
- **Convergent rounding**. Also known as unbiased rounding. Rounds to the nearest even number. If the most significant deleted bit is one, and either the least significant of the remaining bits or at least one of the other deleted bits is one, then one is added to the remaining bits.
- **Round up**: Also known as rounding to plus infinity. Adds the MSB of the discarded bits for positive and negative numbers via the carry in.
- **Saturation:** Puts a limit value (upper limit in the case of overflow, or lower limit in the case of negative overflow) at the output when the input exceeds the allowed range. The upper limit is +2^{*n*-1} and lower limit is -2^{*n*}.

These rounding options can only be applied to the output stage of the filter. The data widths at the intermediate stages are not changed. The next section describes cases where the data width at the intermediate stages can be changed.

Hogenauer Pruning

Hogenauer pruning [Reference] is a technique that utilizes truncation or rounding in intermediate stages with the retained number of bits decreasing monotonically from stage to stage, while the total error introduced is still no greater than the quantization error introduced by rounding the full precision output. This technique helps to reduce the number of logic cells used by the filter and gives better performance.

The existing algorithms for computing the Hogenauer bit width growth for large *N* and *R* values are computationally expensive.

For more information about these algorithms, refer to U. Meyer-Baese, Digital Signal Processing with Field Programmable Gate Arrays, 2nd Edition, Spinger, 2004.

The CIC MegaCore function has pre-calculated Hogenauer pruning bit widths stored within the MegaCore function. There is no need to wait for Hogenauer pruning bit widths to be calculated if Hogenauer pruning is enabled for a decimation filter.

P

Hogenauer pruning is only available to decimation filters when the selected output data width is smaller than the full output resolution data width.

Multi-Channel Support

There are often many channels of data in a digital signal processing (DSP) system that require filtering by CIC filters with the same configuration. These can be combined into one filter, which shares the adders that exist in each stage and reduces the overall resource utilization.

This combined filter uses fewer resources than using many individual CIC filters. For example, a two-channel parallel filter requires two clock cycles to calculate two outputs. The resulting hardware would need to run at twice the data rate of an individual filter. This is especially useful for higher rate changes where adders grow particularly large.

To minimize the number of logic elements, a multiple input single output (MISO) architecture can be used for decimation filters, and a single input multiple output (SIMO) architecture for interpolation filters as described in the following sections.

Multiple Input Single Output (MISO)

In many practical designs, channel signals come from different input interfaces. On each input interface, the same parameters including rate change factors are applied to the channel data that the CIC filter is going to process. The CIC MegaCore function allows the flexibility to exploit time sharing of the low rate differentiator sections.

This is achieved by providing multiple input interfaces and processing chains for the high rate portions, then combining all of the processing associated with the lower rate portions into a single processing chain. This strategy can lead to full utilization of the resources and represents the most efficient hardware implementation. These architectures are known as multiple input single output (MISO) decimation filters.

Figure 4–6 shows an example of the MISO architecture for a CIC filter that processes a total of four channels. In this example, the symbols *A*, *B*, *C*, *D* are multiplexed into one output *A*, *B*, *C*, *D*.





The sampling frequency of the input data is such that it is only possible to time multiplex two channels per bus, therefore the CIC filter must be configured with two input interfaces. Because two interfaces are required, the rate change factor must also be at least two to exploit this architecture. Up to 1,024 channels can be supported by using multiple input interfaces in this way.

F

MISO architecture is applied when a decimation filter type is chosen and the number of interfaces selected in the MegaWizard interface is greater than one.

Single Input Multiple Output (SIMO)

Single input multiple output (SIMO) is a feature associated with interpolation CIC filters. In this architecture, all the channel signals presented for filtering come from a single input interface.

Like the MISO case, it is possible to share the low sampling rate differentiator section amongst more channels than the higher sampling frequency integrator sections. Therefore, this architecture features a single instance of the differentiator section, and multiple parallel instances of the integrator sections.

After processing by the differentiator section, the channel signals are split into multiple parallel sections for processing in a high sampling frequency by the integrator sections.

Figure 4–7 shows an example of the SIMO architecture for a CIC filter that processes a total of eight channels.

In this example, the symbols *A*, *B*, *C*, *D*, *E*, *F*, *G*, *H* are demultiplexed into four outputs *A*, *E*; *B*, *F*; *C*, *G*; and *D*, *H*.





The required sampling frequency of the output data is such that it is only possible to time multiplex two channels per bus. Therefore the CIC filter must be configured with four output interfaces. Because four interfaces are required, the rate change factor must also be at least four to exploit this architecture, but in this example a rate change of eight is illustrated.

SIMO architecture is applied when an interpolation filter type is chosen and the number of interfaces selected in the MegaWizard interface is greater than one.

The total number of input channels must be a multiple of the number of interfaces. To satisfy this requirement, you may need to either insert dummy channels or use more than one CIC MegaCore function.

Data is transferred as packets using Avalon Streaming (Avalon-ST) interfaces. A general description of these interfaces is given in "Avalon Streaming Interface" on page 4–9.

•••

For an example design using multi-channel MISO and SIMO architectures, refer to *AN442: Tool Flow Design of Digital IF for Wireless Systems*.

Variable Rate Change Factors for Decimation and Interpolation

You can optionally set minimum and maximum values for the decimator or interpolator rate change factors and enable the rate change factors to be set at run time. When these options are set, an additional rate port is provided that can be used to specify the rate change factor. For information about how to enable the options for variable rate change factors, refer to "Parameter Setting Examples" on page 3–1.

If variable rate change factors are enabled, the MegaCore function must be reset when the rate change factor is changed otherwise the previous memory/register values would be used. The filter mode (interpolation or decimation) cannot be changed at run time.

Figure 4–8 illustrates the input and output timing relationships for a variable rate change decimation CIC filter. Note how the out_valid signal changes its period according to the variable rate change.





FIR Filter Compensation Coefficients

CIC filters have a low-pass filter characteristic. There are only three parameters (the rate change factor R, the number of stages N, and the differential delay M) that can be modified to alter the passband characteristics and aliasing/imaging rejection.

However, due to their drooping passband gains and wide transition regions, CIC filters alone cannot provide the flat passband and narrow transition region filter performance that is typically required in decimation or interpolation filtering applications.

This problem can be alleviated by connecting the decimation or interpolation CIC filter to a compensation FIR filter which narrows the output bandwidth and flattens the passband gain (Figure 4–9).





You can use a frequency sampling method to determine the coefficients of a FIR filter that equalizes the undesirable passband droop of the CIC and construct an ideal frequency response.

The ideal frequency response is determined by sampling the normalized magnitude response of the CIC filter before inverting the response.

Generally, it is only necessary to equalize the response in the passband, but you can sample further than the passband to fine tune the cascaded response of the filter chain.

A MATLAB script *<variation_name>_fir_comp_coeff.m* is generated in the project directory by the CIC MegaCore function. You can run this script in MATLAB to generate FIR coefficients that provide appropriate passband equalization. The generated coefficients are saved in a text file, which is ready for use by the Altera FIR Compiler MegaCore function.

The MATLAB script requires the following parameters for the compensation FIR filter:

- *L*: FIR filter length, which is same as the number of taps or the number of coefficients
- *F*_{*s*:} FIR filter sample rate in Hz before decimation/interpolation
- F_C : FIR filter cutoff frequency in Hz
- B: Coefficient bit width if coefficients are written in fixed-point numbers

An example of compensation filter response is shown in Figure 4–10 on page 4–9.



Figure 4–10. CIC and Compensation Filter Responses

••••

For more information, refer to AN455: Understanding CIC Compensation Filters.

Avalon Streaming Interface

The Avalon[®] Streaming (Avalon-ST) interface is an evolution of the Atlantic[™] interface. The Avalon-ST interface defines a standard, flexible, and modular protocol for data transfers from a source interface to a sink interface and simplifies the process of controlling the flow of data in a datapath.

Avalon-ST interface signals can describe traditional streaming interfaces supporting a single stream of data without knowledge of channels or packet boundaries. Such interfaces typically contain data, ready, and valid signals.

The Avalon-ST interface can also support more complex protocols for burst and packet transfers with packets interleaved across multiple channels.

The Avalon-ST interface inherently synchronizes multi-channel designs, which allows you to achieve efficient, time-multiplexed implementations without having to implement complex control logic.

The Avalon-ST interface supports backpressure, which is a flow control mechanism where a sink can signal to a source to stop sending data. The sink typically uses backpressure to stop the flow of data when its FIFO buffers are full or when there is congestion on its output.

When designing a datapath which includes the CIC MegaCore function, you may not need backpressure if you know that the downstream components can always receive data.

The *Avalon Interface Specifications* define parameters which can be used to specify any type of Avalon-ST interface. Table 4–1 lists the values of these parameters that are defined for the Avalon-ST interfaces used by the CIC MegaCore function. All parameters not explicitly listed in the table have undefined values.

Table 4–1. Avalon-ST Interface Parameters

Parameter Name	Value
READY_LATENCY	0
BITS_PER_SYMBOL	data width
SYMBOLS_PER_BEAT	(Note 1), (Note 2), (Note 3)
SYMBOL_TYPE	signed
ERROR_DESCRIPTION	00: No error
	01: Missing startofpacket (SOP)
	10: Missing endofpacket (EOP)
	11: Unexpected EOP or any other error

Notes for Table 4-1:

(1) For single input, single output architectures, there is one symbol per beat at the source and the sink.

(2) For MISO architectures, there are *<number of interfaces>* symbols per beat at the sink, and a single symbol per beat at the source.

(3) For SIMO architectures, there are *<number of interfaces>* symbols per beat at the source, and a single symbol per beat at the sink.

The *Avalon Interface Specifications* define many signal types many of which are optional.

Table 4–2 lists the signal types used by the Avalon-ST interfaces for the CIC MegaCore function.

Signal Type	Width
ready	1
valid	1
data	data width
channel	log ₂ (number of channels)
error	2
startofpacket	1
endofpacket	1

 Table 4–2.
 Avalon-ST Interface Signal Types

Any signal type not explicitly listed in the table is not used by the CIC MegaCore function

For a full description of the Avalon-ST interface protocol, refer to the *Avalon Interface Specifications*.

Avalon-ST Interface Data Transfer Timing

Figure 4–11 illustrates the data transfer timing.



Figure 4–11. Avalon-ST Interface Timing with READY_LATENCY=0

The source provides data and asserts valid on cycle 1, even though the sink is not ready. The source waits until cycle 2, when the sink does assert ready, before moving onto the next data cycle. In cycle 3, the source drives data on the same cycle and because the sink is ready to receive it, the transfer occurs immediately. In cycle 4, the sink asserts ready, but the source does not drive valid data.

Packet Data Transfers

A beat is defined as the transfer of one unit of data between a source and sink interface. This unit of data may consist of one or more symbols and makes it is possible to support modules that convey more than one piece of information about each valid cycle.

Packet data transfers are used for multichannel transfers. Two additional signals (startofpacket and endofpacket) are defined to implement the packet transfer.

Figure 4–12 shows an example where four symbols are transferred on each beat. This multiple symbols per beat scenario applies to both the sink interface on MISO CIC filters and the source interface of SIMO CIC filters. All other interfaces operate with a single symbol per beat, but the interfaces also support multiple channels using packets.



Figure 4–12. Packet Data Transfer

The data transfer in Figure 4–12 occurs on cycles 1, 2, 4, and 5, when both ready and valid are asserted.

During cycle 1, startofpacket is asserted, and the first four bytes of packet are transferred. During cycle 5, endofpacket is asserted indicating that this is the end of the packet. The channel signal indicates the channel index associated with the data. For example, on cycle 1, the data D_0 , D_1 , D_2 , and D_3 associated with channel 0 are available.

Signals

Table 4–3 lists the input and output signals for the CIC MegaCore Function.

Signal	Direction	Description		
clk	Input	Clock signal used to clock all internal registers.		
reset_n	Input	Active low reset signal. The CIC MegaCore function must always be reset before receiving data. If the MegaCore function is not reset, the CIC filter may produce unexpected results due to feedback signals.		
clken	Input	Optional top-level clock enable.		
in_data	Input	Sample input. For multiple input cases, the input data ports are named as in0_data, in1_data, and so on.		
in_endofpacket	Input	Marks the end of the incoming sample group. If there are <i>N</i> channels, the end of packet signal must be high when the sample belonging to the last channel, that is channel <i>N</i> -1, is presented at in_data.		
in_error	Input	Error signal indicating Avalon Streaming protocol violations on input side:		
		 O0: No error 		
		 01: Missing start of packet 		
		 10: Missing end of packet 		
		11: Unexpected end of packet		
		Other types of error are also marked as 11.		
in_ready	Output	Indicates when the MegaCore function is able to accept data.		
in_startofpacket	Input	Marks the start of the incoming sample group. The start of packet is interpreted as a sample from channel 0.		
in_valid	Input	Asserted when data at in_data is valid. When in_valid is not asserted, processing is stopped until valid is re-asserted. If clken is 0, in_valid will not be asserted.		
out_channel	Output	Specifies the channel whose result is presented at out_data.		
out_data	Output	Filter output. The data width depends on the parameter settings. For multiple output cases, the output data ports are named as out0_data, out1_data, and so on.		
out_endofpacket	Output	Marks the end of the outgoing result group. If '1', a result corresponding to channel N -1 is output, where N is the number of channels.		
out_error	Output	Error signal indicating Avalon Streaming protocol violations on source side:		
		 O0: No error 		
		 01: Missing start of packet 		
		 10: Missing end of packet 		
		11: Unexpected end of packet		
		Other types of errors may also be marked as 11.		

Table 4-3. CIC MegaCore Function Signals (Part 1 of 2)

Signal	Direction	Description
out_ready	Input	Asserted by the downstream module if it is able to accept data.
out_startofpacket	Output	Marks the start of the outgoing result group. If '1', a result corresponding to channel 0 is output.
out_valid	Output	Asserted by the MegaCore function when there is valid data to output.
rate	Input	This signal is available when the variable rate change factor option is enabled, and can be used to change the decimation/interpolation rate during run time. It has the size $Ceil(log_2(maximum rate))$.

Table 4–3.	CIC MegaCore Function Signals	(Part 2 of 2))

Referenced Documents

Altera application notes, white papers, and user guides providing more detailed explanations of how to effectively design with MegaCore functions and the Quartus II software are available at the Altera web site (www.altera.com). Refer also to the following references:

- Hogenauer, Eugene. An Economical Class of Digital Filters For Decimation and Interpolation, IEEE Transactions on Acoustics, Speech and Signal Processing, Vol. ASSP-29, pp. 155-162, April 1981.
- U. Meyer-Baese, *Digital Signal Processing with Field Programmable Gate Arrays*, 2nd Edition, Spinger, 2004.
- MegaCore IP Library Release Notes and Errata.
- *Altera Software Installation and Licensing* manual.
- AN320: OpenCore Plus Evaluation of Megafunctions.
- DSP Builder User Guide.
- Avalon Interface Specifications.
- Simulating Altera Designs chapter in volume 3 of the Quartus II Handbook.
- AN442: Tool Flow Design of Digital IF for Wireless Systems.
- AN455: Understanding CIC Compensation Filters.



Revision History

The following table displays the revision history for this user guide.

Date	Version	Changes Made
May 2011	11.0	 Updated support level to final support for Arria[®] II GX, Arria II GZ, Cyclone[®] III LS, and Cyclone IV GX devices.
		 Updated support level to HardCopy Compilation for HardCopy III, HardCopy IV E, and HardCopy IV GX devices.
December 2010	10.1	 Added preliminary support for Arria II GZ devices.
		 Updated support level to final support for Stratix[®] IV GT devices.
July 2010	10.0	 Added preliminary support for Stratix V devices
		 Updated parameter name Rate factor to Rate change factor.
November 2009	9.1	Maintenance update
		Preliminary support for Cyclone III LS, Cyclone IV, and HardCopy IV GX devices
March 2009	9.0	 Added an option to optimize for speed
		 Preliminary support for Arria II GX
November 2008	8.1	Full support for Stratix III
		 Applied new technical publications style
		 Withdrawn support for UNIX
May 2008	8.0	Full support for Cyclone III
		 Preliminary support for Stratix IV
October 2007	7.2	 Full support for Arria GX
May 2007	7.1	 Added description of new features for variable interpolation/decimation rate and compensation filter coefficients generation
		■ Preliminary support for Arria [™] GX
		Full support for Stratix II GX and HardCopy [®] II devices
December 2006	7.0	Preliminary support for Cyclone III
December 2006	6.1	 First release of this user guide

How to Contact Altera

For the most up-to-date information about Altera[®] products, refer to the following table.

Contact 1	Contact Method	Address
Technical support	Website	www.altera.com/support
Technical training	Website	www.altera.com/training
	Email	custrain@altera.com
Product literature	Website	www.altera.com/literature

Contact 1	Contact Method	Address
Non-technical support (General)	Email	nacomp@altera.com
(Software Licensing)	Email	authorization@altera.com

Note to table:

(1) You can also contact your local Altera sales office or sales representative.

Typographic Conventions

This document uses the typographic conventions shown in the following table.

Visual Cue	Meaning
Bold Type with Initial Capital Letters	Indicates command names, dialog box titles, dialog box options, and other GUI labels. For example, Save As dialog box.
bold type	Indicates directory names, project names, disk drive names, file names, file name extensions, and software utility names. For example, \qdesigns directory, d: drive, and chiptrip.gdf file.
Italic Type with Initial Capital Letters	Indicates document titles. For example: AN 519: Stratix IV Design Guidelines.
Italic type	Indicates variables. For example, $n + 1$.
	Variable names are enclosed in angle brackets (< >). For example, <i><file name=""></file></i> and <i><project name="">.pof</project></i> file.
Initial Capital Letters	Indicates keyboard keys and menu names. For example, Delete key and the Options menu.
"Subheading Title"	Quotation marks indicate references to sections within a document and titles of Quartus II Help topics. For example, "Typographic Conventions."
Courier type	Indicates signal, port, register, bit, block, and primitive names. For example, data1, tdi, and input. Active-low signals are denoted by suffix n. Example: resetn.
	Indicates command line commands and anything that must be typed exactly as it appears. For example, c:\qdesigns\tutorial\chiptrip.gdf.
	Also indicates sections of an actual file, such as a Report File, references to parts of files (for example, the AHDL keyword SUBDESIGN), and logic function names (for example, TRI).
1., 2., 3., and a., b., c., and so on.	Numbered steps indicate a list of items when the sequence of the items is important, such as the steps listed in a procedure.
	Bullets indicate a list of items when the sequence of the items is not important.
17 - Contraction of the contract	The hand points to information that requires special attention.
CAUTION	A caution calls attention to a condition or possible situation that can damage or destroy the product or your work.
WARNING	A warning calls attention to a condition or possible situation that can cause you injury.
+	The angled arrow instructs you to press the enter key.
•••	The feet direct you to more information about a particular topic.