

Phase-Locked Loop Reconfiguration (ALTPLL_RECONFIG) Megafunction

UG-032405-6.0

User Guide

This user guide describes the features and behavior of the ALTPLL_RECONFIG megafunction that you can configure through the parameter editor in the Quartus[®] II software.



This user guide assumes that you are familiar with megafunctions and how to create them. If you are unfamiliar with Altera megafunctions or the parameter editor, refer to the *Introduction to Megafunctions User Guide*.

Phase-locked loops (PLLs) use divide counters and voltage-controlled oscillator (VCO) phase taps to perform frequency synthesis and phase shifts. In enhanced and fast PLLs, you can reconfigure the counter settings as well as phase shift the PLL output clock in real time. You can also change the charge-pump and loop-filter components, which dynamically affect the PLL bandwidth. The ALTPLL_RECONFIG megafunction implements reconfiguration logic to facilitate dynamic real-time reconfiguration of PLLs in Altera devices. You can use the megafunction to update the output clock frequency, PLL bandwidth, and phase shifts in real time, without reconfiguring the entire FPGA.

Features

The ALTPLL_RECONFIG megafunction offers the following additional features to the ALTPLL megafunction:

- Reconfiguration of pre-scale counter (*N*) parameters.
- Reconfiguration of feedback counter (*M*) parameters.
- Reconfiguration of post-scale output counter (*C*) parameters.
- Reconfiguration of delay element or phase shift of each counter. For Stratix[®] III, Stratix IV, Cyclone[®] III, Cyclone IV, HardCopy[®] III, HardCopy IV, and Arria[®] II GX devices, use the ALTPLL megafunction to access this feature.
- Dynamic adjustment of the charge-pump current and loop-filter components to facilitate dynamic reconfiguration of the PLL bandwidth. This feature is available only in Arria GX, HardCopy II, Stratix II, Stratix II GX, Stratix III, and Stratix IV devices.
- Reconfiguration from multiple configuration files using external read-only memory (ROM) in user mode. This feature is available only in Stratix III, Stratix IV, Cyclone III, Cyclone IV, and Arria II GX devices. The ALTPLL_RECONFIG supports reconfiguration from Memory Initialization File (.mif) and Hexadecimal File (.hex).



© 2012 Altera Corporation. All rights reserved. ALTERA, ARRIA, CYCLONE, HARDCOPY, MAX, MEGACORE, NIOS, QUARTUS and STRATIX words and logos are trademarks of Altera Corporation and registered in the U.S. Patent and Trademark Office and in other countries. All other words and logos identified as trademarks or service marks are the property of their respective holders as described at www.altera.com/common/legal.html. Altera warrants performance of its semiconductor products to current specifications in accordance with Altera's standard warranty, but reserves the right to make changes to any products and services at any time without notice. Altera assumes no responsibility or liability arising out of the application or use of any information, product, or service described herein except as expressly agreed to in writing by Altera. Altera customers are advised to obtain the latest version of device specifications before relying on any published information and before placing orders for products or services.





•••

• For more details about these features, refer to the *Clock Networks and PLLs* chapter of the respective device handbook.

Common Applications

Use the ALTPLL_RECONFIG megafunction in designs that must support dynamic changes in the frequency and phase shift of clocks and other frequency signals. The megafunction is also useful in prototyping environments because it allows you to sweep PLL output frequencies and dynamically adjust the output clock phase. For example, a system generating test patterns is required to generate and transmit patterns at 50 or 100 MHz, depending on the device under test. Reconfiguring the PLL components in real-time allows you to switch between two such output frequencies within a few microseconds. You can also adjust the clock-to-output (tCO) delays in real-time by changing the output clock phase shift. This approach eliminates the need to regenerate a configuration file with the new PLL settings.

Reconfigurable PLLs are very useful in DDR 2 and DDR 3 interfaces to implement the dynamic data path (via the ALTMEMPHY megafunction). The PLL is needed to drive the DLL used in the dynamic external memory interface operation. This operation requires dynamic phase-shifting.

For more information about dynamic phase-shifting in DDR 2 and DDR 3 interfaces, refer to the ALTMEMPHY Megafunction User Guide.

In addition, you can dynamically configure Stratix III, Stratix IV, Cyclone III, Cyclone IV, and Arria II GX PLLs by using multiple configuration files stored on the external ROM.

Device Family Support

The megafunction supports the Stratix series (excluding Stratix V), HardCopy series, Arria GX series, and Cyclone series devices.

Resource Utilization and Performance

For details about the resource usage and performance of the ALTPLL_RECONFIG megafunction in various devices, refer to the compilation reports in the Quartus II software.

To view the compilation reports for the ALTPLL_RECONFIG megafunction in the Quartus II software, follow these steps:

- 1. On the Processing menu, click Start Compilation to run a full compilation.
- 2. After compiling the design, on the Processing menu, click Compilation Report.
- 3. In the Table of Contents browser, expand the Fitter folder by clicking the "+" icon.
- 4. Under Fitter, expand Resource section, and select Resource Usage Summary to view the resource usage information.
- 5. Under Fitter, expand Resource section, and select Resource Utilization by Entity to view the resource utilization information.

Parameter Settings

Altera recommends that you configure the megafunction using the MegaWizard[™] Plug-In Manager. This section describes the parameters in the ALTPLL_RECONFIG parameter editor.

Expert users may choose to instantiate and configure the megafunction using the clear box generator.

Table 1 lists the parameter settings for the ALTPLL_RECONFIG megafunction.

Page	Options	Description
	Currently Selected Device Family	Specifies the chosen device family.
		Scan chain is serial shift register chain that is used to store settings. It acts like a cache. When you assert the reconfig signal, the PLL is reconfigured with the values in the cache. The type of scan chain must follow the type of PLL to be reconfigured.
	Which scan chain	For Arria GX, Stratix II, Stratix II GX, and HardCopy II devices—Specifies the scan chain type as either Enhanced or Fast .
	using?	For Stratix and Stratix GX devices—Specifies the scan chain type as either Long chain or Short chain.
Parameter Settings		For Stratix III, Stratix IV, HardCopy III, and HardCopy IV devices—Specifies the scan chain type as either Top/Bottom or Left/Right . For Cyclone III, Cyclone IV, and Arria II GX devices—The scan chain type has a default value of Left/Right .
	Do you want to specify the initial value of the scan	Specifies the initial value of the scan chain. Select No , leave it blank to not specify a file or select Yes , use this file for the content data to browse for a .hex or .mif file.
		For Arria GX, Arria II GX, Stratix, Stratix GX, Stratix II, Stratix II GX, Stratix III, Stratix IV, HardCopy II, HardCopy III, and HardCopy IV devices—You can also choose to initialize from ROM by turning on Do not use pre-initialized RAM - initialize from ROM instead.
		For Cyclone III and Cyclone IV devices—The option to initialize from a ROM is not available. However, you can choose to add ports to write to the scan chain from an external ROM during runtime by turning on Add ports to write to the scan chain from external ROM during run time.
	Add ports to write to the scan chain from external ROM during run time	This option is only available for Stratix III, Stratix IV, Cyclone III, Cyclone IV, HardCopy III, HardCopy IV, and Arria II GX devices. This option takes advantage of cycling multiple configuration files, which are stored in external ROMs during user mode. This capability is demonstrated in the functional description section, "Functional Description—Implementing Multiple Reconfiguration Using an External ROM" on page 6.

 Table 1. ALTPLL_RECONFIG Parameter Settings

Page	Options	Description
		Specifies the libraries needed for functional simulation.
EDA	Generate netlist	Specifies whether to turn on the option to generate synthesis area and timing estimation netlist.
		Specifies the types of files to be generated. A gray checkmark indicates a file that is automatically generated; a red checkmark indicates an optional file.
		Choose from the following types of files:
		AHDL Include file (<i><function name=""></function></i> .inc)
		VHDL component declaration file (<i><function name="">.cmp</function></i>)
Summary		Quartus II symbol file (<i><function name="">.bsf</function></i>)
		Instantiation template file (<i><function name="">_inst.v</function></i> or <i><function name="">_inst.v</function></i> or <i><function name="">_inst.vhd</function></i>
		Verilog HDL block box file (<function name="">_bb.v)</function>
		If Generate netlist option is turned on, the file for that netlist is also available (<i><function name="">_syn.v</function></i>).

Table 1. ALTPLL_RECONFIG Parameter Settings

You can open a **.mif** in a text editor to make use of the comments embedded within the file. These comments show you the scan chain values and positions based on your design parameterization (see Figure 1). If you open a **.mif** in the Quartus II software, you can regenerate the **.mif** in the ALTPLL parameter editor to restore the comments.

Figure 1. MIF file

File Edit Format View Help	
MIF file representing initial state of PLL Scan PLL Name: reconfig_pll:reconfig_pll_inst[alt PLL Scan Chain: LONG (288 bits) File Name: pll_J1_clk0.mif Generated: Tue Jan 18 13:54:22 2005 WIDTH=1; DEPTH=288;	Chain pll:altpll_component pll
ADDRESS_RADIX=UNS; DATA_RADIX=UNS;	
CONTENT BEGIN 0 : 0; Counter N: Nominal Count 1 : 0; 2 : 0; 3 : 0; 4 : 0; 5 : 0; 6 : 0; 7 : 0; 8 : 0; 9 : 1: Counter N: Bupgers = 1 (1)	= 0 (9 bits)

For more information about implementing PLL reconfiguration in the supported Stratix series, refer to AN 282: Implementing PLL Reconfiguration in Stratix & Stratix GX Devices, AN 367: Implementing PLL Reconfiguration in Stratix II Devices and AN 454: Implementing PLL Reconfiguration in Stratix III Devices.

Checking Design Violations With the Design Assistant

The Design Assistant is a design rule checking tool that allows you to check for design issues early in the design flow. When you run the Design Assistant in the Quartus II software for the ALTPLL_RECONFIG megafunction, you might receive the warning message shown in Figure 2.

Figure 2. Warning Message in Design Assistant

Messages	
Type	Message
	Warning: (Medium) Rule R102: External reset signals should be synchronized usi Warning: Node "reset"
System	Processing (13) / Extra Info / Info (11) / Warning (1) / Critical Warning (1) / Error / Suppressed / Flag
Message: 1 o	f 2 🚯 😫 Location:

This message appears because there is a combinational logic in the megafunction that connects the synchronous signal to the asynchronous external reset signal. To fix the issue, you must synchronize the external reset signal outside the megafunction.

To synchronize the external reset signal, use the sample Verilog HDL code shown in Example 1. In the example, the input of sync_reset_dffel is connected to the external reset pin, and the output of sync_reset_dffel is connected to the reset input port of the ALTPLL_RECONFIG megafunction.

Example 1. Code to Synchronize External Reset Signal

```
module synch_reg (reset, reconfig_clk, sync_reset_dffe2);
input reset, reconfig_clk;
output sync_reset_dffe2;
reg sync_reset_dffe1, sync_reset_dffe2;
always @(posedge reconfig_clk)
begin
    sync_reset_dffe1 = reset;
end
always @(posedge reconfig_clk)
begin
    sync_reset_dffe2 = sync_reset_dffe1;
end
endmodule
```

Simulation

You can perform functional and gate-level timing simulations of the megafunction.



For more information, refer to the appropriate chapter in the *Simulation* section in volume 3 of the *Quartus II Handbook*.

If phase-shifting occurs after a PLL reconfiguration, use gate-level timing simulation instead of functional simulation to verify the correct counter settings and phase shifts. For non-zero PLL phase shifts, the frequency of the output clocks after a reconfiguration is correct, but the phase may be incorrect. If the phase shift is significant, use gate-level timing simulation to verify the timing behavior.

Functional Description—Implementing Multiple Reconfiguration Using an External ROM

The ALTPLL_RECONFIG megafunction allows you to reconfigure the PLL using an external ROM with multiple configuration files. With this feature, you can perform the following:

- Specify an external ROM and feed its content to the ALTPLL_RECONFIG megafunction.
- Use the megafunction with multiple PLL configuration settings that are stored in configuration files during user mode.
- Use the megafunction with applications that require flexible dynamic-shifting of PLL settings during user mode.
- Reconfigure the initial PLL settings from a source other than an embedded random-access memory (RAM), such as an off-chip flash device, which is useful in HardCopy-type applications.
 - This feature is available for Stratix III, Stratix IV, Cyclone III, Cyclone IV, HardCopy III, HardCopy IV, and Arria II GX devices only.

To support reconfiguration from multiple configuration files, the ALTPLL_RECONFIG megafunction has three input ports and two output ports:

- The write_from_rom input port signals the ALTPLL_RECONFIG megafunction instantiation to write to the scan cache from the ROM.
- The rom_data_in input port holds data from the ROM.
- The reset_rom_address input port lets you restart the read process from the ROM. The data arrives serially from the ROM, starting from bit 0.
- The rom_address_out output bus holds the current address of the ROM data to be written to the scan cache.
- The write_rom_ena output port enables the intended ROM to be read out.

The input and output ports to support reconfiguration using multiple configuration files are shown in Figure 3, circled in red.





The reconfiguration feature using multiple configuration files allows you to feed data from multiple ROMs to a multiplexer that feeds the rom_data_in port. Figure 4 shows a sample design. In this scheme, the write_rom_ena signal feeds back to the ROM as the enable signal, which allows the ROM to be read out. The rom_address_out bus provides the intended ROM address, which determines the exact ROM data.



Figure 4. Typical Scheme for Reconfiguring PLLs from External ROMs

To copy the data from a ROM to the ALTPLL_RECONFIG megafunction scan cache (a memory location that stores the PLL reconfiguration settings), you must hold the write_from_rom signal high for 1 clock cycle. The megafunction asserts the busy signal on the first rising edge of the clock after the write_from_rom signal goes high. The busy signal remains asserted until all the bits are written into the scan cache.

On the second rising edge of the clock after the write_from_rom signal goes low again, the intended ROM address for the write operation appears on the rom_address_out port. The data of the ROM specified by the intended address on rom_address_out is fed to the rom_data_in input port of the ALTPLL_RECONFIG megafunction instantiation. The write_rom_ena signal is also asserted on the second rising edge of the clock after the write_from_rom signal goes low again (refer to Figure 5).

Figure 5. Beginning Write to the Scan Cache of the ALTPLL_RECONFIG Megafunction from the ROM



The writing-to-scan cache process continues until the address reaches the specific size of the scan cache (234 for Stratix III device top and bottom PLL, 180 for Stratix III device left and right PLL, and 144 for Cyclone III PLL). This process is completed when the busy signal is deasserted. This means that the scan cache of the ALTPLL_RECONFIG megafunction is written with the intended reconfiguration settings from the ROM.

After this, the reconfig signal can be asserted for 1 clock cycle to reconfigure the PLL to the intended settings that have been written to the scan cache of the ALTPLL_RECONFIG megafunction (refer to Figure 6).



	222	Value at	4.62 us	4.66 us	4.7 us	4.74 us	4.78 us	4.82 us	4.86 us	4.9 us	4.94 us	4.98 us	5.02 us	5.06 us
	Name	0 ps							+4.87 us		+4.93 us			
₽ 0	input_clock	BO	ГЛ											
i ≥1	input_reset	BO												
2	Ⅲ input_intended_rom	B 00							00					
₽5	write_from_rom	BO												
€ 6	reconfig	BO												
₽7	reset_rom_address	BO												
• 8	busy	B 1	1 1 1											
1 1 1 1 1 1 1 1 1 1	write_rom_ena	BO	111											
10	Image: The second s	UO	221 22	2 🛛 223 🔾 22	24 \ 225 \ 22	26 (227 (22	28 \ 229 \ 23	<u>30 (231) 2</u>	32 🛛 233 🗶	112		0		
1 9	rom_data_in	BO												
💿 20	locked	BO	in the second	. L. L. L.					and and and			and and and		
💿 21	c0	BX	LUU	ww	nnn	nn	mm	nn	mm	vvv	ллл	ww	nn	ກກກກາ
22	🗷 output_current_state	UO					3			X	4 <u>x</u> 5 <u>x</u>		6	
			1 1 1	1111						E E E		111		
Note t	- Finuna C.													

Note to Figure 6:

(1) This figure also shows the beginning of the reconfiguration process.

If you assert the reset_rom_address signal, the write_rom_ena signal is deasserted for 1 clock cycle and the rom_address_out signal resets. When the write_rom_ena gets asserted, the write process then restarts from address 0 (refer to Figure 7).

Figure 7. Asserting the reset_rom_address Signal

1	14 1420 -	Mahua at	41.09 us	41.17 us	41.25 us	41.33 us	41.41 us	41.49 us
	Name	0 ps	+41.12 us				+4"+41.35+41.4"+41.45+41.	45 us +41.49 us +41.53 us
▶0	input_clock	BO	ГЛЛ					
≥1	input_reset	BO						
≥2	Image: Input_intended_rom	B 00				00		
▶5	write_from_rom	BO						
⊙ 6	reconfig	BO						
▶7	reset_rom_address	BO						
0)8	busy	B 1						
⊚9	write_rom_ena	BO						
10		UO	0	X1	<u> </u>	5 <u>x 6 x 7 x 8 x 9</u>	<u>×10×0×1</u>	2 (3) 4 (5) 6 (7
	rom_data_in	BO						
o>20	locked	BO						
o≫21	c0	В×						
22	■ output_current_state	UO	0 X 1	χ 2 χ			3	

Design Example

You can download design examples for this megafunction from the following locations:

- On the Documentation: Quartus II Development Software page, in the Using Megafunctions section under I/O
- On the Documentation: User Guides webpage, with this user guide

The designs are simulated using the ModelSim[®]-Altera software to generate a waveform display of the device behavior. For more information about the ModelSim-Altera software, refer to the ModelSim-Altera Software Support page on the Altera website. The support page includes links to such topics as installation, usage, and troubleshooting.

Frequency Division

This design example uses the ALTPLL_RECONFIG megafunction to change the clock frequency of an enhanced PLL. This example demonstrates how to reconfigure the c⁰ counter using the ALTPLL_RECONFIG megafunction to vary the frequency of this counter by changing the *c* value. Figure 8 shows the formula for changing the *c* value for different PLL output frequencies.

Figure 8. Frequency Division Formula

```
Divide-by value = c = (Fin * m)/(Fout * n)

Where:

c value = High time count = Low time count

Fin = Input frequency

m = m modulus value

n = n modulus value

Fout = Required output frequency
```

This example reconfigures the output frequency of c0 from 100 to 50 MHz by changing the divide-by value from 3 to 6.

Generating the ALTPLL and ALTPLL_RECONFIG Megafunctions

To generate the ALTPLL and ALTPLL_RECONFIG megafunctions, follow these steps:

- 1. Open the altpll_reconfig_DesignExample_ex1.zip file and extract pll_recon_ex1_1.1.qar.
- In the Quartus II software, open the pll_recon_ex1_1.1.qar file and restore the archive file into your working directory.
- 3. On the Tools menu, click **MegaWizard Plug-In Manager**. Page 1 of the MegaWizard Plug-In Manager appears.
- 4. Select Create a new custom megafunction variation.
- 5. Click Next. Page 2a of the MegaWizard Plug-In Manager appears.

 Table 2. Configuration Settings for the ALTPLL Megafunction (Part 1 of 2)

MegaWizard Plug-In Manager Page	Settings	Value
	Megafunction	Under the I/O category, select ALTPLL
	Which device family will you be using?	Stratix
2a	Which type of output file do you want to create?	VHDL
	What name do you want for the output file?	reconfig_pll
	Return to this page for another create operation	Turned on
	Currently selected device family	Stratix
	Match project/default	Turned on
	Which device speed grade will you be using?	Any
Parameter Settings	What is the frequency of inclk0 input	100 MHz
(General/Modes)	Which PLL type will you be using?	Enhanced PLL
	How will the PLL outputs be generated?	Select Use the feedback path inside the PLL . Select In normal mode
	Which output clock will be compensated for?	cO
	Create optional inputs for dynamic reconfiguration	Turned on
	Long chain: All 6 core and 4 external clocks are available	Selected
Developmenter Cettinge	Create an 'pllena' input to selectively enable the PLL	Turned off
(Scan/Inputs/Lock)	Create an 'areset' input to asynchronously reset the PLL	Turned on
	Create an 'pfdena' input to selectively enable the phase/frequency detector	Turned off
	Create 'locked' output	Turned on
	Create output file(s) using 'Advanced' PLL parameters	Turned off
	Use this clock	Turned on
Output Clocks	Enter output clock frequency	100 MHz
	Clock phase shift	0 degrees
	Clock duty cycle (%)	50
	Create a clock enable input	Turned off
EDA	Generate netlist	Turned off

MegaWizard Plug-In Manager Page	Settings	Value
	Variation file	Turned on
	PinPlanner ports PPF file	Turned on
Summany	AHDL Include file	Turned on
Summary	VHDL component declaration file	Turned on
	Quartus II symbol file	Turned on
	Instantiation template file	Turned on

Table 2. Configuration Settings for the ALTPLL Megafunction (Part 2 of 2)

- 7. Click **Finish**. The reconfig_pll module is built.
- 8. Click **OK**. The MegaWizard Plug-In Manager resets to page 2a to allow you to create a new custom megafunction variation.
- 9. In the MegaWizard Plug-In Manager pages, select or verify the configuration settings listed in Table 3. Click **Next** to advance from one page to the next.

Table 3. Configuration Settings for the ALTPLL_RECONFIG Megafunction

MegaWizard Plug-In Manager Page	Settings	Value
	Megafunction	Under the I/O category, select ALTPLL_RECONFIG
	Which device family will you be using?	Stratix
2a	Which type of output file do you want to create?	VHDL
	What name do you want for the output file?	pll_reconfig
	Return to this page for another create operation	Turned off
Parameter Settings	Currently selected device family	Stratix
(Conoral)	Match project/default	Turned on
(General)	Which scan chain type will you be using	Long chain
Parameter Settings	Do you want to specify initial value of the scan chain?	Select Yes, use this file for the content data
(General 2)	File name	pll_j1clk0.mif
	Do not use pre initialized RAM - initialize from ROM instead	Turned off
EDA	Generate netlist	Turned off
	Variation file	Turned on
	AHDL Include file	Turned on
Summary	VHDL component declaration file	Turned on
	Quartus II symbol file	Turned on
	Instantiation template file	Turned on

10. Click **Finish**. The pll_reconfig module is built.

Compiling the ALTPLL and ALTPLL_RECONFIG Megafunctions

To add the ALTPLL megafunction to the ALTPLL_RECONFIG megafunction, and then compile the design in the Quartus II software, follow these steps:

- 1. On the Project menu, click **Add/Remove File in Project**. The Settings dialog box appears.
- 2. In the Category list, select Files.
- 3. Click **Browse** (...) after **File name** and select **pll_recon_ex1.vhd** from the project folder. This file is the top-level module that contains the port-mapping between the pll_reconfig and reconfig_pll instances.
- 4. Click **Add** to add the top-level file to the project.
- 5. Click OK.
- 6. On the File menu, click Save Project.

The top-level file is added to the project.

- 7. To compile the design, on the Processing menu, click Start Compilation.
- 8. When the **Full Compilation was successful** message box appears, click **OK**.

You have now created and compiled the complete design file, which can be viewed in the RTL Viewer (Figure 9). To display the RTL Viewer, in the Tools menu, select **Netlist Viewers**, and click on **RTL Viewer**.

Figure 9. RTL Viewer — Complete Design File



Simulating the Design Example

To simulate the design example using the ModelSim-Altera software, follow these steps:

- 1. Unzip the **altpll_reconfig_ex1_msim.zip** file to any working directory on your PC.
- 2. Browse to the folder in which you unzipped the files.
- 3. Open remote_update_ex2.do in a text editor.
- 4. In line 1 of the **altpll_reconfig_ex1_msim.do** file, ensure that the directory path of the library files is correct. For example, C:/Modeltech_ae/altera/verilog/stratix.
- 5. On the File menu, click **Save**.

- 6. Launch the ModelSim-Altera software.
- 7. On the File menu, click Change Directory.
- 8. Select the folder in which you unzipped the files.
- 9. Click OK.
- 10. On the Tools menu, click **Execute Macro**.
- Select the altpll_reconfig_ex1_msim.do file and click Open. This is a script file for ModelSim-Altera software to automate all the necessary settings for the simulation.
- 12. Verify the results shown in the Wave window.

You can rearrange, remove, and add signals, and change the radix by modifying the script **altpll_reconfig_ex1_msim.do**.

Figure 10 and Figure 11 show the expected simulation results in the ModelSim-Altera software. Figure 11 shows the change in c0 frequency starting from 12.75 ms.

Figure 10. Simulation Results in the ModelSim-Altera Software (8.9 to 9.5 ms)



Figure 11. Simulation Results in the ModelSim-Altera Software (9.5 to 13.5 ms)



Pulse Width Variation

This design example uses the ALTPLL_RECONFIG megafunction to modify the pulse width of an enhanced PLL. This example demonstrates how to reconfigure the c1 counter using the ALTPLL_RECONFIG megafunction to vary the pulse width of this counter by changing the high-count and low-count values. The formula for changing the duty cycle is shown in Figure 12.



```
Duty cycle =(Ch/Ct) % high time count and (Cl/Ct) % low time count
            with RSELODD = 0
Where:
      Ch = High time count
      CI = Low time count
      Ct = Total time
When you set RSELODD = 1, you subtract 0.5 cycles from the high time and
                           you add 0.5 cycles to the low time.
For example, if:
      Ch = 2 cycles
      CI = 1 cycle
      (Note: For odd division factors, the larger number is for the
      Ch counter; the smaller number is for the CI counter.)
Setting RSELODD = 1 effectively changes the Ch and Cl to:
      High time count = 1.5 cycles
      Low time count = 1.5 cycles
      Duty cycle = (1.5/3) % high time count and (1.5/3) % low time count
```

In this example, the pulse width is programmed to change from 50% to 25%, and then to 75% of the duty cycle.

Generating the ALTPLL and ALTPLL_RECONFIG Megafunctions

To generate the ALTPLL and ALTPLL_RECONFIG megafunctions, perform the following steps:

- Open ALTPLL_RECONFIG_DesignExample_ex2.zip and extract pll_recon_ex2_1.1.qar.
- 2. In the Quartus II software, open **pll_recon_ex2_1.1.qar** and restore the archive file into your working directory.
- 3. On the Tools menu, click **MegaWizard Plug-In Manager**. Page 1 of the MegaWizard Plug-In Manager appears.
- 4. Select Create a new custom megafunction variation.
- 5. Click Next. Page 2a of the MegaWizard Plug-In Manager appears.

Г

6. In the MegaWizard Plug-In Manager pages, select or verify the configuration settings listed in Table 4. Click **Next** to advance from one page to the next.

Table 4. Configuration Settings for the ALTPLL Megafunction (Part 1 of 2)

MegaWizard Plug-In Manager Page	Settings	Value
	Megafunction	Under the I/O category, select ALTPLL
	Which device family will you be using?	Stratix
2a	Which type of output file do you want to create?	VHDL
	What name do you want for the output file?	reconfig_pll
	Return to this page for another create operation	Turned on
	Currently selected device family	Stratix
	Match project/default	Turned on
	Which device speed grade will you be using?	Any
Parameter Settings	What is the frequency of inclk0 input	20 MHz
(General/Modes)	Which PLL type will you be using?	Enhanced PLL
	How will the PLL outputs be generated?	Select Use the feedback path inside the PLL . Select In normal mode
	Which output clock will be compensated for?	c1
	Create optional inputs for dynamic reconfiguration	Turned on
	Long chain: All 6 core and 4 external clocks are available	Selected
Descue des Octilises	Create an 'pllena' input to selectively enable the PLL	Turned off
(Scan/Inputs/Lock)	Create an 'areset' input to asynchronously reset the PLL	Turned on
	Create an 'pfdena' input to selectively enable the phase/frequency detector	Turned off
	Create 'locked' output	Turned on
	Create output file(s) using 'Advanced' PLL parameters	Turned off
	Use this clock	Turned on
Output Clocks	Enter output clock frequency	15 MHz
	Clock phase shift	0 degrees
	Clock duty cycle (%)	50
	Create a clock enable input	Turned off
EDA	Generate netlist	Turned off

MegaWizard Plug-In Manager Page	Settings	Value
	Variation file	Turned on
	PinPlanner ports PPF file	Turned on
Summary	AHDL Include file	Turned on
Summary	VHDL component declaration file	Turned on
	Quartus II symbol file	Turned on
	Instantiation template file	Turned on

Table 4. Configuration Settings for the ALTPLL Megafunction (Part 2 of 2)

- 7. Click **Finish**. The reconfig_pll module is built.
- 8. Click **OK**. The MegaWizard Plug-In Manager resets to page 2a to allow you to create a new custom megafunction variation.
- 9. In the MegaWizard Plug-In Manager pages, select or verify the configuration settings listed in Table 5. Click **Next** to advance from one page to the next.

Table 5. Configuration Settings for the ALTPLL_RECONFIG Megafunction

MegaWizard Plug-In Manager Page	Settings	Value	
	Megafunction	Under the I/O category, select ALTPLL_RECONFIG	
	Which device family will you be using?	Stratix	
2a	Which type of output file do you want to create?	VHDL	
	What name do you want for the output file?	pll_reconfig	
	Return to this page for another create operation	Turned off	
Paramotor Sottings	Currently selected device family	Stratix	
(Conoral)	Match project/default	Turned on	
(General)	Which scan chain type will you be using	Long chain	
Daramatar Sattings	Do you want to specify initial value of the scan chain?	Select Yes, use this file for the content data	
(General)	File name	pll_j1pll.mif	
(General)	Do not use pre initialized RAM - initialize from ROM instead	Turned off	
EDA	Generate netlist	Turned off	
	Variation file	Turned on	
	AHDL Include file	Turned on	
Summary	VHDL component declaration file	Turned on	
	Quartus II symbol file	Turned on	
	Instantiation template file	Turned on	

10. Click **Finish**. The pll_reconfig module is built.

Compiling the ALTPLL and ALTPLL_RECONFIG Megafunctions

To add the ALTPLL megafunction to the ALTPLL_RECONFIG megafunction, and then compile the design in the Quartus II software, follow these steps:

- On the Project menu, click Add/Remove Files in Project. The Settings dialog box appears.
- 2. In the Category list, select Files.
- 3. Click **Browse** (...) after **File name** and from the project folder, select **pll_recon_ex2.vhd**. This file is the top-level module that contains the port-mapping between the pll_reconfig and reconfig_pll instances.
- 4. To add the top-level file to the project, click Add.
- 5. Click OK.
- 6. On the File menu, click Save Project.

The top-level file is added to the project.

- 7. To compile the design, on the Processing menu, click Start Compilation.
- 8. When the Full Compilation was successful message box appears, click OK.

You have now created and compiled the complete design file, which can be viewed in the RTL Viewer (Figure 13). To display the RTL Viewer, in the Tools menu, select **Netlist Viewers**, and click on **RTL Viewer**.

Figure 13. RTL Viewer — Complete Design File



Simulating the Design Example

To simulate the design example using the ModelSim-Altera software, follow these steps:

- 1. Unzip the **altpll_reconfig_ex2_msim.zip** file to any working directory on your PC.
- 2. Browse to the folder in which you unzipped the files.
- 3. Open the **remote_update_ex2.do** file in a text editor.
- 4. In line 1 of the **altpll_reconfig_ex2_msim.do** file, make sure the directory path of the library files is correct. For example, C:/Modeltech_ae/altera/verilog/stratix.
- 5. On the File menu, click **Save**.
- 6. Launch the ModelSim-Altera software.
- 7. On the File menu, click **Change Directory**.
- 8. Select the folder in which you unzipped the files.
- 9. Click OK.
- 10. On the Tools menu, click Execute Macro.
- Select the altpll_reconfig_ex2_msim.do file and click Open. This is a script file for ModelSim-Altera software to automate all of the necessary settings for the simulation.
- 12. Verify the results shown in the Wave window.

You can rearrange, remove, and add signals. and change the radix by modifying the script **altpll_reconfig_ex2_msim.do**.

Figure 14 through Figure 19 show the expected simulation results in the ModelSim-Altera software. The duty cycle changes from a ratio of 50:50 to 25:75 and finally to 75:25.

Figure 14. Changing Parameters (2.11 to 7.23 ms)



Figure 15. Reconfiguration (6.32 to 26.8 ms)



Figure 16. Pulse Width Changes From 50:50 Ratio to 25:75 Ratio (20 to 26 ms)

Figure 18. Reconfiguration (96.92 to 117.4 ms)

Figure 19. Pulse Width Changes To 75:25 Ratio (110 to 113 ms)

PLL Reconfiguration with Multiple .mif Files

This design example uses the ALTPLL_RECONFIG megafunction to reconfigure the output of the c0 counter based on the PLL settings specified in multiple **.mif** files from external ROMs in Stratix III devices. The **.mif** files specify PLL settings that reconfigure the output of the c0 counter from 100 to 200 MHz, 300 MHz, 400 MHz, and 500 MHz, then back to 200 MHz.

Generating the ALTPLL and ALTPLL_RECONFIG Megafunctions

To generate the ALTPLL and ALTPLL_RECONFIG megafunctions, follow these steps:

- Open the ALTPLL_RECONFIG_DesignExample_ex3.zip file to any directory on your PC.
- 2. Open the ALTPLL_RECONFIG_rom.qar project file.
- 3. On the Tools menu, click **MegaWizard Plug-In Manager**. Page 1 of the MegaWizard Plug-In Manager appears.
- 4. Select the **Create a new custom megafunction variation** option.
- 5. Click Next. Page 2a of the MegaWizard Plug-In Manager appears.
- 6. In the MegaWizard Plug-In Manager pages, select or verify the configuration settings listed in Table 6. Click **Next** to advance from one page to the next.

Table 6. Configuration Settings for the ALTPLL Megafunction (Part 1 of 2)

MegaWizard Plug-In Manager Page	Settings	Value					
	Megafunction	Under the I/O category, select ALTPLL					
	Which device family will you be using?	Stratix III					
2a	Which type of output file do you want to create?	Verilog					
	What name do you want for the output file?	the_pll.v					
	Return to this page for another create operation	Turned on					
	Currently selected device family	Stratix III					
	Match project/default	Turned on					
	Which device speed grade will you be using?	Any					
Parameter Settings	What is the frequency of inclk0 input	50 MHz					
(General/Modes)	Which PLL type will you be using?	Top_Bottom PLL					
	How will the PLL outputs be generated?	Select Use the feedback path inside the PLL . Select In normal mode					
	Which output clock will be compensated for?	cO					

MegaWizard Plug-In Manager Page	Settings	Value				
	Create an 'pllena' input to selectively enable the PLL	Disabled				
	Create an 'areset' input to asynchronously reset the PLL	Turned on				
Parameter Settings (Scan/Inputs/Lock)	Create an 'pfdena' input to selectively enable the phase/frequency detector	Turned off				
	Create 'locked' output	Turned on				
	Enable self reset on loss lock	Turned off				
	Create output file(s) using 'Advanced' PLL parameters	Turned off				
	Create optional inputs for dynamic reconfiguration	Turned on				
		the_pII_initial.mif —taking an inclock of 50 MHz and generating c0 of 100 MHz				
	Initial Configuration File (filename)	Ensure that this option shows the correct path of the .mif file before compiling the design to avoid scan chain mismatch warnings.				
		The files are already generated. They are:				
PLL Reconfiguration		 the_pll_200_mhz.mif—taking an inclock of 50 MHz and generating c0 of 200 MHz 				
	Additional Configuration File (filename)	 the_pll_300_mhz.mif—taking an inclock of 50 MHz and generating c0 of 300 MHz 				
		 the_pll_400_mhz.mif—taking an inclock of 50 MHz and generating c0 of 400 MHz 				
		 the_pll_500_mhz.mif—taking an inclock of 50 MHz and generating c0 of 500 MHz 				
	Create optional inputs for dynamic phase reconfiguration	Turned off				
	Use this clock	Turned on				
Output Clocks	Enter output clock frequency	100 MHz				
(clk c0)	Clock phase shift	0 degrees				
	Clock duty cycle (%)	50				
EDA	Generate netlist	Turned off				
	Variation file	Turned on				
	PinPlanner ports PPF file	Turned on				
	AHDL Include file	Turned on				
Summary	VHDL component declaration file	Turned on				
Juinnaly	Quartus II symbol file	Turned on				
	Instantiation template file	Turned on				
	Verilog HDL block box file	Turned on				
	Reconfiguration File for altpll_reconfig	Turned on				

Table 6.	Configuration	Settings for	the ALTPLL	. Megafunction	(Part 2 o	f 2)

The ALTPLL megafunction allows you to generate additional configuration files without going through a compilation stage. It allows you to generate as many unique configuration files as you need without the difficulty of multiple compilation flows. All you need to do is to set the intended PLL settings, enter the file name, and click **Generate A Configuration File**. Use this capability with the PLL reconfiguration of multiple **.mif** files via external ROMs in the ALTPLL_RECONFIG megafunction.

- 7. Click **Finish**. The **the_pll.v** module is built.
- 8. Click **OK**. The MegaWizard Plug-In Manager resets to page 2a so you can create a new custom function variation.
- 9. In the MegaWizard Plug-In Manager pages, select or verify the configuration settings listed in Table 7. Click **Next** to advance from one page to the next.

Table 7. Configuration Settings for the ALTPLL_RECONFIG Megafunction

MegaWizard Plug-In Manager Page	Settings	Value
	Megafunction	Under the I/O category, select ALTPLL_RECONFIG
	Which device family will you be using?	Stratix III
2a	Which type of output file do you want to create?	Verilog
	What name do you want for the output file?	pll_reconfig_circuit.v
	Return to this page for another create operation	Turned off
Parameter	Currently selected device family	Stratix III
Settings	Match project/default	Turned on
(General)	Which scan chain type will you be using	Top/Bottom
	Do you want to specify initial value of the scan chain?	Select Yes, use this file for the content data
Parameter Settings	File name	the_pll_initial_mif.mif Ensure that this option shows the correct path of the .mif file before compiling the design to avoid scan chain mismatch warnings.
(General)	Do not use pre initialized RAM - initialize from ROM instead	Turned off
	Add ports to write to the scan chain from external ROM during run time	Turned on
EDA	Generate netlist	Turned off
	Variation file	Turned on
	AHDL Include file	Turned on
Summany	VHDL component declaration file	Turned on
Guinnary	Quartus II symbol file	Turned on
	Instantiation template file	Turned on
	Verilog HDL block-box file	Turned on

10. Click Finish. The pll_reconfig_circuit module is built.

Compiling the ALTPLL and ALTPLL_RECONFIG Megafunctions

To add the ALTPLL megafunction to the ALTPLL_RECONFIG megafunction, and then compile the design in the Quartus II software, follow these steps:

- 1. On the Project menu, click **Add/Remove Files in Project**. The **Settings** dialog box appears.
- 2. In the Category list, select Files.
- 3. Click **Browse (...)** after **File name** and from the project folder, select **ALTPLL_RECONFIG_rom.v.** This file is the top-level module that contains the port-mapping between the pll_reconfig_circuit and the_pll instances.
- 4. To add the top-level file to the project, click Add.
- 5. Click OK.
- 6. On the File menu, click Save Project.

The top-level file is added to the project.

- 7. To compile the design, on the Processing menu, click Start Compilation.
- 8. When the Full Compilation was successful message box appears, click OK.

You have now created and compiled the complete design file, which can be viewed in the RTL Viewer (Figure 20). To display the RTL Viewer, in the Tools menu, select **Netlist Viewers**, and click on **RTL Viewer**.

Figure 20. Top-Level Design Implementation Using the RTL Viewer

This design consists of eight modules, which are:

- 1. **the_pll:u1**—This represents the Stratix III PLL (Top and Bottom PLL) that is to be reconfigured. The settings are as follows:
 - inclk = 50 MHz
 - c0 = 100 MHz

- inclk = 50 MHz
- c0 = 100 MHz
- 3. **rom_muxer:u3**—This represents a 4-to-1 multiplexer used to multiplex serial data coming from four ROMs to the rom_data_in port of the pll_reconfig_circuit module. The multiplexer is used because the rom_data_in port is 1 bit in size; however, it is controlled by a 2-bit selector, hence its ability to multiplex four signals.
- 4. rom_1:u4—This represents the external ROM, which contains the intended reconfiguration settings of the PLL. It has a 1-bit output port (q) because of the serial nature of writing the intended PLL settings to the scan-chain cache of the pll_reconfig_circuit module. It has a capacity of 256 words of 1-bit size. The ROM uses 256 words because that is the closest approximate size of the scan-chain file for this type of PLL, which is 234 bits. For this ROM, it is represented by the the_pll_200_mhz.mif file, which is 234 bits. The settings are as follows:
 - inclk = 50 MHz
 - c0 = 200 MHz
- 5. rom_2:u5—This represents the external ROM, which contains the intended reconfiguration settings of the PLL. It has a 1-bit output port (q) because of the serial nature of writing the intended PLL settings to the scan-chain cache of the pll_reconfig_circuit module. It has a capacity of 256 words of 1-bit size. The ROM uses 256 words because that is the closest approximate size of the scan-chain file for this type of PLL, which is 234 bits. For this ROM, it is represented by the the_pll_300_mhz.mif file, which is 234 bits. The settings are as follows:
 - inclk = 50 MHz
 - c0 = 300 MHz
- 6. rom_3:u6—This represents the external ROM, which contains the intended reconfiguration settings of the PLL. It has a 1-bit output port (q) because of the serial nature of writing the intended PLL settings to the scan-chain cache of the pll_reconfig_circuit module. It has a capacity of 256 words of 1-bit size. The ROM uses 256 words because that is the closest approximate size of the scan-chain file for this type of PLL, which is 234 bits. For this ROM, it is represented by the .mif file the_pll_400_mhz.mif, which is 234 bits. The settings are as follows:
 - inclk = 50 MHz
 - c0 = 400 MHz

- 7. rom_4:u7—This represents the external ROM, which contains the intended reconfiguration settings of the PLL. It is has a 1-bit output port (q) because of the serial nature of writing the intended PLL settings to the scan-chain cache of the pll_reconfig_circuit module. It has a capacity of 256 words of 1-bit size. The ROM uses 256 words because that is the closest approximate size of the scan-chain file for this type of PLL, which is 234 bits. For this ROM, it is represented by the .mif file the_pll_500_mhz.mif, which is 234 bits. The settings are as follows:
 - inclk = 50 MHz
 - c0 = 500 MHz
- 8. **control_sm:u8**—This represents the state machine that controls the three main processes involved in the PLL reconfiguration with multiple **.mif** files via external ROMs. The state machine selects the ROM to be reconfigured, initiates the writing of the ROM content to the scan-chain cache, and initiates the reconfiguration of the PLL using the written content in the scan-chain cache to the PLL. You can modify this simple state machine to suit your design needs.

Figure 21 shows the state diagram for the state machine.

Figure 21. Control_sm Module State Diagram

Figure 22 shows the corresponding condition for the state transition.

Figure 22. Control_sm Module State Transition Conditions

	Source State	Destination State	Condition
1	state_0	state_0	(!want_to_reconfig)
2	state_0	state_1	(want_to_reconfig)
3	state_1	state_2	
4	state_2	state_2	(!busy)
5	state_2	state_3	(busy)
6	state_3	state_3	(busy)
7	state_3	state_4	(!busy)
8	state_4	state_5	
9	state_5	state_5	(!busy)
10	state_5	state_6	(busy)
11	state_6	state_0	(!busy)
12	state_6	state_6	(busy)

Figure 23 shows how the whole state machine module (control_sm) is being implemented in the RTL Viewer.

Figure 21 through Figure 23 show how the state machine's control paths and data paths are implemented. The next section describes the state machine behavior in detail.

Simulating the Design Example

To simulate the design example using the ModelSim-Altera software, follow these steps:

- 1. Unzip the altpll_reconfig_ex3_msim.zip file to any directory on your PC.
- 2. Browse to the folder in which you unzipped the files.
- 3. Open remote_update_ex2.do file in a text editor.
- 4. In line 1 of the **altpll_reconfig_ex3_msim.do**, ensure that the directory path of the library files is correct. For example, C:/Modeltech_ae/altera/verilog/stratix
- 5. On the File menu, click **Save**.
- 6. Launch the ModelSim-Altera software.
- 7. On the File menu, click Change Directory.
- 8. Select the folder in which you unzipped the files.
- 9. Click OK.
- 10. On the Tools menu, click Execute Macro.
- 11. Select the **altpll_reconfig_ex3_msim.do** file and click **Open**. This is a script file for the ModelSim-Altera software to automate all of the necessary settings for the simulation.
- 12. Verify the results shown in the Wave window.

Figure 24 shows the simulation results when writing from ROM 1 to scan cache of the ALTPLL_RECONFIG megafunction for the duration of 0 to 250 ns.

Figure 24. Initial Writing from ROM 1 to the Scan Cache of the ALTPLL RECONFIG Megafunction (0 to 250 ns)

The simulation begins when the PLL gets locked (refer to Figure 24); the locked signal is asserted at 90 ns. The PLL output c0 produces a 100 MHz clock. The original settings of the PLL have an input clock of 50 MHz and generates an output clock of 100 MHz.

The output_current_state signal is 0, which shows the current state of the state machine that controls the PLL reconfiguration process from the external ROMs.

When the state machine is at 0 (indicated by the output_current_state signal), it is waiting for the assertion of the input_want_to reconfig signal together with the value of the input_intended_rom [1:0] signal, which is 00. The state machine remains at this state until the above conditions are satisfied.

At 140 ns, the input_want_to_reconfig signal is asserted for 1 clock cycle and the input_intended_rom [1:0] signal is set to 00. The input_want_to_reconfig signal controls the write_from_rom signal of the ALTPLL_RECONFIG instantiation. This begins the process of writing the contents of the intended ROM to the scan cache of the ALTPLL_RECONFIG megafunction. The input_intended_rom [1:0] signal is used to control the selector (sel [1:0] signal) of the multiplexer instantiation, which multiplexes the intended ROM contents (in this case, ROM 1) to the rom_data_in signal of the ALTPLL_RECONFIG instantiation.

At 150 ns, the state machine is at 1 (indicated by the output_current_state signal). This signifies that the input_want_to_reconfig signal has been asserted together with the value of the input_intended_rom [1:0] signal, which is 00. This causes the write_from_rom signal of the ALTPLL_RECONFIG instantiation to be asserted. This also causes the selector (sel [1:0] signal) of the multiplexer instantiation to multiplex the intended ROM contents (in this case, ROM 1) to the rom_data_in signal of the ALTPLL_RECONFIG instantiation.

At 170 ns, the state machine is at 2 (indicated by the output_current_state signal). At this state, the state machine is waiting for the assertion of the tapout_busy signal, which signifies the busy signal of the ALTPLL_RECONFIG instantiation. The state machine tracks the busy signal because whatever operation the ALTPLL_RECONFIG is in (for example, read_param, write_param, reconfig, or write_from_rom) when asserted for 1 clock cycle, the busy signal is asserted for a particular duration. This indicates that the particular operation is being processed by the ALTPLL_RECONFIG instantiation. In this state, the tapout_busy signal has been asserted, signifying that the ALTPLL_RECONFIG instantiation has begun processing the write_from_rom operation.

At 190 ns, the state machine is at 3 (indicated by the output_current_state signal). This signifies that the tapout_busy signal has been asserted. At this point the state machine waits until the tapout_busy signal gets deasserted, to signify that the process of writing from the ROM to the scan cache of the ALTPLL_RECONFIG instantiation has been completed. Observe that the tapout_rom_common_rden signal has been asserted. This is the probed-out signal of the write_rom_ena signal, which is part of the ALTPLL_RECONFIG instantiation. This signal functions as the enable signal to the ROMs used in this design. Observe that the tapout_rom_common_address [7:0] signal begins changing value. This is the probed-out signal of the rom_address_out [7:0], which is part of the ALTPLL_RECONFIG instantiation. This signal controls which address of the ROM should be read out to the multiplexer instantiation. When the tapout_rom_common_rden signal is asserted together with the value of 0 for the tapout_rom_common_address [7:0] signal, it reads out the data from address 0 of the ROM 1 to the q port of the ROM, which is connected to the data_0 signal of the multiplexer. Then the data is multiplexed according to the selector of the multiplexer, and sent out to the rom_data_in port of the ALTPLL_RECONFIG instantiation. This port is probed out and is observed by the tapout_rom_data_in port. Therefore, the data from the intended ROM can be observed in simulation.

F

The tapout_rom_common_rden signal is asserted 1 clock cycle later, after the tapout_busy signal is asserted.

Figure 25 shows the simulation results when writing from ROM 1 to the scan cache of the ALTPLL_RECONFIG megafunction for the duration of 60 to 580 ns.

Figure 25. Initial Writing from ROM 1 to the Scan Cache of the ALTPLL_RECONFIG Megafunction (60 to 580 ns)

vsim1:/altpll_reconfig_rom_vlg_vec_tst/input_clock	1		Ц	Ţ	Ľ						þ.				L			Л					Л
+ vsim1:/altpll reconfig rom vlg vec tst/input intended rom	00	00					+					1	╞	╪	-1								
vsim1:/altpll_reconfig_rom_vlg_vec_tst/input_want_to_reconfig	0														1								
vsim1:/altpll_reconfig_rom_vlg_vec_tst/input_main_reset_rom_address	0																						
vsim1:/altpll_reconfig_rom_vlg_vec_tst/tapout_reconfig	St0																_						
vsim1:/altpll_reconfig_rom_vlg_vec_tst/locked	St1														i								
ysim1:/altpll_reconfig_rom_vlg_vec_tst/c0	St1		ப்ப	ιпп	Л	ากก	LL		UГ	Л	ЪΠ	ЪЛ	h	լլլ	Л	บน	лл	JU	UЦ	บบ	UП	ப்ப	илл
vsim1:/altpll_reconfig_rom_vlg_vec_tst/tapout_busy	St1												1		Ì								
ysim1:/altpll_reconfig_rom_vlg_vec_tst/tapout_rom_common_rden	St1											1			1								
#	7	0							1	2	3	4	5	6		7	8)(9) 10	(11	(12	13)14
sim1:/altpll_reconfig_rom_vlg_vec_tst/tapout_rom_data_in 🗸 🗸	St1				_						<u> </u>	<u> </u>			Ĩ								
vsim1:/altpll_reconfig_rom_vlg_vec_tst/output_current_state	3	0			_1	1 <u>)</u> 2	3						\square		-								
Now	000000 ps	11	00 ns	C. L. L. L.	μÌ		200	i ns	LLI	1.1.1			300	ns '		L L L	L		400	ns		l.	
Cursor 1	190000 ps					1	90 ns	H	20000	DS					1								
Cursor 8	210000 ps	ps 210 ns 2000C ps																					
Cursor 9	230000 ps	230 ns 2000 ps																					
Cursor 10	250000 ps									25	0 ns	2000	0 ps										
Cursor 11	270000 ps	ps 270 ns 2000C ps																					
Cursor 12	290000 ps	ps 290 ns 20000 ps																					
Cursor 13	310000 ps	00 ps 310 ns 20000 ps																					
Cursor 14	330000 ps														330	ns							

When data from the ROM is written to the scan cache of the ALTPLL_RECONFIG, it is done serially, meaning a 1-by-1 bit per cycle, from address 0 to address 233. You can observe this via the tapout_rom_data_in signal. The valid data read out from the ROM is delayed by 2 clock cycles.

When the simulation is at 270 ns, the tapout_rom_common_rden signal is asserted with the tapout_rom_common_address [7:0] signal with a value of 4. The data read out has a value of 1 in the **.mif** file in Figure 25. However, this value only appears when the tapout_rom_common_rden signal is asserted via the tapout_rom_common_address [7:0] signal with a value of 6 at 310 ns, implying a 2-clock-cycle delay.

This writing process continues until it has reached address 233. Figure 26 shows the simulation results of the final process in writing the contents of ROM 1 to the scan cache of the ALTPLL_RECONFIG megafunction.

Figure 26. Ending Process of Writing the Contents of ROM 1 to the Scan Cache of the ALTPLL_RECONFIG Megafunction (4700 to 5040 ns) ⁽¹⁾

Note to Figure 26:

(1) This figure also shows the initialization of the reconfiguration process.

At 4850 ns, the tapout_rom_common_rden signal is asserted with the tapout_rom_common_address [7:0] signal with a value of 233. This is the last address read out from ROM 1.

Le The data is available only 2 clock cycles later on the tapout_rom_data_in signal. The tapout_rom_common_rden signal and the tapout_busy signal are still asserted. The output_current_state signal still has a value of 3. It will remain in this state until the tapout_busy signal is deasserted.

At 4870 ns, the tapout_rom_common_rden signal is deasserted with the tapout_rom_common_address [7:0] signal with a value of 0. This stops the ROM 1 from reading out data; therefore, the address becomes 0. The tapout_rom_data_in signal still generates valid output data and the tapout_busy signal is asserted. The output_current_state signal still has a value of 3.

At 4890 ns, the tapout_rom_common_rden signal remains deasserted with the tapout_rom_common_address [7:0] signal with a value of 0. Observe that the tapout_rom_data_in signal generates the last valid output data from ROM 1 (from address 233). The tapout_busy signal is deasserted and the output_current_state signal still has a value of 3.

At 4910 ns, the tapout_rom_common_rden signal remains deasserted with the tapout_rom_common_address [7:0] signal with a value of 0.

The tapout_rom_data_in signal no longer generates valid output data. The tapout_busy signal remains deasserted. The output_current_state signal changes value from 3 to 4. In this state, the state machine is initiating the reconfiguration process.

You can observe this state by the assertion of the tapout_reconfig signal for 1 clock cycle. This signal controls the reconfig signal of the ALTPLL_RECONFIG instantiation. When this signal is asserted for 1 clock cycle, the ALTPLL_RECONFIG instantiation begins the PLL reconfiguration process by using the settings written from ROM 1 to the scan cache of the ALTPLL_RECONFIG instantiation.

At 4930 ns, the tapout_reconfig signal is deasserted and the tapout_busy signal is asserted. This indicates that the state machine tracks the busy signal. The state machine tracks the busy signal because whatever operation the ALTPLL_RECONFIG is in (for example read_param, write_param, reconfig, write_from_rom) when asserted for 1 clock cycle, the busy signal is asserted for a particular duration. This indicates that the particular operation is being processed by the ALTPLL_RECONFIG instantiation. The output_current_state signal changes value from 4 to 5. It remains in this state until the tapout_busy signal is asserted.

At 4950 ns, the tapout_busy signal remains asserted. The output_current_state signal changes value from 5 to 6. It remains in this state until the tapout_busy signal is deasserted.

Figure 27 shows the final part of the reconfiguration process.

Figure 27. PLL Reconfiguration (10,000 to 10,400 ns) (1)

Note to Figure 27:

(1) From c0 = 100 MHz to c0 = 200 MHz.

At 10,130 ns, the tapout_busy signal remains asserted. The output_current_state signal remains at a value of 6. Therefore, the state machine is still waiting for the tapout_busy signal to be deasserted. The c0 signal is still at 100 MHz and the locked signal remains asserted, which means the PLL is still locked to a 100-MHz signal.

At 10,170 ns, the tapout_busy signal remains asserted. The output_current_state signal remains at a value of 6. Therefore, the state machine is still waiting for the tapout_busy signal to be deasserted. The locked signal is deasserted, which means the PLL has lock loss, and the c0 signal is at a 0 value and not producing a clock pulse.

At 10,190 ns, the tapout_busy signal is deasserted. This means the PLL reconfiguration process is complete. The output_current_state signal remains at a value of 6. The locked signal remains deasserted. The c0 signal is an unknown value and still not producing a clock pulse.

At 10,210 ns, the tapout_busy signal remains deasserted. The output_current_state signal changes to a value of 0. This is the original state, in which the state machine waits for the next reconfiguration from an external ROM. The locked signal remains deasserted. The c0 signal is an unknown value and still does not produce a clock pulse.

At 10,290 ns, the tapout_busy signal remains deasserted. The output_current_state signal remains at a value of 0. The locked signal is asserted. The c0 signal now produces a 200-MHz clock signal, which is the intended setting from ROM 1.

Figure 28 through Figure 30 show the PLL reconfiguration process from the remaining ROMs (ROM 2, ROM 3, and ROM 4, respectively).

Figure 28. PLL Reconfiguration from ROM 2 (20,330 to 20,600 ns) (1)

Note to Figure 28:

(1) From c0 = 200 MHz to c0 = 300 MHz.

Figure 29. PLL Reconfiguration from ROM 3 (30,480 to 30,750 ns) ⁽¹⁾

Note to Figure 29:

(1) From c0 = 300 MHz to c0 = 400 MHz.

vism1:/alpll_reconfig_rom_vig_vec_tst/input_clock vism1:/alpll_reconfig_rom_vig_vec_tst/input_reset vism1:/alpll_reconfig_rom_vig_vec_tst/input_reset vism1:/alpll_reconfig_rom_vig_vec_tst/input_mant_to_reconfig vism1:/alpll_reconfig_rom_vig_vec_tst/apout_reconfig vism1:/alpll_reconfig_rom_vig_vec_tst/apout_tom_common_rden vism1:/alpll_reconfig_rom_vig_vec_tst/apout_tom_common_rden vism1:/alpll_reconfig_rom_vig_vec_tst/apout_rom_common_rden vism1:/alpll_reconfig_rom_vig_vec_tst/apout_rom_common_rden vism1:/alpll_reconfig_rom_vig_vec_tst/apout_rom_common_rden vism1:/alpll_reconfig_rom_vig_vec_tst/apout_rom_common_rden vism1:/alpll_reconfig_rom_vig_vec_tst/apout_rom_common_rden vism1:/alpll_reconfig_rom_vig_vec_tst/apout_rom_common_rden vism1:/alpll_reconfig_rom_vig_vec_tst/apout_rom_common_rden	1 00 0 50 50 50 50 50 0 500 0						10			
Now Cutser 15 Cutser 21 Cutser 23 Cutser 23 Cutser 24 Cutser 24	000000 ps 0 ps 130000 ps 170000 ps 190000 ps 210000 ps 290000 ps	40850 ns	4090	0 ns	i l i i	40950 ns		41	us	41050 ns

Note to Figure 30:

(1) From c0 = 400 MHz to c0 = 500 MHz.

The next part of the simulation demonstrates the PLL reconfiguration from ROM 1 again, but highlights the ROM address resetting capabilities during writing from an external ROM to the scan cache of the ALTPLL_RECONFIG instantiation. The c0 signal is 500 MHz and is reconfigured to 100 MHz. Figure 31 shows the process of initiating writing the contents of ROM 1 to the ALTPLL_RECONFIG instantiation.

Figure 31. Initial Writing from ROM 1 to the Scan Cache of the ALTPLL_RECONFIG Megafunction (41,070 to 41,330 ns)

Figure 32 shows how the reset_rom_address capability is used.

Figure 32. Resetting the Address when Writing from ROM 1 to the Scan Cache of the ALTPLL_RECONFIG Megafunction (41,200 to 41,450 ns)

At 41,250 ns, the tapout_rom_common_rden signal is asserted with the tapout_rom_common_address [7:0] signal with a value of 4. Observe that the tapout_busy signal is asserted. The output_current_state signal is 3. The normal writing process from ROM to scan cache of the ALTPLL_RECONFIG instantiation continues.

At 41,290 ns, the tapout_rom_common_rden signal is asserted with the tapout_rom_common_address [7:0] signal with a value of 6. The tapout_rom_data_in signal contains the valid data from address 4 because of the 2-clock-cycle delay. The tapout_busy signal is asserted. The output_current_state signal is 3.

At 41,380 ns, the input_main_reset_rom_address is asserted for 1 clock cycle. This signal controls the reset_rom_address of the ALTPLL_RECONFIG instantiation. It resets the address counter in the ALTPLL_RECONFIG instantiation to 0.

At 41,390 ns, the tapout_rom_common_rden signal is deasserted for 1 clock cycle. The tapout_rom_common_address [7:0] signal is changed to a value of 0. The tapout_rom_data_in signal still generates the previous 2-clock-cycle output data (address 9), which is of value 1. The tapout_busy signal is still asserted. The output_current_state signal is 3.

At 41,410 ns, the tapout_rom_common_rden signal is reasserted. The tapout_rom_common_address [7:0] signal is changed to a value of 0. This restarts the writing of the contents of ROM 1 to the ALTPLL_RECONFIG scan cache from address 0. The tapout_busy signal is still asserted. The output_current_state signal is 3.

The PLL reconfiguration process continues as normal until the c0 signal is 200 MHz, as shown in Figure 33.

Figure 33. PLL Reconfiguration From ROM1 (40,800 to 41,090 ns) ⁽¹⁾

Note to Figure 33:

(1) From c0 = 500 MHz to c0 = 200 MHz.

You can modify the design to suit your requirements when attempting to reconfigure the PLL from multiple **.mif** files via external ROMs.

Specifications

This section describes the prototypes, component declarations, ports, and parameters of the ALTPLL_RECONFIG megafunction. These ports and parameters are available to customize the ALTPLL_RECONFIG megafunction according to your application.

Verilog HDL Prototype

The following Verilog HDL prototype is located in the Verilog Design File (.v) **altera_mf.v** in the *<Quartus II installation directory>***eda\synthesis** directory.

modulealtpll_reconfig

```
#( parameterintended_device_family = "unused",
    parameterinit_from_rom = "NO",
    parameterpll_type = "UNUSED",
    parameterscan_chain = "UNUSED",
    parameterscan_init_file = "UNUSED",
```

```
parameteruse_scanclk_sync_register = "NO",
   parameterlpm_type = "altpll_reconfig",
   parameterlpm_hint = "unused")
   outputwirebusy,
(
   inputwireclock,
   inputwire[2:0]counter_param,
   inputwire[3:0]counter_type,
   inputwire[8:0]data_in,
   outputwire[8:0]data_out,
   outputwirepll_areset,
   inputwirepll_areset_in,
   outputwirepll_configupdate,
   outputwirepll_scanaclr,
   outputwirepll_scanclk,
   outputwirepll_scanclkena,
   outputwirepll_scandata,
   inputwirepll_scandataout,
   inputwirepll_scandone,
   outputwirepll_scanread,
   outputwirepll_scanwrite,
   inputwireread_param,
   inputwirereconfig,
   inputwirereset,
   inputwirereset_rom_address,
   outputwire[7:0]rom_address_out,
   inputwirerom_data_in,
   inputwirewrite_from_rom,
   inputwirewrite_param,
   outputwirewrite_rom_ena)/* synthesis syn_black_box=1 */;
```

```
endmodule //altpll_reconfig
```

VHDL Component Declaration

The following VHDL component declaration is located in the VHDL Design File (.vhd) altera_mf_components.vhd in the <*Quartus II installation directory*>\libraries\vhdl\altera_mf directory.

```
component altpll_reconfig
generic (
    intended_device_family:string := "unused";
    init_from_rom:string := "NO";
    pll_type:string := "UNUSED";
```

```
scan_chain:string := "UNUSED";
      scan_init_file:string := "UNUSED";
      use_scanclk_sync_register:string := "NO";
      lpm_hint:string := "UNUSED";
      lpm_type:string := "altpll_reconfig"
   );
   port(
      busy: out std_logic;
      clock: in std_logic;
      counter_param:in std_logic_vector(2 downto 0) := (others =>
'0');
      counter_type:in std_logic_vector(3 downto 0) := (others =>
'0');
      data_in:in std_logic_vector(8 downto 0) := (others => '0');
      data_out:out std_logic_vector(8 downto 0);
      pll_areset:out std_logic;
      pll_areset_in:in std_logic := '0';
      pll_configupdate:out std_logic;
      pll_scanaclr:out std_logic;
      pll_scanclk:out std_logic;
      pll_scanclkena:out std_logic;
      pll_scandata:out std_logic;
      pll_scandataout:in std_logic := '0';
      pll_scandone:in std_logic := '0';
      pll_scanread:out std_logic;
      pll_scanwrite:out std_logic;
      read_param:in std_logic := '0';
      reconfig:in std_logic := '0';
      reset: in std_logic;
      reset_rom_address:in std_logic := '0';
      rom_address_out:out std_logic_vector(7 downto 0);
      rom_data_in:in std_logic := '0';
      write_from_rom:in std_logic := '0';
      write_param:in std_logic := '0';
      write_rom_ena:out std_logic
   );
end component;
```

Ports and Parameters

This section describes the ports and parameters of the ALTPLL_RECONFIG megafunction.

Table 8 lists the ALTPLL_RECONFIG megafunction input ports.

 Table 8. ALTPLL_RECONFIG Megafunction Input Ports (Part 1 of 3)

Port Name	Required?	Description
		Clock input for loading individual parameters. This signal also clocks the PLL during reconfiguration.
clock	Yes	The clock input port must be connected to a valid clock.
		Refer to the <i>DC and Switching Characteristics</i> chapter of the respective device handbooks for the clock f_{MAX} .
		Asynchronous reset input to the megafunction.
reset	Yes	Altera recommends that you reset this megafunction before first use to guarantee that it is in a valid state. However, it does power up in the reset state. This port must be connected.
		Data input that provides parameter value when writing parameters.
data_in[]	No	A 9-bit input port that provides the data to be written to the scan cache during a write operation. The bit width of the counter parameter to be written determines the number of bits of $data_in[]$ that are read into the cache. For example, the low bit count of the c0 counter is 8-bit wide, so $data_in[70]$ is read to the correct cache location. The bypass mode for the C0 counter is 1-bit wide, so $data_in[0]$ is read for the value of this parameter. If omitted, the default value is 0.
		Specifies the counter type.
		An input port in the form of a 4-bit bus that selects which counter type should be selected for the corresponding operation (read, write, or reconfig). The following table specifies the mapping between the counter_type value and the physical counter to be set. For details, refer to the following tables:
counter_type[]	No	 Table 11 on page 45 counter_type[30] settings for Stratix III, Stratix IV, and Cyclone III devices.
		 Table 13 on page 47 counter_type[30] settings for Stratix II, Stratix II GX, Arria GX and HardCopy II devices.
		 Table 14 on page 49 counter_type[30] settings for Stratix and Stratix GX devices.
		Specifies the parameter for the value specified in the counter_type port.
		An input port in the form of a 3-bit bus that selects which parameter for the given counter type should be updated. The mapping to each parameter type and the corresponding parameter bit-width are defined in the following tables:
counter_param[]	No	 Table 12 on page 46 counter_param[20] settings for Stratix III, Stratix IV, and Cyclone III devices.
		 Table 13 on page 47 counter_param[20] settings for Stratix II, Stratix II GX, Arria GX and HardCopy II devices.
		 Table 14 on page 49 counter_param[20] settings for Stratix and Stratix GX devices.

Table 8. ALTPLL_RECONFIG Megafunction Input Ports (Part 2 of 3)

Port Name	Required?	Description
		Reads the parameter specified with the counter_type and counter_param ports from cache and fed to the data_out[] port.
read_param	No	When asserted, the read_param signal indicates that the scan cache should be read and fed to data_out[]. The bit location of the scan cache and the number of bits read and sent to data_out[] depend on the counter_type and counter_param values. The read_param signal is sampled at the rising clock edge. If it is asserted, the parameter value is read from the cache. Assert the read_param signal for 1 clock cycle only to prevent the parameter from being read twice.
		The busy signal is asserted on the rising clock edge following the assertion of read_param. While the parameter is being read, the busy signal remains asserted. After the busy signal is deasserted, the value on data_out[] is valid and the next parameter can be loaded. While the busy signal is asserted, the value on data_out[] is not valid.
		When the read_param signal is asserted, the busy signal is only asserted on the following rising edge of the clock and not on the same clock cycle as read_param.
		Writes the parameter specified with the <code>counter_type</code> and <code>counter_param</code> ports to the cache with the value specified on the <code>data_in[]</code> port.
write_param	No	When asserted, the write_param signal indicates that the value on data_in[] should be written to the parameter specified by counter_type[] and counter_param[]. The number of bits read from the data_in[] port depends on the parameter. The write_param signal is sampled at the rising clock edge. If it is asserted, the parameter value is written to the cache. Assert the write_param signal for 1 clock cycle only to prevent the parameter from being written twice.
		The busy signal is asserted on the rising clock edge following the assertion of write_param. While the parameter is being written, the busy signal remains asserted and input to data_in[] is ignored. After the busy signal is deasserted, the next parameter can be written.
		When the write_param signal is asserted, the busy signal is only asserted on the following rising edge of the clock and not on the same clock cycle as write_param.
		Specifies that the phase-locked loop (PLL) should be reconfigured with the PLL settings specified in the current cache.
		When asserted, the reconfig signal indicates that the PLL should be reconfigured with the values in the cache. The reconfig signal is sampled at the rising clock edge. If it is asserted, the cached settings are loaded in the PLL. Assert the reconfig signal for 1 clock cycle only to prevent reloading the PLL configuration. The busy signal is asserted on the rising clock edge following the assertion of reconfig. While the PLL is being loaded, the busy signal remains asserted. After the busy signal is deasserted, the parameter values can be modified again.
reconfig	Yes	During and after reconfiguration, the scan chain data cache remains unchanged. This allows you to easily create a new set of reconfiguration settings that differs from the previous one in only one parameter.
		If write_param has not been asserted since the previous assertion of reconfig, in Stratix II devices, the pll_scanwrite signal is pulsed during reconfiguration. This feature supports burst-phase stepping. However, in Stratix III, Stratix IV, Cyclone III, Cyclone IV, and Arria II GX devices, the entire scan chain is shifted in to the PLL again.
		When the $reconfig$ signal is asserted, the $busy$ signal is only asserted on the following rising edge of the clock and not on the same clock cycle as $reconfig$.

Port Name	Required?	Description
		Input signal indicating that the PLL should be reset.
pll_areset_in	No	When asserted, the pll_areset_in signal indicates the PLL megafunction should be reset. This port defaults to 0 if left unconnected. When the ALTPLL_RECONFIG megafunction is used in a design, you cannot reset the PLL in any other way; you must use this megafunction port to manually reset the PLL.
		Input port for the ALTPLL_RECONFIG megafunction that signals update done from the PLL module. This port is driven by the PLL's scandone output signal and determines when the PLL is reconfigured.
pll_scandone	No	For Stratix III and Stratix IV devices, pll_scandone is asserted on most operations, and deasserted as soon as it detects the assertion of configupdate. Upon the completion of all PLL reconfiguration updates, scandone is reasserted.
		This is different than the scandone signal in older device families, such as Stratix devices. In Stratix devices, the scandone signal is deasserted most of the time. The scandone signal is asserted for 1 clock cycle to mark the completion of PLL reconfiguration.
pll_scandataout		Input port driven by the scandataout signal from the ALTPLL megafunction. It can be used to read the current configuration of the ALTPLL megafunction.
	Yes	This input port holds the ALTPLL megafunction scan data output from the dynamically reconfigurable bits. The pll_scandataout port must be connected to the scandataout port of the PLL. The activity on this port can only be observed when the reconfig signal is asserted.
		Serial data input to the PLL from the ROM.
rom_data_in	No	This 1-bit port allows the external ROM to be serially written into the scan cache of the ALTPLL_RECONFIG megafunction. The value on this port is valid 2 clock cycles after the write_rom_ena signal is asserted and remains valid until 2 clock cycles after the write_rom_ena signal is deasserted. This port is available for Stratix III, Stratix IV, Cyclone III, Cyclone IV, HardCopy III, HardCopy IV, and Arria II GX devices only.
		Specifies that the scan chain must be written from the external ROM.
write_from_rom	No	When asserted, this signal tells the ALTPLL megafunction to write the scan cache from the external ROM. At the next rising clock edge, the ALTPLL_RECONFIG megafunction asserts the write_rom_ena signal and begins placing valid ROM addresses on the rom_address_out port. Assert the write_from_rom signal for 1 clock cycle only. This port is available for Stratix III, Stratix IV, Cyclone III, Cyclone IV, HardCopy III, HardCopy IV, and Arria II GX devices only.
		Resets the ROM address.
reset_rom_address	No	When asserted, this signal tells the ALTPLL megafunction to restart the read from ROM at address 0. Assert the reset_rom_address signal for 1 clock cycle only. This port is available for Stratix III, Stratix IV, Cyclone III, Cyclone IV, HardCopy III, HardCopy IV, and Arria II GX devices only.

Table 8. ALTPLL_RECONFIG Megafunction Input Ports (Part 3 of 3)

Table 9 lists the ALTPLL_RECONFIG megafunction output ports.

 Table 9. ALTPLL_RECONFIG Megafunction Output Ports (Part 1 of 2)

Port Name	Required?	Description
		Data read from the cache when read_param is asserted.
data_out[]	No	9-bit output bus that provides the parameter data to the user. When the read_param signal is asserted, the values on counter_type[] and counter_param[]determine the parameter value that is loaded from cache and driven on the data_out[] bus. When the megafunction deasserts the busy signal, the appropriate bits of the bus (for example,[0] or [30]) hold a valid value.
		Indicates when the PLL is reading or writing a parameter to the cache, or is configuring the PLL.
busy	No	While the busy signal is asserted, no parameters can be read or written, and no reconfiguration can be initiated. Changes to the megafunction can be made only when the busy signal is not asserted. The signal goes high when the read_param, write_param, or reconfig input port is asserted, and remains high until the specified operation is complete. In the case of a reconfiguration operation, the busy signal remains high until the pll_areset signal is asserted and then deasserted.
		Drives the areset port on the PLL to be reconfigured.
pll_areset	Yes	The pll_areset port must be connected to the areset port of the ALTPLL megafunction for the reconfiguration to function correctly. This signal is active high. pll_areset is asserted when pll_areset_in is asserted, or, after reconfiguration, at the next rising clock edge after the scandone signal goes high. If you use the ALTPLL_RECONFIG megafunction, drive the PLL areset port using the pll_areset output port.
		Drives the configupdate port on the PLL to be reconfigured.
pll_configupdate	No	When asserted, the pll_configupdate port loads selected data to PLL configuration latches. The signal is asserted after the final data bit is sent out. This port is available for Stratix III, Stratix IV, Cyclone III, Cyclone IV, HardCopy III, HardCopy IV, and Arria II GX devices only.
		Drives the scanclk port on the PLL to be reconfigured.
pll_scanclk	Yes	For information about the maximum scanclk frequency for the various devices, refer to the respective device handbook.
		This acts as a clock enable for the scanclk port on the PLL to be reconfigured.
pll_scanclkena	No	Reconfiguration begins on the first rising edge of pll_scanclk after pll_scanclkena is asserted. On the first falling edge of pll_scanclk, after the pll_scanclkena signal is deasserted, the megafunction stops scanning data to the PLL.
		Drives the scanaclr port on the PLL to be reconfigured.
pll_scanaclr	Yes	Not available for Stratix II, Stratix III, Stratix IV, Cyclone III, Cyclone IV, HardCopy II, HardCopy II, HardCopy IV, Arria GX, and Arria II GX devices.
		Drives the scanread port on the PLL to be reconfigured.
pll_scanread	No	Not available for Stratix III, Stratix IV, Cyclone III, Cyclone IV, HardCopy III, HardCopy IV, and Arria II GX devices.
		Drives the scanwrite port on the PLL to be reconfigured.
pll_scanwrite	No	Not available for Stratix III, Stratix IV, Cyclone III, Cyclone IV, HardCopy III, HardCopy IV, and Arria II GX devices.

Port Name	Required?	Description
		Drives the scandata port on the PLL to be reconfigured.
pll_scandata	Yes	This output port from the megafunction holds the scan data input to the PLL for the dynamically reconfigurable bits. The pll_scandata port sends scandata to the PLL. Any activity on this port can only be observed when the reconfig signal is asserted.
		Specifies the address in ROM from which data is written to the scan chain.
rom_address_out	No	During the write operation, the address increments from address 0 to the size of the scan cache. The rom_address_out port is valid only while the write_rom_ena port is asserted. Each address is asserted for 1 clock cycle. This port is available for Stratix III, Stratix IV, Cyclone III, Cyclone IV, HardCopy III, HardCopy IV, and Arria II GX devices only.
		Enables the ROM.
write_rom_ena	No	When the write_rom_ena signal is asserted, the ALTPLL_RECONFIG megafunctions generates valid addresses on the rom_address_out port. This port is available for Stratix III, Stratix IV, Cyclone III, Cyclone IV, HardCopy III, HardCopy IV, and Arria II GX devices only.

Table 9. ALTPLL_RECONFIG Megafunction Output Ports (Part 2 of 2)

Table 10 lists the ALTPLL_RECONFIG megafunction parameters.

 Table 10.
 ALTPLL_RECONFIG Megafunction Parameters (Part 1 of 2)

Parameter	Туре	Required?	Desci	ription		
init_from_rom[]	String	No	Specifies initialization from ROM. Initi reset (to match RAM .mif file behavio NO. If omitted, the default value is NO.	Specifies initialization from ROM. Initializes on power-up and not after every reset (to match RAM .mif file behavior). The available values are YES and NO. If omitted, the default value is NO.		
pll_type	String	No	Specifies the type of PLL to instantiate. For Stratix III, Stratix IV, Cyclone III, Cyclone IV, Arria II GX, HardCopy III, and HardCopy IV devices, values are TOP_BOTTOM and LEFT_RIGHT. For Stratix II, Stratix II GX, Arria GX, and HardCopy II devices, values are ENHANCED and FAST.			
	String	No	Specifies the valid PLL types. Available for Stratix and Stratix GX devices only. Values are LONG, SHORT, and UNUSED. If omitted, the default value is UNUSED.			
and the last			Value	Configuration Setting		
scan_chain			LONG	288-bit scan chain used to control PLLs with 12 counters		
			SHORT	192-bit scan chain used to control PLLs with 8 counters		

Parameter	Туре	Required?	Desc	ription	
			Specifies the name of the .mif or .hex used as the initial value of the scan chain cache. Values are <i><filename></filename></i> and UNUSED. If omitted, the value for every entry in the cache is 0. You must set the input file as shown in the following table:		
			Device	Input File Size	
scan_init_file	String I	No	Stratix series devices (except Stratix III and Stratix IV devices)	192 bits or 288 bits depending on the scan_chain length	
			Stratix III and Stratix IV Top/Bottom PLL devices	234 bits	
			Stratix III and Stratix IV Right/Left PLL devices	180 bits	
			Cyclone III and Cyclone IV devices	144 bits	
			Arria II GX devices	180 bits	
use_scanclk_sync_ register	String	No	Specifies whether to use the scanclk the register. Available for all supporte Cyclone III, Cyclone IV, HardCopy III, Values are YES and NO. If omitted, the	port for the synchronization mode for d devices except Stratix III, Stratix IV, HardCopy IV, and Arria II GX devices. default value is NO.	

Table 10. ALTPLL_RECONFIG Megafunction Parameters (Part 2 of 2)

Table 11 lists the counter_type settings for Stratix III, Stratix IV, Cyclone III, Cyclone IV, and Arria II GX devices.

Table 11. Arria II GX	counter_type[30] Settings for Stratix III, Stratix IV, Cyclone Devices (Part 1 of 2)	e III, Cyclone	IV, and
	• • • • •	D .	

Counter Selection	Binary	Decimal
Ν	0000	0
M	0001	1
CP/LF	0010	2
VCO	0011	3
C0 (1)	0100	4
C1 (1)	0101	5
C2 (1)	0110	6
C3 (1)	0111	7
C4 (1)	1000	8
C5 ⁽²⁾	1001	9
C6 ⁽²⁾	1010	10
C7 (3)	1011	11
C8 (3)	1100	12
C9 (3)	1101	13
Illegal value	1110	14

Table 11. counter_type[3..0] Settings for Stratix III, Stratix IV, Cyclone III, Cyclone IV, and Arria II GX Devices (Part 2 of 2)

Counter Selection	Binary	Decimal
Illegal value	1111	15
Natao Ao Tabla da.		·

Notes to Table 11:

(1) For Stratix III and Stratix IV Top/Bottom PLL, Stratix III and Stratix IV Left/Right PLL, and Cyclone III and Cyclone IV PLL.

(2) For Stratix III and Stratix IV Top/Bottom PLL, Stratix III and Stratix IV Left/Right PLL, and Arria II GX PLL.

(3) For Stratix III and Stratix IV Top/Bottom PLL only.

Table 12 lists the counter_param settings for Stratix III, Stratix IV, Cyclone III, Cyclone IV, and Arria II GX devices.

Table 12. counter_param[2..0] Settings for Stratix III, Stratix IV, Cyclone III, Cyclone IV, and Arria II GX Devices

Counter Type	Counter Param	Binary	Decimal	Width (bits)
Regular counters	High count	000	0	8
CO-C9: Top-Bottom	Low count	001	1	8
Stratix III and Stratix IV	Bypass	100	4	1
C0-C6: Left-Right Stratix III and Stratix IV				
CO-C4: Cyclone III and Cyclone IV	Mode (odd/even division)	101	5	1
CO-C6: Arria II GX				
	Charge pump unused	101	5	5
	Charge pump current	000	0	3
CP/LF	Loop filter unused	100	4	1
	Loop filter resistor	001	1	5
	Loop filter capacitance	010	2	2
VCO	VCO Post Scale	000	0	1
	High count	000	0	8
	Low count	001	1	8
M/N Counters	Bypass	100	4	1
	Mode (odd/even division)	101	5	1
	Nominal count	111	7	9

Note to Table 11:

(1) For even nominal count, the counter bits are automatically set as follows:

- high_count = Nominalcount/2
- low_count= Nominalcount/2
- For odd nominal count, the counter bits are automatically set as follows:
- high_count = (Nominalcount + 1)/2
- low_count = Nominalcount high_count
- odd/even division bit = 1

For nominal count = 1, Bypass bit = 1.

Table 13 lists the counter_type and counter_param settings for Stratix II, Stratix II GX, Arria GX, and HardCopy II devices.

Table 13.	counter_	type and counter	_param Settings for	Stratix II, Stratiz	k II GX, Arria GX, and
HardCopy	II Devices	\$ (Part 1 of 2)			

Counter		Settings	
	4-bit bus that selects which counter type must be updated. The following mapping determines which counter is specified for each counter_type value.		
	counter_type[30]	Selected Counter	
	0000 (0x0)	N [Enhanced PLL/ Fast PLL]	
	0001 (0x1)	M [Enhanced PLL/ Fast PLL]	
	0010 (0x2)	P/LF [Enhanced PLL/ Fast PLL]	
	0011 (0x3)	(Illegal value)	
	0100 (0x4)	C0 [Enhanced PLL/ Fast PLL]	
	0101 (0x5)	C1 [Enhanced PLL/ Fast PLL]	
<pre>counter_type[]</pre>	0110 (0x6)	C2 [Enhanced PLL/ Fast PLL]	
	0111 (0x7)	C3 [Enhanced PLL/ Fast PLL]	
	1000 (0x8)	C4 [Enhanced PLL]	
	1001 (0x9)	C5 [Enhanced PLL]	
	1010 (0xA)	(Illegal value)	
	1011 (0xB)	(Illegal value)	
	1100 (0xC)	(Illegal value)	
	1101 (0xD)	(Illegal value)	
	1110 (0xE)	(Illegal value)	
	1111 (0xF)	(Illegal value)	

Counter		Settings		
	3-bit bus that selects which parameter for the given counter type should be updated. The mapping to each parameter type and the corresponding parameter bit-width is defined as follows:			
	<pre>counter_param[20]</pre>	Selected Parameter	Width	
	000 (0x0)	nominal count ⁽¹⁾	9	
	001 (0x1)	spread count ⁽¹⁾	9	
	000 (0x0)	high cycles count ⁽²⁾	8	
	001 (0x1)	low cycles count ⁽²⁾	8	
	000 (0x0)	high cycles count ⁽³⁾	4	
	001 (0x1)	low cycles count (3)	4	
counter param[]	000 (0x0)	nominal count ⁽⁴⁾	2	
<u>-</u>	010 (0x2)	phase step setting	2	
	100 (0x4)	counter bypass bit	1	
	101 (0x5)	counter odd division bit ⁽⁵⁾	1	
	101 (0x5)	spread counter bypass ⁽¹⁾	1	
	000 (0x0)	charge pump current ⁽⁶⁾	4	
	001 (0x1)	loop filter resistor (6)	6	
	010 (0x2)	loop filter capacitor ⁽⁶⁾	2	
	011 (0x3)	(illegal value)	—	
	110 (0x6)	(illegal value)	—	
	111 (0x7)	(illegal value)	—	

Table 13. counter_type and counter_param Settings for Stratix II, Stratix II GX, Arria GX, and HardCopy II Devices (Part 2 of 2)

Notes to Table 13:

(1) For Enhanced PLL M and N.

(2) For Enhanced PLL CO-C5.

(3) For Fast PLL CO-C3 and M.

(4) For Fast PLL N.

(5) For CO-C5, Fast PLL M.

(6) For CP/LF.

Table 14 lists the counter_type and counter_param settings for Stratix and Stratix GX devices.

Counter	Settings			
	4-bit bus that selects which c mapping determines which c value.	4-bit bus that selects which counter type must be updated. The following mapping determines which counter is specified for each counter_type value.		
	counter_type[30] Selected Counter (1)			
	0000 (0x0)	Μ		
	0001 (0x1)	Ν		
	0010 (0x2)	(Illegal value)		
	0011 (0x3)	(Illegal value)		
	0100 (0x4)	GO		
	0101 (0x5)	G1		
counter_type[]	0110 (0x6)	G2		
	0111 (0x7)	G3		
	1000 (0x8)	LO		
	1001 (0x9)	L1		
	1010 (0xA)	(Illegal value)		
	1011 (0xB)	(Illegal value)		
	1100 (0xC)	E1		
	1101 (0xD)	E2		
	1110 (0xE)	E3		
	1111 (0xF)	E4		

Table 14. counter_type and counter_param Settings for Stratix and Stratix GX Devices (Part 1 of 2)

Counter		Settings		
	3-bit bus that selects which parameter for the given counter type should be updated. The mapping to each parameter type and the corresponding parameter bit-width is defined as follows:			
	counter_param[20] (5)	Selected Parameter	Width	
	000 (0x0)	nominal count ⁽²⁾	9	
	001 (0x1)	spread count ⁽²⁾	9	
	000 (0x0)	high cycles count ⁽³⁾	9	
counter_param[]	001 (0x1)	low cycles count (3)	9	
	010 (0x2)	delay element setting	4	
	011 (0x3)	(illegal value)	—	
	100 (0x4)	counter bypass bit	1	
	101 (0x5)	counter odd division bit ⁽⁴⁾	1	
	110 (0x6)	(illegal value)	_	
	111 (0x7)	(illegal value)	—	

Table 14. counter_type and counter_param Settings for Stratix and Stratix GX Devices (Part 2 of 2)

Notes to Table 14:

- (1) The lower 2 bits indicate the counter number for the G, L, and E counters. Additionally, the Ex counters are only valid for the LONG scan chain PLLs.
- (2) For M and N.
- (3) For G, L, and E.
- (4) Must be 0 for M or N.
- (5) The upper 2 bits determine the width (for example, $00 \times = 9$, $01 \times = 4$, $10 \times = 1$)

Document Revision History

Table 15 lists the revision history for this document.

Table 15. Document Revision History (Part 1 of 2)

Date	Version	Changes
February 2012	6.0	 Added information about nominal count usage in Table 12.
		 Updated the decimal value in Table 12.
August 2010	5.0	Updated for the Quartus II software version 10.0.
		 Added support for Stratix IV devices.
		 Updated screenshots for "MegaWizard Plug-In Manager Page Descriptions" section.
	4.0	 Updated "Features" section.
July 2009		 Updated "General Description" section.
July 2000		 Added "Simulation" section.
		 Added "Checking Design Violations With the Design Assistant" section
		 Added comment for pll_scanclk port.
		 Added support for new port, pllena.

 Table 15. Document Revision History (Part 2 of 2)

Date	Version	Changes
November 2007	3.2	 Updated for the Quartus II software version 7.2, including: Added new user-mode reconfiguration from external ROM.
		Added three new input ports: rom_data_in, write_from_rom, and reset_rom_address
		 Added two new output ports: rom_address_out and write_rom_ena
		 Updated design example format
		 Updated: Figure 5, Figure 6, Figure 7, Figure 17, Figure 18, Figure 19, Figure 20, Figure 21, Figure 22
		 Changed altpll_reconfig to ALTPLL_RECONFIG throughout the document.
March 2007	3.1	Added Cyclone III to list of supported devices.
December 2006	3.0	Updated for Quartus II software version 6.1.
October 2006	2.0	Updated for Quartus II software version 6.0.
April 2005	1.0	Initial release.