# Agilent E8257DS02-S15 Source Modules User Guide

http://www.manuallib.com/agilent/e8257ds02-s15-source-modules-user-guide.html

The E8257DS02, S03, S05, S06, S08, S10, S12, and S15 are Millimeter-wave Source Modules that are manufactured by Oleson Microwave Labs (OML) and is provided as an ordering convenience by Agilent Technologies. This product can be ordered directly from OML. For additional Millimeter-wave Source Modules information go to the Agilent website at http://www.agilent.com/find

ManualLib.com collects and classifies the global product instrunction manuals to help users access anytime and anywhere, helping users make better use of products.

http://www.manuallib.com

# Agilent Technologies E8257DS02 - S15

User's Guide

**Millimeter Source Modules** 

E8257DS02, E8257DS03, E8257DS05, E8257DS06, E8257DS08, E8257DS10, E8257DS12 and E8257DS15



Manufacturing Part Number: E8251-90283 Printed in USA April 2014 Supersede November 2011

 $\ensuremath{\mathbb{C}}$  Copyright Agilent Technologies, Inc. 2005, 2006, 2009, 2011, 2014

## **Warranty Statement**

THE MATERIAL CONTAINED IN THIS DOCUMENT IS PROVIDED "AS IS," AND IS SUBJECT TO BEING CHANGED, WITHOUT NOTICE, IN FUTURE EDITIONS. FURTHER, TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, AGILENT DISCLAIMS ALL WARRANTIES, EITHER EXPRESS OR IMPLIED WITH REGARD TO THIS MANUAL AND ANY INFORMATION CONTAINED HEREIN, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. AGILENT SHALL NOT BE LIABLE FOR ERRORS OR FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE FURNISHING, USE, OR PERFORMANCE OF THIS DOCUMENT OR ANY INFORMATION CONTAINED HEREIN. SHOULD AGILENT AND THE USER HAVE A SEPARATE WRITTEN AGREEMENT WITH WARRANTY TERMS COVERING THE MATERIAL IN THIS DOCUMENT THAT CONFLICT WITH THESE TERMS, THE WARRANTY TERMS IN THE SEPARATE AGREEMENT WILL CONTROL.

## **DFARS/Restricted Rights Notice**

If software is for use in the performance of a U.S. Government prime contract or subcontract, Software is delivered and licensed as "Commercial computer software" as defined in DFAR 252.227-7014 (June 1995), or as a "commercial item" as defined in FAR 2.101(a) or as "Restricted computer software" as defined in FAR 52.227-19 (June 1987) or any equivalent agency regulation or contract clause. Use, duplication or disclosure of Software is subject to Agilent Technologies' standard commercial license terms, and non-DOD Departments and Agencies of the U.S. Government will receive no greater than Restricted Rights as defined in FAR 52.227-19(c)(1-2) (June 1987). U.S. Government users will receive no greater than Limited Rights as defined in FAR 52.227-14 (June 1987) or DFAR 252.227-7015 (b)(2) (November 1995), as applicable in any technical data.

## **Safety Notes**

The following safety notes are used throughout this document. Familiarize yourself with each of these notes and its meaning before performing any of the procedures in this document.

WARNING	Warning denotes a hazard. It calls attention to a procedure which, if not correctly performed or adhered to, could result in injury or loss of life. Do not proceed beyond a warning note until the indicated conditions are fully understood and met.			
CAUTION	Caution denotes a hazard. It calls attention to a procedure that, if not correctly performed or adhered to, could result in damage to or destruction of the instrument. Do not proceed beyond a caution sign until the indicated conditions are fully understood and met.			

## Definitions

- Specifications describe the performance of parameters covered by the product warranty (temperature +20 to +30 °C, unless otherwise noted.)
- Typical describes additional product performance information that is not covered by the product warranty. It is performance beyond specification that 80% of the units exhibit with a 95% confidence level over the temperature range 20 to 30 °C. Typical performance does not include measurement uncertainty.
- *Nominal* values indicate expected performance or describe product performance that is useful in the application of the product, but is not covered by the product warranty.
- Characteristic Performance describes performance parameter that the product is expected to meet before it leaves the factory, but is not verified in the field and is not covered by the product warranty. A characteristic includes the same guard bands as a specification.

iv

## Contents

E8257DS02-S15	
Introduction	2
Description	2
Content list	2
System Setup	3
Performance Specifications	4
Safety and Regulatory Information	6
Introduction	6
Safety Earth Ground	6
Declaration of Conformity.	6
Statement of Compliance	6
Before Applying Power	7
Servicing	8
Connector Care and Cleaning Precautions	8
Electrostatic Discharge Protection	9
Regulatory Information	0
Instrument Markings	0
Battery Collection	1
Electrical Safety Compliance	1
EMI and EMC Compliance	1
Agilent Support, Services, and Assistance	2
Service and Support Options	2
Contacting Agilent	2
Shipping Your Product to Agilent for Service or Repair1	2

## Contents

Contents-2

# E8257DS02-S15

User's Guide E8251-90283

This Manual:http://www.manuallib.com/agilent/e8257ds02-s15-source-modules-user-guide.html

1

## Introduction

The E8257DS02, S03, S05, S06, S08, S10, S12, and S15 are Millimeter-wave Source Modules that are manufactured by Oleson Microwave Labs (OML) and is provided as an ordering convenience by Agilent Technologies. This product can be ordered directly from OML. For additional Millimeter-wave Source Modules information go to the Agilent website at *http://www.agilent.com/find* 

This product is warranted by OML against defective materials and workmanship. Refer to documentation supplied with this product or go to *http://www.omlinc.com* for more information.

**NOTE** A periodic calibration is not required for millimeter-wave modules.

## Description

The millimeter-wave source modules are designed to work with the E8247C, E8257C, E8257D, E8267C or E8267D PSG Series Synthesized Sources.

The following list of adapters are required to connect the PSG RF Output to the millimeter-wave source module RF Input. The adapter is included with the PSG product, but is not included with the millimeter-wave source module. Refer to the following table for required adapters.

#### Table 1 Adapters

Instrument Options	Adapter Description	Agilent Part Number
520	3.5 mm (f) to (f)	5061-5311
532, 540, 550 and 567	2.4 mm (f) to 3.5 mm (f)	1250-2187
1ED	3.5 mm (f) to Type-N (m)	1250-1744

## **Content list**

2

Each source module ordered includes one each of the standard accessories listed below:

- Source Module Interface cable (2 meter)
- RF cable SMA (m) to SMA (m) (1 meter)

## System Setup

- 1. Connect the interface cable (included with this option) from the millimeter-wave source module and to the rear panel on the PSG. Refer to Figure 1.
- Connect the RF cable (included with this option) from the SMA RF Input connector on the millimeter-wave source module to the RF Output connector on the PSG, using the adapter listed in Table 1. Refer to Figure 2.

#### Figure 1 Interface Cable Installation



Source Module Interface Connector

#### Figure 2 RF Cable Installation



## **Performance Specifications**

The following table provides specifications or each of the millimeter source models. Refer to the millimeter source module used for your application. All specification apply over a temperature range of +20 to +30 °C.

 Table 2
 Millimeter Source Model Performance Specifications

ltem <sup>1</sup>	S15	S12	S10	S08	S06	S05	S03	S02
Multipliers	x4	x6	x6	x8	x12	x12	x18	x30
FREQ IN (GHz)	12.5 to 18.7	10.0 to 15.0	12.5 to 18.4	11.2 to 17.5	9.1 to 14.1	11.6 to 18.4	12.2 to 18.1	10.83 to 16.67
FREQ OUT (GHz)	50.0 to 75.0	60.0 to 90.0	75.0 to 110.0	90.0 to 140.0	110.0 to 170.0	140.0 to 220.0	220.0 to 325.0	325 to 500
RF IN					+10 dBm			
RF IN Damage Level				-	+36 dBm			
RF OUT <sup>2</sup> (typical)	+8 dBm	+6 dBm	+5 dBm	—5 dBm	—13 dBm	$-15 \text{ dBm}^3$	–25 dBm <sup>4</sup>	$-27~\mathrm{dBm}^4$
Harmonics & Sub-Harmonics <sup>5</sup> (typical)	≤ –20 dBc							
In-Band Spurious <sup>6</sup> (typical)	$\leq -20~\text{dBc}$ $\leq -15~\text{dBc}$ (in the lower 10% band) $\leq -2$				0 dBc			
RF IN VSWR (typical)	≤2							
RF OUT VSWR (typical)	≤ 1.7	≤ 1.7	≤ 1.7	≤ 1.7	≤ 1.7	≤ 1.7	≤ <b>3</b> .0	≤ <b>3</b> .0
RF IN Port	SMA Female							
Manually Adjustable Attenuator <sup>7</sup>	25 dB minimum n/a							
RF OUT Port <sup>8</sup>	WR-15	WR-12	WR-10	WR-08	WR-06	WR-05	WR-03	WR-02
Power (typical)	Supplied by E82xx Series PSG (+8 Vdc at 1.2 A max, +15 Vdc at 150 mA max)							

1. Specifications subject to change without notice.

2. Not traceable to NIST above 110 GHz.

3. Up to 200 GHz, rolling off at -25 dBm typ. at 220 GHz as measured by OML's calorimeter.

4. Output power estimated due to sensitivity limitation of OML's calorimeter, measured power data not traceable or provided.

5. As related to the desired output frequencies.

6. In-band mixing products. Typically  $\leq -15$  dBc in the lower 10% of WR-15, WR12, or WR10 waveguide band.

7. Available as Option A25. Not available in the E8257DS02 module.

8. RF Output port flange configuration per MIL-F-3922-67B-xx.

#### Table 3Instrument Dimensions

Net Weight	Height <sup>1</sup>	Width	Depth <sup>2</sup>
< 2.0 lb (907 g) <i>nominal</i>	2.8 in (7.11 cm)	4.3 in (10.92 cm)	5.7 in (14.47 cm)

1. Height excludes the adjustable rubber feet length and attenuator adjustment knob.

2. Depth dimension excludes the output waveguide length.

The following OML millimeter-wave source module model part numbers corresponding with the Agilent model part numbers.

Table 4 OML and Agilent Model Numbers

OML Model Number	Agilent Model Number
S15MS-AG	E8257DS15
S12MS-AG	E8257DS12
S10MS-AG	E8257DS10
S08MS-AG	E8257DS08
S06MS-AG	E8257DS06
S05MS-AG	E8257DS05
S03MS-AG	E8257DS03
S02MS-AG	E8257DS02

## Safety and Regulatory Information

#### Introduction

Review this product and related documentation to familiarize yourself with safety markings and instructions before you operate the instrument.

This product has been designed and tested in accordance with accepted industry standards, and has been supplied in a safe condition. The documentation contains information and warnings that must be followed by the user to ensure safe operation and to maintain the product in a safe condition.

#### **Safety Earth Ground**

WARNING	This is a Safety Class I Product (provided with a protective earthing ground incorporated in the power cord). The mains plug shall be only be inserted in a socket outlet provided with a protective earth contact. Any interruption of the protective conductor inside or outside of the product is likely to make the product dangerous. Intentional interruption is prohibited.				
CAUTION	Always use the three prong AC power cord supplied with this product. Failure to ensure adequate earth grounding by not using this cord may cause product damage and the risk of electrical shock.				

#### **Declaration of Conformity**

A copy of the Declaration of Conformity is available upon request, or a copy is available on the Agilent Technologies web site at *http://regulations.corporate.agilent.com/DoC/search.htm* 

#### **Statement of Compliance**

This instrument has been designed and tested in accordance with CAN/CSA 22.2 No. 61010-1-04, UL Std No. 61010-1 (2nd Edition).

## **Before Applying Power**

Verify that the premises electrical supply is within the range of the instrument. The instrument has an autoranging power supply.

WARNING	If this product is not used as specified, the protection provided by the equipment could be impaired. This product must be used in a normal condition (in which all means for protection are intact) only.
CAUTION	The Mains wiring and connectors shall be compatible with the connector used in the premise electrical system. Failure, to ensure adequate earth grounding by not using the correct components may cause product damage, and serious injury.
CAUTION	Always use the three prong AC power cord supplied with this product. Failure to ensure adequate earth grounding by not using this cord may cause product damage and the risk of electrical shock.
CAUTION	This product is designed for use in Installation Category II and Pollution Degree.
CAUTION	Before switching on this instrument, make sure the supply voltage is in the specified range.
CAUTION	Verify that the premise electrical voltage supply is within the range specified on the instrument.
CAUTION	Ventilation Requirements: When installing the instrument in a cabinet, the convection into and out of the instrument must not be restricted. The ambient temperature (outside the cabinet) must be less than the maximum operating temperature of the instrument by 4 °C for every 100 watts dissipated in the cabinet. If the total power dissipated in the cabinet is greater than 800 watts, forced convection must be used.

## Servicing

WARNING	These servicing instructions are for use by qualified personnel only. To avoid electrical shock, do not perform any servicing unless you are qualified to do so.
WARNING	Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended. Discard used batteries according to manufacturer's instructions.
WARNING	For continued protection against fire hazard replace line fuse only with same type and rating. The use of other fuses or material is prohibited.
WARNING	These servicing instructions are for use by qualified personnel only. To avoid electrical shock, do not perform any servicing unless you are qualified to do so.
WARNING	The opening of covers or removal of parts is likely to expose the user to dangerous voltages. Disconnect the instrument from all voltage sources before opening.
WARNING	No operator serviceable parts inside. Refer servicing to qualified personnel. To prevent electrical shock, do not remove covers.
WARNING	The detachable power cord is the instrument disconnecting device. It disconnects the mains circuits from the mains supply before other parts of the instrument. The front panel switch is only a standby switch and is not a LINE switch (disconnecting device).

#### **Connector Care and Cleaning Precautions**

Remove the power cord to the instrument. To clean the connectors use alcohol in a well ventilated area. Allow all residual alcohol moisture to evaporate, and fumes to dissipate prior to energizing the instrument.

WARNING	To prevent electrical shock, disconnect the <b>"Agilent Technologies E8257DS02</b> - <b>S15</b> " from mains electrical supply before cleaning. Use a dry cloth or one slightly dampened with water to clean the external case parts. Do not attempt to clean internally.
WARNING	If flammable cleaning materials are used, the material shall not be stored, or left open in the area of the equipment. Adequate ventilation shall be assured to prevent the combustion of fumes, or vapors.

## **Electrostatic Discharge Protection**

Protection against electrostatic discharge (ESD) is essential while removing assemblies from or connecting cables to the instrument. Static electricity can build up on your body and can easily damage sensitive internal circuit elements when discharged. Static discharges too small to be felt can cause permanent damage. To prevent damage to the instrument:

- always have a grounded, conductive table mat in front of your test equipment.
- always wear a grounded wrist strap with grounding cord, connected to a grounded conductive table
  mat, having a 1 MW resistor in series with it, when handling components and assemblies or when
  making connections.
- *always* wear a heel strap (9300-1126) when working in an area with a conductive floor. If you are uncertain about the conductivity of your floor, wear a heel strap.
- *always* ground yourself before you clean, inspect, or make a connection to a static-sensitive device or test port. You can, for example, grasp the grounded outer shell of the test port or cable connector briefly.
- *always* ground the center conductor of a test cable before making a connection to the analyzer test port or other static-sensitive device. This can be done as follows:
  - 1. Connect a short to one end of the cable to short the center conductor to the outer conductor.
  - 2. While wearing a grounded wrist strap, grasp the outer shell of the cable connector.
  - 3. Connect the other end of the cable to the test port and remove the short from the cable.

#### Figure 3 ESD Protection Setup



## **Regulatory Information**

This section contains information that is required by various government regulatory agencies.

#### **Instrument Markings**



10

User's Guide E8251-90283

#### **Battery Collection**

Do not throw batteries away but collect as small chemical waste, or in accordance with your country's requirements. You may return the battery to Agilent Technologies for disposal. Refer to "Contacting Agilent" on page 12 for assistance.

#### **Electrical Safety Compliance**

#### SAFETY

Complies with European Low Voltage Directive 2006/95/EC

- IEC/EN 61010-1, 2<sup>nd</sup> Edition
- Canada: CSA C22.2 No. 61010-1-04
- USA: UL std no. 61010-1, 2<sup>nd</sup> Edition
- Acoustic statement (European Machinery Directive 2022/42/EC, 1.7.4.2U) Accoustical noise emission LpA<70 dB Operator position Normal operation mode Per ISO 7779

#### **EMI and EMC Compliance**

#### EMC

Complies with European EMC Directive 2004/108/EC

- IEC/EN 61326-1
- CISPR Pub 11 Group 1, class A
- AS/NZS CISPR 11
- ICES/NMB-001 This ISM device complies with Canadian ICES-001. Cet appareil ISM est conforme a la norme NMB du Canada.
- South Korean Class A EMC declaration: This equipment is Class A suitable for professional use and is for use in electromagnetic environments outside of the home.

A 급 기기 (업무용 방송통신기자재)이 기기는 업무용 (A 급) 전자파적합기기로서 판 매자 또는 사용자는 이 점을 주 의하시기 바라 며, 가정외의 지역에서 사용하는 것을 목적으 로 합니다.

### **Agilent Support, Services, and Assistance**

#### **Service and Support Options**

There are many other repair and calibration options available from the Agilent Technologies support organization. These options cover a range of service agreements with varying response times. Contact Agilent for additional information on available service agreements for this product.

#### **Contacting Agilent**

Assistance with test and measurements needs and information or finding a local Agilent office are available on the Web at: http://www.agilent.com/find/assist

If you do not have access to the Internet, contact your field engineer.

**NOTE** In any correspondence or telephone conversation, refer to the Agilent product by its model number and full serial number. With this information, the Agilent representative can determine the warranty status of your unit.

#### Shipping Your Product to Agilent for Service or Repair

# **IMPORTANT** Agilent Technologies reserves the right to reformat or replace the internal hard disk drive in your analyzer as part of its repair. This will erase all user information stored on the hard disk. It is imperative, therefore, that you make a backup copy of your critical test data located on the analyzer's hard disk before shipping it to Agilent for repair.

If you wish to send your instrument to Agilent Technologies for service or repair:

- Include a complete description of the service requested or of the failure and a description of any failed test and any error message.
- Remove and retain the front handles and all rack mount hardware. The analyzer should be sent to Agilent in the same configuration as it was originally shipped.
- · Ship the analyzer using the original or comparable antistatic packaging materials.
- Contact Agilent for instructions on where to ship your analyzer.