Lanier Scanning User Guide

Scanning documents using any of the Lanier copiers requires that you have an account on the pharmacy domain servers. The userid and password that you use to log on to your computer is that same userid and password that you will be required to enter when scanning a document. If you do not have an account, then please contact pharmacy computer support.

Scanning your document.

Perform the following steps.



1) Press the scanner button located on the left of the copier display. (See picture above.) The display will change and look like the following picture.

2) Touch the simulated button called username on the touch screen display. A keyboard should appear on the screen where you can enter your pharmacy userid. Touch the OK button on the upper right portion of the screen after typing.

	-			DigiD	ocFlow	3
0						
		Username				
Login		Password		-		
Refresh						
Settings "						
			System Status	Job List	FEB 12, 10:56AM	,2009

Username		(Cancel	ОК
- 1 2 3 4	0/64 5 6 7	89		
a s d f z x c v	g h j b n m	k l		
Shift Lock Shift	Space			
Text Entry User Text				
	System Statu	Job List	FE	B 12,2009

3) Touch the simulated button called password. A keyboard should appear on the screen where you can enter your pharmacy password. Touch the OK button on the upper right portion of the screen after typing.

4) Touch the simulated button called Login at middle left of the touch screen.





5) Select the type of document you wish to receive. (Recommend Searchable PDF)

6) Select the simulated button Optional File Name. Type in the filename that the scanned document will be created as. Select the Properties button on left side of the touch screen, and select the dpi, color, or photo type of the document to be scanned.



7) Place your document, book, photo on the copier and press the green start button (lower right corner) to begin scanning.

8) When finished select the logout button from the dialog box on the touch screen.

	DigiDocFlow 🤳							
10 C	Searchable PDF							
	Questions							
	Scanning done							
	Do you want to use the metadata again?							
Photo & Text Black and White	Yes No Logout							
300 dpi 1 Sided								
Properties								
	 required field 							
	System Status Job List							

Summary for Lanier scanning.

- 1. Press the scanner button located on the left of the copier display.
- 2. Enter your pharmacy userid and password. Login.
- 3. Select the type of document to create.
- 4. Type in a filename to save the scanned document as.
- 5. Check that the properties for the scan match the document to be scanned.
- 6. Position the document on the copier, and press the start button to begin scanning.
- 7. When done press the logout button.

Retrieving a scanned document

- 1. Open My Computer.
- 2. The document will appear in the S:\ network drive.

😼 My Computer			_	
<u>File E</u> dit <u>V</u> iew F <u>a</u> vorites <u>T</u> ools <u>H</u> elp				1
🕞 Back 🔹 🕥 🕤 🏂 🔎 Search	Polders	🎯 🗙 🍤	•	
Address 😼 My Computer				~
Name	Total Size	Free Space	Туре	
Hard Disk Drives				
SYSTEM (C:)	24.4 GB	15.9 GB	Local Disk	
PAGING SPACE (D:)	4.29 GB	281 MB	Local Disk	
Sers DATA (F:)	113 GB	103 GB	Local Disk	
Devices with Removable Storage				
43 31/2 Floppy (A:)			3½-Inch Floppy Disk	
DVD-RW Drive (G:)			CD Drive	
Network Drives				
😪 user on 'rx5\Staff-data-Parks' (J:)	832 GB	478 GB	478 GB Network Drive	
😪 user on 'rx5\Scan' (S:)	832 GB	478 GB	Network Drive	
7 objects			😼 My Computer	

3. It is recommended that you move your scanned document into your "My Documents" folder or to your desktop. The Scan folder is not meant to be a permanent storage area.

If your computer operating system is not Microsoft Windows, then

- 1. Authenticate to the Pharmacy Domain by your usual method.
- 2. Mount your home directory and at rx5.pharmacy.ohio-state.edu mount the Scan folder.
- 3. Look inside the scanned folder and find your document, then move it to your home folder.
- 4. Drag the Scan folder to your Trash can or use other method to log off.