



新完給 λ·5\/--30mΔ/百和) 新完給 λ·5\/--230mΔ(存由金)

给充电仓充电(未充满):指示灯呈红灯闪烁

绘耳机奈由夫奈浦·指示灯是白灯长亭

 布由仓充港由·长亭

京由会指示打 ・ 京由会由景太兄・ 井会等財早红红色の

給買机充滿由·打灭

产品操作说明 1 平和 方式一: 打开充电仓上盖, 耳机自动开机。 方式二: 用手指长按耳机功能触模键3S, 耳机开机。 方式一: 将耳机放回充电仓, 关上充电仓上盖, 耳机关机。 方式二: 左右耳机开机状态下, 长按耳机功能触模键5S后, 耳机关机。(未连 接蓝牙设备)

步骤二、打开智能设备的蓝牙列表、搜索"联想thinkolus-LP1"并连接(支持

步骤一,打开充电仓上盖,主副互机自动开机并组对:





恢复出厂设置

后 学和



单个耳机开机后未与手机配对状态下,连续单击耳机功能键5次清除配对信息





产品、规格及信息仅供参考,内容亦会随时更新于网页,恕不另行通知。

就本文件附随的产品做如下保证:如产品在您购买日起十二(12)个月

("保修期")内,在正常使用情况下因质量瑕疵发生损坏,能修理的

产品中有害物质名称及含量

产品中有害物质的名称及含量

部件名称 編(Pb) 素(Hg) 編(Cd) / (7hB) / (PBB) / (PB		有害物质							
	部件名称	铅(Pb)	汞(Hg)	镉(Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)		
外壳等小结构件 〇 〇 〇 〇 〇	印刷电路组件	0	0	0	0	0	0		
	外壳等小结构件	0	0	0	0	0	0		

本表格依据S.I/T 11364的规定编制。

-):表示该有害物质在该部件所有均质材料中的含量均在
- GB/T 26572 规定的限量要求以下。 :表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 細空的限量要求
- 表单标记"X"的部件,皆因全球技术发展水平限制而无法实现有害

印刷电路板组件*:包括印刷电路板及其零部件,电子元器件等, 根据产品型号不同,您所购买的产品可能不会含有以上所有部件



标志、标志内的数字代表在正常的使用状态下的产品的 环保使用期限.

本使用手册没有任何形式的担保、立场表达或其他暗示,本使用手册所提到的

免费修理: 经厂家确认无法修理的,免费更换: 修理或更换后的产品,在剩

根据FCC规则第15部分,本设备经过测试,符合B类数字设备的限制。这些 限制旨在提供会理的住宅设施由的有害干扰防护 该设备产生使用并可辐射射 犄能量,如果未按照规定安装和使用该指示可能会对无线电通信造成有害干扰, 。然而,有不能保证在特定安装中不会发生干扰。如果这个设备有对无线电或 电视接收造成有害干扰,可通过转动来确定设备,关闭和打开时,鼓励用户尝 试通过一个或多个以下更多措施,

- 重新定向或重新定位接收天线。
- 増加设备和接收架之间的间距
- 设备连接到与接收器不同的电路上的插座已连接。
- 请咨询经销商或经验主常的无线由/由视技术人员以获得帮助。


此设备符合FCC规则的第15部分。操作受以下两个条件限制条件。 (1) 本裝置不得引起有害干扰。

(2) 本装置必须接受任何接收到的干扰,包括可能导致意外操作的干扰。未

经合规责任方明确批准的变更或修改可能使用用户对设备的操作权限失效。 产品及随附物料的齐备和外观完好不属于保证范围,您应在接收产品时当场检

验并对任何不符提出异议。以上保证是我们就产品做出的全部保证,且仅在中 ECC ID. 248SE-22090002

Lenovo thinkplus LivePods LP1



Manual

Please read all instructions carefully

and retain for future use

User manual X 1 Product schematic description

(1) Don't attempt to disassemble the unit and change any part, except there is operation method mentioned in the manual

not a waterproof product. (3) Disconnect the unit with your BT device and move it to the safe area if the liquid get inside the unit.

(4) Don't assemble or disassemble the unit to avoid electric shock. if there is water on your hands.

(6) Don't place the unit in an electromagnetic interference environment to avoid malfunction.

Packing list





(2) Don't expose the unit to liquid, moisture or humidity, since it is Battery canacity: 30mAh Playing time: About 4 hours (headphone) Charging time: About 1 hours (headphone) Rated input: 5V == 30m A

of the unit in fire as it will result in an explosion.

Charging case specification

Rattery canacity: 230m∆h Charging time: About 1.5 hours Rated input: 5V == 230mA

ransmission distance: ≥10M


LED指示灯状态

BT Version: V5.3

(All technical information is subject to actual performance)

To Charge the case Connect the Type-C cable to the 5V power adaptor, and another end to the charging port of the Charging Case.

Connect the Type-C cable to the 5V power adaptor, and another end to the charging port of the Charging Case.



I FD Indicator Status

 Charge the charging case (not fully charged): The indicator Case LED light will be flash in red.

• The charging case is fully charged: The indicator light will

3 B23t

单百使用)。

■ 触控按键的操作

音乐播放模式 ■■ 左/右耳机操作

> . The headphones are not fully charged: The indicator will Fully charged the headphones: The indicator light is turn

——— 上一曲:三击左耳机(L)功能键

- 音量+: 単击右耳机(R)功能键

- 暂停/播放: 双击任意耳机功能键

Method 1: Open the case, the headphones will turn on automatically. Method 2: Long touch the ME button of the headphones for 3s to turn on the headphones.


2. Power off

Method 1: Put the headphones into the charging case directly and close the case to turn off. Method 2 : Long touch the MF button of the headphones for 5s to

turn off the headphones.(The headphone is not connected to the BT

3.Pairing to the BT device

Step 1: open the upper cover of the charging case, and the main and auxiliary headphones will automatically connected: Step 2: open the BT list of smart devices, search "联想thinkplus-LP1" and Connect (single ear use is supported)



Touch control button operating Music playing mode

Left/Right headphone operating

Last song: Short press the MF button of left headphone 3 times. Next song: Short press the MF button of right Volume -: Short press the MF button of left headphone. Pause/Play: Short press the MF button of one headphone 2 times

Hands free function

Left/ Right headphone operating (incoming call)

Reject: Long press the MF button of any headphone for 2 seconds. Hang up: Short press the MF button of any

Active the voice assistant function (the smart devices support voice assistant function) I eft/ Right headphone operating

Activation: Press and hold the MF button of any — headphone for 2 seconds, then hear "Tone" to release.

When you turn on the headphones, make sure it does not connect to any BT device, and click the MF button 5 times to clear the pairing record, then

Name and content of hazardous substances in products

	Harmful materials							
Part Name	Pb	Hg	Cd	Cr(VI)	PBB	PBDE		
Printed circuit assembly	0	0	0	0	0	0		
Small structural parts such as shell	0	0	0	0	0	0		

- omogeneous materials of the part is in Below the limit
- least one of the homogeneous materials of the part exceeds The limit requirements specified in GB/T 26572. The parts marked with "X" on the form are all harmful due to the

product model, the product you purchased may not contain all the Electronic and electrical products sold in the People

ne logo represents the product under normal use onmental protection use period.

Warranty statement

This user manual does not have any form of guarantee, position expression or other implication. The mentioned products, specifications and information are for reference only, and the ontent will also be updated on the webpage at any time, without Varranty statement:

he product attached to this document is quaranteed as follows: If he product is twelve (12) months from the date of purchase ("Warranty Period"), under normal conditions of use due to quality

that it cannot be repaired, free replacement; repaired or replaced roduct, Continue to enjoy the warranty during the remaining arranty period (the shortest not less than 30 days). Purchase date

余保修期(最短不少于30天)内继续宣有保修。购买日以销售发票日期为准:

如申请保修,请先致电产品服务热线,并按我们指示的方式执行。由请保修时

如无法确定购买日,则保修期自产品生产日期起按十三(13)个月计算。

3.因误用、滥用或不适当的运输、使用、维护或保管而导致的故障或损坏;

4.因不可抗力(如地震、战争、火灾等)或意外导致的故障或损坏;

0.产品正常使用过程中发生的老化、脱色、磨损、破裂和其他损耗。

国大陆地区境内适用。本文件的任何内容均不影响根据法律规定不能排除或限

Lenovo", "thinkplus" 是联想集团所属企业的商标,提及的其他公

11 加产品原有标识标签被更改或损毁。本保证将失效。

您需要提供准确、完整和清晰填写的有效销售发票。

1) 上保证不适田干下列情况。

5 拉锚、塔扣因受力过大而损坏:

6.因承载过重造成的脱线或撕裂;

7 任何因尖锐物体造成的损坏

8. 有烧损或水浸渍象的产品:

Q 网络白垢水导致的垛坯.

到的消费多权利

服务执线, 400-812-0102

售后邮箱: frank@szevsan.cn

司,产品和服务名称可能是其他公司的商标。

版权所有 © 2022 联想集团所属企业和其许可方保留所有权利。

2.涂改保修卡、产品编码与产品本体不符;

1 紹讨三包有效期的:

- If you apply for a warranty, please call the product service hotline first and execute it in the manner instructed by us. When applying for warranty, you need to provide an accurate uarantee does not apply to the following situations:
 The validity period of the three packs is exceeded:
- . Alteration of the warranty card and product code does not match . Causes caused by misuse, abuse or improper transportation, use,
- naintenance or storageimpaired or damaged; . Failure or damage caused by force majeure (such as earthquake, /ar, fire, etc.) or accident bad:
- The zipper and buckle are damaged due to excessive force; Disconnection or tearing caused by excessive load; . Any damage caused by sharp objects:
- Products with signs of burning or water immersion . Damage caused by unauthorized disassembly: . Aging, discoloration, abrasion, rupture and other losses occurred
- iring normal use of the product I If the original identification label of the product is changed or lamaged, this guarantee will become invalid. The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee. You should Check on the spot
- The above guarantees are all guarantees we make regarding the lothing in this document affects consumer rights that cannot be

After-sales service Emal: frank@szevsan.cn

Service supervision hotline: 400-812-0102

"Lenovo" "thinkolus" belongs to affiliated enterprises of Lenovo services'name may be a trademark of affiliated enterprises of Lenovo Group or another company.

Copyright © 2022 Lenovo Group and its licensors. All rights reserved

This equipment has been tested and found to comply with the limits or a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is r juarantee that interference will not occur in a particular installation If this equipment does cause harmful interference to radio or tele on reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference

 Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for

help. This device complies with part 15 of the FCC Rules. Operation is subject to the following twoconditions This device may not cause harmful interference, and

2) this device must accept any interference received, including terference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible fo compliance could void the user's authority to operate the FCC ID: 2A8SE-22090002