



# funxim Z6 Magsafe Foldable Charging Station Instruction Manual

[Home](#) » [funxim](#) » funxim Z6 Magsafe Foldable Charging Station Instruction Manual 

## Contents


- [1 funxim Z6 Magsafe Foldable Charging Station](#)
- [2 Product Description](#)
- [3 Method of use](#)
- [4 Safety Notice](#)
- [5 Frequently Asked Questions](#)
- [6 Documents / Resources](#)

# Funxim

## funxim Z6 Magsafe Foldable Charging Station



## Product Description



**Name:** Foldable charging station  
 Conversion rate < 80%  
**Input :** DC 5V/2A DC9V/2A&above  
**Output:** 15W Max  
**Watch output:** 2.5W  
**Size :** 72(L)x72(W)x19.5(H)mm

### Method of use

1. Put the Phone8 or above model or MagSafe protective case close to the magnetic absorption charging of the product The magnetic attraction is fixed on the product and automatically aligned with the charging position. The phone is in charge state.
2. Place the mobile phone with MagSafe wireless charging function close to the magnetic charging area of the product The magnetic mutual attraction is fixed to the product, automatically aligned with the charging position, and the mobile phone enters the charging state.
3. Place the watch in the charging area of the watch, automatically aim at the charging at position, and the watch enters the charging stateState.
4. Place the headset in the charging area of the headset of your mobile phone, automatically aim charging position, and the headset enters the charging state
5. Devices that support the Qi protocol will be aligned to the charging area and the device will be powered on.
6. Remove the device and restore the product to standby.

### Safety Notice

1. Do not pull the power cord hard to avoid breaking or falling off
2. Do not disassemble or throw it into or water to avoid short circuit leakage.
3. Do not use in severe high temperature, humidity or corrosive environment to avoid leakage of damaged circuit

## Frequently Asked Questions

1. Charging is slower than the mobile phone itself or the external receiving coil allows the wireless charging current to vary in size, or the application runs at a higher power consumption when the mobile phone is charging. It is recommended to reduce or close the application.
2. The mobile phone is charging intermittently and the charging current is insufficient.  
Use a full power charging head (adapter) of 9V/2A or above QC2.0.
3. Charging Fever  
It is normal for the receiving coil or launching plate to heat up during wireless charging. It is recommended to adjust the charging position.
4. Charger does not work  
Do not place metal objects or magnetic cards in the charging area. If the product overheats and does not work, remove the phone to cool down and try charging again.
5. Your phone or watch won't charge  
If the receiving coil of the mobile phone or watch is faulty or the charging position is inaccurate, it is recommended to replace the receiving coil or repair it.  
FCC Requirement changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules.

### Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.
3. **Class Note:** This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:- Reorient or relocate the receiving antenna.- Increase the separation between the equipment and receiver. – Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. – Consult the dealer or An experienced radio/TV technician for help.
4. FCC 20cm Statement This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 between the radiator & your body, This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

## Documents / Resources



[funxim Z6 Magsafe Foldable Charging Station](#) [pdf] Instruction Manual  
2AVJR-Z6, 2AVJRZ6, z6, Z6 Magsafe Foldable Charging Station, Z6, Magsafe Foldable Charging Station, Foldable Charging Station, Charging Station

