

GRAND TETON



ASSEMBLY INSTRUCTIONS

ITEM#: A102010902/A102010903/A102010904

SKU#: 810545411/810545412/810545413

GRAND TETON 10X12 HARDTOP METAL GAZEBO

Need help? We are here for you! 1(866)578-6569 24/7 • Toll Free

GENERAL BEST PRACTICES FOR ASSEMBLY:

- Please read and understand this entire manual before attempting to assemble or install the product.
 - Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.
 - The assembled gazebo should be located at least 6 feet from any obstruction such as fence, garage, house, overhanging branches, laundry lines or electrical wires.
 - Some parts may contain sharp edges. Wear protective gloves if necessary, during assembly.
 - This unit is heavy. For safety, do not assemble this item alone. Four people are recommended for safe assembly.
 - Check all nuts and bolts periodically for tightness and, when required, tighten them again.
 - Pay attention to the parts orientation
-
-

WARNINGS:

- Install the gazebo on level ground. Stakes are provided to secure the gazebo to the ground.
 - Do not assemble the gazebo on sandy, muddy or loose soil, as stakes do not have enough anchorage in these types of soil.
 - If you wish to secure the gazebo to a wood deck or concrete surface, use anchors suited to these surfaces.
 - Snow must be cleared off regularly during snowy days. Remove the snow at the roof top when it is thicker than 2 inches. In order to avoid damage, use a plastic snow rake to remove excessive snow and ice buildup from roof and keep away from falling debris.
 - Do not leave the gazebo where there is a risk of high wind, as possible damage will occur to the structure.
 - Any assembly or maintenance of the product must be carried out by adults only.
 - Keep all flame and heat sources away from the tent fabric. This tent is made with fabric that meets CPAI-84 specifications for flame resistance. It is not fire proof. The fabric will burn if in continuous contact with any flame source.
-
-

WARRANTY:

WHAT IS COVERED ?


The limited warranty is extended to the original purchaser and applies to material and manufacturer's defect provided the item is maintained with care and used only for personal, residential purposes.

Warranty: 1 Year



















MAINTENANCE:

















- Steel components for this gazebo are treated with rust inhibiting paint that protects it from rusting. However, due to the nature of steel, surface oxidation (rusting) will occur if these protective coatings are scratched. This is not a defect and thus not covered by the warranty.
- To minimize this condition, it is recommended to use care when assembling and handling the product to prevent scratching the paint. Should any scratching or damage occur, it is recommended to cover the scratch immediately with rust inhibiting paint (not included).
- Surface rust can also be easily removed with a very light application of regular cooking oil or WD-40. If surface oxidation (rusting) occurs and if no measure is taken to prevent this, the oxidation may start dripping onto deck or patio and caused damaging stains, which may be difficult to remove. This can be prevented if the above-mentioned measures are taken to keep the product from oxidizing.
- Do not use bleach, acid, or other abrasive cleaners on the roof or frame parts.
- Keep instruction manual for future reference.
- Keep the original packaging to store the gazebo.
- Periodically check and ensure that all bolts are well-tighten during use









EXPLODED DRAWING








PARTS LIST

Label	Part Number	Description	Qty	Part Image
A	P000200557	Post	4	
B	P006100206	Base cover	4	
C	P000100405	Base plate	4	
D	P000501514	Connector for slant beam	4	
E	P000401082	Short screen 1	2	
F	P000401083	Short screen 2	2	
G	P000401080	Long screen 1	2	
J	P000401081	Long screen 2	2	
K	P005700789	Short netting tube	4	
L	P005700787	Long netting tube	4	
M	P000501515	Connector for middle beam	4	
N	P000500239	Big top connector	4	
P	P000500238	Big roof frame short side	2	
Q	P000500237	Big roof frame long side	2	
R	P000600327	Slanting beam	4	
S	P000600355	Middle beam	4	
T	P000501541	Small connector for small roof	1	
U	P000600388	Slant beam for small roof	4	

V	P005800001	Hook	1	
W	P000600523	Small roof top beam(short side)	2	
X	P000600537	Small roof top beam(long side)	2	
Y	P000700889	Small roof cover 1	4	
AA	P000700891	Small roof middle cover	2	
AB	P000700890	Small roof cover 2	4	
AC	P000800320	Small roof sloping beam cover plate	4	
AD	P000700888	Small top cover	1	
AE	P000600577	Big roof short beam 1	4	
AF	P000600713	Big roof left lower beam(short side)	2	
AG	P000600744	Big roof long beam 1	4	
AJ	P000601306	Big roof left lower beam(long side)	2	
AK	P000600715	Big roof right lower beam(short side)	2	
AL	P000601307	Big roof right lower beam(long side)	2	
AM	P000700892	Big roof middle cover 1	2	
AN	P000700893	Big roof middle cover 2	4	




AP	P000700894	Big roof middle cover 3	4	
AQ	P000700895	Big roof middle small cover (left)	4	
AR	P000700896	Big roof middle small cover (right)	4	
AS	P000700897	Big roof left cover	4	
AT	P000700898	Big roof right cover	4	
AU	P000800321	Big roof sloping beam cover plate	4	
AV	P001300120	Curtain	1	
AW	P001200245	Mosquito Netting	1	

HARDWARE LIST

Label	Part Number	Description	Qty	Add	Part Image
H1	H100010047	Bolt M6*20	246	13	
H2	H100010046	Bolt M6*40	12	1	
HR	P005100264	Ring	104	6	
HS	H070010003	Stake Φ8*180	8	0	
HW1	H090010017	Wrench M6	2	0	


HELPFUL HINTS

- Tools needed and not included:
- How many people needed for the installation work
- Estimate assemble time: 150-180 minutes





Provided in hardware pack

How many people needed for the installation work



STEP 1




Attach the Base plate(C) and Base cover(B) to the Post(A) by Bolt(H1), then attach Connector for cant beam(D) to the upper Post(A), tight them by Wrench(HW1)

Assembled View:




STEP 2





Insert the screen(G/E) to screen(J/F),fixed with bolt(H1). Then attached netting tube(L/K)and Connector for middle beam(M) with bolt(H1) to screen(E/F/G/J),tighten with wrench(HW1).

Assembled View:




STEP 3




Attached the assembled short screen(E/F) to the post (A) with bolt(H1), tighten with wrench(HW1).

Assembled View:




STEP 4








Attached the assembled long screen(G/J) to the post (A) with bolt(H1), tighten with wrench(HW1).

Assembled View:




STEP 5




Assemble the Big roof frame long side(Q), Big roof frame short side(P) and Big top connector(N) by Bolt(H1),tighten with wrench(HW1).

Assembled View:



STEP 6









Assemble the Slanting beam(R), Connector for slant beam(D) and Big top connector(N) by Bolt(H1), tighten with wrench(HW1).

Assembled View:



STEP 7








Attached the Middle beam(S) to Connector for middle beam(M) on Big roof frame (P/Q) with bolt(H1), tighten with wrench(HW1).

Assembled View:



STEP 8




Attach Small roof connection tube(T) to Slant beam for small roof (U) by Bolt(H1) and Wrench(HW1), then tight up the Hook(V) to Small roof connection tube(T).

Assembled View:



STEP 9





Assemble the small roof top beam(W/X) to Slant beam for small roof(U) by Bolt(H1) and Wrench(HW1), then locked them to the Big top connector(N) by Bolt(H1) and Wrench(HW1).

Assembled View:



STEP 10








Refer to upper image to place the Cover(Y/AA/AB) to the correct location, then locked them by Bolt(H1) and Wrench(HW1)

Assembled View:




STEP 11



Attached Small roof sloping beam cover plate(AC) to samll roof with bolt(H2), tighten with wrench(HW1).

Assembled View:



STEP 12





1x

AD




2x

H1








Attached Small top cover(AD) to samll roof with bolt(H1), tighten with wrench(HW1).

Assembled View:




STEP 13







Attach Big roof short beam1(AE), Big roof long beam 1(AG) to Slanting beam(R) and Middle Beam(S) with Bolt(H1), tighten with wrench(HW1).

Assembled View:



STEP 14




Attach Big roof left lower beam(AF/AJ) and Big roof right lower beam(AK/AL) to Slanting beam(R) and Middle Beam(S) with Bolt(H1), tighten with wrench(HW1).


Assembled View:








STEP 15



Put Big roof middle cover 1 (M) to the middle location of long side like right image



STEP 16








Put the Big roof middle cover 2 (AN) and Big roof middle cover 3 (AP) beside the Big roof middle cover 1 (AM) at the long side, then put the Big roof middle cover 2 (AN) and Big roof middle cover 3 (AP) at the short side, locked them by Bolt(H1) and Wrench(HW1)

Assembled View:



STEP 17










Put the Big roof middle small cover (AQ,AR) beside the Big roof middle cover 2(AN) and Big roof middle cover 3(AP) ,lock them by Bolt(H1) and Wrench(HW1)

Assembled View:



STEP 18




Put the Big roof left cover(AS) and Big roof right cover(AT) beside the Big roof middle small cover (AQ/AR), lock them by Bolt(H1) and Wrench(HW1)

Assembled View:



STEP 19








Attach Big roof sloping beam cover plate(AU) to the Big top by Bolt(H2) and Wrench(HW1)


Assembled View:



STEP 20




Please do the matching of zippers for different panels as showing the picture




Hang the Curtain (AV) on the netting tube (K/L) with Ring(HR)

Assembled View:



STEP 21






Please do the matching of zippers for different panels as showing the picture

Hang the Mosquito Netting (AW) on the netting tube (K/L) with Ring (HR)

Assembled View:



STEP 22



Pulling UP the Base Cover(B), the fixed the Gazebo to the ground by Stake(HS) and Base Plate(C)

Assembled View:

