

TECHNICAL BULLETIN

Logix 3000MD Series Digital Positioner



Experience In Motion



Superior Performance and Reliability

Introducing the Flowserve Logix[™] 3000MD Series Digital Positioner

The Flowserve [®] Logix[™] 3000MD series high-performance digital positioners utilize state-of-the-art piezo technology to provide superior performance and reliability. This is accomplished through the use of a powerful 32-bit microprocessor and a proprietary two-stage electronic relay (patent pending). Among the Logix 3000MD series more attractive features are the on-board QUICK-CAL[™] button, DIP switches, Jog buttons, and variable gain selector. These features allow the user to complete setup and calibration of either diaphragm or piston operated valves in a couple of minutes, without the need of additional handheld devices or software.

The Logix 3000MD series positioners offer valve status updates at a glance using the highly visible LEDs. Users can easily determine if a valve or actuator is functioning properly, and quickly diagnose any problems using the smart LED blink codes. This means that maintenance personnel can provide a visual check of the valve status without having to remove the cover or connect a HART handheld device or maintenance PC/laptop.

Predictive diagnostics is available using the ValveSight software available through FDT/DTM technology. ValveSight is a diagnostic solution for control valves that can be seamlessly integrated into most host control and/or plant asset management systems. The power of ValveSight is in the intelligent diagnostic engine which is constantly monitoring the valve, actuator, positioner and control signal for patterns of behavior that may indicate a problem and provides actional advice proactively.

Inside the Logix 3200MD

Figure 1 – Logix 3200MD Controls





The Logix 3000MD Series Digital Positioner - How It Works

Logix 3000MD Positioner Overview

Figure 1: System Positioning Algorithm for Logix 3400MDDigital Positioners



TUNING

Unlike other positioners that have only one set gains to set the response of the positioner, the Logix 3200MD positioner uses a multi-variable variable gain tuning algorithm. This allows the positioner to make large step changes with minimal overshoot, while achieving the resolution to respond to very small step changes.

The Auto Tune procedure cycles the actuator to produce a measured response and selects those gain values that provide appropriate actuator performance. The Auto Tune function includes a gain modifier selector that can be used to increase or decrease the calculated gain in order to achieve optimal performance.

By setting the Auto Tune on/off DIP switch, the tuning mode can be changed from auto to manual. The Logix 3000MD Series positioners provide several preset gain settings with a locally adjustable gain set selector directly from the user interface on the positioner. If custom settings are desired, tuning sets can be modified with a handheld or ValveSight, to accomodate a wide range of actuator sizes and types.



The Logix 3400MD for Foundation Fieldbus Applications

Complete local configuration, on any valve/actuator and local.

FF Simulate - Run a control strategy without process

FF Write Protect - Locks out unauthorized writes to NVRAM

So status and alert and messages displayed locally via there easy-to-read LEDs

FOUNDATION Fieldbus made easy.

(In OOS) Calibrate stroke and adjust tuning without entering the Transducer Block —Updates the Block when complete.

Logix 3400MD Features	
RFI/EMI Immunity	\checkmark
FISCO Compliant, User Interface	\checkmark
Polarity Insensitive UI (Potted UI)	\checkmark
AO Block (30mS)	\checkmark
PID Block (6 PID Equations) (90mS)	\checkmark
2 DI Block (20mS)	\checkmark
1 DO Block (30mS)	\checkmark
1 IS Block (50mS)	\checkmark
1 OS Block (50mS)	\checkmark
LAS (Link Master Device)	\checkmark
Auto Tune (Positioner Performance)	\checkmark
High Friction Stability	\checkmark
FF Code Download	\checkmark
Flash Ram (Local Positioner Embedded Code Upgrade)	\checkmark
Local Valve Signature Storage	\checkmark
Local Calibration and Setup (While in OOS)	\checkmark
24/7 Local Fault Monitoring	\checkmark
Local Adjustable Gain	\checkmark
Wizard/Method for On-line Commissioning	\checkmark

Logix 3400MD Features	
Local Jog Buttons to Adjust 100% Command Position (While in OOS)	~
Linkable Position feedback (AO Read Back)	~
Four Response Curves (Linear, =%, QO, and Custom) Locally Activated, or Through FF	~
Multiple View Objects in Transducer Block	~
Honeywell PKS Partner with FDM	~
Methods Setup Wizard	~
DTM Available	~
Yokogawa VIP Partner & PRM supported	~
Honeywell PKS Advantage Partner	\diamond



Flowserve is a Honeywell Partner, with Flowserve DTM support pending in the ExperionDCS Field Device Manager. Please contact your Honeywell representative for details.





The Logix 3200MD for HART Applications

Complete local configuration, just like the Logix 3400MD, but HART protocol

- Local status and alert messages
- Tuning (Auto Tune function and manual adjustment)
- Jog buttons to manually adjust 100% position
- Easy-to-install 4-20 mA analog feedback card option



Simple plug-in AO card, automatically zero and spans position feedback during Quick Cal

Logix 3200MD Features	
RFI/EMI Immunity	~
Auto Tune (Positioner Performance)	\checkmark
High Friction Stability Tuning	\checkmark
Integral 4-20 mA Feedback Option	\checkmark
Flash RAM (Local Positioner Embedded Code Upgrade)	~
Local Valve Signature Storage	~
Local Calibration and Setup	~
24/7 Local Fault Monitoring	~
Local Adjustable Gain	~
Three Response Curves (Linear, =% and custom)	\checkmark
Local Jog Buttons to Adjust 100% Command Position	\checkmark
Valve Signature Diag. "Valve Analysis" AMS SnapOn® Application	~
AMS Device Manager	\checkmark
DTM Available	\checkmark
Yokogawa VIP Partner	\checkmark
Honeywell PKS Partner with Honeywell HART FDM	~



ValveSight Dashboard for Logix 3200MD or 3400MD Advanced DTM and Pro diagnostics



The Logix 3200MD can be set up with 10 VDC milliamp current supply current and 45 psi (min.) air supply on any

Calibration, configuration and tuning parameters from the local interface will be automatically updated in the HART

registers on the Logix 3200MD. Local setup and calibration

that does not require a link to a host controller, PC or hand-

held device, and local validation that setup is correct make

With the Logix 3200MD, the local interface shown to the

right can be used to set up the unit in seconds through the

any HART[™] installation easy and straightforward.

valve/actuator platform.

following steps:



The Logix 3000MD Series Positioners – no software or handheld device required... easy as 1, 2, 3



With the Logix 3400MD, function blocks are no longer required to set up, configure and perform a simple stroke calibration. The 3400MD can be set up with 9-32 VDC supply and 45 psi (min.) air supply on any valve/actuator platform.

Calibration, configuration and tuning parameters from the local interface will be automatically updated in the Transducer Block on the Logix 3400MD. Local setup and calibration that does not require a link to a host controller, PC or hand-held device, as well as local validation that setup is correct, make any FOUNDATION Fieldbus[™] installation easy and straightforward.

When the 3400MD is in OOS (Out Of Service mode), the local interface shown to the right is accessible and setup can be carried out through the following steps:

Common Configuration Steps

- 1. Make sure the mechanical linkage, air tubing and actuator mounting are correct.
- 2. Set the configuration switches to the desired operation of the valve/actuator.

3. Set the quick calibration switch to Jog or Auto. In Jog, the 100% position can be manually adjusted using the yellow up and down buttons after Re-Cal is pressed. In Auto, the positioner finds the 100% position and calibration is complete. LED blink codes will guide the user through the process. Four green blinks (GGGG) or (GGGY) at the end of the sequence confirm that the calibration was successful.

4. If needed, the GAIN switch located to the right of the jog buttons will speed up or slow down the positioner's response to command changes. With the Auto Tune configuration switch set to "On", the positioner's algorithm will select a gain with no over-shoot. The 'E" position of the rotary GAIN dial indicates "neutral" with respect to gain adjustment. Turning clockwise from E to H and will speed up the response. Tuning counter-clockwise from E will slow it down, with A being the slowest response.





Time is Money

Shorter commissioning time gets you up and running, making money faster



3000MD Series Facts

The local interface in the 3000MD series positioners and the two way communication capability allows the user to quickly commission loops.

3400

- Three versions: Basic, Advanced (Advanced includes pressure sensors), and Pro (Pro includes pressure sensors and full featured valve diagnostics)
- ITK CFF 4.6, 5.0
- DD available at www.fieldbus.org or www.flowserve.com
- Stores a valve signature onboard in NVRAM
- Linkable Position Feedback as part of the AO Function block.
- Contains: A0, PID, 2-DI, D0, OS, IS function blocks.
- Onboard temperature sensor to measure local positioner ambient
- Stroke speed limiter (configurable in transducer block)
- Stainless steel version available
- DTM Available

3200

- Three versions: Basic, Advanced (Advanced includes pressures), Pro (Pro includes pressure sensors and full featured valve diagnostics)
- HART Command 1, 3, 9, 33 & 48
- · Burst Mode available to continuously transmit
 - · Position command analog loop current
 - Final value of command after characterization
 - Supply pressure (advanced), Temperature (basic)
 - · Stem position in percent
- Onboard temperature sensor to measure local positioner ambient
- Stroke speed limiter (configurable through HART)
- Stainless steel version available
- Enhanced Device Description for advanced signature diagnostics
 - · Step test, friction test, HRL, data logger
- DTM Available



There's a Flowserve Expert Inside - ValveSight FDT/DTM Technology

FLOWSERVE'S VALVESIGHT DTM SOFTWARE HELPS MANAGE FIELD DEVICES BY COMBINING THE FEATURES OF FIELD NETWORK HARDWARE AND THE HART (3200MD) OR FOUNDATION FIELDBUS (3400MD) COMMUNICATION PROTOCOLS USING FDT/DTM TECHNOLOGY WITH THE LOGIX 3000MD SERIES POSITIONERS. VALVESIGHT IS A COMPLETE SOFTWARE PACKAGE, FEATURING A UNIQUE AND EASY TO UNDERSTAND HEALTH STATUS OF THE DEVICE THAT SHOWS NOT ONLY PROBLEMS, BUT THE MAGNITUDE OF DEVELOPING PROBLEMS AS WELL. VALVESIGHT ALSO HAS CONFIGURATION AND CALIBRATION SCREENS TO FULLY SUPPORT THE LOGIX 3000MD POSITIONER FAMILY. ADDITIONALLY, THE USER CAN ACCESS CUSTOMIZED REPORTS FOR ALL CONFIGURATION, CALIBRATION AND EVENT DATA. FLOWSERVE'S VALVESIGHT DTM OPENS THE 'WINDOW' TO THE DEVICE AND ALLOWS IMMEDIATE VIEWS WITH LIVE FEEDBACK ON ALL ACTIVE DEVICE SENSORS INCLUDING VALVE STEM POSITION, CONTROL SIGNAL, FRICTION, RESPONSE TIME AND OTHER IMPORTANT SYSTEM METRICS.

ValveSight DTM software enables communication between the software and field device networks using the HART or FF protocol and provides access to the 24/7 diagnostic information from field devices. Using FDT/DTM technology maintenance personnel can access any Logix 3000MD series positioner on the network from a single workstation. Additionally, the software has capability to store configuration and calibration history and view event logs for each digital positioner accessible through the network.

DIAGNOSTIC ENGINE

Users can now obtain a new level of detailed real time diagnostic information with ValveSight DTM software. ValveSight features an "Expert Inside' performing real time on-line diagnostics 24 hours a day, 7 days a week. The diagnostic assessment of the 'expert inside' is instantly displayed on the local interface and through the ValveSight DTM software. The 'health bars' in the Dashboard view instantly indicate any developing issues and quickly direct the user to the implications and solutions for each problem. The system automatically prioritizes alarms to direct the user to the root cause.

CONFIGURATION MANAGEMENT

ValveSight DTM software also allows the user to easily upload a configuration from the positioner. This means that a new replacement positioner can be identically configured with the simple click of a mouse once the correct configuration has been identified. ValveSight enables users to edit individual configurations and print a positioner configuration report.

21-POINT CHARACTERIZATION CURVE

With ValveSight DTM software, the user can adjust a 21-point characterization curve to change the response of the positioner in order to meet the process requirements. The output of each control point is independent, allowing the user to create a custom curve with very high resolution. This customized curve can be saved in the memory of the Logix 3000MD positioners, and either activated or overridden with a simple on-board selector switch.

SIGNATURES

The Logix 3000MD positioners are designed to assure that data is easily gathered, stored and compared to historical valve data so the user can determine the performance of critical valves.

With ValveSight DTM software a user-defined signature ramp or step response test can be generated with a Logix 3000MD positioner. Signatures can be saved and cataloged (and later retrieved) for comparison with a more recent signature.

A special partial stroke signature function wil automatically test the valve/actuator and give a pass/fail indication.



POSITIONER PERFORMANCE

Static performance and accuracy measures such as hysteresis, deadband, linearity, and repeatability can be obtained with the Logix 3000MD positioners. These values can be graphically depicted, stored and later retrieved for comparative analysis.



Logix 3000MD Series Features List for ValveSight DTM

Image: status in the			VALVESIGHT DTM		LOGIX 3200MD POSITIONERS		SITIONERS	LOGIX 3400MD POSITION		SITIONERS
Mail All-Alarm Annunciator Image: Mail of the			ValveSight Basic	ValveSight Advanced	Logix 3200MD	Logix 3210MD	Logix 3220MD	Logix 3400MD	Logix 3410MD	Logix 3420MD
Image: State of the s	/IEW	Dashboard	✓ ₁	~	✓ _{1,3}	✓ ₁	\checkmark	✓ _{1,3}	✓ ₁	\checkmark
Image: Strate Control ·	OVER	All-Alarm Annunciator	\checkmark	~	✓ _{2,3}	✓ ₂	\checkmark	✓ _{2,3}	✓ ₂	\checkmark
Position Cutoff ·		Configuration Management	\checkmark	√	√	\checkmark	\checkmark	~	\checkmark	~
Soft Limits · <th< td=""><td></td><td>Local Interface Control</td><td>\checkmark</td><td>✓</td><td>\checkmark</td><td>~</td><td>\checkmark</td><td>\checkmark</td><td>\checkmark</td><td>\checkmark</td></th<>		Local Interface Control	\checkmark	✓	\checkmark	~	\checkmark	\checkmark	\checkmark	\checkmark
Command Deviation Settings · <t t=""></t> <t t=""></t> <t t=""></t> >		Position Cutoff	\checkmark	✓	~	~	~	\checkmark	\checkmark	~
Command Deviation Settings · <t t=""></t> <t t=""></t> <t t=""></t> >	TION	Soft Limits	~	 ✓ 	~	~	~	\checkmark	\checkmark	~
Command Deviation Settings · <t t=""></t> <t t=""></t> <t t=""></t> >	GURA	Custom Stroke Characterization	~	 ✓ 	~	~	~	\checkmark	\checkmark	~
Command Deviation Settings · <t t=""></t> <t t=""></t> <t t=""></t> >	CONFI	Counters and Travel Settings	~	✓	~	~	~	\checkmark	\checkmark	\checkmark
All-Variable Editor ·	0		\checkmark	~	\checkmark	~	\checkmark	\checkmark	\checkmark	\checkmark
All-Variable Editor ✓		Custom Units of Measure	\checkmark	~	√_ <u>_</u>	~	\checkmark	√_ <u>_</u>	\checkmark	\checkmark
Analog Input Calibration · <td></td> <td>All-Variable Editor</td> <td>~</td> <td>✓</td> <td></td> <td>~</td> <td>\checkmark</td> <td></td> <td>\checkmark</td> <td>~</td>		All-Variable Editor	~	✓		~	\checkmark		\checkmark	~
Pressure and Friction Calibration ·	_	Analog Output Calibration	~	 ✓ 	~	~	~			
Pressure and Friction Calibration ·	ATION	Analog Input Calibration	~	 ✓ 	~	~	~			
Pressure and Friction Calibration ·	ALIBR	Stroke Calibration	\checkmark	✓	~	~	~	~	\checkmark	~
Normalized biology Ramp Test · </td <td>Ö</td> <td>Pressure and Friction Calibration</td> <td>\checkmark</td> <td>✓</td> <td></td> <td>√₂</td> <td>~</td> <td></td> <td>√₂</td> <td>✓</td>	Ö	Pressure and Friction Calibration	\checkmark	✓		√ ₂	~		√ ₂	✓
Step Test ·	(0	Ramp Test	\checkmark	✓	√ ₃		~	√ ₃		✓
Data Logger ✓ <th< td=""><td>LINE</td><td>Step Test</td><td>\checkmark</td><td>~</td><td></td><td>~</td><td>~</td><td></td><td>\checkmark</td><td>~</td></th<>	LINE	Step Test	\checkmark	~		~	~		\checkmark	~
Data Logger ✓ <th< td=""><td>OFF-I IAGNC</td><td>HDRL Test</td><td></td><td>~</td><td></td><td>√</td><td>\checkmark</td><td></td><td>~</td><td>✓</td></th<>	OFF-I IAGNC	HDRL Test		~		√	\checkmark		~	✓
Supply Pressure ✓		Data Logger		✓	✓ ₃	~	~			
Friction ✓ ✓ ✓ ✓ ✓ ✓ Actuation Ratio ✓ ✓ ✓ ✓ ✓ ✓ Pneumatic Leak ✓ ✓ ✓ ✓ ✓ ✓ Long-Term Trends ✓ ✓ ✓ ✓ ✓ ✓ Partial Stroke Test ✓ ✓ ✓ ✓ ✓ ✓ Valve Health View ✓ ✓ ✓ ✓ ✓ ✓ Positioner Health View ✓ ✓ ✓ ✓ ✓ ✓ Actuator Health View ✓ ✓ ✓ ✓ ✓ ✓ ✓ Notrol Health View ✓ ✓ ✓ ✓ ✓ ✓ ✓ Image: Store of Do Image: Store of Do Image: Store of Do ✓ ✓ ✓ ✓ Image: Store of Do Image: Store of Do Image: Store of Do Image: Store of Do ✓ ✓ ✓ Image: Store of Do Image: Store of Do Image: Store of Do Image: Store of Do ✓ ✓ ✓ ✓		Supply Pressure	~	~		~	~		~	✓
Signature Image: state of the state o		Friction		~			~			
Positioner Health View ✓ ✓ ✓ ✓ Actuator Health View ✓ ✓ ✓ ✓ Control Health View ✓ ✓ ✓ ✓ A0 ✓ ✓ ✓ ✓ PID ✓ ✓ ✓ ✓ D0 ✓ ✓ ✓ ✓ D1 ✓ ✓ ✓ ✓ OS ✓ ✓ ✓ ✓	ŝ	Actuation Ratio		~			~			\checkmark
Positioner Health View ✓ ✓ ✓ ✓ Actuator Health View ✓ ✓ ✓ ✓ Control Health View ✓ ✓ ✓ ✓ A0 ✓ ✓ ✓ ✓ PID ✓ ✓ ✓ ✓ D0 ✓ ✓ ✓ ✓ D1 ✓ ✓ ✓ ✓ OS ✓ ✓ ✓ ✓	ISTIC:	Pneumatic Leak		~			~			\checkmark
Positioner Health View ✓ ✓ ✓ ✓ Actuator Health View ✓ ✓ ✓ ✓ Control Health View ✓ ✓ ✓ ✓ A0 ✓ ✓ ✓ ✓ PID ✓ ✓ ✓ ✓ D0 ✓ ✓ ✓ ✓ D1 ✓ ✓ ✓ ✓ OS ✓ ✓ ✓ ✓	AGNC	Long-Term Trends		~			\checkmark			\checkmark
Positioner Health View ✓ ✓ ✓ ✓ Actuator Health View ✓ ✓ ✓ ✓ Control Health View ✓ ✓ ✓ ✓ A0 ✓ ✓ ✓ ✓ PID ✓ ✓ ✓ ✓ D0 ✓ ✓ ✓ ✓ D1 ✓ ✓ ✓ ✓ OS ✓ ✓ ✓ ✓	NE D	Partial Stroke Test		✓			\checkmark			\checkmark
Positioner Health View ✓ ✓ ✓ ✓ Actuator Health View ✓ ✓ ✓ ✓ Control Health View ✓ ✓ ✓ ✓ A0 ✓ ✓ ✓ ✓ PID ✓ ✓ ✓ ✓ D0 ✓ ✓ ✓ ✓ D1 ✓ ✓ ✓ ✓ OS ✓ ✓ ✓ ✓	N-L	Valve Health View		~			\checkmark			\checkmark
Control Health View V V V V A0 V V V V PID V V V V D0 V V V V DI V V V V OS V V V V	0	Positioner Health View		~			\checkmark			\checkmark
V V MO MO MO MO Plant		Actuator Health View		~			\checkmark			\checkmark
VI V V Image: Constraint of the second		Control Health View		~			\checkmark			\checkmark
PID Odd Odd V V V V V V V V V V V V V V V V V V V V V V V V	S	AO						\checkmark	\checkmark	\checkmark
V V OD OD Identified Identified <td>CKS</td> <td>PID</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>\checkmark</td> <td>\checkmark</td> <td>✓</td>	CKS	PID						\checkmark	\checkmark	✓
Lonndation Lonnortion IS IS IS IS IS IS IS IS IS IS IS IS IS	N FIEI BLO	DO						\checkmark	\checkmark	✓
V V	ATION STION	DI						\checkmark	\checkmark	✓
	ound Fund	OS						\checkmark	\checkmark	✓
1. Limited Function. No health information.								\checkmark	\checkmark	\checkmark

1. Limited Function. No health information.

2. Limited function. No friction or force monitoring.

3. Limited function. No pressure monitoring or information.



The Logix 3000MD Positioner Specifications

Specifications for Logix 3400MD

Table I: Electrical Specifications

Power Supply	Two-wire, 9-32 VDC	
	FF compatible	
IS	Fisco compliant	
Communications	FF Protocol ITK 4.6x, 5.0	
Operating Current	23 mA	
Maximum Voltage	36.0 VDC	

Table II: Environmental Conditions

Operating Temperature	Standard	-40° to 176°F
Range	Stalluaru	(-40° to 80°C)
Transport and Storage Temperature Range	-40° to 176°F (-40° to 80°C)	
Operating Humidity	0 - 100% non-co	ndensing

Note: The air supply must conform to ISA Standard ISA 7.0.01 (a dew point at least 18 degrees Fahrenheit below ambient temperature, particle size below five microns—one micron recommended—and oil content not to exceed one part per million).

Specifications for Logix 3200MD

Table I: Electrical Specifications

Power Supply	Two-wire, 4-20 mA			
	10.0 to 30.0 VDC			
Compliance Voltage	10.0 VDC @ 20 mA			
Effective Resistance	495 Ω @ 20 mA Typical			
	Add 20 Ω when HART communication active			
Communications	HART Protocol ITK 5,6			
Minimum Operating Current	3.6 mA without AO board			
	3.7 mA with AO board			
Maximum Voltage	30.0 VDC			

Table II: Environmental Conditions

Operating Temperature Range	Standard	-4° to 176°F
	Stanuaru	(-20° to 80°C)
	1	-40° to 176°F
	Low	(-40° to 80°C)
Transport and Storage Temperature Range	-40° to 176°F (-40° to 80°C)	
Operating Humidity	0 - 100% non-condensing	

Note: The air supply must conform to ISA Standard ISA 7.0.01 (a dew point at least 18 degrees Fahrenheit below ambient temperature, particle size below five microns—one micron recommended—and oil content not to exceed one part per million).

Table III: Physical Specifications

,	•
Housing Material	Cast, powder-painted aluminum or stainless steel
Soft Goods	Buna-N / Florosilicone
Weight	8.3 pounds (3.9 kg) aluminum 20.5 pounds (9.3 kg) stainless steel

Table IV: Positioner Specifications

Deadband	<0.1% full scale
Repeatability	<0.05% full scale
Linearity	<0.5% (rotary), <0.8%, (sliding stem) full scale
Air Consumption	<0.3 SCFM (0.5 Nm³/hr) @ 60 psi (4 bar)
Air Supply	30-150 psig (ISA 7.0.0.1 compliant)
Air Delivery	12 SCFM @ 60 psi (0.27 Cv)

Table III: Physical Specifications

Housing Material	Cast, powder-painted aluminum or stainless steel
Soft Goods	Buna-N / Florosilicone
Weight	8.3 pounds (3.9 kg) aluminum 20.5 pounds (9.3 kg) stainless steel

Table IV: Positioner Specifications

Deadband	<0.1% full scale
Repeatability	<0.05% full scale
Linearity	<0.5% (rotary), <0.8%, (sliding stem) full scale
Air Consumption	<0.3 SCFM (0.5 Nm³/hr) @ 60 psi (4 bar)
Air Supply	30-150 psig (ISA 7.0.0.1 compliant)
Air Delivery	12 SCFM @ 60 psi (0.27 Cv)



Brand	Model	Size		iting Kit	Brand	Model	Size Mounting		ng <u>Kit</u>	
er		30	213905		33	В	173298			
		34		0.5" – 1.5" stroke	lan 's)		4	170200		
		40	- 141410	stroke	Masoneilan (Rotary Actuators)	35	6	1732	298	
			171516	0.5" – 1.5"	laso (Rc Actu	00	7	173298		
		50		stroke	2 4	70	10			
	657 & 667		171517	2" stroke		10			0.75	
		60	171516	0.5" – 1.5" stroke	Valtek	Trooper		166636	– 1.50 Std	
Fisher			171517	2" stroke	×		R314	141180	НD	
_		70	171518	4" stroke	Automax					
		80	171519		Aut	SNA115 NF		NK3 [.]	13A	
		225			Vangard	37/64		175100		
	1250	450	173371				ATO ATC	175128		
		675	-		Air-Torque	AT Series	ATO – AT6			
	1052	33	171549	Rotary	SNA Series SNA3 – SNA2000					
	657-8	40	173798		Automax	N Series	N250.300	-		
S	R	RC		1512	12		R2 – R5	Consult factory		
Neles		RD		178258		R Series RPC				
					Bettis	Series	RP – TPC11000			
Foxboro		Slid-Std Linear		173567		G Series	G2009-M11 – G3020-M11			
					EL-0-	E Series	E25 – E350			
lla	VST-VA3R	17-in. dia.	173798		Matic	P Series	P35 – P4000			
Honeywell		12-in. dia.	173798		Hytork	XL Series	XL45 – XL4580			
ЮН	VSL-VA1D				Unitorq	M Series	M20 – M2958			
		9			Worcester	39 Series	2539 - 4239			
		9 11	- 17	1721	*Adjustable mounting kit 173798 may be needed if handwh are used.				heels	
	37	13	17	1720						
	57				NAMUR Accessory Mounting Kit Part					
		18		3382						
		24	1	3896	Numbers					
		11		3235		racket Option Description				
irs)		13		3234	28					
uato	38	15		6070	28	38 mm pinion x 80 mm bolt spacing				
Act		18		3382*			30 mm pinion x 80 mm bolt spacing			
ear		24		3896	513	50 mm pinion x 130 mm bolt spacing				
(Lir		25		3325			on Description			
ilan	71 Domotor	50	17	3335	Α	10-24 UNC bolting				
Masoneilan (Linear Actuators)		100	17	3336	В	10-32	10-32 UNF bolting			
	88	6	17	1722	L	M58 metric bolting				
	00	16	17	3827	Example: NK313A, NAMUR Accessory Mounting Kit with 30 mm					
		В	17	3361	pinion x 80) mm bolt spacing and 10-24 UNC bolting.				
	47	D			Please contact your Flowserve representative for addi-					
	47 48	B	17	3361	PLEASE CONT	ACT YOUR F	OWSERVE REPRESENT	TATIVE FOR	ADDI-	
				3361 5141	Please cont tional moun			TATIVE FOR	ADDI-	
	48 "D" Domotor	В	17					TATIVE FOR	ADDI-	

The Logix 3000MD E.O.M. Mounting Kits



3000MD Series dimensions

NOTE: Dimensions in inches (mm)





How to order

Selection		Code	Example			
		3	ω			
Protocol	HART	2	4			
	Foundation Fieldbus	4	 			
	Standard (No Sensors)	0				
Diagnostics	Advanced (With Sensors)	1				
	Pro Diagnostics (with sensors and full ValveSight dianostics)	2				
	Aluminum, White Paint (Valtek)	0				
	Stainless Steel, No Paint (Valtek)	1				
Material	Aluminum, Black Paint (Automax)	2	-			
	Aluminum, Food-Grade White Paint (Automax)	3				
	Aluminum, Black Paint (Accord)	4				
	Aluminum, Food-Grade White Paint (Accord)	5				
Design Version			MD			
	Nonincendive Ex nL nA IIC, ATEX II 3 G, T4amb -40°C to +85°C, T5 Tamb -40°C to	04				
	+55°C; Intrinsically Safe Ex ia IIC, T4 Tamb -40°C to +85°C, T5 Tamb -40°C to +55°C; Ex	(3400MD)				
	ia D 20, T95°C -40°C to +80°C (CENELEC)	, ,				
	INMETRO BR-EX ia IIC T4/T5; BR-Ex d IIB+H ₂ T5 (South America)	06				
	Explosionproof Ex d IIB + H ₂ , Ex tD A21 T95°C, ATEX II 2 G (CENELEC)	07				
	(GOST GGTN Ex d IIB+H ₂)	(3400MD))			
	Explosionproof Class I, Div 1, Groups B, C, D Intrinsically Safe Class I,					
	Div 1, Groups A through G (FM, CSA) FM Nonincendive. CSA Class I,	10				
	Div 2, Class I, Zone 1, Group IIB + H ₂ and Exia Class 1, Zone 0, Group IIC (CSA Only)					
	General Purpose	14	14			
Certifications	· · ·	15				
	Intrinsically Safe Ex ia IIC, T4 Tamb -40°C to +85°C, T5 Tamb -40°C to +55°C; Ex ia D 20, T95°C -40°C to +80°C, ATEX II 1 G D (CENELEC) (GOST GGTN Ex i Intrinsically Safe IIC)					
		(3400MD)				
	IECEx Explosionproof	16				
	IECEX Intrinsically Safe	21				
	ATEX: Explosion Proof: U2G Ex d UB+H T5: U2D Ex tD A21 T = -40% to +8%					
	Explosion Proof: II2G Ex d IIB+H ₂ T5; II2D Ex tD A21 T _{amb} -40°C to +80°C Intrinsically Save: II1G Ex ia IIC, T4 T _{amb} -40°C to +85°C, T5 T _{amb} -40°C to +55°C	28				
	II1D Ex iaD 20 T95°C -40°C to + 80°C	(3200MD)				
	Nonincendive: II3G Ex nL nA IIC, T4 T _{amb} -40°C to +85°C, T5 T _{amb} -40°C to +55°C	(02002)				
	II3D Ex tD A22 T95°C -40°C to + 80°C					
	KOSHA*					
Shaft	DD 316 Stainless Steel Shaft (Valtek Standard)	D6	D6			
	NAMUR 316 Stainless Steel (VDI/VDE 3845)	N6				
Conduit	1⁄2" NPT	E	3			
Connections	M20	М				
	Four-way (Double-Acting)	04				
Action	Three-way (Single-Acting)	03	4			
	Four-way Vented (Double-Acting)	4V				
	Three-way Vented (Single-Acting)	3V				
Temperature	Low Temperature (-40°F to 176°F; -40°C to 80°C)	40	40			
	SS with brass internals, psi (bar/kPa) (Valtek Standard)					
	SS with SS internals, psi (bar/kPa)	OS				
Gauges	SS with brass internals, psi (kg/cm2)	KG	KS			
	SS with SS internals, psi (kg/cm2) KS	KS				
	No Gauges	U				
	No special options	00				
analal Antiona	4-20 mA Position Feedback	OF				
Special Options	Remote Mount Feedback (Only Available with Certi cation Option 14)	RM	유			
	Fail Option Feedback*	SF				

For each category, select the code for one of the options.

* Contact factory before specifying this option

Logix 3400MD Hazardous Area Certifications

lotified Body	Certification Option	Approval	Entity Parameters	Temperature Code	Enclosur Rating
	-01	Explosionproof: Class I, Div 1, Groups B,C,D Dust Ignition Proof: Class II, III, Div 1, Groups EFG (See Warning No. 1, 2)	Not Applicable	T6 $T_{amb} \leq = 60^{\circ}C$	NEMA 4X
FM	-02	Intrinsically Safe: Class I, II, III, Div 1, Groups A,B,C,D Class 1, Zone 0, AEx ia IIC	Entity Fisco Parameters Parameters Ui = 24 Vdc Ui = 17.5 Vdc li = 250mA Ii = 380mA Pi = 1.2 W Pi = 5.32W Ci = 3300pF Ci = 3300 pF Li = 10µH Li = 10µH	$T4 T_{amb} \leq = 60^{\circ}C$	NEMA 4X
		(See Warning No. 2,3)	(refer to control drawing No. 234401)		
	-02	Non-Incendive: Class I, II, III, Div 2, Groups A,B,C,D (See Warning No. 2)	Install per NEC Article 501-4 when barriers are not used.	T6 T_{amb} -20° to 60° C	NEMA 4X
SP ®	-01	Explosionproof: Class I, Div 1, Groups B,C,D Class II, Div 1, Groups E,F,G Class III Ex d IIB+H2 (See Warning No. 2)	Not Applicable	-20° ≤ Ta ≤ +55°C	Type 4X
	-07	Explosionproof (Flameproof): II 2 GD Ex d IIB + H ₂ Ex tD A21 T95°C (See Warning No. 1, 2)	Not Required	T5 (T =-40°C to + 80°C)	IP65
ATEX	-04 or -15	(See Warning No. 2, 3)	Ui = 30 Volts Ii = 100mA Pi = 800mW Ci = 30 nF Li = 0 Co = 36 nF	T4 (T_{amb} -40°C to + 85°C) T5 (T_{amb} -40°C to + 55°C)	IP65
	-04	Non-Incendive: II 3 G Ex nL nA IIC (See Warning No. 2)	Not Required	T4 T _{amb} -40°C to + 85°C) T5 T _{amb} -40°C to + 55°C)	IP65
		Explostionproof (Flameproof): 1Ex d IIBT5/H ₂ X (See Warning No. 1,2)	Not Required	T5 (-50ºC ≤Ta ≤ +55ºC)	IP65
GOST		Intrinisically Safe: 0Ex ia IICT4X	Ui = 24 Vdc Ii = 250mA Pi = 1.2W Ci = 330 pF Li = 10 μH	T4 (T_{amb} -50°C to + 60°C)	IP65
IECEx	-21	Intrinsically Safe: Ex ia IIC (See Warning No. 2, 3)	Ui = 24 Vdc li = 250mA Pi = 01.2W Ci = 330 pF Li = 10 μH	T4 (T_{amb} -20°C to + 60°C)	IP65
INMETRO	-06	Explosionproof (Flameproof): BR-Ex d IIB + H ₂ (See Warning No. 1, 2)	Not Required	T5 (-40°C≤ Ta ≤ + 55°C)	IP65
	-06 or -22	Intrinsically Safe: BR- Ex ia IIC (See Warning No. 2, 3)	Ui = 24 Vdc li = 250mA Pi = 1.2W Ci = 3300 μF Li = 10 μF	T5 (-40°C≤ Ta ≤ + 55°C) T4 (-40°C≤ Ta ≤ + 85°C)	IP65

WARNINGS:

FLOWSERVE

1. In order to maintain the explosionproof certifications do not remove or loosen covers during operation.

2. To avoid the possibility of static discharge clean only with a damp cloth.

3. The positioner must be connected to suitable rated intrinsically safe equipment, and must be installed in accordance with intrinsically safe installation standards.

FLOWSERVE Logix 3000MD Series Digital Positioner FCD LGENTB0059-01 – 10/09 Logix 3200MD Hazardous Area Certifications

Notified Body	Certification	Approval	Entity Parameters	Temperature Code	Enclosure
	Option -10	Explosionproof: Class I, Div 1, Groups B,C,D Dust Ignition Proof: Class II, III, Div 1, Groups EFG (See Warning No. 1, 2)	Not Applicable	T6 $T_{amb} \leq = 60^{\circ}C$	Rating NEMA 4X
FM APPROVED	-10	Intrinsically Safe: Class I, II, III, Div 1, Groups A,B,C,D Class 1, Zone 0, AEx ia IIC (See Warning No. 2,3)	Vmax = 30 Volts Imax = 100mA Pmax = 800mW Ci = 30 nF Li = 0 (refer to control drawing No. 198736)	$\begin{array}{rl} T4 \ T_{amb} \leq & = 85^{\circ}\text{C} \\ T5 \ T_{amb} \leq & = 55^{\circ}\text{C} \end{array}$	NEMA 4X
	-10	Non-Incendive: Class I, Div 2, Groups A,B,C,D (See Warning No. 2)	Install per NEC Article 501-4 when barriers are not used.	$\begin{array}{rl} T4 \ T_{amb} & \leq & = 85^{\circ} C \\ T5 \ T_{amb} & \leq & = 55^{\circ} C \end{array}$	NEMA 4X
	-10	Explosionproof: Class I, Div 1, Groups B,C,D Class II, Div 1, Groups E,F,G Class III (See Warning No. 1, 2)	Not Applicable	-25° ≤ Ta ≤ +40°C	Туре 4Х
St.	10	Intrinsically Safe: Class I, II, III, Div 1, Groups A,B,C,D	Vmax = 30 Volts Imax = 100mA Pmax = 800mW Ci = 30 nF Li = 0 (refer to control drawing No.	T4 $T_{amb} \leq = 80^{\circ}C$	Туре 4Х
	10	(See Warning No. 2, 3) Non-Incendive: Class I, II, Div 2, Groups A,B,C,D (See Warning No. 2)	Not Required	$T4 T_{amb} \leq = 80^{\circ}C$	Type 4X
	-28	Explosionproof (Flameproof): II 2 GD Ex d IIB + H ₂ Ex tD A21 T95°C (See Warning No. 1, 2)	Not Required	T5 (T = -40°C to + 80°C)	IP65
ATEX	-28	Intrinsically Safe: II 1 G D Ex ia IIC Ex iaD 20 T95°C (See Warning No. 2, 3)		$\begin{array}{l} T4 \ (T_{amb} \ -40^{\circ} C \ to \ +85^{\circ} C) \\ T5 \ (T_{amb} \ -40^{\circ} C \ to \ +55^{\circ} C) \\ (Ta \ =-40^{\circ} C \ to \ +80^{\circ} C) \end{array}$	IP65
	-28	Non-Incendive: II 3 G Ex nL nA IIC Ex tD A22 T95°C (See Warning No. 2)	Not Required	T4 T_{amb} (-40°C to + 85°C) T5 T_{amb} (-40°C to + 55°C) (Ta = -40°C to + 80°C)	IP65
	-16	Explosionproof (Flameproof): Ex d IIB + H ₂ (See Warning No. 1, 2)	Not Required	T5 (T_{amb} -20°C to + 55°C) T5 (T_{amb} -40°C to + 80°C)	IP65
IECEx	-21	Intrinsically Safe: Ex ia IIC (See Warning No. 2, 3)	Ui = 30 Vdc Ii = 100mA Pi = 0.8W Ci = 30 nF Li = 0	T4 (T _{amb} -40°C to + 85°C)	IP65
		Explosionproof (Flameproof): 1Ex d IIBT5/H ₂ X (See Warning No. 1,2)	Not Required	T5 (-50ºC ≤Ta ≤ +55ºC)	IP65
GOST		Intrinisically Safe: OEx ia IICT4X OEx ia IICT5X (See Warning No 2,3)	Ui = 30 Volts Ii = 100mA Pi = 800mW Ci = 30 nF Li = 0	T4 (T_{amb} -50°C to + 60°C)	IP65
Ν	-06	Explosionproof (Flameproof): BR-Ex d IIB + H ₂ (See Warning No. 1, 2)	Not Required	T5 (-40°C ≤ Ta ≤ + 80°C)	IP65
INMETRO	-06	Intrinsically Safe: BR- Ex ia IIC (See Warning No. 2, 3)	Ui = 30 Vdc Ii = 100mA Pi = 800mW Ci = 30 nF Li = 0 Co = 36 nF	T5 (-40°C ≤ Ta ≤ + 55°C) T4 (-40°C ≤ Ta ≤ + 85°C)	IP65

<u>15</u>





FCD LGENTB0059-01 10/09 Printed in USA.

To find your local Flowserve representative:

For more information about Flowserve Corporation, visit www.flowserve.com or call USA 1 800 225 6989

Flowserve Corporation has established industry leadership in the design and manufacture of its products. When properly selected, this Flowserve product is designed to perform its intended function safely during its useful life. However, the purchaser or user of Flowserve products should be aware that Flowserve products might be used in numerous applications under a wide variety of industrial service conditions. Although Flowserve can (and often does) provide general quidelines, it cannot provide specific data and warings for all possible applications. The purchaser/user must therefore assume the ultimate responsibility for the proper sizing and selection, installation, operation, and maintenance of Flowserve products. The purchaser/user should read and understand the installation Operation Maintenance (IOM) instructions included with the product, and train its employees and contractors in the safe use of Flowserve products in connection with the specific application.

While the information and specifications contained in this literature are believed to be accurate, they are supplied for informative purposes only and should not be considered certified or as a guarantee of satisfactory results by reliance thereon. Nothing contained herein is to be construed as as warranty or guarantee, express or implied, regarding any matter with respect to this product. Because Flowserve is continually improving and upgrading its product design, the specifications, dimensions and information contained herein are subject to change without notice. Should any question arise concerning these provisions, the purchaser/user should contact Flowserve Corporation at any one of its word/wide operations or offices.

© 2006 Flowserve Corporation, Irving, Texas, USA. Flowserve is a registered trademark of Flowserve Corporation.

Flowserve Headquarters

5215 N. O'Connor Blvd., Suite 2300 Irving, TX 75039 Telephone: 972 443 6500

Control Valve Manufacturing

1350 Mountain Springs Parkway Springville, UT 84663-3004 USA Telephone: 1 801 489 8611 Fax: 1 801 489 3719

Singapore

12 Tuas Ave. 20, 638824 Republic of Singapore Telephone: +65 862 3332 Fax: +65 862 4940

Austria

Kasernengasse 6 Villach Austria 9500 Telephone: +43 0 4242 41181 0 Fax: +43 0 4242 41181 50

Australia

14 Dalmore Dr. Scoresby, Victoria, Australia 3179 Telephone: +61 3 9759 3300 Fax: +61 3 9759 3301

China

585, Hanwei Plaza 7 Guanghua Road Beijing, China 100004 Telephone: +86 10 6561 1900

flowserve.com