



Optimizing wakeup time and power consumption
in CR95HF and STRFNFCA devices

Introduction

This document describes several tips for application engineers to effectively manage CR95HF and STRFNFCA operating states and modes to define an adapted wakeup condition to return to its Active state to start communication with the external world in order to reduce power consumption.

The CR95HF and STRFNFCA have 2 main functional domains. In the first one, Active mode, the devices are able to communicate with a host using one of the serial interfaces (UART or SPI) or with RFID tags using its RF capabilities. In this mode, the device consumption is only a few milliamps, and when it emits RF signals, its field consumption becomes tens of milliamps. In the second domain, Wait for Event (WFE) mode, the device remains quiescent while waiting for an external event. In this mode, a very low level of power consumption (only a few microamps) may be achieved.

An application engineer is able to manage the wakeup conditions in order to adapt his strategy to optimize wakeup time or system power consumption.

This application note will provide guidelines for choosing the best implementation.

Contents

Introduction	1
1 Reference information	4
1.1 Reference documents	4
1.2 Terms and acronyms	4
1.3 Notation conventions	4
2 Management of CR95HF or STRFNCA activity	6
2.1 Overview of operating modes	6
2.2 Idle command	7
2.3 Idle command parameters	9
2.4 Using LFO frequency setting to reduce power consumption	10
2.5 Optimizing wake-up conditions	11
2.5.1 Wake-up source register	11
2.6 Using various techniques to return to Ready state	12
2.6.1 Default setting: from POR to Ready state	12
2.6.2 From Ready state to Hibernate state and back to Ready state	12
2.6.3 From Ready state to Sleep state and back to Ready state	12
2.7 Tag detection calibration procedure	14
3 Power consumption considerations	16
3.1 Transition from Ready to Hibernate state	16
3.2 Transition from Ready to Sleep state	18
3.3 Wake-up by Tag Detection	18
Appendix A Tag detection principle	22
A.1 Tag detection sequence	23
Appendix B Tag Detection Calibration process	26
B.1 Tag Detection Calibration algorithm	26
B.2 Tag Detection calibration command	27
Appendix C Example of CR95HF tag detection calibration process	29

**Appendix D Example of CR95HF tag detection command using results of tag
detection calibration 32**

Revision history 33

1 Reference information

1.1 Reference documents

CR95HF: 13.56 MHz Multi-protocol Contactless Transceiver IC with SPI and UART serial access datasheet

STRFNFCA: Near field communication transceiver datasheet

1.2 Terms and acronyms

Table 1. List of terms and acronyms

Term	Meaning
AFE	Analog Front End
DAC	Digital-to-analog converter
DFT	Design for Test
NVM	Non Volatile Memory
RFID	Radio frequency identification
RFU	Reserved for Future Use
WFE	Wait For Event

1.3 Notation conventions

The following symbols correspond to:

>>>: Frame sent by the host to CR95HF or STRFNFCA

<<<: Frame sent by the CR95HF or STRFNFCA to the host

Table 2. List of characteristic values

Symbol	Definition	Value
CalRef	Tag Calibration Reference level and DAC threshold level for device setup	
DacDataH	High Level detection limit	
DacDataL	Low Level detection limit	
MaxSleep	Number of inactivity periods (t_{INACTIVE}) before a timeout.	
SwingCnt	Number of 13.56 MHz periods in the RF burst	
t_{DAC}	DAC set up time	
t_{HFO}	Period of RF carrier (13.56 MHz)	73 ns
t_{INACTIVE}	Inactivity period, delay between two wakeups for RF burst emissions in a Tag Detection sequence	$t_{\text{INACTIVE}} = (\text{WuPeriod} + 1) * t_{\text{REF}}$
t_{LFO}	Period of device Low frequency oscillator (32 kHz)	31.25 μ s

Table 2. List of characteristic values (continued)

Symbol	Definition	Value
t_{OSC}	Oscillator set-up time	
t_{REF}	Reference time	$t_{REF} = 256 * t_{LFO} = 8 \text{ ms}$
t_{SWING}	RF Burst duration in Tag detection	$t_{SWING} = \text{Swing} * t_{HFO}$
t_{TO}	Timeout delay after which the device will automatically leave WFE mode.	$t_{TO} = (\text{MaxSleep}) * t_{INACTIVE}$
WuPeriod	Number of reference times (RT) in an inactivity period ($t_{INACTIVE}$)	

2 Management of CR95HF or STRFNFCA activity

2.1 Overview of operating modes

The CR95HF and STRFNFCA have 2 operating modes: Wait for Event (WFE) and Active. In Active mode, the device communicates actively with a tag or an external host (MCU). WFE mode includes four low consumption states: Power-up, Hibernate, Sleep and Tag Detector.

The CR95HF or STRFNFCA can switch from one mode to another.


Table 3. CR95HF or STRFNFCA operating modes and states

Mode	State	Description
Wait For Event (WFE)	Power-up	This mode is accessible directly after POR. Low level on $\overline{\text{IRQ_IN}}$ pin (longer than 10 μs) is the only wakeup source. LFO (low-frequency oscillator) is running in this state.
	Hibernate	Lowest power consumption state. The device has to be woken-up in order to communicate. Low level on $\overline{\text{IRQ_IN}}$ pin (longer than 10 μs) is the only wakeup source.
	Sleep	Low power consumption state. Wakeup source is configurable: – Timer – $\overline{\text{IRQ_IN}}$ pin – SPI_SS pin LFO (low-frequency oscillator) is running in this state.
	Tag Detector	Low power consumption state with tag detection. Wakeup source is configurable: – Timer – $\overline{\text{IRQ_IN}}$ pin – SPI_SS pin – Tag detector LFO (low-frequency oscillator) is running in this state.
Active	Power-up	This mode is accessible directly after POR. Low level on $\overline{\text{IRQ_IN}}$ pin (longer than 10 μs) is the only wakeup source. LFO (low-frequency oscillator) is running in this state.
	Hibernate	Lowest power consumption state. The device has to be woken-up in order to communicate. Low level on $\overline{\text{IRQ_IN}}$ pin (longer than 10 μs) is the only wakeup source.

Hibernate, Sleep and Tag Detector states can only be activated by a command from the external host (MCU). As soon as any of these three states are activated, the device can no longer communicate with the external host. It can only be woken up.

The behavior of the device in 'Tag Detector' state is defined by the Idle command.

Figure 1. CR95HF or STRFNFCA initialization and operating state change



2.2 Idle command

The Idle command switches the device into WFE mode (low consumption) and defines the way it returns to Ready state.

In WFE mode, the device has two low consumption states: Hibernate and Sleep/Tag-Detector.

In Hibernate state, the device power consumption is extremely low (a few microamps) because most of its resources are switched off. When it receives an external event (pin $\overline{\text{IRQ_IN}}$), it will return to Ready mode in only a few milliseconds.

In Sleep/Tag-Detector state, the device power consumption is low (tens of microamps) depending on the selected wakeup source. The wakeup source can be an internal timer, an external interrupt or the presence of a tag detected by the device.

In Tag-Detector state, after executing an initial Tag Detection Calibration procedure to set-up the device, the application engineer must adjust command parameters to select the best trade-off between the wakeup delay and the power budget.

Table 4. Idle command description

Direction	Data	Comments	Example
Host to CR95HF or STRFNFCA	07	Command code	Example of switch from Active mode to Hibernate state: >>>0x07 0E 08 04 00 04 00 18 00 00 00 00 00 00 00 00
	0E	Length of data	
	<WU Source>	Specifies authorized wakeup sources and the LFO frequency	Example of switch from Active to WFE mode (wakeup by low pulse on <u>IRQ_IN</u> pin): >>>0x07 0E 08 01 00 38 00 18 00 00 00 00 00 00 00 00
	EnterCtrlL	Settings to enter WFE mode	
	EnterCtrlH		
	WUCtrlL	Settings to wake up from WFE mode	
	WUCtrlH		
	LeaveCtrlL	Settings to leave WFE mode (Default value = 0x1800)	Example of switch from Active to WFE mode (wakeup by low pulse on <u>SPI_SS</u> pin): >>>0x07 0E 10 01 00 38 00 18 00 00 00 00 00 00 00 00
	LeaveCtrlH		
	<WUPeriod>	Period of time between two tag detection bursts. Also used to specify the duration before timeout.	Example of wakeup by timeout (7 seconds): Duration before Timeout = 256 * t _L * (WU period + 2) * (MaxSleep + 1) >>>0x07 0E 01 21 00 38 00 18 00 60 60 00 00 00 00 08
	<OscStart>	Defines the Wait time for HFO to stabilize: <OscStart> * t _L (Default value = 0x60)	
	<DacStart>	Defines the Wait time for DAC to stabilize: <DacStart> * t _L (Default value = 0x60)	Example of switch from Active to Tag Detector mode (wakeup by tag detection or low pulse on <u>IRQ_IN</u> pin) (32 kHz, inactivity duration = 272 ms, DAC oscillator = 3 ms, Swing = 63 pulses of 13.56 MHz), 0A = Infinite sequence, 0B = Until TimeOut: >>>0x07 0E 0A 21 00 79 01 18 00 20 60 60 64 74 3F 08
	<DacDataL>	Lower compare value for tag detection ⁽¹⁾ . This value must be set to 0x00 during Tag Detection Calibration.	
	<DacDataH>	Higher compare value for tag detection ⁽¹⁾ . This is a variable used during Tag Detection Calibration.	
	<SwingsCnt>	Number of swings HF during tag detection (Default value = 0x3F)	
	<MaxSleep>	Max. number of tag detection trials before timeout ⁽¹⁾ . This value must be set to 0x01 during Tag Detection Calibration. Also used to specify duration before timeout. MaxSleep must be: 0x00 < MaxSleep < 0x1F	Example of a basic Idle command used during the Tag Detection Calibration process: >>>0x07 0E 03 A1 00 F8 01 18 00 20 60 60 00 xx 3F 01 where xx is the DacDataH value.

Table 4. Idle command description (continued)

Direction	Data	Comments	Example
CR95HF or STRFNFCA to Host	0x00	Result code	This response is sent only when CR95HF or STRFNFCA exits WFE mode. <<<0x000101 Wakeup by timeout <<<0x000102 Wakeup by tag detect <<<0x000108 Wakeup by low pulse on $\overline{\text{IRQ_IN}}$ pin
	0x01	Length of data	
	<Data>	Data (Wakeup source)	
CR95HF or STRFNFCA to Host	0x82	Error code	<<<0x8200 Invalid command length
	0x00	Length of data	

1. An initial calibration is necessary to determine DacDataL and DacDataH values required for leaving Tag Detector state. For more information, contact your ST sales office for the corresponding application note.

2.3 Idle command parameters

The Idle command (Host to device) has the following structure (all values are hexadecimal):

Table 5. Idle command structure

07	0E	xx	yy zz	yy zz	yy zz	aa	bb	cc	dd ee	ff	gg
Command code	Data length	WU source	Enter Control	WU Control	Leave Control	WU Period	Osc Start	DAC Start	DAC Data	Swing Count	Max Sleep

Table 6. Summary of parameters

Parameter	Description
Command code	This byte is the command code. '07' represents the Idle command. This command switches the device from Active mode to WFE mode.
Data length	This byte is the length of the command in bytes. Its value depends on the following parameter values.
WU Source	This byte defines the authorized wakeup sources in the wakeup source register. Predefined values are: 01: Time out 02: Tag Detection 08: Low pulse on $\overline{\text{IRQ_IN}}$ 10: Low pulse on $\overline{\text{SPI_SS}}$
Enter Control	These two bytes (EnterCtrlL and EnterCtrlH) define the resources when entering WFE mode. 0x0400: Hibernate 0x0100: Sleep (or 0x2100 if Timer source is enabled) 0xA100: Tag Detector Calibration 0x2100: Tag detection
WU Control	These two bytes (WuCtrlL and WuCtrlH) define the wakeup resources. 0x0400: Hibernate 0x3800: Sleep 0xF801: Tag Detector Calibration 0x7901: Tag detection

Table 6. Summary of parameters (continued)

Parameter	Description
Leave Control	These two bytes (LeaveCtrlL and LeaveCtrlH) define the resources when returning to Ready state. <div> <div>0x1800: Hibernate</div> <div>0x1800: Sleep</div> <div>0x1800: Tag Detector Calibration</div> <div>0x1800: Tag detection</div> </div>
WU Period	This byte is the coefficient used to adjust the time allowed between two tag detections. Also used to specify the duration before timeout. (Typical value: 0x20) Duration before Timeout = $256 * t_L * (WU \text{ period} + 2) * (MaxSleep + 1)$
Osc Start	This byte defines the delay for HFO stabilization. (Recommended value: 0x60) Defines the Wait time for HFO to stabilize: $\langle OscStart \rangle * t_L$
DAC Start	This byte defines the delay for DAC stabilization. (Recommended value: 0x60) Defines the Wait time for DAC to stabilize: $\langle DacStart \rangle * t_L$
DAC Data	These two bytes (DacDataL and DacDataH) define the lower and higher comparator values, respectively. These values are determined by a calibration process. When using the device demoboard, these values should be set to approximately 0x64 and 0x74, respectively.
Swing Count	This byte defines the number of HF swings allowed during Tag Detection. (Recommended value: 0x3F)
Max Sleep	This byte defines the maximum number of tag detection trials or the coefficient to adjust the maximum inactivity duration before timeout. MaxSleep must be: $0x00 < MaxSleep < 0x1F$ This value must be set to 0x01 during the Tag Detection Calibration process. Also used to specify duration before timeout. Duration before Timeout = $256 * t_L * (WU \text{ period} + 2) * (MaxSleep + 1)$ (Typical value: 0x28)

2.4 Using LFO frequency setting to reduce power consumption

In WFE mode, the high frequency oscillator (HFO) is stopped and most processes being executed are clocked by the low frequency oscillator (LFO). To minimize CR95HF or STRFNFCA power consumption in WFE mode, the slower the LFO frequency, the lower the power consumption.

Example 1: Setting a lower LFO frequency

The following equation defines a basic timing reference:

$$t_{REF} = 256 * t_L \text{ ms (where } t_L = 1/f_{LFO})$$

$$t_{REF} = 8 \text{ ms (when bits [7:6] are set to '00', or 32 kHz)}$$

$$t_{REF} = 64 \text{ ms (when bits [7:6] are set to '11', or 4 kHz)}$$

2.5 Optimizing wakeup conditions

Using the Wakeup source register, it is possible to cumulate sources for a wakeup event. It is strongly recommended to always set an external event as a possible wakeup source.

To cumulate wakeup sources, simply set the corresponding bits in the wakeup source register. For example, to enable a wakeup when a tag is detected (bit 1 set to '1') or on a low pulse on pin $\overline{\text{IRQ_IN}}$ (bit 3 set to '1'), set the register to 0x0A.

2.5.1 Wakeup source register

Wakeup conditions are defined in the 8-bit wakeup condition register. These bits select one or several external conditions to be evaluated by the device in order to exit Idle mode.

Bit 0: When set, the device will wake up and return to Ready state at the end of a predefined cycle. The Time Out (TO) value is defined by the Max sleep and Wake Up period:

$$\text{TO} = (\text{MaxSleep} * (\text{WuPeriod} + 1) * \text{RT}) \text{ or } \text{RT} = 256 * t_{\text{LFO}} = 8 \text{ ms}$$

This bit must be set when using the timer as a possible wakeup source. It must be set during Tag Detection Calibration to force a wakeup after the first Tag Detection trial.

Bit 1: When set, the device will wake up when a Tag is detected in the RF field. This bit must also be set during Tag Detection Calibration or during Tag Detection (when the RF field is active).

Bit 2: This bit is RFU.

Bit 3: When set, the device will wake up when an external interrupt (low level on pin $\overline{\text{IRQ_IN}}$) is detected. This is useful for SPI communications.

It is recommended to set this bit to '1' in order to recover in the event of a system crash.

Bit 4: When set, the device will wake up when an external interrupt (low level on pin $\overline{\text{SPI_SS}}$) is detected. This is useful for UART communication.

Bits [7:5] These bits are RFU.

Cumulation of wakeup conditions

The wakeup conditions selected in the Wakeup condition register can be cumulated.

When the device returns to Ready state, it is possible to use the RdReg command to read the Wakeup condition register to know which event caused the device to wake up from Idle mode.

```
Read Wakeup condition register:          08 03 62 01 00
Reply ('xx' represent the Wakeup condition register bits): 00 01 xx
```

This information is used after each iteration during the Tag Detection Calibration process to determine the CalRef level. This level corresponds to the switching of the bits in the Wakeup condition register from 0x02 (Tag Detector) to 0x01 (TimeOut) when using the device previously calibrated in a free-air environment (no tags present).

2.6 Using various techniques to return to Ready state

The Idle command and reply set offers several benefits to users by enabling various methods to return the CR95HF or STRFNFCA to Ready state. Some methods are nearly automatic, such as waiting for a timer overflow or a tag detection, but others consume more power compared to the ones requesting a host action. A description of each method follows below.

2.6.1 Default setting: from POR to Ready state

After power-on, the CR95HF or STRFNFCA enters Power-up state.

To wake up the device and set it to Ready state, the user must send a low pulse on the $\overline{\text{IRQ_IN}}$ pin. The device then automatically selects the external interface (SPI or UART) and enters Ready state and is able to accept commands after a delay of approximately 3 ms.

2.6.2 From Ready state to Hibernate state and back to Ready state

In Hibernate state, most resources are switched off to achieve an ultra-low power consumption.

The only way the CR95HF or STRFNFCA can wake up from Hibernate state is by an external event (low pulse on pin $\overline{\text{IRQ_IN}}$).

A basic Idle command is:

```
>>>0x07 0E 08 04 00 04 00 18 00 00 00 00 00 00 00
```

Note: The Wakeup flag value is NOT significant when returning to Ready state from Hibernate state or after a POR.

2.6.3 From Ready state to Sleep state and back to Ready state

Wake up by external event (low pulse on $\overline{\text{IRQ_IN}}$ or $\overline{\text{SPI_SS}}$ pin)

In Sleep or Power-up states, operating resources are limited in function of the selected wakeup source to achieve a moderate power consumption level.

An Idle command example when wakeup source is pin $\overline{\text{IRQ_IN}}$:

```
>>>0x07 0E 08 01 00 38 00 18 00 00 60 00 00 00 00
```

A similar command can be implemented using pin $\overline{\text{SPI_SS}}$ as a wakeup source:

```
>>>0x07 0E 10 01 00 38 00 18 00 00 60 00 00 00 00
```

Wakeup by Timeout

The LFO is required to use the timer. However, this increases the typical power consumption by 80 μA . Several parameters can be modified to reduce power consumption as much as possible.

The Duration before Timeout is defined by parameters WU period and MaxSleep, respectively 0x60 and 0x08 in the following example.

Duration before Timeout = $256 * t_L * (\text{WU period} + 2) * (\text{MaxSleep} + 1)$

Note: Note that: $0x00 < \text{MaxSleep} < 0x1F$.

An Idle command example when wakeup source is timer (0x01) when $f_{LFO} = 32$ kHz (mean power consumption is 25 μ A)

```
>>>0x07 0E 01 21 00 38 00 18 00 60 60 00 00 00 00 08
```

An Idle command example when wakeup source is timer (0xC1) when $f_{LFO} = 4$ kHz (mean power consumption is 20 μ A):

```
>>>0x07 0E C1 21 00 38 00 18 00 60 60 00 00 00 00 08
```

The same command can be used mixing a timer and the $\overline{IRQ_IN}$ pin (0xC9) as a wakeup source:

```
>>>0x07 0E C9 21 00 38 00 18 00 60 60 00 00 00 00 08
```

Wakeup by Tag Detection

In this mode, the typical consumption can greatly vary in function of parameter settings (WU period without RF activity and Swing Count defining the RF burst duration). Using default settings, consumption in the range of 100 μ A can be achieved.

Tag Detector is a state where the CR95HF or STRFNFC is able to detect an RF event and a wakeup will occur when a tag sufficiently modifies the antenna load and is detected by the device.

An Idle command example when wakeup source is Tag Detection (0x02):

```
>>>0x07 0E 02 21 00 79 01 18 00 20 60 60 64 74 3F 08
```

The same command can be used mixing Tag Detection and the $\overline{IRQ_IN}$ pin (0x0A) as a wakeup source:

```
>>>0x07 0E 0A 21 00 79 01 18 00 20 60 60 64 74 3F 08
```

The tag detection sequence is defined by dedicated parameters:

- WU source (Byte 3)
 - The Timeout bit (bit 0) must be set to '1' in order to manage a certain number of emitted bursts. Otherwise, bursts will be sent indefinitely until a stop event occurs (for example, tag detection or a low pulse on pin $\overline{IRQ_IN}$).
 - The Tag Detect bit (bit 1) must be set to '1' to enable RF burst emissions.
 - It is recommended to also set Bits 3 or 4 to '1' to ensure that it is possible to leave Tag Detect mode via an external event (for example, a low pulse on pin $\overline{IRQ_IN}$).
- WU period (Byte 10): Defines the period of inactivity ($t_{INACTIVE}$) between two RF bursts:

$$t_{INACTIVE} = (WuPeriod + 2) * t_{REF}$$
- OscStart, DacStart (Bytes 11 and 12): Define the set-up time of the HFO and Digital Analog Converter, respectively. In general, 3 ms is used both set-up times.

$$HFO \text{ I DAC set-up time} = (OscStart \text{ I DacStart}) * t_L$$
- DacDataL, DacDataH (Bytes 13 and 14): Reference level for Tag Detection (calculated during the tag detection calibration process).
- SwingsCnt (Byte 15): Represents the number of 13.56-MHz swings allowed during a Tag Detection burst. We recommend using 0x3F.
- MaxSleep (Byte 16): The CR95HF or STRFNFC emits (MaxSleep + 1) bursts before leaving Tag Detection mode if bit 0 (Timer Out) of the WU source register is set to '1'. Otherwise, when this bit is set to '0', a burst is emitted indefinitely.

Note: Bytes 4 to 9 should be used as shown in the examples in [Section 2.3: Idle command parameters](#).

Note that the MaxSleep value is coded on the 5 least significant bits, thus:
 $0x00 < \text{MaxSleep} < 0x1F$.

All the previously described command parameters must be chosen accordingly for the initial tag detection calibration when setting up the CR95HF or STRFNFCA.

Their value will impact tag detection efficiency and CR95HF or STRFNFCA power consumption during Tag Detection periods.

2.7 Tag detection calibration procedure

The Idle command allows the use of a tag detection as a wakeup event. Certain parameters of the Idle command are dedicated to setting the conditions of a tag detection sequence.

During the tag detection sequence, the CR95HF or STRFNFCA regularly emits RF bursts and measures the current in the antenna driver I_{DRIVE} using the internal 6-bit DAC.

When a tag enters the device antenna RF operating volume, it modifies the antenna loading characteristics and induces a change in I_{DRIVE} , and consequently, the DAC data register reports a new value.

This value is then compared to the reference value established during the tag detection calibration process. This enables the device to decide if a tag has entered or not its operating volume.

The reference value (DacDataRef) is established during a tag detection calibration process using the device application setting with no tag in its environment.

The calibration process consists in executing a tag detection sequence using a well-known configuration, with no tag within the antenna RF operating volume, to determine a specific reference value (DacDataRef) that will be reused by the host to define the tag detection parameters (DacDataL and DacDataH).

During the calibration process, DacDataL is forced to 0x00 and the software successively varies the DacDataH value from its maximum value (0xFE) to its minimum value (0x00). At the end of the calibration process, DacDataRef will correspond to the value of DacDataH for which the wakeup event switches from timeout (no tag in the RF field) to tag detected.

To avoid too much sensitivity of the tag detection process, we recommend using a guard band. This value corresponds to 2 DAC steps (0x08).

Recommended guard band value:

$$\text{DacDataL} = \text{DacDataRef} - \text{Guard} \text{ and } \text{DacDataH} = \text{DacDataRef} + \text{Guard}$$

The parameters used to define the tag detection calibration sequence (clocking, set-up time, burst duration, etc.) must be the same as those used for the future tag detection sequences.

When executing a tag detection sequence, the device compares the DAC data register value to the DAC Data parameter values (DacDataL and DacDataH) included in the Idle command. The device will exit WFE mode through a Tag Detection event if the DAC data register value is greater than the DAC Data parameter high value (DacDataH) or less than the DAC Data parameter low value (DacDataL). Otherwise, it will return to Ready state after a timeout.

An efficient 8-step calibration algorithm is described in [Example of CR95HF tag detection calibration process on page 29](#).

An example of a basic Idle command used during the Tag Detection Calibration process:

```
>>>0x07 0E 03 A1 00 F8 01 18 00 20 60 60 00 xx 3F 01
```

where xx is the DacDataH value.

An example of a tag detection sequence is provided in [Example of CR95HF tag detection command using results of tag detection calibration on page 32](#).

3 Power consumption considerations

This chapter describes the advantages and benefits for using the various Idle command parameters to select the best wakeup configuration for your device to ensure optimal power consumption for your application.

The previous chapter describes how to use the Idle command to set the device from Ready to one of the three WFE modes (Hibernate, Sleep, and Tag Detector). The following sections describe the various wakeup processes for the selected WFE mode.

3.1 Transition from Ready to Hibernate state

Hibernate state consumes the least amount of power of all the possible device states.

Only an Idle command can set the device from Ready state to Hibernate state. After receiving the Hibernate command via the SPI bus, the device ([Figure 2](#)) stops the oscillator and analog resources and the device enters Hibernate state.

A basic Idle command to set the device from Ready state to Hibernate state is:


```
>>> 0x07 0E 08 04 00 04 00 18 00 00 00 00 00 00 00
```

In Hibernate state, the device minimizes its power consumption by disabling most of its resources before stopping the external oscillator. In this state, power consumption will decrease from approximately 2.5 mA to less than 2 μ A.

The only way the device can wakeup from Hibernate state is by an external event (pin $\overline{\text{IRQ_IN}}$ goes low).


The device will only send its response after having returned to Ready state after an external event is detected.

When the device wakes up from Hibernate state ([Figure 3](#)), it restarts the external oscillator and all other resources, including the selected communication interface, before returning to Ready state and waiting for a new command.

Figure 2. Transition from Ready to Hibernate state

1. In the above figure, yellow represents the 27.12-MHz (HFO) oscillator and the SPI_SCK signal is in green.

[Figure 3](#) shows the device waking up from Hibernate state when pin $\overline{\text{IRQ_IN}}$ (green) goes low. When the device returns to Ready state, the HF oscillator (yellow) restarts analog resources.

Figure 3. Wakeup from Hibernate state

3.2 Transition from Ready to Sleep state

This transition ensures low power consumption as well as a fast recovery (switch to Ready state).

When the CR95HF or STRFNFCA receives an Idle command with the Sleep option, it only partially disables its resources. In this state, power consumption will decrease from 2.5 mA to approximately 20 μ A.

The device can wake up from Idle state only at the end of pre-defined timeout or by an external event (pin $\overline{\text{IRQ_IN}}$ or $\overline{\text{SPI_SS}}$ goes low).

A basic Idle command used to wake up the device at the end of pre-defined timeout is:

```
>>> 0x07 0E 01 01 00 38 00 18 00 60 00 00 00 00 00
```

In this example, the timer uses only the LF oscillator. The timeout period is defined by the following command parameters:

$$TO = 256 \cdot t_{LFO} \cdot WuPeriod \cdot MaxSleep$$

A basic Idle command used to wake up the device by an external event (pin $\overline{\text{IRQ_IN}}$) is:

```
>>> 0x07 0E 08 01 00 38 00 18 00 60 00 00 00 00 00
```

A basic Idle command used to wake up the device by an external event (pin $\overline{\text{SPI_SS}}$) is:

```
>>> 0x07 0E 10 01 00 38 00 18 00 60 00 00 00 00 00
```

The device will only send its response after having returned to Ready state after an external event is detected.

When the device wakes up from Sleep state, it restarts the external oscillator and all other resources, including the selected communication interface, before returning to Ready state and waiting for a new command.

In certain cases (mainly when using the UART), it may be necessary to use an Echo command to re-synchronize the host and CR95HF or STRFNFCA device.

3.3 Wakeup by Tag Detection

The Tag Detection process requires the temporary use of internal resources such as the 13.56-MHz HF oscillator or the DAC which are usually switched off in WFE mode and only turned on during an RF burst emission to determine if tag entered the device operating range.

The delay (t_{INACTIVE}) between two RF burst emissions is defined in the Idle command by the WuPeriod parameter.

For a complete description of the Tag Detection process, see [Appendix A: Tag detection principle](#).


$$t_{\text{INACTIVE}} = (WuPeriod + 1) \cdot t_{\text{REF}}$$

In the example shown in [Figure 4](#):

$$t_{\text{INACTIVE}} = (32 + 1) \cdot 8 \text{ ms} = 264 \text{ ms}$$


Figure 4 illustrates a Tag Detection cycle.

Figure 4. Typical cycle in Tag Detection mode



1. In the above figure, yellow represents the 27.12-MHz (HFO) oscillator and the RF emission is in green.
Figure 5 shows a zoomed image of Figure 4 including the HFO stabilization time (OscStart) and the DAC initialization time (DacStart).

Figure 5. Restart of resources in Tag Detection mode



1. In the above figure, yellow represents the 27.12-MHz (HFO) oscillator and the RF emission is in green.


The duration of the RF burst (t_{SWING}) is defined by SwingsCnt, the number of 13.56-MHz pulses emitted. This value must be adjusted initially in the application environment to obtain the best measurement stability.

$$t_{\text{SWING}} = \text{Swing} * t_{\text{HFO}} = 64 * 73 \text{ ns} = 4.5 \mu\text{s}$$

Increasing the SwingsCnt value improves DAC accuracy, but also increases the power consumption of the RF drivers (pin VPS_TX).

When using the CR95HF or STRFNCA demoboard, we recommend a SwingsCnt value of 0x3E. This value corresponds to 64 RF pulses per burst (in blue) for a duration of 4.7 μs as shown in [Figure 6](#). This results in a mean power consumption of 100 μA .


Figure 6. RF burst in Tag Detection mode



1. In the above figure, yellow represents the 27.12-MHz (HFO) oscillator and the RF emission is in green.

The device consumes the most power during RF emissions in Tag Detection mode (Figure 7). The User can regulate the mean consumption by modifying the period between bursts (Wuperiod).

Figure 7. Power consumption in Tag Detection mode



1. In the above figure, yellow represents the 27.12-MHz (HFO) oscillator and the device power consumption is in green.

Appendix A Tag detection principle

The Tag Detection process requires the temporary use of internal resources such as the 13.56 MHz HF oscillator or the DAC which are usually switched off in WFE mode and only turned on during an RF burst emission to determine if tag entered the device operating range.

To detect the presence of a tag, the device measures a portion of the device antenna's current using the DAC (DacLevel) and compares this value to a reference value (CalRef) determined in the same way when the application is initialized.

To do this, once the HF oscillator is stabilized, the device emits an RF burst and monitors its antenna current using its internal 64-bit DAC. This result is then compared to a reference value established during the Tag Detection Calibration phase.

The device is initially calibrated by the user application in a free-air environment (no tags present) in order to obtain a reference value (CalRef) that corresponds to the basic threshold of its comparator.

When a new measurement of the antenna's current results in a value different from the CalRef value, a tag is probably present in the RF field.

To reduce the margin of error for false detections, in addition to comparing the value of the measured antenna current (DacLevel) to the reference value (CalRef), the device checks that the measured value is within a given range:


$$\text{DacDataL} < \text{DacLevel} < \text{DacDataH}$$

Using range limits ensures a stable Tag Detection process. We usually choose:

$$\text{DacDataL} = \text{CalRef} - 0x08 \text{ and } \text{DacDataH} = \text{CalRef} + 0x08$$

The parameters that define measurement resources, oscillator and DAC setup times or RF burst duration, can be individually adjusted within the Idle command parameters, but they must remain unchanged between the calibration and tag detection periods.

We recommend for the HF oscillator and DAC stabilization times (OscStart and DacStart, respectively) using a minimum value of 0x60 that corresponds to a duration of 3 ms ($96 * t_{LFO}$).

Figure 8. Tag detection principle (levels of antenna current)

A.1 Tag detection sequence

Several parameters of the tag detection sequence can be managed to optimize the wakeup time or power budget.

By adjusting the inactivity time (t_{INACTIVE}), the time between two tag detection RF bursts, the power consumption can be modified through the WuPeriod parameter in the Idle command (usually set to 0×20).

$$t_{\text{INACTIVE}} = (\text{WuPeriod} + 1) \cdot t_{\text{REF}}$$

The user can choose to limit number of tag detection trials by adjusting the MaxSleep value. This MaxSleep value is validated only when the correct Wakeup condition is set (Bit 0 of the Wakeup condition register). Otherwise, the tag detection sequence is repeated continuously until a wakeup event occurs.

A minimum duration of 3 ms must be set for the DAC and HFO setup times to obtain a good accuracy of measure. This phase is a high consumption period, so we recommend keeping it short. These setup times (DacStart and OscStart, respectively) are defined in the Idle command and are both usually set to 0×60 .

The RF burst length (SwingCnt) corresponds to the acquisition time necessary for the DAC. It must be sufficient to obtain a reproducible measurement, but it means turning on the RF driver which consumes the most energy. The SwingCnt parameter value is defined in the Idle command and is usually set to $0 \times 3F$.

Figure 9 illustrates a time-limited tag detection sequence where no tag is present in the operating volume, none is detected and the device wakes up after a timeout. (The lower part of the figure illustrates the power consumption profile.)

A basic Idle command used for a time-limited tag detection sequence is:

```
>>> 0x 07 0E 0B 21 00 79 01 18 00 20 60 60 54 64 3F 08
```

Figure 9. Time-limited tag detection sequence (display of device consumption)





Figure 10 illustrates an unlimited tag detection sequence interrupted by a tag entering the device operating volume. (The lower part of the figure illustrates the power consumption profile during tag detection and after the device automatically returns to Ready state.)

A basic Idle command used for an unlimited tag detection sequence is:

```
>>> 0x 07 0E 0A 21 00 79 01 18 00 20 60 60 54 64 3F 08
```

Figure 10. Tag detection sequence, Wakeup after tag entry in operating volume (display of device consumption)



Appendix B Tag Detection Calibration process

The Tag Detection Calibration process must be performed when the application is initialized.

A fast and efficient dichotomist flow in 8 steps is proposed to achieve best results.

Before starting this flow, the user must define its basic setup which consists in defining the following parameters using the Idle command. These parameters are described in [Section 2.3: Idle command parameters on page 9](#).

When using the CR95HF or STRFNCA demoboard and development kit, the following values are recommended:

- Wakeup condition: 0x03 (tag detection or timeout)
- EnterCtrlL/EnterCtrlH, WUCtrlL/WUCtrlH, and LeaveCtrlL/LeaveCtrlH values define internal parameters settings during the tag detection process. We recommend:

```
>>> 0xA1 00 F8 01 18 00
```
- MaxSleep: MUST be set to '01' in Tag Detection Calibration process for immediate wakeup. This means that only one detection impulse will be sent and immediately afterwards the device will exit Tag Detection Calibration mode.
- Oscillator and DAC stabilization times. We recommend: 0x60
- Number of 13.56 MHz swings during tag detection (SwingsCnt), we recommend using 0x3F to obtain a good reproducibility of measurements.
- WakeUp period. This parameter is not used during the Tag Detection Calibration process.
- The Host can then use the RdReg command to read the Wakeup condition register to determine the cause of the wakeup or check the reply code.

A basic Tag Detection Calibration command is:

```
>>> 0x 07 0E 03 A1 00 F8 01 18 00 20 60 60 00 xx 3F 01
```

B.1 Tag Detection Calibration algorithm

To determine the RF Field reference level (CalRef) corresponding to your application setup, you must use the Tag Detection Calibration function (TagCal).

For calibration purposes, parameters are set to execute only one RF field evaluation before leaving Tag Detection state.

This is achieved by setting the WU condition parameter to 0x03 (wakeup upon timeout or tag detection) and the MaxSleep value to 0x01 forcing the CR95HF or STRFNCA to leave the Tag Detection state after only one attempt.

The value of the Wakeup flag is updated to the following value each time the device leaves Tag Detection state.

Here, the WakeUp_n variable corresponds to the third byte of the device Idle command reply.

If the measured antenna current is between DacDataL and DacDataH, the wakeup event will be a timeout: WakeUp_n = 1

If the measured antenna current is less than DacDataL or greater than DacDataH, the wakeup event will be a tag detection: WakeUp_n = 2

During the calibration process, DacDataL is set to 0x00 and the reference level is determined changing only the DacDataH parameter.

The reference level corresponds to the switching level between wakeup sources. It is determined using the fast dichotomist process in 8 steps;

The Tag Detection Calibration command is formatted as follows:

```
TagCal (Ref_H) = 0x07 0E 03 A1 00 F8 01 18 00 20 60 60 00 Ref_H 3F 01
```

All the parameters are predefined to fit applicative requests in terms of wakeup sources and power consumption. A compromise must be established between the detection period and power consumption.

TagDet (64,74, or DacDataL and DacDataH, respectively) is defined using the command:

```
>>> 0x07 0E 0B 21 00 79 01 18 00 20 60 60 64 74 3F 00
```

B.2 Tag Detection calibration command

The Tag Detection Calibration command (TagCal) is a special setting of the Tag Detection command (TagDet) for which the only variable is Ref_H.

```
>>> 0x07 0E 03 A1 00 F8 01 18 00 01 60 60 00 XX 3F 00
```

```
<<< 0x00 01 01 (in the event of a timeout)
```

or

```
<<< 0x00 01 02 (in the event of a tag detection in the RF field)
```

Here, the third byte (the WakeUp_n variable) defines the Wakeup event.

It is also possible to directly use the Wakeup Flag command: 0x08 03 62 01 00

Read Wakeup Flag reply:

- In case of timeout: 0x00 01 01 (WakeUp_n = 0x01)
- In case of Tag Detection: 0x00 01 02 (WakeUp_n = 0x02)

In [Figure 11](#), the function TagCal (0xRef_n) corresponds to the execution of the following device Idle command:

```
>>> 0x07 0E 03 A1 00 F8 01 18 00 20 60 60 00 0xRef_n 3F 01
```


```
<<< 0x00 01 01 (in the event of a timeout)
```

or

```
<<< 0x00 01 02 (in the event of a tag detection in the RF field)
```

Here, the third byte (the WakeUp_n variable) defines the Wakeup event.

Figure 11. Dichotomist algorithm for tag detection calibration



Appendix C Example of CR95HF tag detection calibration process

From this Revision 1.1, we can directly use the CR95HF reply during Tag Detection Calibration or Tag Detection sequences and avoid using the RdREG command.

This is a dichotomic approach to quickly converge to the DacDataRef value for which a wakeup event switches from tag detection to timeout. In this process, only the DacDataH parameter is changed in successive Idle commands. And we look at the wakeup event reply to decide the next step.

```
<<< 00 01 02 corresponds to a Tag Detection (WakeUp_n = 2)
<<< 00 01 01 corresponds to a Timeout (WakeUp_n = 1)
```

REM, Tag Detection Calibration Test

REM, Sequence: Power-up Tag Detect Wake-up by Tag Detect (1 try measurement greater or equal to DacDataH) or Timeout

REM, CMD 07 0E 03 A100 F801 1800 20 60 60 00 XX 3F 01

REM, 03 WU source = TagDet or Timeout

REM, A100 Initial Dac Compare

REM, F801 Initial Dac Compare

REM, 1800 HFO

REM, 20 WuPeriod = 32, Inactivity period = 256ms (LFO @ 32kHz)

REM, 60 Osc 3ms (LFO @ 32kHz)

REM, 60 Dac 3ms (LFO @ 32kHz)

REM, 00 DacDataL = minimum level (floor)

REM, xx DacDataH 00 = minimum level (ceiling)

REM, 3F Swing 13.56 4.6 us

REM, 01 Maximum number of Sleep before Wakeup 2

REM, Tag Detection Calibration Test

REM, During tag detection calibration process DacDataL = 0x00

REM, We execute several tag detection commands with different DacDataH values to determine DacDataRef level corresponding to CR95HF application set-up

REM, DacDataReg value corresponds to DacDataH value for which Wake-up event switches from Timeout (0x01) to Tag Detect (0x02)

REM, Wake-up event = Timeout when DacDataRef is between DacDataL and DacDataH

REM, Search DacDataRef value corresponding to value of DacDataH for which Wake-up event switches from Tag Detect (0x02) to Timeout (0x01)

REM, Step 0: force wake-up event to Tag Detect (set DacDataH = 0x00)

REM, With these conditions Wake-Up event must be Tag Detect

>>> CR95HFDLL_STCMD, 01 070E03A100F801180020606000**00**3F01

<<< 00 01 **02**

REM, Read Wake-up event = Tag Detect (0x02); if not, error .

REM, Step 1: force Wake-up event to Timeout (set DacDataH = 0xFC)

REM, With these conditions, Wake-Up event must be Timeout

>>> CR95HFDLL_STCMD, 01 070E03A100F801180020606000**FC**3F01

<<< 00 01 **01**

REM, Read Wake-up event = Timeout (0x01); if not, error.

REM, Step 2: new DacDataH value = previous DacDataH +/- 0x80

REM, If previous Wake-up event was Timeout (0x01) we must decrease DacDataH (-0x80)

>>> CR95HFDLL_STCMD, 01 070E03A100F801180020606000**7C**3F01

<<< 00 01 **01**

REM, Read Wake-up event = Timeout (0x01) or Wake-up event = Tag Detect (0x02)

REM, Step 3: new DacDataH value = previous DacDataH +/- 0x40

REM, If previous Wake-up event was Timeout (0x01), we must decrease DacDataH (-0x40); else, we increase DacDataH (+ 0x40)

>>> CR95HFDLL_STCMD, 01 070E03A100F801180020606000**3C**3F01

<<< 00 01 **02**

REM, Read Wake-up event = Timeout (0x01) or Wake-up event = Tag Detect (0x02)

REM, Step 4: new DacDataH value = previous DacDataH +/- 0x20

REM, If previous Wake-up event was Timeout (0x01), we must decrease DacDataH (-0x20); else, we increase DacDataH (+ 0x20)

>>> CR95HFDLL_STCMD, 01 070E03A100F801180020606000**5C**3F01

<<< 00 01 **02**

REM, Read Wake-up event = Timeout (0x01) or Wake-up event = Tag Detect (0x02)

REM, Step 5: new DacDataH value = previous DacDataH +/- 0x10

REM, If previous Wake-up event was Timeout (0x01), we must decrease DacdataH (-0x10); else, we increase DacDataH (+ 0x10)

>>> CR95HFDLL_STCMD, 01 070E03A100F801180020606000**6C3F**01

<<< 00 01 **02**

REM, Read Wake-up event = Timeout (0x01) or Wake-up event = Tag Detect (0x02)

REM, Step 6: new DacDataH value = previous DacDataH +/- 0x08

REM, If previous Wake-up event was Timeout (0x01), we must decrease DacDataH (-0x08); else, we increase DacDataH (+ 0x08)

>>> CR95HFDLL_STCMD, 01 070E03A100F801180020606000**743F**01

<<< 00 01 **01**

REM, Read Wake-up event = Timeout (0x01) or Wake-up event = Tag Detect (0x02)

REM, Step 7: new DacDataH value = previous DacDataH +/- 0x04

REM, If previous Wake-up event was Timeout (0x01), we must decrease DacDataH (-0x04); else, we increase DacDataH (+ 0x04)

>>> CR95HFDLL_STCMD, 0 1070E03A100F801180020606000**703F**01

<<< 00 01 **01**

REM, Read Wake-up event = Timeout (0x01) or Wake-up event = Tag Detect (0x02)

REM, If last Wake-up event = Tag Detect (0x02), search DacDataRef = last DacDataH value

REM, If last Wake-up event = Timeout (0x01), search DacDataRef = last DacDataH value -4

REM, For tag detection usage, we recommend setting DacDataL = DacDataRef -8 and DacDataH = DacDataRef +8

>>> CR95HFDLL_STCMD, 01 070E0B210079011800206060**64743F**01

<<< 00 01 **01**

Appendix D Example of CR95HF tag detection command using results of tag detection calibration

This is an example of a Tag Detection command when a tag is not present in the RF operating volume using CR95HF revision 1.1.:

```
>>> CR95HFD11_STCmd, 01 070E0B21007901180020606064743F01
<<< 00 01 01 Wake-up event = Timeout (0x01)
>>> CR95HFD11_STCmd, 01 0803620100
<<< 00 01 01
```

This is an example of a Tag Detection command when a tag is present in the RF operating volume using CR95HF revision 1.1.:

```
>>> CR95HFD11_STCmd, 01 070E0B21007901180020606064743F01
<<< 00 01 02 Wake-up event = Tag Detect (0x02)
>>> CR95HFD11_STCmd, 01 0803620100
<<< 00 01 02
```


Revision history

Table 7. Document revision history

Date	Revision	Changes
05-Dec-2011	1	Initial release.
23-Feb-2012	2	Updated the document throughout to include the STRFNCA device.

Please Read Carefully:

Information in this document is provided solely in connection with ST products. STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, modifications or improvements, to this document, and the products and services described herein at any time, without notice.

All ST products are sold pursuant to ST's terms and conditions of sale.

Purchasers are solely responsible for the choice, selection and use of the ST products and services described herein, and ST assumes no liability whatsoever relating to the choice, selection or use of the ST products and services described herein.

No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted under this document. If any part of this document refers to any third party products or services it shall not be deemed a license grant by ST for the use of such third party products or services, or any intellectual property contained therein or considered as a warranty covering the use in any manner whatsoever of such third party products or services or any intellectual property contained therein.

UNLESS OTHERWISE SET FORTH IN ST'S TERMS AND CONDITIONS OF SALE ST DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY WITH RESPECT TO THE USE AND/OR SALE OF ST PRODUCTS INCLUDING WITHOUT LIMITATION IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE (AND THEIR EQUIVALENTS UNDER THE LAWS OF ANY JURISDICTION), OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT.

UNLESS EXPRESSLY APPROVED IN WRITING BY TWO AUTHORIZED ST REPRESENTATIVES, ST PRODUCTS ARE NOT RECOMMENDED, AUTHORIZED OR WARRANTED FOR USE IN MILITARY, AIR CRAFT, SPACE, LIFE SAVING, OR LIFE SUSTAINING APPLICATIONS, NOR IN PRODUCTS OR SYSTEMS WHERE FAILURE OR MALFUNCTION MAY RESULT IN PERSONAL INJURY, DEATH, OR SEVERE PROPERTY OR ENVIRONMENTAL DAMAGE. ST PRODUCTS WHICH ARE NOT SPECIFIED AS "AUTOMOTIVE GRADE" MAY ONLY BE USED IN AUTOMOTIVE APPLICATIONS AT USER'S OWN RISK.

Resale of ST products with provisions different from the statements and/or technical features set forth in this document shall immediately void any warranty granted by ST for the ST product or service described herein and shall not create or extend in any manner whatsoever, any liability of ST.

ST and the ST logo are trademarks or registered trademarks of ST in various countries.

Information in this document supersedes and replaces all information previously supplied.

The ST logo is a registered trademark of STMicroelectronics. All other names are the property of their respective owners.

© 2012 STMicroelectronics - All rights reserved

STMicroelectronics group of companies

Australia - Belgium - Brazil - Canada - China - Czech Republic - Finland - France - Germany - Hong Kong - India - Israel - Italy - Japan - Malaysia - Malta - Morocco - Philippines - Singapore - Spain - Sweden - Switzerland - United Kingdom - United States of America

www.st.com