

Usage Guide of Legend Network Adapter (Intel Pro100S V1.0)

Catalogue

Features and functions	1
Hardware installation	2
Driver installation	2
1. Windows 95/98	2
2. Windows NT 4.0	3
Trouble shooting	4
Precautions	4

Intel Pro100S is a high-performance 32-bit PCI Ethernet adapter featuring plug and play and easy installation. This product is made strictly in line with the regulations of PCI REV2.2, supporting half/full duplex, adopting automatic adjustment technology to test and monitor the web speed and transmission mode and its driver can support different OS like Netware, Windows9X, Windows NT, etc.

Features and functions

- 32bit PCI port and low CPU occupancy;
- made by IEEE 802.3 CSMA/CD and attains the criteria of 100Base-TX and 10Base-T;
- Full duplex design, doubling its performance to 20/200Mbps (requiring a HUB to switch and support full duplex);
- Support 10/100 Mbps auto control;
- Support PCI REV2.2 and automatically allocate IRQ and I/O address;
- Support web-alarms function;
- Has standard RJ-45 port and can use 5-type UTP (100Base-TX) or 3, 4, 5-type UTP (10Base-T);
- Support remote vectoring;
- Possess auto-adjusting function and can monitor web speed;
- Display web status by LED:
- LINK/100: green, 100Mbps ok;
- LINK/10: yellow, 10Mbps ok;
- Act: red, Tx/Rx effective. Glittering: info transferring
- support ACPI and PCI power management with low consumption and fit for green PC system.

Hardware installation


The installation of network adapter is as follows:

shut down the computer (should completely switch off ATX) and open the housing;

plug the adapter into PCI slot;

screw up the adapter and close up the housing;

connect the adapter with the web wire.

 Notices: Static electricity may cause damages to electric appliances. Please take precautions beforehand:

- Please discharge static electricity on your body before touching any electric appliances. You can discharge is by touching the metal without plugs inside the computer.
- Before getting prepared for installation, please do not take the adapter out of the anti-static electricity container; when plug out the adapter from the computer, please put it back to the original container;
- Do not let your clothes touch any of the electronic devices;
- When you want to discard this adapter, please hold its edge and do not touch the parts on top of it.

Driver installation

1. Windows 95/98

1. click right "My computer" on the desktop and select "property";
2. under the window of "system property", select "equipment manager" and

then click "renew"; the system will prompt "find the new hardware" (PCI Ethernet Controller);

3. According to the system prompt, click the next step and designate the installation route as "X:\ LX_NET\Intel" (X refers to the assumed CD mark of your machine); install it by the system's prompt. In the course of it, the system may say that certain loaded file is not available. In this case, you have to re-designate the route of "copy file" (same as above: X:\LX_net\Intel) until the end of installation.
4. Reboot the computer and end the installation of hardware driver.

2. Windows NT 4.0

Based on the installed OS of Windows NT4, we will now explain how to install the attached network adapter:

1. enter the window of "control panel", double click the icon of "network";
2. there will come the window of "network" on the screen and under the prompt of "already installed the following network components", there should be no info about the adapter. If there is, please delete it with "delete" (before loading the adapter, the "delete" is virtual", single click "add";
3. there will be the window of "please select the desired network components " and select "adapter";
4. from the adapter list given by OS, single click "install from floppy disk", select the route as:" X:\ LX_NET\Intel" and click "confirmed";
5. prompted by the system, please select "protocol", single click "add";
6. add the required network communication protocol name and working group's name. When finishing the loading of network protocol, single click "confirmed";
7. reboot the computer.

Trouble shooting

Whenever you come across any problems in the course of using the network adapter, please first make sure whether the driver is installed correctly, the wires are connected in a right way, the HUB performance quota are matching with the adapter, whether 10Mbps 10Base-T is adopted or the 100Mbps 100Base-TX. After that, check LED. This product provides 3 LED to demonstrate the network status. Please refer to the "Features and functions" for details.

Precautions

This product may generate Hertzian waves and cause certain impact over the wireless communications if installed or used improperly. When you have some problem with TV or radio and you think it is because of this product, please shut down the computer to see if there is still any interference. If the problem definitely comes from the computer, you can solve it by the following methods:

- reinstall the receiving antenna;
- put the transceiver far away from the computer;
- do not plug the wires of computer and receivers into the same socket;
- put shields at the housing's outlet of all expansion slots;
- make sure all the metal supports are closely connected with the computer.