

## User's Guide of MotherBoard

### (I845PE/A /N V1.0)

## Catalogue

The installation of motherboard's chip driver .....	1
The installation of On-board audio driver .....	1
The installation of on-board LAN driver .....	2
The installation of on-board USB2.0 controller driver .....	3

## The installation of motherboard's chip driver

If you have reinstalled Windows OS, you may install the motherboard's chip driver in the driver's CD enclosed with the machine.

We shall illustrate to you how to install by Windows XP (the "X" hereunder means the disk mark of your CD-ROM).

1. Install Windows XP.
2. Insert the CD of "Legend computer driver" into CD-ROM drive.
3. Enter the directory: "X:\Lx\_chip\Intel\Inf".
4. Run the process of Setup.exe and select the options as the system prompted in the course of installation. Single click "Next" or "OK" until the very end without any alterations.
5. Reboot the computer and the installation finishes.

Other Windows OS installation directory:

Windows 98:

"X:\Lx\_chip\intel\inf\Setup.exe"

Windows 2000:

"X:\Lx\_chip\intel\inf\Setup.exe"

MotherBoard

## The installation of On-board audio driver

The motherboard we use here integrates an audio chip that can be installed after loading motherboard's chip driver. You can install its driver with the drive CD supplied with the machine and the steps are as follows:

1. Install Windows XP and install chip driver.
2. Insert the CD of "Legend computer driver" into the CD driver.
3. Enter the directory: "X:\LX\_SOUND\ALC201A".

4. Run the process of Setup.exe and select the options as the system prompted in the course of installation. Single click "Next" or "OK" until the very end without any alterations.
5. Reboot the computer and the installation finishes.

Other Windows Operation System installation directory:

Windows 98:

"X:\LX\_SOUND\ALC201A\Setup.exe."



Notices: If you have a floppy, which has the caption "USB2.0\_Win2K Driver & ALC201A\_Win98 Patch", please insert the floppy disk and run the process "A:\ALC201A\_Win98\_Patch\Patch.exe".

Windows 2000:

"X:\LX\_SOUND\ALC201A\Setup.exe."



Notices: If you meet a warning message of Windows Logo during the installing, please select "continue" and it will have no effect on the Audio.

## The installation of on-board LAN driver

The motherboard we use here integrates 10/100M network chip, which can be installed after loading motherboard chip's driver. You can install it with the driver CD supplied with the machine and the steps are as follows:

1. Install Windows XP and install chip driver.
2. Insert the CD of "Legend computer driver" into CD-ROM drive.
3. Enter the directory: "X:\Lx\_net\intel".
4. Run the process of SETUP.exe.

5. "License Agreement" select "I accept the terms in the license agreement" and then click "Next".
6. Select the options as the system prompted in the course of installation. Single click "Next" or "OK" until the very end without any alterations.
7. Reboot the computer.

Other Windows Operation System installation directory:

Windows 98:

"X:\Lx\_net\intel \Setup.exe."

Windows 2000:

"X:\Lx\_net\intel \Setup.exe."



Notice:

1. Because the installation of network adapter need to install communication protocol and initialize relevant Network configuration, Please refer to your network administrator's opinion
2. It is normal phenomenon to boot slowly, when your PC system has been installed the network driver.

## The installation of on-board USB2.0 controller driver

The motherboard we use here integrates USB2.0 controller network chip, which can be installed after loading motherboard chip's driver. You can install it with the driver CD supplied with the machine and the steps are as follows:

1. Install Windows XP and install chip driver.
2. Insert the CD of "Legend computer driver" into CD-ROM drive.
3. Enter the directory: "X:\Lx\_USB2.0\Winxp\QFE\EN"

4. Run the "Q312370\_WXP\_SP1\_x86\_ENU.exe" (AS for WIN2000 this program is not run)
5. Select the options as the system prompted in the course of installation. Single click "Next" or "OK" until the very end without any alterations. Reboot the computer.
6. Choose the "Device manager" and double click " USB Controller " with the left button. In the "properties" category, click the "Update driver ".
7. Under the dialogue of "Hardware Update Wizard", to choose "Install from a list or specific location" and click "Next"
8. Remember to choose "Include this location in the search", and specify a location at "X:\lx\_usb20\winxp\EHCI Package", click "Next" and "finish" at the end. (AS for WIN2000 directory is "X:\Lx\_usb20\win2k\3615\_Win2K")

**NOTICE:**

1. Please don't install on-board USB2.0 controller driver if you have installed Windows XP SP1. Otherwise you should get a wrong message.
2. We do not offer the usb2.0 driver program under Windows 98 and Windows NT systems. In these cases, the USB can only be used in USB1.1 mode.
3. If you want to use the USB Harddisk, you need to connect your Harddisk's DC power.