



INSTRUCTION MANUAL

CONTROLS

OUT LED (yellow)

The yellow LED indicates the output status.

READY LED (green)

During functioning, the green LED permanently ON indicates a normal operating condition and blinking indicates an output overload condition.

DELAY LED (orange)

The orange DELAY LED ON indicates the timing function activation on the digital output.

KEYLOCK LED (orange)

The orange KEYLOCK LED ON indicates the active keyboard status. **BARGRAPH**

The reading sensitivity level is signalled on the bargraph.

PUSH-BUTTON (white)

The pressing of the (SET) push-button unlocks the keyboard, memorises the sensitivity and activates the digital output timing.

(red) and (green) push-buttons

The sensitivity adjustment procedure is activated by pressing the 🕈 and push-buttons.

See the "SETTING" paragraph for setup procedure indications.

INSTALLATION

The sensor can be positioned by means the two Ø3.5mm housing's holes using or threaded M5 holes with 6 mm max. depth

Warning: the use of excessively long screws can damage the product.

The connector can be oriented at five different positions by rotating the block. The position chosen is guaranteed by a mechanical blocking system.

The rotation can be carried-out even after sensor installation as the connector block is completely self-contained inside the housing.







- (SET) (+)

Power supply:

Consumption

Output current:

Analogue output:

Analogue output

Response time:

Switching frequency:

impedance:

Delay:

Indicators:

Push-buttons:

Operating temperature:

Electric shock protection:

Minimum spot dimension:

Ambiente light rejection:

Storage temperature:

Operating distance:

Emission type:

Shock resistance:

Housing material:

Mechanical protection:

Lens material:

Connections:

Weight:


Vibrations

(output current excluded):


Output saturation voltage:

Ripple:

Output:




CONNECTIONS



DIMENSIONS

LD46-UL-735 LD46-UL-755 (40mm LENS) (22mm LENS)



TECHNICAL DATA

15...30 Vdc limits value

2 Vpp max.

50mA max @ 24Vcc

1 PNP output

1 NPN output

100 mA max.

 $\leq 2 \ V$

0.75 ... 5.5 V max.

 $2.2 \text{ k}\Omega$

(short-circuit protection)

250 μs

2 kHz

0 / 20 ms selectable

(no-delay default configuration)

OUT LED (yellow) / READY LED (green)

DELAY LED and KEYLOCK LED (orange)

5-segment bargraph

+, SET, -

-10 ... 55 °C

-20 ... 70 °C

double insulation

10 ... 20 mm (LD46-UL-715)

20 ... 40 mm (LD46-UL-755)

30 ... 50 mm (LD46-UL-735)

2 x 8 mm @10mm (LD46-UL-715)

3x11 mm @ 24mm (LD46-UL-755)

4x15 mm @ 50mm(LD46-UL-735)

UV 375nm LEDs, Class 1

according to EN 60947-5-2

0.5 mm amplitude, 10 ... 55 Hz frequency, per

each axis (EN60068-2-6)

11 ms (30 G) 6 shock per each axis

(EN60068-2-27)


Aluminium

Glass

IP67


M12 5-pole connector


180 g. max



LD46-UL-715

(9mm LENS)





mm

SETTING

KEYLOCK function (patent-covered)

The KEYLOCK function deactivates the keyboard thus avoiding accidental changes in the sensor setting

At sensor powering the keyboard is blocked (KEYLOCK LED OFF). To activate it, press (SET) for 5 seconds until the KEYLOCK LED (orange) turns

The keyboard is automatically blocked if not used for 2 minutes. Unblock the keyboard to proceed with sensor adjustment.











NORMAL FUNCTIONING

During normal functioning a LED on the bargraph visualises the sensitivity level.



OUT READY (5)

SET +


SENSITIVITY ADJUSTMENT

This mode regulates the sensor reading sensitivity, i.e. the capability of detecting objects with different luminescence degrees.

The sensitivity is increased or decreased by pressing the or push-buttons.

The adjustment speed is increased by keeping the (+) or push-buttons pressed.


The sensitivity level which is being set blinks on the bargraph during this



Press (SET) to memorise the new threshold value or wait 30sec for automatic

DELAY SETTING

The DELAY extends the minimum active output status duration to 20ms, allowing even slower interface systems to detect shorter pulses. The delay is signalled by the corresponding orange LED ON.



Delay activation

Delay deactivation

OFF

- Press (SET) for 2 sec until DELAY LED turns ON.

- Press (SET) for 2 sec until DELAY LED turns

2 sec.




OUTPUT OVERLOAD

The digital output overload is signalled by the rapid blinking of the READY

ANALOGUE OUTPUT

The analogue output supplies a voltage proportional to the signal received by the sensor. The voltage supplied is 0.75 ÷ 5.5V.



EX-II-3DG IP67 T6

T6 (<85°C) Temperature class:

1500 mW at 30 Vdc Max. Power consumption: Max. Internal capacitance: 380 pF Internal inductance negligible

DECLARATION OF CONFORMITY

We DATASENSOR S.p.A. declare under our sole responsibility that these products are conform to the 2004/108/CE, 2006/95/CE Directives and successive amendments.

DATASENSOR S.p.A. warrants its products to be free from defects

DATASENSOR S.p.A. will repair or replace, free of charge, any product found to be defective during the warranty period of 36 months from the manufacturing date.

This warranty does not cover damage or liability deriving from the improper application of DATASENSOR products.

DATASENSOR S.p.A. Via Lavino 265

40050 Monte S. Pietro - Bologna - Italy Tel: +39 051 6765611 Fax: +39 051 6759324 http://www.datasensor.com e-mail: info@datasensor.com

DATASENSOR S.p.A. cares for the environment: 100% recycled paper. DATASENSOR S.p.A. reserves the right to make modifications and improvements without

826003232 Rev.B